

# Industrial Computer Products

# Data Acquisition Systems

# ET-7x00/PET-7x00 Series User Manual



ET-7000/ET-7200 Series (Ethernet I/O)



PET-7000/PET-7200 Series (PoE I/O)

Author: Liam Lin Editor: Janice Hong

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for one

year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product.

ICP DAS reserves the right to change this manual at any time without notice.

The information furnished by ICP DAS is believed to be accurate and reliable. However,

no responsibility is assumed by ICP DAS for its use, nor any infringements of patents or other

rights of third parties resulting from its use.

Copyright

Copyright © 2014 by ICP DAS CO., LTD. All rights are reserved.

**Trademarks** 

The names are used for identification purposes only and may be registered trademarks of their

respective companies.

**Contact Us** 

If you have any problems, please feel free to contact us. You can count on us for a quick

response.

Email: <a href="mailto:service@icpdas.com">service@icpdas.com</a>

# **Revision History**

The table below shows the revision history.

Revision	Date	Description
1.1.4	May. 2024	<ul> <li>Since FW3.11 (or later), the factory defaults for ID or password are not supported. Users need to create them during their initial login. Refer to 3.3 for the updated information on Authentication.</li> <li>Since FW3.11 (or later), a maintenance feature has been added that enables users to export/import configurations, making bulk module configuration easier. Refer to Section 3.6 for an explanation of Maintenance.</li> </ul>
1.1.3	Jun. 2023	<ul> <li>Add chapter 3.2.3-(F) NTC Thermistor Temperature Settings - User Defined Type</li> </ul>
	Oct. 2022	<ul> <li>3.4.1 Add pictures for AO, DI, DO</li> <li>Revision of chapter content</li> <li>Add chapters         <ul> <li>6.3.2. Using the 7188EU.exe and Command Line Appendix E Convert Modbus Data to the Actual Value</li> </ul> </li> <li>Remove chapters         <ul> <li>1.4. Companion CD</li> <li>2.6. Enabling the Adobe Flash Player in Your Browser</li> <li>4.3. Data Encoding</li> <li>4.4. Data Model</li></ul></li></ul>
1.1.2	Feb. 2014	<ul> <li>Added product information for the ET-7200/PET-7200 in each section of the manual.</li> </ul>
1.1.1	Apr. 2013	<ul> <li>Added the tip about selecting the input/output range of each analog input/output channel in section 3.2.3. (D)</li> <li>Analog Output Settings and 3.2.3. (E) Analog Input Settings.</li> </ul>
1.1.0	Feb. 2013	<ul> <li>Added the I/O configuration instructions in section 2.7. Configuring the I/O Functions.</li> <li>Added the revision history in appendix H. Revision History</li> </ul>
1.0.1	Dec. 2011	Initial issue

# **Table of Contents**

Chapt	ter 1.	Introduction	8
1.1.	Feature	es	10
1.2.	Overvi	ew	13
1.3.	Dimens	sions	16
Chapt	ter 2.	Getting Started	18
2.1.	Mount	ing the ET-7x00/PET-7x00	19
2.2.	Configu	uring the Boot Mode	20
2.3.	ET-7x00	0/PET-7x00 Hardware Connections	21
2.4.	Installir	ng the MiniOS7 Utility	23
2.5.	Using t	he MiniOS7 Utility to Assign an IP Address	24
2.6.	Configu	uring the I/O Functions	27
Chapt	ter 3.	Web Applications	31
3.1.	Overvie	ew	33
3.2.	Configu	uration	34
3.2	2.1. Ne	twork Settings	35
3.2	2.2. Bas	sic Settings	36
(	(A) Basi	c Settings	36
(	(B) Rest	ore All Default Settings	39
3.2	2.3. Mc	odule I/O Settings	45
(	(A) Com	nmon Functions	46
(	(B) Digit	tal Output Settings	47
(	(C) Digit	tal Input Settings	48
(	(D) Anal	log Output Settings	49
(	(E) Anal	log Input Settings	51
	(F) NTC	Thermistor Temperature Settings (for ET-7005) – User Defined Type !	54

	(G) A	Alarm Settings	58
3.3.	Au	thentication	60
3.	3.1.	Account Management	61
	(A)	Configuring the User Accounts	62
	(B)	Restoring the Factory Default User Accounts	62
3.	3.2.	Accessible IP Settings	64
3.4.	We	b HMI	65
3.	4.1.	Web HMI	66
3.	4.2.	Web Edit	68
3.5.	1/0	Pair Connection	77
3.	5.1.	Example 1: Pair Connection - AI to AO	80
3.	5.2.	Example 2: Pair Connection - DI to DO	85
3.6.	Ma	intenance	89
3.7.	Mc	ore Information	93
Chap	ter 4	l. Modbus TCP/IP	. 94
-		dbus TCP/IP Message Format	
4.1.	Mc		94
4.1. 4.2.	Mc Fur	odbus TCP/IP Message Format	94 97
4.1. 4.2.	Mc Fur 2.1.	odbus TCP/IP Message Format	94 97 97
4.1. 4.2. 4.	Mc Fur 2.1. 2.2.	odbus TCP/IP Message Format	94 97 97 98
4.1. 4.2. 4. 4.	Mc Fur 2.1. 2.2. 2.3.	odbus TCP/IP Message Format	94 97 97 98 99
4.1. 4.2. 4. 4. 4.	Mc Fur 2.1. 2.2. 2.3. 2.4.	odbus TCP/IP Message Format	94 97 97 98 99
4.1. 4.2. 4. 4. 4. 4.	Mc Fur 2.1. 2.2. 2.3. 2.4. 2.5.	odbus TCP/IP Message Format	94 97 97 98 99 .00
4.1. 4.2. 4. 4. 4. 4. 4.	Mc Fur 2.1. 2.2. 2.3. 2.4. 2.5. 2.6.	odbus TCP/IP Message Format	94 97 98 99 .00
4.1. 4.2. 4. 4. 4. 4. 4. 4.	Mc Fur 2.1. 2.2. 2.3. 2.4. 2.5. 2.6. 2.7.	odbus TCP/IP Message Format	94 97 98 99 .00 .01
4.1. 4.2. 4. 4. 4. 4. 4. 4.	Mo Fur 2.1. 2.2. 2.3. 2.4. 2.5. 2.6. 2.7. 2.8.	odbus TCP/IP Message Format	94 97 98 99 .00 .01 .02 .03

4.3	3.2.	Modbus Master Tool	)8
4.4.	Мо	odbus Demo Programs12	l1
Chap	ter 5	5. Calibration1	12
5.1.	Vol	tage and Current Calibration	L2
5.2.	The	ermocouple Calibration12	L7
5.3.	RTE	O Calibration	18
5.4.	Rec	cover Calibration to the Factory Setting12	20
Chap	ter 6	5. MiniOS7 Utility Tools1	21
6.1.	Esta	ablishing a Connection12	21
6.2.	Exc	hanging the Protocol (TCP/IP to UDP)12	24
6.3.	Upo	dating the ET-7x00/PET-7x00 OS12	25
6.3	3.1.	Using the MiniOS7 Utility	25
6.3	3.2.	Using the 7188EU.exe and Command Line	29
6.4.	Upo	dating the ET-7x00/PET-7x00 Firmware13	31
Chap	ter 7	7. SCADA and System Integration Tools1	34
7.1.	Lab	OVIEW	34
7.2.	OP	C Server13	35
7.3.	SCA	ADA13	36
7.3	3.1.	InduSoft	37
7.3	3.2.	Citect	38
7.3	3.3.	iFix	39
Appe	ndix	A Description of I/O Functions1	40
A.	1.	Dual Watchdog14	10
Α.	2.	Power-on Value	11
Α.	3.	Safe Value14	13
Α.	4.	Al High/Low Alarm	15
Α.	5	Al High/Low Latch	50

Appendix B	Analog Input Type and Data Format Table	151
Appendix C	Analog Output Type and Data Format Table	156
Appendix D	Convert Modbus Data to the Actual Value	. 157
Appendix E	Network Address Translation	160
Appendix F	Troubleshooting	162

# **Chapter 1. Introduction**

The ET-7200/PET-7200 series is a kind of Ethernet I/O module, including Analog Input/Output, Digital Input/Output, Power Relay, Thermocouple, and RTD modules. The ET-7200/PET-7200 series provides full networking capabilities, and a variety of I/O functions, together with web-based Ethernet I/O monitoring and control modules, meaning that the modules can be remotely controlled using the Modbus TCP/UDP protocol via a 10/100 M Ethernet network. Modbus has become the de facto standard protocol for industrial communication and is now the most commonly available means of connecting industrial electronic devices. This ensures that the ET-7200/PET-7200 series provides perfect integration with HMI, SCADA, PLC, and other industrial control software systems.



Visit the ET-7000/ET-7200 selection guide page to choose the desired modules.

## **Analog I/O Modules:**

https://www.icpdas.com/en/product/guide+Remote\_\_I\_O\_\_Module\_\_and\_\_Unit+Ethernet \_\_I\_O\_\_Modules+ET-7000#650

#### Digital I/O Modules:

https://www.icpdas.com/en/product/guide+Remote\_\_I\_O\_\_Module\_\_and\_\_Unit+Ethernet \_\_I\_O\_\_Modules+ET-7000#652

## **Encoder/Frequency/Counter:**

https://www.icpdas.com/en/product/guide+Remote\_\_I\_O\_\_Module\_\_and\_\_Unit+Ethernet\_\_I\_ O Modules+ET-7000#654

# Comparison between (P)ET-7000 and (P)ET-7200 Series

## The PET-7x00 has some unique features that are different from the ET-7x00

Model	ET-7000	PET-7000	ET-7200	PET-7200	
Software					
Embedded Web Server	Yes				
Web HMI	Yes				
I/O Pair Connection		Yes			
CPU Module					
Dual Watchdog	Mod	ule, Communicati	on (Programm	nable)	
Ethernet					
Ports	1 x RJ-45, 10/100M Base-TX 2 x RJ-45, 10/100 Base Switch Ports				
Security		ID, Password, a	and IP Filter		
Protocol	Modbus TCP and Modbus UDP				
LED Indicators					
System Operation		Yes			
Ethernet Link/Activity		Yes			
I/O Status	-		Yes		
Power					
Reverse Polarity Protection		Yes			
Powered from PoE	-	Yes	-	Yes	
Powered from Terminal Block	+10 ~ +30 VDC	+12 ~ +48 VDC	+12 ~ +48 VDC		
Power Inputs	One pair		Two pairs		
Mechanical					
Dimensions (mm)	72 x 123 x 35 (W x L x H)		76 x 120 x 38 (W x L x H)		
Other					
Reset Button	-	-		Yes	

## 1.1. Features


## Power over Ethernet (PoE)

The **PET**-7x00 series module features true IEEE802.3af-compliant (classification, Class 1) PoE technology that allows both power and data to be carried over a single Ethernet cable, meaning that a device can operate solely from the power it receives through the data cable. This also eliminates the need for additional wiring and power supply.



## **Daisy-Chain Ethernet Cabling**

The ET-7200/PET-7200 series has a built-in two-port Ethernet switch to implement daisy-chain topology. The cabling is much easier and the total costs of cable and switch are significantly reduced.



## **LAN Bypass**



The ET-7200/PET-7200 series modules provide a LAN bypass feature that guarantees Ethernet communication. It will automatically activate to continue the network traffic when the module loses its power.

## **Communication Security**

To change the settings or monitor the status of I/O, the account and password are needed when logging into the web server. An IP address filter is also included, which can be used to allow or deny connections with specific IP addresses.

## **Support for both Modbus TCP and Modbus UDP Protocols**

The Modbus TCP/UDP slave function Ethernet port can be used to provide data to remote SCADA software.

## **Built-in I/O**

Various I/O components are mixed with multiple channels in a single I/O module, which provides the most cost-effective I/O usage and enhances the performance of I/O operations.

## **Dual Watchdog**

The Dual Watchdog consists of a Module Watchdog and a Communication Watchdog. The action of AO and DO is also associated with the Dual Watchdog.

<u>Module Watchdog</u> is a built-in hardware circuit to monitor the operation of the module and will reset the CPU if a failure occurs in the hardware or the software. Then the Power-on Value of AO and DO will be loaded.

<u>Communication Watchdog</u> is a software function to monitor the communication between the host and the I/O module. The timeout of the communication Watchdog is programmable, when the I/O doesn't receive commands from the host for a while, the watchdog forces the AO and DO to pre-programmed the Safe Value to prevent unpredictable damage to the connected devices.

## **Highly Reliable Under Harsh Environment**

Wide Operating Temperature Range: -25 ~ +75°C


Storage Temperature: -30 ~ +80°C

Humidity 10 ~ 90% RH (Non-condensing)



## I/O Pair Connection

This function is used to create an AI/DI to AO/DO pair through the Ethernet. Once the configuration is completed, the I/O module can poll the status of remote AI/DI devices and then use the Modbus TCP protocol to continuously write to local AO/DO channels in the background.



#### **Power-on Value and Safe Value**

Besides setting by the set AO and DO commands, the AO and DO can be set under two other conditions.

<u>Power-on Value</u>: The Power-on Value will be loaded to the AO or DO on three conditions: Power-on, reset by Module Watchdog and reset by reset command.

<u>Safe Value</u>: When the Communication Watchdog is enabled and a Communication Watchdog timeout occurs, the "safe value" is loaded into the AO, DO.

#### **LED indicators for DIO status**

The LED indicators for DIO status are for the ET-7200/PET-7200 series.

#### **Reset button**

The reset button is for the ET-7200/PET-7200 series. It is used to clear all data and restore all settings to factory default values. It is very useful especially when you forget the ID, password to log into the web server, or IP address to access the Ethernet I/O module.




## Two pairs of power input pins

For (P)ET-7000 series, there are only two pins for power input. To ease the wiring, the pins are increased to four pins as two pairs for (P)ET-7200 series.

## 1.2. Overview


The front panel of the ET-7x00/PET-7x00 series module contains the Ethernet Port, connectors, and LEDs. Refer to data sheets for specific ET-7x00/PET-7x00 models for details of pin assignments, which can be found at:

https://www.icpdas.com/en/product/guide+Remote\_\_I\_O\_\_Module\_\_and\_\_Unit+Ethernet\_\_I\_ O\_\_Modules+ET-7000



Model	Label	Status	Description		
	L1	Flashing	The unit is turned on and is ready for use.		
		On	A link has been established on the E1 port.		
ET-7000/	L2	Off	No link is established on the E1 port.		
PET-7000		Flashing	Data transmission or receiving activity is occurring on the E1 port.		
	L3	On	The E1 port is operating at 100 Mb/s.		
		Off	The E1 port is operating at 10 Mb/s.		
	RUN	Flashing	The unit is turned on and is ready for use.		
	E1	On	A link has been established on the E1 port.		
ET-7200/		Off	No link is established on the E1 port.		
PET-7200		Flashing	Data transmission or receiving activity is occurring on the E1 port.		
PE1-7200	E2	On	A link has been established on the E2 port.		
		Off	No link is established on the E2 port.		
		Flashing	Data transmission or receiving activity is occurring on the E2 port.		

The bottom panel of the ET-7x00/PET-7x00 module contains the Ethernet port and the reset button. Note that the PoE function is only for PET-7000 and PET-7200.




## Reset button (for ET-7200/PET-7200 series modules only)

The reset button is used to restore the following settings to their factory defaults by pressing and holding the reset button for 5 seconds.

- Network Settings
- Authentication
- Web HMI
- Pair Connection

For more information about these settings, refer to section 3.2.2. "Basic Settings - (C)".

The back panel of the ET-7x00/PET-7x00 series module contains the frame ground and the operating mode selector switch.



## **Operating Mode Selector Switch**

## **Init Mode:**

This mode is used for MiniOS7 configuration.

## **Normal Mode:**

This mode is used to execute and run firmware.

On the ET-7x00/PET-7x00 series module, the operating mode selector switch should usually be in the Normal position. The switch should only be moved from the **Normal** position to the **Init** position when updating the ET-7x00/PET-7x00 firmware or the OS. Once the update has been completed, ensure that the switch is returned to the Normal position.

#### Frame Ground

Electronic circuits are constantly vulnerable to Electrostatic Discharge (ESD), which becomes worse in a continental climate area. The ET-7x00/PET-7x00 series features a new design for the frame ground that provides a path for bypassing ESD, allowing enhanced static (ESD) protection capabilities and ensuring that the module is more reliable.

As the figure below, the user can choose one of the frame grounds to provide a better level of protection for the module. These two frame grounds are conductive inside the module. When a DIN-Rail is mounted, it will in contact with the metallic board of the upper F.G., so a ground wire can be connected to either the lower F.G. or to the DIN-Rail.

F.G. 1.


ET-7000




# 1.3. Dimensions

The following diagrams provide the dimensions of the ET-7x00/PET-7x00 module and can be used as a reference when defining the specifications for any custom enclosures. All dimensions are in millimeters.

## For the ET-7000, PET-7000: 72 x 123 x 35



## For the ET-7200, PET-7200: 76 x 120 x 42




# **Chapter 2. Getting Started**

If you are a new user, begin with this chapter as it includes a guided tour that provides a basic overview of how to install, configure and use the ET-7x00/PET-7x00 module.

https://www.icpdas.com/en/download/show.php?num=2218

Before starting any task, please check the package contents. If any of the following items are either missing or damaged, contact your dealer or distributor.







**Quick Start Guide** 

Before operating the ET-7x00/PET-7x00 module, a basic understanding of the hardware specifications is required, such as the dimensions of the module, the usable input voltage range of the power supply, and the type of communication interfaces.

# 2.1. Mounting the ET-7x00/PET-7x00


The ET-7x00/PET-7x00 module can be mounted by attaching the bottom of the chassis to a DIN-Rail, to the wall, or by piggybacking it to another module.


## **DIN-Rail Mounting**

The ET-7x00/PET-7x00 module includes simple rail clips that can be used to reliably mount it on a standard 35 mm DIN-Rail.

## Mounting the Chassis on a DIN-Rail

1. Hook the upper tab over the upper flange of the DIN-Rail.





2. Tilt the module toward the DIN-Rail until it snaps securely to the rail.

## **Piggyback Mounting**

The ET-7x00/PET-7x00 module has a hole on either side of the casing that can be used for piggyback mounting.



# 2.2. Configuring the Boot Mode

The ET-7x00/PET-7x00 module has two operating modes, which can be determined by the switch mechanism on the chassis.

#### **Init Mode**



Init mode is a way to use MiniOS7 configuration mode.





Init mode is a method to use MiniOS7 configuration mode and update the software. After the update is completed, set the switch to the Normal position.



#### **Normal Mode**




Normal mode is the default mode of operation and the one you will use most of the time. Use this mode for more tasks and configurations. Programs also are executed in this mode.

# 2.3. ET-7x00/PET-7x00 Hardware Connections

ET-7x00/PET-7x00 series modules provide a variety of communication interfaces to suit a range of applications. Below is a description of the configuration for simple applications using the ET-7x00/PET-7x00 when implementing both Non-PoE and PoE solutions.

## Non-PoE

- 1. Connect the PC to the Ethernet Port via the Hub or Switch.
- 2. Connect the positive of the power supply to the terminal marked "(R)+Vs" on the ET-7x00.
- 3. Connect the negative of the power supply to the terminal marked "(B)GND" on the ET-7x00.



## PoE


- 1. Connect the PC to the Ethernet Port via the PoE Switch.
- 2. Connect the power supply to the PoE Switch, which in turn supplies power to the PET-7x00.

## PET-7X00






Only the E1 port of the PET-7x00 supports the PoE feature.







# 2.4. Installing the MiniOS7 Utility

The MiniOS7 Utility is a useful tool that provides a quick and easy way to update the OS image or the firmware, configure the Ethernet settings, and upload files to the ET-7x00/PET-7x00 from a PC.

Step 1: Install the MiniOS7 Utility tool




The latest version of the MiniOS7 Utility can be obtained from the ICP DAS website: https://www.icpdas.com/en/product/guide+Software+Development\_\_Tools+MiniOS7

## Step 2: Follow the instructions in the Setup Wizard to complete the installation

After the installation has been completed, a new short cut for the MiniOS7 Utility will be displayed on your desktop.






# 2.5. Using the MiniOS7 Utility to Assign an IP Address


The ET-7x00/PET-7x00 is a web-based device and is configured using a default IP address, meaning that you must first assign a new IP address to the ET-7x00/PET-7x00 before operation.

The factory default IP settings are as follows:


Item	Default
IP Address	192.168.255.1
Subnet Mask	255.255.0.0
Gateway	192.168.0.1

Step 1: Run the MiniOS7 Utility





Step 2: Click "Connection > Search" on the menu bar (or press "F12") to search modules




Step 3: Click the "192.168.255.1" item in the IP/Port field and click the "IP Settings" button

Click the item you want to configure (the default IP= "192.168.255.1") and click the "IP Settings" button to display the IP Settings dialog box.

🚵 MiniOS7 Scan				_	□ >	×
Search Options Co	onnect Clear IP sett					
Туре	IP/Port	Name	Alias	Mask	Gateway	^
TCP BroadCast	192.168.85.103	DL-302	EtherI0	255.255.0.0	192.168.1.1	
► TCP BroadCast	192.168.255.1	ET-7255/PET-7255		255.255.0.0	192.168.0.1	
TCP BroadCast	192.168.79.26	ET-7026/PET-7026	TEST	255.255.0.0	192.168.1.1	
TCP BroadCast	192.168.12.100	iKAN-124	LED	255.255.0.0	192.168.0.1	
TCP BroadCast	192.168.11.16	WP5XXX	PMC-5151	255.255.0.0	192.168.1.1	v
<					>	
Search done.						


#### Step 4: Assign a new IP address and then click the "Set" button

In the IP Settings dialog box, you can manually assign an IP Address, Mask Address, Gateway, and Alias, or you can enable the DHCP function to dynamically assign IP addresses. Once the appropriate values have been entered, click the "**Set**" button to save the settings.



Step 5: After rebooting, click the "Connection > Search" (F12) from the menu bar to check the IP settings

After completing the settings, reboot the module and search it by using MiniOS7 Utility to make sure that the IP settings are correct.



# 2.6. Configuring the I/O Functions

The ET-7x00/PET-7x00 series provide a web-based configuration interface that allows users to perform module settings and monitor and control the I/O status by using a web browser to log on to the built-in web page. Users do not need to install any utility.

Step 1: Be sure that the switch is set to the "Normal" position and then reboot the module



## Step 2: Open a browser

Use a standard internet browser to view the ET-7x00/PET-7x00 web pages, such as Google Chrome, Mozilla Firefox or Internet Explorer, etc.

## Step 3: Enter the URL address for the ET-7x00/PET-7x00

If you haven't changed the default IP address of the ET-7x00/PET-7x00 module, please refer to section 2.5. "Using the MiniOS7 Utility to Assign an IP Address" to configure it.



## Step 4: Enter your User name and Password

After entering the IP address, the login dialog box will appear, prompting you to enter your user name and password.

The factory default user name and password are as follows:




## Step 5: Welcome to the ET-7x00/PET-7x00 web interface

After logging into the ET-7x00/PET-7x00 web interface, the Overview page will be displayed.




## Step 6: Configure and browse the I/O functions

Expand the "Web HMI" menu and click the "Web HMI" item to set and browse the I/O functions.



For more information about the I/O specification, pin assignment, I/O functions, etc. for each ET-7x00/PET-7x00, please refer to "ET7000\_ET7200 Register Table", which can be obtained from: https://www.icpdas.com/en/download/show.php?num=2217



# **Chapter 3. Web Applications**

The ET-7x00/PET-7x00 contains an advanced web configuration system that provides users with access to ET-7x00/PET-7x00 applications through a standard web browser.

## Logging into the ET-7x00/PET-7x00 web pages

You can log into the ET-7x00/PET-7x00 web pages from any computer that has Internet access.

#### Step 1: Open a browser

Use a standard internet browser to view the ET-7x00/PET-7x00 web pages, such as Mozilla Firefox or Internet Explorer, etc.


## Step 2: Enter the URL address for the ET-7x00/PET-7x00

If you haven't changed the default IP address of the ET-7x00/PET-7x00 module, please refer to section 2.5. "Using the MiniOS7 Utility to Assign an IP Address" to configure it.

## Step 3: Enter your User name and Password


After entering the IP address, the login dialog box will appear, prompting you to enter your user name and password.

The factory default user name and password are as follows:




## Step 4: Welcome to the ET-7x00/PET-7x00 web interface

After logging into the ET-7x00/PET-7x00 web interface, the "Overview" page will be displayed.




## 3.1. Overview



# 3.2. Configuration

The "Configuration" menu includes the following settings:



## **Network Settings:**

Provides access to the **Ethernet Configuration** section which allows you to access the IP settings and check the software version.

#### **Basic Settings:**


Provides access to the **Basic Settings** section which allows you to configure the basic information for the web interface. Also, the **Restore All Default Settings** section allows you to reset the module to factory settings.

## **Module I/O Settings:**

Provides access to **Common Functions, Modbus Definition,** and I/O-related sections, which allows you to configure the I/O settings of the module.

## 3.2.1. Network Settings

The **Network Settings** page provides the **Ethernet Configuration** section that allows you to perform the following functions:



## ♦ Manual Configuration (Manually):

The user can enter the IP, Mask, and Gateway addresses for the module and then click the **SUBMIT** button to finish the setting.

#### IP address:

Each ET-7x00/PET-7x00 on the network must have a unique IP address.

#### Subnet mask:

The subnet mask splits the IP address into the host and network addresses, thereby defining which part of the IP address belongs to the device and which part belongs to the network.

#### **Gateway:**

A gateway (or router) can be used to connect local devices to other networks.


## ♦ Dynamic Configuration (Using DHCP):

The Dynamic Host Configuration Protocol (DHCP) is a network application protocol that automatically assigns an IP address to a device. The user can choose **Using DHCP** in the **Configure** drop-down menu and click the **SUBMIT** button to finish the setting.

## 3.2.2. Basic Settings

The **Basic Settings** page provides **Basic Settings** and **Restore All Default Setting** sections that allow you to perform the following functions.

## (A) Basic Settings



## **♦** Configure the module information

## Module Name:

The initial value for this field will depend on the model of the module and cannot be modified.


## **Module Information**:

The module information field indicates the name of the alias that is used to identify the module.

#### Configure the web interface information

#### Page Header Information (First line) and Page Header Information (Second line):


The title of the website is displayed in the top left-hand corner of the interface, for example, the company name and web address as per the example below.



#### **More Information URL**:

This item allows you to specify the URL that will be displayed when the "**More Information**" option is clicked to provide additional support for the ET-7x00/PET-7x00.

After completing the settings and refreshing the web page (F5), click the "More Information" option to check that the link to the web site is correct as the figure below.



#### Web Server Port:

This option specifies which port is to be used for the web server. By default, the HTTP port is 80.

#### **Modbus TCP Port:**


This option specifies which port is to be used for communication on the Modbus TCP. By default, the Modbus protocol uses port 502.

#### **Modbus TCP Port (WAN)**:

This option specifies which port is to be used for Modbus communication between the remote host and local EX-7x00/PET-7x00. This setting can be ignored if ET-7x00/PET-7x00 is not located behind a router.

To configure the web interface information, follow the procedure below:

- Step 1: Enter the desired information into the respective fields.
- Step 2: Click the "Submit" button to finish configuring the module information.




# (B) Restore All Default Settings

The reset function is divided into categories based on the menu options for the web interface and can be used to restore the individual settings to their factory default state.

To reset the settings to their factory default, follow the procedure below:


- Step 1: Check the relevant check boxes for the items you wish to reset.
- Step 2: Click the "Submit" button to reset the settings to their factory default state.



# Tips & Warnings



For ET-7200/PET-7200 modules, in addition to using the reset function in the web-based **Basic Settings** page, you can also press and hold the reset button for five seconds to restore the ET-7200/PET-7200 to factory defaults.



# (B.1) Factory Default Settings for the "Configuration" Menu Options

The tables below outline the factory default settings for the items listed in the "Configuration" menu.

# **Network Settings**

#### **Ethernet Configuration**

Item	Factory Default Settings
IP Address	192.168.255.1
Subnet Mask	255.255.0.0
Gateway	192.168.0.1

# **Basic Settings**

#### **Basic Settings**

Item	Factory Default Settings
Module Name	Depends on the name of the module
Module Information	Empty
Page Header Information (First line)	ICP DAS
Page Header Information (Second line)	https://www.icpdas.com
More Information URL	https://www.icpdas.com
Web Server Port	80
Modbus TCP Port	502
Modbus TCP Port (WAN)	502

# **Module I/O Settings**

Note that all settings displayed on this page vary depending on the model number.

# **Common Functions**

Item	Factory Default Settings
Host Watchdog Timeout	0 (0: Disabled, 1 ~ 65535: Enabled) (units: 0.1 seconds)

#### **Modbus Definition**

Item	Factory Default Settings
Modbus Unit ID	1

#### **Digital Output Settings**

Item	Factory Default Settings
Power-on Value	OFF
Safe Value	OFF

#### **Digital Input Settings**

Item	Factory Default Settings
DI Latched Status	Disabled
Digital Input Counter	Disabled
Counter Value Inverse	Disabled
Low-Pass Filter	100 Hz. The Min. width is 5 ms

#### **Analog Output Settings**

Item	Factory Default Settings
Range	This value varies depending on the model
	of the module
Slew Rate	00, Immediate
Power-on Value	0.0
Safe Value	0.0

# **Analog Input Settings**

Item		Factory Default Settings
Channel		Enable
Panga		This value varies depending on the model
Range		of the module
Compling Boto	Normal mode (10 Hz)	Normal mode
Sampling Rate	Fast mode (50 Hz)	Normal mode
Filtor Cotting	60 Hz Rejection	CO Uz Bojection
Filter Setting	50 Hz Rejection	60 Hz Rejection
Data Format	HEX 2's complement	HEV 2's complement
Data i offiliat	Engineering	HEX 2's complement

**Note**: The analog input and the analog output share the same data format settings.

# **Alarm Settings**

Item		Factory Default Settings
	Channel	Disable
High Alarm	gh Alarm High Limit Value	This value varies depending on the model
I IIgii Alaiiii		of the module
Mode	Mode	Momentary
	Channel	Disable
Low Alarm	arm Low Limit Value	This value varies depending on the model
LOW Alarm		of the module
	Mode	Momentary

# (B.2) Factory Default Settings for the "Authentication" Menu Options

The tables below outline the factory default settings for the items listed in the "Authentication" menu.

#### **Account Management**

#### **Privilege Management**

Item	Factory Default Settings
Authority	Administrator
Admin	Admin
Password	Admin
Note: Since firmware version V3.11 (or later), the default username and password are not	

# **Accessible IP Settings**

#### **IP Filter Settings**

Item	Factory Default Settings
Enable the IP filter table	
Activate	Empty, there is no limit to allowing any
From (IP Address)	outgoing access.
To (IP Address)	

# (B.3) Factory Default Settings for "Web HMI" Menu Option

supported. Users need to create them for their initial login.

The tables below outline the factory default settings for the items listed in the "Web HMI" menu.

#### Web HMI

Factory Default Settings
Depends on the Modbus setting function of the ET-7x00/PET-7x00.

#### **Web Edit**

Factory Default Settings
Main Page

# (B.4) Factory Default Settings for the "Pair Connection" Menu Option

The table below outlines the factory default settings for the "Pair Connection" option.

#### **Pair Connection**

#### **Configuration of Communication**

Item	Factory Default Settings			
Connection Timeout (ms)	2000			
Reconnect Interval (ms)	3000			

#### Remote DI to Local DO


Item	Factory Default Settings
Communication Timeout (ms)	1000
Scan Time (ms)	1000
Local DO Base Address	0
I/O Count	0
IP Address of the Remote Device	192.168.255.200
Modbus TCP Port	502
Modbus ID	1
Remote DI Base Address	0

#### **Local DI to Remote DO**

Item	Factory Default Settings
Communication Timeout (ms)	1000
Scan Time (ms)	1000
Local DI Base Address	0
I/O Count	0
IP Address of the Remote Device	192.168.255.200
Modbus TCP Port	502
Modbus ID	1
Remote DO Base Address	0

# 3.2.3. Module I/O Settings

After completing the general configuration of the ET-7x00/PET-7x00 module described in the previous section, the settings for the input and output channels need to be configured, such as the channel range and the alarm, etc.



#### **Tips & Warnings**




The contents displayed on this page will be depending on the Modbus functions applicable to the specific ET-7x00/PET-7x00 module. Please refer to the user manual for each module for details on how to configure the relevant I/O settings.

In this example, ET-7026/PET-7026 will be used to explain the I/O settings. (The ET-7026/PET-7026 is a multi-function module that has 6 AI channels, 2 AO channels, 2 DI channels and 2 DO channels.)

# (A) Common Functions


The **Common Functions** area provides options that allow the settings for the Modbus functions to be configured.





#### (B) Digital Output Settings

The **Digital Output settings** area provides details of the configuration settings for all digital output channels.



#### Power-on value:

Used to preset the power-on value of the DO.

#### **Safe Value**

#### When choosing the "Disabled – Maintain the current status" option

Whether the Host Watchdog or Pair-Connection feature is enabled, the Safe Value will not take effect (the DO remains in its original state).

#### When choosing the "Enabled - Host Watchdog" option

Remember to set a Host Watchdog timeout in the "Common Functions" section. Notice that the Host Watchdog will be enabled by entering a non-zero value.



If the Host Watchdog is enabled, the digital outputs will be set to the safe value when the communication between a Host PC and the ET-7x00/ PET-7x00 module is interrupted. In this case, the timeout is set to 10 seconds.


#### When choosing the "Enabled – Pair-Connection" option

Make sure that the Pair Connection function has been configured, refer to Section 3.5. If the communication between the module and the remote module is failed, the digital outputs will be set to the safe value.

Refer to "Appendix A. Description of I/O Functions" for more information.

#### (C) Digital Input Settings

All digital input channels in ET-7x00/PET-7x00 modules can be used as 32-bit counters and each counter consists of two address values, the Low word, and the High word. Specific individual DI channels can be counted via the Digital Input settings web page.



#### • Enable DI Latched Status:

When the DI Latch function is enabled, once the digital input channel detects any change in input status, the input status will be latched until it is cleared by using the clear command manually.

#### <u>Digital Input Counter</u>:

When the Counter mode is selected, one counter will record the number of pulses from the digital signal for the selected channel, and will then record the count value in the register.

#### Preset Value for Digital Input Counter:

This option allows the default values for the counters to be set.




When the signal occurs for a short time, the Host (Modbus TCP master) may not be in a hurry to read the changed state of DI, and will mistakenly think that DI has not changed all the time.

In this case, you can read the state of the DI Latch or DI Input Counter to determine whether DI has ever changed.

#### (D) Analog Output Settings

The **Analog Output settings** section contains the Range, Slew Rate, Power-on Value, and Safe Values Settings that will be described in detail below.



#### Range:

In a manner, a different range can be set for individual analog output channels. Select the required voltage/current range from the respective drop-down menus. For more detailed technical specifications related to the output range for each analog output channel, please refer to: "Appendix C. Analog Output Type and Data Format Table".

# Tips & Warnings



For modules that support the Voltage/Current type (e.g., <u>ET-7017</u>) or the Voltage/Current/ Thermocouple type (e.g., <u>ET-7018Z/S</u>), the jumper is at the [Voltage/Thermocouple] position by default. To use the Current signal, you need to adjust the jumper(s).

Before selecting the range for each AIO channel, make sure that jumpers are set properly. For more detailed related to the jumper settings for each ET-7x00/PET-7x00 module, please refer to "ET7000 ET7200 Register Table".

# Voltage / Current Input Selection Jumper Voltage Input Thermocouple Input OH Current Input

#### Slew Rate:

This is the programmable output slew rate for the analog output channels, i.e., the rate of change in the analog output voltage/current as it changes from one output voltage/current to another. Select the most appropriate value from the respective drop-down menus.

#### Power-on Value:

A power-on value can be set for a specific analog output channel. After rebooting the module, the analog output value will be set to the power-on value.


#### Safe Value:

The Host Watchdog can be enabled or disabled by configuring the Host Watchdog Timeout setting in the (A) "Common Functions" section. When communication between the Host PC and the ET-7x00/PET-7x00 module is interrupted, the analog output value will be set to a predefined safe value.

For a more detailed description of these Modbus functions, please refer to "Appendix C. Modbus Application Notes".

#### (E) Analog Input Settings

**The Analog Input Settings** area contains two parts, the Range settings, and Modbus function Settings, which will be described in detail below.



#### Enable/Disable:

This section allows the user to enable or disable each analog input channel. For the ET-7000/ET-7200 series module, all analog input channels share a single A/D Chip so the user can

disable unused channels to improve the sampling rate for each channel. For example, the sampling rate for a total of eight AI channels of an ET-7017 is 10 Hz. If all channels are enabled, the sampling rate for each channel is 1.25 Hz. If three channels are disabled, the sampling rate for the enabled five channels is 2 Hz.


• Range:

ET-7x00/PET-7x00 modules provide a programmable input voltage/current range on all analog input channels, where a different range can be set for each analog input channel. Select the required voltage/current range from the respective drop-down menus. For more detailed technical specifications related to the input range for each analog input channel, please refer to: "Appendix B. Analog Input Type and Data Format Table".



For modules that support the Voltage/Current type (e.g., <u>ET-7017</u>) or the Voltage/Current/ Thermocouple type (e.g., <u>ET-7018Z/S</u>), the jumper is at the [Voltage/Thermocouple] position by default. To use the Current signal, you need to adjust the jumper(s).

Before selecting the range for each AIO channel, make sure that jumpers are set properly. For more detailed related to the jumper settings for each ET-7x00/PET-7x00 module, please refer to "ET7000 ET7200 Register Table".



#### Normal Mode/Fast Mode:

ET-7x00/PET-7x00 modules support sample rates in either "Normal" or "Fast" mode. The fast mode uses 60 Hz with a 16-bit resolution, while the Normal mode uses 10 Hz with a 16-bit resolution.

#### • <u>60/50 Hz Rejection</u>:

To remove the noise from the power supply, ET-7x00/PET-7x00 analog input modules feature two built-in rejection filters, that operate at different frequencies, 50 or 60 Hz, that are designed to remove noise generated by different power supplies.

#### Data Format:

The analog value can be displayed in either hexadecimal or engineering.

#### Hexadecimal format:

All ranges of the Modbus 16-bit Register can be applied, where no resolution loss for the A/D or D/A value.

#### Engineering format:

Converting values is simple in this way, but there is some resolution loss when using the entire range of the Modbus 16-bit Register to express the value.

#### For example,

The input range of the ET-7017 is set to +/-10V,

00	10 - 110 V	Engineering Unit	+10000	-10000
08	-10 ∼ +10 V	2's comp HEX	7FFF	8000

If the real value is +6 V, the Modbus date will be:

<u>Value in Hexadecimal:</u> 6/10 \* 0x7FFF = 0.6 \* 32767 = 19660 (or 0x4CCC)

Each scale is 10 V / 32767 = 0.305 mV


<u>Value in Engineering:</u> 6/10 \* 10000 = 6000 (or 0x1770)

Each scale is 10 V / 32767 = 1 mV

#### 2's comp HEX

# Real Value Modbus Register +10 V 32767 0 V 0 -10 V -32768

#### **Engineering Unit**



#### (F) NTC Thermistor Temperature Settings (for ET-7005) – User Defined Type

(P)ET-7005 supports NTC Thermistors, and the resistance/temperature characteristics of each manufacturer's Thermistor may vary. Although the (P)ET-7005 already supports several well-known brand of thermistors, it provides users with the function to create their own conversion formulas to match other thermistor..

The equipment listed below is used in this example.

#### 1. ET-7005 \* 1:

#### https://www.icpdas.com/en/product/ET-7005

The ET-7005 is a Ethernet I/O module with 8-ch Thermistor input and 4-ch DO. With a maximum resistance measurement of 200K ohms, the ET-7005 is capable of supporting temperatures as low as -40°C.


#### 2. CA-TM-P100-L050 \*1:

https://www.icpdas.com/en/product/ET-7005#Accessories

NTC Thermistor, Epoxy Resin Cable, 5M (-40 °C to +80 °C)



Step1: In the Analog Input Settings section, enable the channel you want to use (e.g., Ch0), set the Range to "71, User- Defined, -50 ~ 150°C", and click the SUBMIT button.




Step2: Users can refer to the thermistor's resistance-temperature table and enter three resistance values and their corresponding temperatures into the User-DefinedType-71 item. It is recommended to follow the rules for optimal accuracy.

(1) 
$$-40^{\circ}$$
C <= T1, T2, T3 <= 150°C (2) |T2 - T1| <= 50°C (3) |T3 - T2| <= 50°C

Resistance (ohm)	Temperature (°C)
67770	-20
12090	20
3020	60

Temp.	Valore di Resistenza		Temp.	Valore d	i Resistenza		Temp.	Valore d	li Resistenza		
	Max.	Tipico	Min.		Max.	Tipico	Min.	_	Max.	Tipico	Min
°C	ΚΩ	ΚΩ	ΚΩ	°C	ΚΩ	ΚΩ	ΚΩ	°C	ΚΩ	ΚΩ	ΚΩ
-50	344,60	329,50	314,90	1	26,65	26,13	25,62	56	3,50	3,43	3,35
-49	325,00	310,90	297,30	2	25,52	25,03	24,55	57	3,39	3,32	3,25
-48	306,60	293,50	280,90	3	24,44	23,99	23,54	58	3,28	3,22	3,15
-47	289,40	277,20	265,40	4	23,42	23,00	22,57	59	3,18	3.12	3,05
-46	273,40	262,00	251,00	5	22,45	22,05	21,66	60	3,09	3,02	2,95
-45	258,30	247,70	237,40	6	21,53	21,15	20,78	61	2,99	2,93	2,86
-44	244,20	234,30	224,70	7	20,64	20,30	19,95	62	2,90	2,84	2,77
-43	231,00	221,70	212,80	8	19,81	19,48	19,15	63	2,82	2,75	2,69
-42	218,60	209,90	201,60	9	19,01	18,70	18,39	64	2,73	2,67	2,61
-41	207,00	198,90	191,00	10	18,25	17,96	17,67	65	2,65	2,59	2,53
-40	196,00	188,50	181,10	11	17,51	17,24	16,97	66	2,57	2,51	2,45
-39	185,50	178,50	171,60	12	16,81	16,56	16,30	67	2,50	2,44	2,38
-38	175,60	169,00	162,60	13	16,14	15,90	15,67	68	2,42	2,36	2,31
-37	166,30	160,20	154,20	14	15,50	15,28	15,06	69	2,35	2,30	2,24
-36	157,60	151,90	146,30	15	14,89	14,69	14,48	70	2,28	2,23	2,17
-35	149,40	144,10	138,80	16	14,31	14,12	13,92	71	2,22	2,16	2,11
-34	141,70	136,70	131,80	17	13,75	13,58	13,39	72	2,15	2,10	2,05
-33	134,50	129,80	125,20	18	13,22	13,06	12,89	73	2,09	2,04	1,99
-32	127,70	123,30	119,00	19	12,72	12.56	12,40	74	2,03	1,98	1,93
-31	121,20	117,10	113,10	20	2,24	12,09	11,94	75	1,98	1,92	1,87
-30	115,20	111,30	107,50	21	11,77	11,63	11,50	76	1,92	1,87	1,82
-29	109,40	105,70	102,20	22	11,32	11,20	11,07	77	1,87	1,82	1,77
-28	103,90	100,50	97,20	23	10,90	10,78	10,66	78	1,81	1,77	1,72
-27	98,68	95,52	92,45	24	10,49	10,38	10,27	79	1,76	1,72	1,67
-26	93,80	90,84	87,97	25	10,10	10,00	9,90	80	1,72	1,67	1,62
-25	89,20	86,43	83,73	26	9,73	9,63	9,53	81	1,67	1,62	1,58
-24	84,85	82,26	79,74	27	9,38	9,28	9,18	82	1,62	1,58	1,53
-23	80,76	78,33	75,96	28	9,04	8,94	8,84	83	1,58	1,53	1,49
-22	76,89	74,61	72,39	29	8,72	8,62	8,52	84	1,54	1,49	1,45
-21	73,23	71.10	69,01	30	8,41	8,31	8,21	85	1,49	1,45	1,41
-20	€9,77	67,77	65,82	31	8,11	8,01	7,92	86	1,45	1,41	1,37
-19	56,44	64,57	62,74	32	7,83	7,73	7,63	87	1,42	1,37	1,33
-18	63,30	61,54	59,83	33	7,55	7,45	7,36	88	1,38	1,34	1,30
-17	60,32	58,68	57,07	34	7,29	7,19	7,10	89	1,34	1,30	1,26
-16	57,51	55,97	54,46	35	7,04	6,94	6,85	90	1,31	1,27	1,23
-15	54,85	53,41	51,99	36	6,79	6,70	6,61	91	1,27	1,23	1,19
-14	52,33	50,98	49,65	37	6,56	6,47	6,37	92	1,24	1,20	1,16
-13	49,95	48,68	47,43	38	6,34	6,25	6,15	93	1,21	1,17	1,13
-12	47,69	46,50	45,32	39	6,12	6,03	5,94	94	1,17	1,14	1,10
-11	45,55	44,43	43,33	40	5,92	5,83	5,74	95	1,14	1,11	1,07
-10	43,52	42,47	41,43	41	5,72	5,63	5,54	96	1,12	1,08	1,04
-9	41,55	40,57	39,60	42	5,53	5,44	5,35	97	1,09	1,05	1,02
-8	39,69	38,77	37,86	43	5,34	5,26	5,17	98	1,06	1,02	0,99
-7	37,92	37,06	36,21	44	5,17	5,08	4,99	99	1,03	1,00	0,97
-6	36,25	35,44	34,64	45	5,00	4,91	4,83	100	1,01	0,97	0,94
-5	34,66	33,90	33,15	46	4,83	4,75	4,67	101	0,98	0,95	0,92
4	33,15	32,44	31,73	47	4,68	4,59	4,51	102	0,96	0,92	0,89
-3	31,72	31,05	30,39	48	4,52	4,44	4,36	103	0,93	0,90	0,87
-2	30,36	29,73	29,11	49	4,38	4,30	4,22	104	0,93	0,90	0,85
-1	29,06	28,48	27,89	50	4,24	4,16	4,08	105	0,89	0,86	0,83
0	27,83	27,28	26,74	51	4,10	4,03	3,95	106	0,89	0,84	0,81
	27,03	27,20	20,74	52	3,97	3,90	3,82	107	0,84	0,82	0,79
				53	3,85	3,77	3,70	108	0,82	0,80	0,79
				54	3,73	3,65	3,58	109	0,80	0,78	0,77
				55	3,61	3,54	3,46	110	0,79	0,76	0,73

**Step3:** Once the **Calculate** button is clicked, the Steinhart coefficient will be computed. Then, click the **Save** button to save the settings and finalize the configuration.




**Step4:** The user can view the current temperature of the AIO on the **Web HMI** page.





#### (G) Alarm Settings

The ET-7x00/PET-7x00 modules feature a built-in alarm function. The alarm settings include two parts, the high limit value, and the low limit value, and each need to be configured for a specific channel.




#### Enable/Disable:

This section allows each analog input alarm to be set to enable or disabled.

#### High/Low Limit Value:

Both the high alarm value and the low alarm value can be defined in the High (or Low) Limit Value text box. When the analog input value is higher than the high alarm value, or lower than the low alarm value, an alarm occurs. The alarm status will then be activated and switched to on.



#### • Mode:

The ET-7x00/PET-7x00 allows the alarm to be selected as either Momentary or Latch mode, which can be set using the Mode combo box for both the low alarm and the high alarm.

#### ➤ Latch Mode:


An alarm will be triggered when the analog input value exceeds alarm limits. When the AI value is back to normal, the alarm status will keep until the clear command is sent to the specific address.

#### ➤ Momentary Mode:

An alarm will be triggered when the analog input value exceeds alarm limits. When the AI value is back to normal, the alarm status will automatically be cleared.

# 3.3. Authentication

The "Authentication" menu contains the following options:



#### **Privilege Management:**


Provides access to the Privilege Management and Reset Settings sections. The user can manage user accounts and their associated privileges and also reset the settings.


#### **Accessible IP Settings:**

Provides access to the IP Filter Settings page, which allows you to control access to the web page.

# 3.3.1. Account Management

The **Privilege Management** page provides functions that allow the following tasks to be performed:





#### (A) Configuring the User Accounts

The ET-7x00/PET-7x00 interface supports a maximum of five user accounts, including:

#### An Administrator Account

FW V3.0x (or older) provides a default administrator account (Admin). Sine FW v3.11 (or later), the user needs to create an administrator account upon login, which must be at least 4 characters long. This account cannot be deleted, but administrators can change the username/password.

#### Four User-defined Accounts

Each account consists of an username, a password, and an authority level.

There are two types of authority levels: Administrator and User.

#### ➤ Admin:

With the highest authority, the administrator has full access to all functions on the ET-7x00/ PET-7x00 web page, including modifying or reviewing all settings.

#### ➤ <u>User</u>:

This level only allows the user to view some of the module settings. The user cannot modify any settings through the ET-7x00/PET-7x00 web page.


#### (B) Restoring the Factory Default User Accounts

The ET-7x00/PET-7x00 has a built-in administrator account (**Admin**) that can be modified but cannot be deleted. The firmware version 30x allows the user to restore the default settings (password: Admin) by clicking the "**Reset Settings**" button.


#### Note:

Firmware v3.11 (or later) does not include a default administrator account for security reasons. Also, there is no "Reset Settings" button on this page.

However, users can remove all usernames/passwords on the "Basic Settings" page and then create a new one the next time they log in. Alternatively, the ET-72xx/PET-72xx series have a physical Reset button that can be pressed and held for 5 seconds to restore the factory settings.




Press and hold the **Reset** button on the ET-7200/PET-7200 for 5 seconds to restore the factory settings.



# 3.3.2. Accessible IP Settings

The **IP Filter Settings** page allows the user to whitelist a range of IP addresses. Only those in the list will have access to this module. **Note:** By default, there is no restriction on outgoing access.




Follow the steps to configure the accesible IP addresses:

- **Step 1:** Check the "**Active**" checkbox and input the Start and End IP addresses. Alternatively, users can only enter the Start IP address if you are not using continuous IP addresses.
- **Step 2:** After making changes, click each "**SAVE**" button to save the settings.
- **Step 1:** Reboot the module to apply the settings.

# 3.4. Web HMI

The "Web HMI" menu contains the following options:



#### Web HMI:

Provides access to the I/O monitor page, which allows you to remotely monitor and control the I/O status of the ET-7x00/PET-7x00 module.

#### Web Edit:


Provides access to the "Web Page Configuration" page, which allows you to create up to ten dynamic web HMI pages and set one of them as the start page so that it will be displayed when logging in to an ET-7000/ET-7200.

#### 3.4.1. Web HMI


The ET-7x00/PET-7x00 module features a Web HMI web interface that can be used to display real-time I/O data values and alarms via the LAN or the Internet. Real-time I/O data values and alarms can be monitored at either the local or remote site using any web browser. Also, the Web HMI is completed immediately without requiring any programming skills (HTML or Java).

First, you can see the default I/O monitoring page (Main Page), which displays the supported I/O tabs for the module.


#### Al page




#### AO page



#### DI page




#### DO page



#### 3.4.2. Web Edit


The ET-7x00/PET-7x00 module provides functions that enable users to create customized web pages. Users can upload specific I/O layout diagrams in either .bmp, .jpg, or .gif format and can define a description for each page.

By default, there is only a Main page, you can click the "Add a new page" button to add a page. Up to 10 user-defined web pages can be created.





Next, you can also set the new page (e.g., Carriage) as a start page so that it will be displayed when logging in to an ET-7000/ET-7200. Click **"Yes"** under the **"Set as the Start Page"** section and click the **"SUBMIT"** button.



THIS COMPUTER -- ET-7000 Overview Configuration CARRIAGE PAGE02 AI AO DI DO PAGE03 Network Settings Basic Settings Carriage Module I/O Settings Authentication Account Management Accessible IP Settings Web HMI Web HMI Web Edit **Pair Connection** Motor More Information Channel No. Alias Status Action DI0 PHS1 OFF

OFF

Motor

Click the "Web HMI" item to see the start pages (e.g., Carriage).


Below is an example of how to create a customized web page.

DO0

# **Example**

#### Objective:

Create a Web page to monitor the I/O status of a conveyor system, as shown below. The I/O system contains a sensor that is used to detect the products and a switch that is used to turn the conveyor motor on and off.




ON

OFF


#### Step 1: Add a New Page

Click the "Add a new Page" button to begin creating a new page.



#### Step 2: Upload an Image

Click the "Choose File" button to select an image, and then click the "UPLOAD" button to upload the image to the ET-7x00/PET-7x00 module, as shown in the figure below.



#### **Tips & Warnings**




The image can be in either .jpg, .gif, or .bmp format with a maximum file size of 64 KB. The recommended resolution for the image to be displayed on the editing Web page is 340 \* 250 pixels.

After the upload is completed, you can see the image. Also, the file name will be added to the "Image" dropdown list box. (See the step3)




#### Step 3: Set the Page Name and Select the Image


Enter a name for the page in the "Page Name" field and then select an image from the "Image" dropdown list box. After selecting the image, it will be displayed in the preview window. Then, click the "SUBMIT" button.




#### Step 4: Add a Modbus Register Item to be used to read the selected sensor input


On the **Carriage** page, click the **"Edit"** button in the first row to display the **"Edit Group Register"** page.







Now, a new Register item will be displayed in the list. To edit the item, click the "EDIT" button to access the Edit Group Register page, or to remove the item, click the "REMOVE" button.





Step 6: Add a Modbus Register Item to be used to write the selected motor output

Click the "Edit" button in the second row of the list, and the "Edit Group Register" page will be displayed.



Step 7: Add a DO that is to be used to write the "Motor" output to turn the conveyor motor on and off






Step 8: Add an AI that is to be used to read the speed of the conveyor (In this case, 0-2.5 m/s)


Set the Speed as an AI tag (use the Modbus Register "0", i.e., AIO).

(See the figure on the next page)


- Set the Register Type to "Input" (Read).
   Enter "Speed" in the Alias field.
   Set the Scaling as "Enabled" and enter the Gain value
- 3. Set the **Scaling** as "**Enabled**" and enter the **Gain** value as "**0.25**" (i.e., 2.5/10 = 0.25).



-10 V




4. Click the **SUBMIT** button to save the settings.




Step 9: Browse the "Carriage" web page

After clicking the Web HMI item, you can click on the Carriage tab to see the added page.






On the **Carriage** page, you can click the control button of the motor to set it as ON. For testing, when the AI value is "5", the value will be converted to a conveyor speed of  $5 \times 0.25 = 1.25$  (m/s)




# 3.5. I/O Pair Connection

The "Pair Connection" feature enables configuring connections between remote and local I/O, facilitating the remote transmission of input data to output channels.




The **pair connection** function is a particular feature of the ET-7x00/PET-7x00 module that can be used to enable a pair of DI-to-DO (or AI-to-AO) via Modbus TCP.

With the pair connection function enabled, the ET-7x00/ PET-7x00 module can poll the status of remote input devices using the Modbus/TCP protocol and then continuously write to its output channels in the background. The **Pair Connection** function consists of the following parameters:



<u>Connection Timeout</u>: The (P)ET-7x00 module wait for a connection to the remote module for a specified period of time.

**Reconnect Interval**: The (P)ET-7x00 module attempt to reconnect to the remote module at specified intervals.



# **Communication Timeout (ms)**:

The (P)ET-7x00 module wait for a response from the remote module for a specified period of time.

### IP Address of the Remote Device:

The IP address of the remote module.

#### Scan Time (ms):

The polling frequency of the remote module.

#### **Modbus TCP Port**:

The Modbus TCP Port of the remote module.

### **Local DO Base Address:**

The start number of the local DO channel, used for mapping to the remote DI channel.

#### **Modbus ID**:


The Modbus Net ID of the remote module.

# I/O Count:

The count of mapped I/O channels starting from the initial channel number.

#### **Remote DI Base Address:**

The start number of the remote DI channel, used for mapping to the local DO channel.



Except for these two items, all descriptions are the same as noted before.

## **Local AO Base Address**:

The start number of the local AO channel, used for mapping to the remote AI channel.

### **Remote AI Base Address**:


The start number of the remote AI channel, used for mapping to the local AO channel.

# 3.5.1. Example 1: Pair Connection - AI to AO

This example will describe how to use this feature to achieve remote AI/AO mapping between two I/O modules.

### **Hardware Devices**:

- 1. PET-7026 (with AI, AO, DI, and DO)
- 2. ET-7017 (with AI and DO)
- 3. PoE Ethernet Switch
- 4. Power Supply (24 V)
- 5. Power Supply (48 V)




### **Software Configuration:**

The following provides step-by-step instructions for how to configure the ET-7x00/PET-7x00 via the built-in web interface.

In this example, we will configure the PET-7026's settings page to map its AO to the ET-7017's AI. Then, when the ET-7017's AI receives 7.5V, the PET-7026's AO will automatically output 7.5V.


## Step 1: Log in to the PET-7026 web interface

Enter the IP address of the PET-7026 in the browser, and then enter your user name and password to log in to the PET-7026 web interface. Refer to chapter 3, "Web Applications", for more details.



## Step 2: Configure the AO type for the PET-7026

Click the "Module I/O Settings" option in the Configuration menu and set the voltage (or current) range to "-10 ~ 10V" in the "Analog Output Settings" section. Then, click the "Submit" button. Follow the same procedure to set the AI range for the ET-7017.




**Tips & Warnings** 




The settings for both the AO type for the PET-7026 and the AI type for the ET-7017 must be the same. In this example, they are both "-10 ~ 10V".

### Step 3: Configure the Modbus Settings for the PET-7026

Click the "Pair Connection" option in the main menu and enter the details noted in the table below info the respective fields.




After completing the configuration, click the "Submit" button to save the settings.



### **Testing:**


Before starting the test, confirm that the data format of ET-7017 is the same as that of PET-7026. To do this, click the "Module I/O Settings" option in the "Configuration" menu and check the "Range" setting in the "Analog Input Settings" section.




To supply +7.5V to Al0 and +5.5V to Al1 on the ET-7017 and click the "Web HMI" item in the "Web HMI" menu.

The wiring for ET-7017 in this example:


ET-7017		<b>External Power</b>	ET-7017		<b>External Power</b>	
Vin0+	$\rightarrow$	+Vs (7.5V)	Vin1+	<del>&gt;</del>	+Vs (5.5V)	
Vin0-	$\rightarrow$	GND	Vin1-	<del>&gt;</del>	GND	



Click the "AI" tab on the **Web HMI** page of the ET-7017. As shown in the figure below, AI0 received about 7.5V. AI1 received about 5.5V.



Next, click the "AO" tab on the Web HMI page of the ET-7026 and you can see that AO0 outputs about 7.5 V and AO1 outputs about 5.5V. automatically.




# 3.5.2. Example 2: Pair Connection - DI to DO

In this example, we will show how to use this feature to achieve remote DI/DO mapping between two I/O modules.

### **Hardware devices:**

- 1. PET-7026 (with AI, AO, DI, and DO)
- 2. PET-7044 (with DI and DO)
- 3. PoE Switch
- 4. Power Supply (48 V).

## **Hardware Connections:**




### **Software Configuration:**

The following provides step-by-step instructions for how to configure the ET-7x00/PET-7x00 via the built-in web interface.

In this example, we will configure the settings page of PET-7026 to map its DO to the DI of PET-7044. Then, when the DI status of PET-7044 changes to ON, the DO of PET-7026 will automatically be set to ON.


## Step 1: Log in to the PET-7026 web interface


Enter the IP address of the PET-7026 in the browser, and then enter your user name and password to log in to the PET-7026 web interface. Refer to chapter 3, "Web Applications", for more details.




## Step 2: Configure the Modbus Settings for the PET-7026

Click the "Pair Connection" option in the Main Menu, and enter the details listed in the table below into the respective fields.






After completing the configuration, click the "Submit" button to save the settings.




# For Testing the function:


The user can view the Wire Connection in the data sheet on the product page. In this example, the wiring of the PET-7044 is shown below.



On the **Web HMI** page of the PET-7044. Depending on the wiring above, if DO1 is set to ON, DI1 will become ON.



On the "Web HMI - DO" page of PET-7026, the status of DO1 becomes ON automatically.




# 3.6. Maintenance

The function is supported sine the firmware version 3.11.

# **Import / Export Configuration:**


Used to import or export the configuration file of the I/O module.



The "Maintenance" menu as below:



The "Import / Export Configuration" page allows users to import or export the configuration file of the module.



# **Export the Configuration**


After completing the module settings, the user can add some notes in the text box and then click the "Export" button to export the configuration file. The file will be saved in your default download location.

(File name: module name\_cfg\_v1.bin)





### **Import the Configuration**

**Step 1:** Click the "Choose File" button.




Step 2: Choose the file (.bin) to be imported, and then click the "Open" button.






Users can uncheck unwanted items or select only the "Entire Configuration" option, which includes all default checked options.



**Step 3:** Click the "**Import**" button, and the prompt message will appear based on the module settings. Users can review the imported configuration values again.




# 3.7. More Information

The "More Information" option in the main menu can be used to open the ICP DAS site in your browser. The default URL is <a href="http://www.icpdas.com">http://www.icpdas.com</a>.



Also, refer to Section 3.2.2 Basic Settings to modify the URL if it is necessary.



# Chapter 4. Modbus TCP/IP

With the support of the Modbus TCP protocol, the (P)ET-7000/(P)ET-7200 series module can send Modbus data via Ethernet for remote I/O monitoring applications. Modbus TCP is an Ethernet communication based on the Master/Slave (or Client/Server) architecture. The Master sends a query or control command, and the Slave executes the Master's request according to the function code in the command and then responds with a message to the Master.

The Modbus TCP Client connects to the (P)ET-7x00 with standard TCP/IP communication. Up to 12, Modbus TCP connections are available at one time for a (P)ET-7x00. Visit the website <a href="http://www.modbus.org">http://www.modbus.org</a> for more information about the Modbus protocol.

# 4.1. Modbus TCP/IP Message Format

Modbus TCP ADU consists of the Modbus Application Protocol (MBAP) Header and the Modbus PDU. When sending a Modbus message, the MBAP header is used for identifying the Modbus TCP package.

Modbus TCP Application Data Unit (ADU)						
MBAP Header	Function Code Data					
	Protocol Data Unit (PDU)					

### **MBAP** Header

Field	Length	Description
Transaction Identifier	2 bytes	Specified by Modbus TCP Master (Client)
Protocol Identifier	2 bytes	0 = Modbus protocol
Length Field	2 bytes	Number of following bytes (Counting from the <b>Unit Identifier</b> to the last data of PDU)
Unit Identifier	1 byte	Identification of the remote Slave device

### **Function Code**

Modbus TCP supports several function codes, and the Slave device can perform actions according to function codes. The Modbus/TCP feature of the ET-7x00/PET-7x00 series module supports eight function codes, which allows read/write data from/to the register.

Function Code	Function
01 (0x01)	Read Coil Status
02 (0x02)	Read Input Status
03 (0x03)	Read Holding Registers
04 (0x04)	Read Input Registers
05 (0x05)	Force Single Coil
06 (0x06)	Preset Single Register
15 (0x0F)	Force Multiple Coils
16 (0x10)	Preset Multiple Registers

Any function codes that are not supported by ET-7000/ET-7200 will be replied to with an exception code to inform the Client to do appropriate actions


### **Data**

The data field is used to specify the register's address of the Slave device to be accessed. In addition, the data field needs to contain the necessary information according to the function code, such as the number of registers to be accessed.

# Response

When the Master sends a request to the Slave device, the following conditions may occur.

- 1. If the Slave receives the request and no communication error occurs, it will make a normal response.
- 2. If the Slave does not receive a request due to a communication error or if the unit ID in the request does not match, it will not respond.
- 3. If the Slave receives a request but the function code is not supported or the specified register address is incorrect, it will respond with an exception code to notify the Master for appropriate processing.



# 4.2. Function Code

# 4.2.1. 01 (0x01) Read Coils

This function code is used to read the status of digital outputs.

Here is an example of a request to read two digital outputs of the ET-7026/PET-7026 module:

Reque	st		Response	
Field Name	Field Name		Field Name	(Hex)
		01		01
AADAD Haadaa		02		02
		00	MBAP Header	00
MBAP Header		00	WIDAF HEAUEI	00
				00
		06		04
Unit ID		01	Unit ID	01
Function Code		01	Function Code	01
Ctarting Address	Hi	00	Byte Count	01
Starting Address	Lo	00	Outputs Status (0-1)	02
Channels	Hi	00		
Chamileis	Lo	02		

The status of outputs in the Modbus response is expressed in hexadecimal 02, also binary 0000 0010. The LSB (Least Significant Bit) indicates the status of DO0 (0=OFF) and the bit1 indicates the status of DO1 (1=ON).

# 4.2.2. 02 (0x02) Read Discrete Inputs

This function code is used to read the status of digital inputs.

Here is an example of a request to read two digital inputs of the ET-7026/PET-7026 module:

Reque	st		Response		
Field Name	Field Name		Field Name	(Hex)	
		01		01	
		02		02	
MPAD Hooder		00	MBAP Header	00	
MBAP Header		00	WIDAP neauer	00	
		00		00	
		06		04	
Unit ID		01	Unit ID	01	
Function Code		02	Function Code	02	
Ctarting Address	Hi	00	Byte Count	01	
Starting Address	Lo	00	Digital Inputs Status (0-1)	03	
Quantity of Innuts	Hi	00	_		
Quantity of Inputs	Lo	02			

The status of inputs in the Modbus response is expressed in hexadecimal 03, also binary 0000 0011. The LSB (Least Significant Bit) indicates the status of DIO (0=OFF) and the bit1 indicates the status of DII (1=ON).

# 4.2.3. 03 (0x03) Read Holding Registers

This function code is used to read the value of analog outputs.

Here is an example of a request to read two analog outputs of the ET-7026/PET-7026 module:

Reque	st		Response			
Field Name		(Hex)	Field Name	(Hex)		
		01			01	
		02			02	
MBAP Header		00	MDAD Hoodor		00	
		00	MBAP Header		00	
		00			00	
					07	
Unit ID		01	Unit ID		01	
Function Code		03	Function Code		03	
Ctarting Address	Hi	00	Byte Count		04	
Starting Address	Lo	00	Docietes Value (ACO)	Hi	02	
Overstitus of Oversta	Hi	00	Register Value (AO0)	Lo	2B	
Quantity of Outputs	Lo	02	Docietes Value (AO1)	Hi	00	
			Register Value (AO1)	Lo	64	

The AO value is made up of 1 word (2 bytes). The AOO value in the Modbus response is expressed in hexadecimal 022B, i.e., decimal 555. The AO1 value is expressed in hexadecimal 0064, i.e., decimal 100.

# 4.2.4. 04 (0x04) Read Inputs Registers

This function code is used to read the value of analog inputs.

Here is an example of a request to read two analog inputs of the ET-7026/PET-7026 module:

Reque	st		Response			
Field Name		(Hex)	Field Name	(Hex)		
MBAP Header		01			01	
		02			02	
		00	MDAD Hoodor		00	
		00	MBAP Header		00	
		00			00	
		06			07	
Unit ID		01	Unit ID		01	
Function Code		04	Function Code		04	
Charting Address	Hi	00	Byte Count		04	
Starting Address	Lo	00	Docietos Valvo (AIO)	Hi	00	
Occupation of Imports	Hi	00	Register Value (AI0)	Lo	0A	
Quantity of Inputs	Lo	02	2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Hi	00	
			Register Value (AI1)	Lo	64	

The AI value is made up of 1 word (2 bytes). The AIO value in the Modbus response is expressed in hexadecimal 000A, i.e., decimal 10. The AI1 value is expressed in hexadecimal 0064, i.e., decimal 100.

# 4.2.5. 05 (0x05) Write Single Coil

This function code is used to write a single DO to either ON or OFF.

Here is an example of a request to write DO1 of ET-7026/PET-7026 ON:

Reque	st		Response		
Field Name		(Hex)	Field Name	(Hex)	
MBAP Header		01			01
		02			02
		00	MPAD Hoador		00
		00	IVIDAP Neduel	MBAP Header	
		00			00
		06		06	
Unit ID		01	Unit ID		01
Function Code		05	Function Code		05
Output Address	Hi	00	Output Address	Hi	00
Output Address	Lo	01	Output Address	Lo	01
Output Value	Hi	FF	Output Value	Hi	FF
Output Value	Lo	00	Output Value	Lo	00

In the Modbus request, the output value is FF00 in Hex which means to output ON; the output value is 0000 in Hex which means to output OFF. The normal response is an echo of the request, returned after the DO status has been written.

# 4.2.6. 06 (0x06) Write Single Register

This function code is used to write a single AO value. The normal response is an echo of the request, returned after the value has been written.

Here is an example of a request to write AO1 of ET-7026/PET-7026 to 55 FF (hex):

Reque	st		Response		
Field Name		(Hex)	Field Name	(Hex)	
MBAP Header		01			01
		02			02
		00	MPAD Hoador		00
		00	IVIDAP NEduci	MBAP Header	
					00
		06		06	
Unit ID		01	Unit ID		01
Function Code		06	Function Code		06
Dogistor Address	Hi	00	Dogistor Address	Hi	00
Register Address	Lo	01	Register Address	Lo	01
Hi		55	5 · · · · · · ·	Hi	55
Register Value	Lo	FF	Register Value	Lo	FF

# 4.2.7. 15 (0x0F) Write Multiple Coils

This function code is used to write several DO to either ON or OFF.

The requested ON/OFF states are specified by the contents of the request data field. A logical '1' in a bit position of the field requests the corresponding output to be ON. A logical '0' requests it to be OFF. The normal response returns the function code, starting address, and several digital outputs to be written.

Here is an example of a request to write a series of 2 digital outputs starting at DOO:

The request data content is one byte: **02** hex (0000 0010 binary). The binary bits correspond to the outputs in the following way:

Bit (0-7)	0	0	0	0	0	0	1	0
Output	-	-	-	-	-	-	DO1	DO <b>0</b>

Reque	st		Response		
Field Name		(Hex)	Field Name	(Hex)	
		01			01
		02			02
MBAP Header		00	MBAP Header		00
		00	IVIBAP neduer		00
		00			00
					06
Unit ID		01	Unit ID		01
Function Code		OF	Function Code		0F
Ctouting Address	Hi	00	Chambina Address	Hi	00
Starting Address	Lo	00	Starting Address	Lo	00
Overetity of Ovtracts	Hi	00	Over attitude land	Hi	00
Quantity of Outputs	Lo	02	Quantity Value		02
Byte Count		01			
Outputs Value	Lo	02			

# 4.2.8. 16 (0x10) Write Multiple Registers

This function code is used to write several AO values. The normal response returns the function code, starting address, and the number of analog outputs to be written.

Here is an example of a request to write two AO values starting at AOO:

Request			Response		
Field Name		(Hex)	Field Name		(Hex)
MBAP Header		01	MBAP Header		01
		02			02
		00			00
		00			00
		00			00
		OB			06
Unit ID		01	Unit ID		01
Function Code		10	Function Code		10
Starting Address	Hi	00	Starting Address	Hi	00
	Lo	00		Lo	00
Quantity of Registers	Hi	00	Quantity Value	Hi	00
	Lo	02		Lo	02
Byte Count		04			
Registers Value	Hi	00			
	Lo	0A			
	Hi	01			
	Lo	02			

The AO value is made up of 1 word (2 bytes). In the Modbus request, the AO0 value to be written is 000A in hexadecimal and the AO1 value to be written is 0064 in hexadecimal.

# 4.3. Modbus Master Simulators

In the previous section, we introduced the Modbus communication protocol. Now, we will describe how to achieve the Modbus/TCP communication between the ET-7x00/PET-7x00 module and PC-connection.

# 4.3.1. Modbus/TCP Client


**Modbus Utility** is a Modbus master simulator and test utility designed primarily to help users who want to test and simulate the Modbus protocol. Using the Modbus/TCP Client application, you can compose and send individual Modbus requests to a Modbus slave, and it can also continually poll (send read and write requests to) the slave. Subsequently, you can re-run the sequence of commands.

For each Modbus request, you specify the slave ID, function code, starting address, and quantity. You can refer to the previous section for more detailed information about the Modbus communication protocol. The software can be obtained from the website at:


www.icpdas.com/en/product/guide+Software+Development\_\_Tools+Modbus\_\_Tool#676 or www.icpdas.com/en/download/show.php?num=1028

The following instructions will help you to read the status of digital inputs in an ET-7026 by using the **Modbus Utility**.


**Step 1:** Right-click the **Modbus Utility** and select the **Run as administrator** option. Next, click the Modbus/TCP button for the ET-7000 module.




**Step 2:** Select the **Modbus/TCP Client** item from the **Client Tools** menu.




**Step 3:** Enter the IP address of ET-7026 in the **Modbus TCP** section and click the "**Connect**" button to connect the module.



**Step 4:** In this case, the request is to read the status of DIO and DI1 on ET-7026 and its Modbus ID is "1". Click the "Send Command" button to send the Modbus request to ET-7026.



**Step 5:** If no error occurs, a data field of a response from the ET-7026 to the Modbus TCP Client contains the status of digital inputs of ET-7026.



For a more detailed description of this function code, see the "Protocol Description" group box.

# 4.3.2. Modbus Master Tool

Modbus Master Tool is a Modbus master simulator designed by ICP DAS. It is used to help developers of Modbus slave devices or others that want to test the Modbus connection.

The software can be obtained from the website at:


www.icpdas.com/en/product/guide+Software+Development Tools+Modbus Tool#674

The following are step-by-step instructions on how to read the DO status of PET-7026.

Step 1: Double-click the "ModbusMasterToolPC.exe" to open it.





Step 2: Click the "Setup > Definition" in the menu bar to setup the parameters.



ET-7X00/PET-7X00 User Manual v1.1.4

We use the same example in <u>section 4.5.1</u>; you can see the parameters in the table.






#### **Tips & Warnings**




When reading or writing the AO or AI channel, select the "Hex" options in the "Format" drop-up menu.


Step 3: Click the "Connection > Connect" to set TCP Connection.



- 1. Select "TCP/IP" in the "Interface" field.
- 2. Fill out the PET-7026's IP address in the "Remote Server IP".
- 3. You can keep the settings of other fields or change them then click OK.



Now, the DO status of PET-7026 will show on the screen. (1: ON; 0: OFF)



# 4.4. Modbus Demo Programs

nModbus is a C# 3.0 implementation of the Modbus protocol. It is developed and maintained voluntarily and provided free of change.

The DLL based on the official releases from <a href="http://nmodbus.googlecode.com">http://nmodbus.googlecode.com</a> was verified and improved. Programmers can use the DLL released to develop a Modbus application for regular Windows-based PCs.

The relevant Modbus demo and SDK can be obtained from the following ICP DAS website.

• Documents, DLL, and Demo:

https://www.icpdas.com/en/download/index.php?root=&model=&kw=nModbus

# **Chapter 5. Calibration**

#### **Tips & Warnings**



It is not recommended that calibration be performed until the process is fully understood.

# 5.1. Voltage and Current Calibration

## Analog Input Calibration Requirement for ET-7x00/PET-7x00

Connect the calibration voltage/current source to channel 0 and only channel 0 should be enabled during calibration.

#### **Type Code**

The following table shows all of the type codes for use in voltage and current, you can use it upon the model number of ET-7x00/PET-7x00 (e.g. ET-7017 can use type  $07 \sim 1A$ ).

Type Code	00	01	02	03	04
Zero Input	0 mV	0 mV	0 mV	0 mV	0 V
Span Input	+15 mV	+50 mV	+100 mV	+500 mV	+1 V

Type Code	05	06	07	08	09
Zero Input	0 V	0 mA	0mA	0 V	0 V
Span Input	+2.5 V	+20 mA	+20 mA	+10V	+5 V

Type Code	0A	ОВ	0C	0D	1A
Zero Input	0 V	0 mV	0 mV	0 mA	0 mA
Span Input	+1 V	+500 mV	+150 mV	+20 mA	+20 mA

The following steps will show you how to calibrate the ET-7017 (8 AI, 4 DO):


#### Step 1: Warm up the module for 30 minutes.

#### Step 2: Enable channel 0 to calibrate and disable other channels.

Go to the configuration page of Modules I/O Settings, and set AIO as ON and the others as OFF.

#### Step 3: Set the type code to the type you want to calibrate.

Select the AI range (e.g. 09,  $-5V \sim 5V$ ) then click the "Submit" button.




#### **Step 4: Enable calibration.**

We will complete steps 4 to 8 by using Modbus Master Tool.

Modbus Master Tool can be obtained from the ICP DAS FTP site at:

https://www.icpdas.com/en/product/guide+Software+Development\_\_Tools+Modbus\_\_Tool#674

4.1 Double-click the "ModbusMasterToolPC.exe" to open it and click the "Setup > **Definition"** in the menu bar to setup the parameters.



#### **Modbus Address for Calibration**


Register	Points	Description	Access Type
		Enable/Disable Calibration	
00830	1	0=Disabled	R/W
		1=Enabled	
00831	1	Zero calibration command of ch0 (1 = run)	W (Pulse)
00832	1	Span calibration command of ch0 (1 = run)	W (Pulse)

**Note:** When calibrating the current type (i.e. type 06, 07, and 1A), the jumper of the corresponding channel should be short.


Refer to the ET-7x00 and PET-7x00 Register Table for details.

https://www.icpdas.com/en/download/show.php?num=2217

4.2 Click the "Connection > Connect" in the menu bar and enter ET-7017's IP address to establish a TCP Connection.



4.3 Double-click on address 830 to set it as "ON". (Enable Calibration)




Step 5: Apply the zero calibration voltage/current to channel 0.

In this example, we use type code - 09 and its "Zero Input" is 0 V.

Type Code	09				
Input Range	-5V ~ +5 V				

#### Step 6: Send the zero calibration command.

Double-click on address 831 to set it as ON. If the calibration is successful, the value will return 0.




#### Step 7: Apply the span calibration voltage/current to channel 0.

In this example, we use type code - 09 and its "Span Input" is +5 V.

Type Code	09
Input Range	-5V ~ +5 V

#### **Step 8: Send the span calibration command.**

Double-click on address 832 to set it as ON. If the calibration is successful, the value will return 0.



#### Step 9: Disable calibration.

As figure above, double-click on address 830 to set it as "OFF".

# 5.2. Thermocouple Calibration

#### **Type Code**

The following table shows all of the type codes for use in the thermocouple.

Type Code	14	18	0E	10	12	13	15	16	19	OF	11	17
Thermocouple Calibration Range	0	0				01					02	
Zero Input	0 r	nV		0 mV					0 mV			
Span Input	+15	mV			-	-50 m\	/			+	100 m	V

The calibration procedure is similar to section 5.1. But, the difference between them is that the ET-7x00/PET-7x00 doesn't directly support type code -  $0E \sim 19$  for AI calibration, so you need to change the channel 0 as a range -  $00 \sim 02$  to complete the work, refer to section 5.1 step 3.

- Step 1 Warm up the module for the latest 30 minutes.
- Step 2 Set the type code to the type you wish to calibrate.
- Step 3 Enable calibration.
- Step 4 Apply the zero calibration voltage to channel 0.
- Step 5 Send the zero calibration command.
- Step 6 Apply the span calibration voltage to channel 0.
- **Step 7 Send the span calibration command.**
- Step 8 Disable calibration.

#### For example

If you want to calibrate type 0E, you need to set the Range of channel 0 to [01] ±50 mV.



# 5.3. RTD Calibration

## **Type Code**

The following table shows all of the type codes for use in RTD calibration.

Type Code	20 ~ 29	2E	2F	80	81	83	2B	2C	82	2A	2D
Zero Calibration Resistor	ο Ω		0 Ω			0 Ω					
Span Calibration Resistor			375 Ω	!				200 Ω	!	3200	0 Ω

#### **Modbus Address for Calibration**

Register	Points	Description	Access Type
		Enable/Disable Calibration	
00830	1	0=Disabled	R/W
		1=Enabled	
00831	1	Zero calibration command of ch0 (1=run)	W (Pulse)
00832	1	Span calibration command of ch0 (1=run)	W (Pulse)
00833	1	Zero calibration command of ch1 (1=run)	W (Pulse)
00834	1	Span calibration command of ch1 (1=run)	W (Pulse)
00835	1	Zero calibration command of ch2 (1=run)	W (Pulse)
00836	1	Span calibration command of ch2 (1=run)	W (Pulse)
00837	1	Zero calibration command of ch3 (1=run)	W (Pulse)
00838	1	Span calibration command of ch3 (1=run)	W (Pulse)
00839	1	Zero calibration command of ch4 (1=run)	W (Pulse)
00840	1	Span calibration command of ch4 (1=run)	W (Pulse)
00841	1	Zero calibration command of ch5 (1=run)	W (Pulse)
00842	1	Span calibration command of ch5 (1=run)	W (Pulse)

The calibration procedure is similar to section 5.1. However, the RTD calibration required an external resistor and must be calibrated for each channel rather than just the ch0 we mentioned before.

The calibration procedure is as follows:

- Step 1 Warm up the module for the latest 30 minutes.
- Step 2 Set the type code to the type you wish to calibrate.
- **Step 3** Enable calibration.
- **Step 4** Connect the zero calibration resistor.

(Refer to the table – Type Code)

**Step 5 Send the zero calibration command.** 

(Refer to the table - Modbus Address for Calibration)

**Step 6** Connect the span calibration resistor.

(Refer to the table – Type Code)


**Step 7 Send the span calibration command.** 

(Refer to the table - Modbus Address for Calibration)

**Step 8** Disable calibration.

# 5.4. Recover Calibration to the Factory Setting

In the Modules I/O Settings – Analog Input Settings configuration page, click the "Restore Analog Calibration to Factory Settings" item and click the Submit button to complete the function.



# **Chapter 6. MiniOS7 Utility Tools**


MiniOS7 Utility is a tool for uploading firmware to flash memory and updating the OS to ET-7x00/PET-7x00 module embedded with MiniOS7 with easiness and quickness.


If you haven't the MiniOS7 Utility installed on your system, installation of the MiniOS7 Utility should be the first step. Please refer to section "2.4 Installing MiniOS7 Utility" to install it.

## 6.1. Establishing a Connection

To upload firmware or update the OS to ET-7x00/PET-7x00 module, you must first establish a connection between the PC and the ET-7x00/PET-7x00 module.


**Step 1: Run the MiniOS7 Utility** 





#### Step 2: Press the "F12" key or choose the "Search" option from the "Connection" menu

After pressing the "F12" key or choosing the "Search" option from the "Connection" menu, the MiniOS7 utility performs a search of all modules on your network.




Step 3: Click the IP address in the IP/Port field list and then click the "Connect" icon in the toolbar

After the search has been completed, click the IP address for the ET-7x00/PET-7x00 module in the IP/Port field list and then click the "Connect" icon in the toolbar to connect to the ET-7x00/PET-7x00.

MiniOS7 Scan	2.			-	□ >	<
Search Options	Connect Clear	IP setting Help	E <u>x</u> it			
Туре	IP/Port	е	Alias	Mask	Gateway	^
TCP BroadCast	192.168.101.15	<b>1.</b> b <sub>2</sub>	EtherI0	255.255.0.0	192.168.1.1	
TCP BroadCast	192.168.79.3	₩ET-2228	EtherI0	255.255.0.0	192.168.1.1	
► TCP BroadCast	192.168.15.17	ET-7017/PET-7017		255.255.0.0	192.168.1.1	
TCP BroadCast	192.168.16.35	PET-7026		255.255.0.0	192.168.1.1	V
<		1			>	
Search done.						_/,

#### Step 4: Check the connection symbol to make sure that the connection is established

A connection symbol is displayed on the top right side of the screen to make sure the connection has been established.



# 6.2. Exchanging the Protocol (TCP/IP to UDP)


MiniOS7 Utility supports both UDP and TCP protocols. For MiniOS7 Utility, the TCP/IP is the default protocol for communicating with ET-7x00/PET-7x00, and the UDP is used to update the OS. Changing the protocol to UDP if you want to update the OS.

#### Step 1: Establish a connection to the ET-7x00/PET-7x00

For more information, refer to section "6.1. Establishing a Connection".


#### **Step 2: Stop running the firmware**

Right-click the file list of the right side windows, and then choose "Quit Firmware" to stop the firmware running and exchange TCP/IP protocol to UDP protocol.



Step 3: Click the "Yes" button to continue and the settings will take effect

After executing the Quick Firmware command, the "Confirm" dialog will appear, and then click the "Yes" button to continue and stop the firmware running.




# 6.3. Updating the ET-7x00/PET-7x00 OS

Additional features to ET-7x00/PET-7x00 OS will continue to be added in the future, so we advise you to periodically check with the ICP DAS website for the latest updates.

## 6.3.1. Using the MiniOS7 Utility

Step 1: Download the latest version of the MiniOS7 OS image



#### For ET-7000/PET-7000 series module:

The latest version of the MiniOS7 OS image can be obtained from the ICP DAS website at: https://www.icpdas.com/en/download/show.php?num=2235

### For ET-7200/PET-7200 series module:


The latest version of the MiniOS7 OS image can be obtained from the ICP DAS website at: https://www.icpdas.com/en/download/show.php?num=2236

Step 2: Be sure that the switch is set to the "Init" position and then reboot the module




#### Step 3: Establish a connection to ET-7x00/PET-7x00

Refer to section "6.1. Establishing a Connection & 6.2 Exchange the protocol". Waiting for a while to search available **UDP** devices.




If the connection fails, it is recommended to click the "**Options**" from the "**Configuration**" menu to change the "**Response Timeout**" setting (e.g., 1200 ms).




#### Step 4: Choose "Update MiniOS7 Image" from the "File" menu

Choose "Update MiniOS7 Image" from the File menu to start the update procedure.



#### Step 5: Select the latest version of the MiniOS7 OS image

After choosing the update MiniOS7 Image command, the "Select MiniOS7 Image file" dialog will appear, and then select the latest version of the MiniOS7 OS image. Note that DO NOT update the same version as the current one.




#### Step 6: Click "OK" to finish the procedure


After confirming the command, you just need to wait a while until the following dialog appears, and then click the "**OK**" button to finish the procedure.



#### Step 7: To check the OS version

After pressing "F7" or choosing "info" from the "Command" menu, check the OS version of the "Build" entry.






## 6.3.2. Using the 7188EU.exe and Command Line

Note: If you cannot update OS successfully, use the method of the command line instead.

#### Step 1: Be sure that the switch is set to the "Init" position and then reboot the module

It is necessary to update the MinisOS7 image under the INIT mode, adjust the switch to INIT on the back of the module, and reboot.

Step 2: Run the MiniOS7 Utility and the file folder of the MinisOS7 image.




#### Step 3: Connect to the module by using UDP

Click **Tools > 7188EU** on the menu bar and enter "/s: IP address of the module /p:23" in the "Parameters" dialog.

#### Description of parameters:


/s:192.168.255.1  $\rightarrow$  IP address of the module

/p:23  $\rightarrow$  UDP Port 23 (fixed)




#### Step 4: Upload the MiniOS7 image

Press Enter to see "ET7K\_UDP>" in the window and input the **upload** command, then press Enter. Also, press **ALT + E** and enter the full name of the image file (e.g., ET7K\_UDP\_20161124.img)



#### Step 5: Update the OS image file to a Flash

Enter the **bios1** command to update the image to the flash. It spends 15 seconds for updating and does not perform power off or reboot.



Step 6: Confirm the version of the MiniOS7 by using the "ver" command

```
[UDP]Connect to 192.168.15.17:23 path=C:\ICPDAS\MiniOS7_Utility\OS_IMAGE\ET-7000 — 

ET7K_UDP>bios1

ET7K_UDP>ver

ICP_DAS MiniOS7_UDP for ET-7K Ver. 2.04 build 000,Nov 24 2016 11:17:39

OS id=31

SRAM:512K, FLASH MEMORY:512K
[CPU=RDC 1120]

CPU internal WDT is ENABLED(WDT timeout=0.8 sec)

ET7K_UDP>__
```

# 6.4. Updating the ET-7x00/PET-7x00 Firmware

The firmware is stored in flash memory and can be updated to fix functionality issues or add additional features, so we advise you to periodically check the ICP DAS website for the latest updates.

Step 1: Download the latest version of the firmware

#### ET-7x00, PET-7x00

The latest version of the ET-7000/PET-7000 firmware can be obtained from:

https://www.icpdas.com/en/download/show.php?num=3790

#### ET-7200, PET-7200

The latest version of the ET-7200/PET-7200 firmware can be obtained from:

V1:

https://www.icpdas.com/en/download/show.php?num=3785

V2:

https://www.icpdas.com/en/download/show.php?num=2233

Step 2: Be sure that the switch is set to the "Init" position and then reboot the module



Step 3: Establish a connection to connect to the ET-7x00/PET-7x00

For a more detailed description of this instruction, refer to section "6.1. Establishing a Connection".

#### **Tips & Warnings**




If the connection fails, it is recommended to click the "**Options**" from the "**Configuration**" menu to change the "**Response Timeout**" setting (e.g., 1200 ms).

You have to delete all files that existed on the ET-7x00/PET-7x00 before uploading the firmware.


#### Step 4: Choose "Erase Disk" from the "Command" menu

After establishing a connection, then choose "Erase Disk" from the "Command" menu (or right-click on the right of the window) to erase the contents of the flash memory.




#### Step 5: In the Confirm dialog box, click the "Yes" button to continue.

After executing the Erase Disk command, the **Confirm** dialog will appear, and then click the "**Yes**" button to continue erasing the memory contents.



#### Step 6: Select the latest version of the firmware.

Select the new version of the firmware and click the **Upload(F5)** button to upload the file to ET-7x00/PET-7x00.




**Step 7:** After the update is complete, set the switch on the back of the module to the "**Normal**" position and reboot.



# Chapter 7. SCADA and System Integration Tools

ET-7x00/PET-7x00 supports several external tools to aid in developing your applications

## 7.1. LabVIEW



LabVIEW is the best way to acquire, analyze, and present data. LabVIEW delivers a graphical development environment that can be used to quickly build data acquisition, instrumentation, and control systems, boosting productivity and saving development time. With LabVIEW, it is possible to quickly create user interfaces that enable interactive control of software systems. To specify your system functionality, simply assemble a block diagram – a natural design notation for scientists and engineers.

The document containing the detailed instructions for linking to the ET-7x00/PET-7x00 using the Modbus protocol is located at

https://www.icpdas.com/en/download/show.php?num=1029

## 7.2. OPC Server

OPC (OLE for Process Control) is the first standard resulting from the collaboration of several leading worldwide automation suppliers working in cooperation with Microsoft. Originally based on Microsoft's OLE COM (Component Object Model) and DCOM (Distributed Component Object Model) technologies, the specification defines a standard set of objects, interfaces, and methods for use in process control and manufacturing automation applications to facilitate interoperability.

There are many different mechanisms provided by various vendors that allow access to a variety of devices via specific applications. However, if an OPC Server is provided for the device, other applications will be able to access the OPC Server via the OPC interface.

## **7.3. SCADA**

SCADA stands for Supervisor Control and Data Acquisition. It is a production automation and control system based on PCs.

SCADA is wildly used in many fields e.g. power generation, water systems, the oil industry, chemistry, and the automobile industry. Different fields require different functions, but they all have common features:

- Graphic interface
- Process mimicking
- Real-time and historic trend data
- Alarm system
- Data acquisition and recording
- Data analysis
- Report generator

#### Accessing the ET-7x00/PET-7x00 module

SCADA software can access ET-7x00/PET-7x00 devices using Modbus communication protocols and can communicate without the need for other software drivers.

#### **Famous SCADA software**

Citect, ICONICS, iFIX, InduSoft, Intouch, Entivity Studio, Entivity Live, Entivity VLC, Trace Mode, Wizcon, Wonderware, etc.

In the following sections, 3 popular brands of SCADA software are introduced together with detailed instructions on how to use them to communicate with ET-7x00/PET-7x00 module using the Modbus/TCP protocol.

#### 7.3.1. InduSoft



<u>InduSoft Web Studio</u> is a comprehensive platform that includes all the tools you'll need to make SCADA and HMI applications that have real power behind them. The development environment allows you to develop once and deploy anywhere.


InduSoft Web Studio supports all Windows runtime platforms (including 32 and 64-bit), ranging from Windows Embedded Compact, Windows Embedded Standard, Windows 8.1/10, and Windows Server Editions (Server 2012/2016/2019), along with built-in support for local or remote (web) based visualization.

Build powerful graphical displays and take advantage of the 250+ available communication drivers for all major PLC products. InduSoft Web Studio includes OPC UA and OPC Classic (HDA and DA), trends, alarms, reports, recipes, and built-in SQL database support as standard features.

The document containing detailed instructions for linking to the ET-7x00/PET-7x00 module using the Modbus protocol is located on

https://www.icpdas.com/en/faq/index.php?kind=133

#### 7.3.2. Citect



Citect SCADA is a fully integrated Human Machine Interface (HMI) / SCADA solution that enables users to increase return on assets by delivering a highly scalable, reliable control and monitoring system. Easy-to-use configuration tools and powerful features enable rapid development and deployment of solutions for any size application.

The document containing detailed instructions for linking to the ET-7x00/PET-7x00 module using the Modbus protocol is located on

https://www.icpdas.com/en/faq/index.php?kind=133

https://www.icpdas.com/en/product/guide+Software+Development\_\_Tools+Modbus\_\_Tool#1150

## 7.3.3. iFix



The document containing detailed instructions for linking to the ET-7x00/PET-7x00 module using the Modbus protocol is located on

https://www.icpdas.com/en/faq/index.php?kind=133


https://www.icpdas.com/en/product/guide+Software+Development\_\_Tools+Modbus\_\_Tool#1150

# **Appendix A** Description of I/O Functions

## A.1. Dual Watchdog

The Dual Watchdog consists of Module Watchdog and Host Watchdog.

- 1. **The Module Watchdog** is a built-in hardware circuit that will reset the CPU module if a failure occurs in either the hardware or the software. If the application does not refresh the watchdog timer within 0.8 seconds, the watchdog circuit will initiate a reset of the CPU.
- 2. The Host Watchdog is a software function that can be used to monitor the operating status of the host. Its purpose is to prevent network communication problems or host failure. If the Watchdog timeout interval expires, the module will return all outputs to a predefined Safe value (Refer to the Safe Value application note), which can prevent the controlled target from an unexpected situation.




#### A.2. Power-on Value

Many industrial applications require a "safe" start-up condition to prevent accidents at critical points in the process. Each ET-7x00/PET-7x00 contains an initial power-on value which is used to configure the analog/digital outputs on power up. In other words, the power-on value can be considered a start-up value. The power-on value is loaded into the output modules under 3 conditions: power on, reset by Module Watchdog, and reset by the reset command.


Users can set the power-on value of the specific analog/digital output channel and the power-on value is stored in EEPROM.

#### **Setting the Power-on Value for a Specific Digital Output Channel**



- **Step 1:** Log into the ET-7x00/PET-7x00 web page, and then click the "**Module I/O Settings**" option in the "**Configuration**" section of the Main Menu.
- **Step 2:** Enable the Power-on Value by checking the "**ON**" radio button.
- **Step 3:** Click the "Submit" button to complete the configuration of the power-on Value.

## **Setting the Power-on Value for a Specific Analog Output Channel**




- **Step 1:** Log into the ET-7x00/PET-7x00 web page, and then click the "**Module I/O Settings**" option in the "**Configuration**" section of the Main Menu.
- **Step 2:** Set the Power-on Value in the "Power-on Value" text box.
- **Step 3:** Click the "**Submit**" button to complete the configuration of the Power-on Value and save the settings to the EEPROM.

#### A.3. Safe Value


When the Host Watchdog is enabled and the communication between the host PC and ET-7x00/PET-7x00 modules is broken, the analog/digital output channels can generate a predefined value to prevent unpredictable damage to the connected devices. By default, this feature is disabled. Users can enable this feature by configuring the Host WDT Timeout.

#### **Setting the Safe Value for a Specific Digital Output Channel**



- **Step 1:** Log into the ET-7x00/PET-7x00 web page, and then click the "**Module I/O Settings**" option in the "**Configuration**" section of the Main Menu.
- **Step 2:** Enable the Safe Value by checking the "**ON**" radio button.
- **Step 3:** Click the "Submit" button to complete the configuration of the Safe Value.

## **Setting the Safe Value for a Specific Analog Output Channel**



- **Step 1:** Log into the ET-7x00/PET-7x00 web page, and then click the "**Module I/O Settings**" option in the "**Configuration**" section of the Main Menu.
- **Step 2:** Set the Safe Value in the "**Safe Value**" text box.
- **Step 3:** Click the "**Submit**" button to complete the configuration of the Safe Value and save the settings to the EEPROM.

#### A.4. Al High/Low Alarm

ET-7x00/PET-7x00 module equipped with the High/Low Alarm function. When the alarm function is activated, the value of the specified registers is 1. The status of the alarm is the result of comparing the analog input value with a given high alarm value or a low alarm value.

Address 00636 to 00667 can be used to enable/disable the AI High Alarm function. Address 00668 to 00699 can be used to enable/disable the AI Low Alarm function.

#### Al High/Low Alarm Switch Table

Channel	Δ	Al High Alarm		Al Low Alarm
Number	Register	Description	Register	Description
AI0	00636	0: Disable/1: Enable	00668	0: Disable/1: Enable
Al1	00637	0: Disable/1: Enable	00669	0: Disable/1: Enable
AI2	00638	0: Disable/1: Enable	00670	0: Disable/1: Enable
AI3	00639	0: Disable/1: Enable	00671	0: Disable/1: Enable
Al4	00640	0: Disable/1: Enable	00672	0: Disable/1: Enable
AI5	00641	0: Disable/1: Enable	00673	0: Disable/1: Enable
Al6	00642	0: Disable/1: Enable	00674	0: Disable/1: Enable
AI7	00643	0: Disable/1: Enable	00675	0: Disable/1: Enable
AI8	00644	0: Disable/1: Enable	00676	0: Disable/1: Enable
AI9	00645	0: Disable/1: Enable	00677	0: Disable/1: Enable

Address 40296 to 40327 records the High Alarm value. Address 40328 to 40359 record the Low Alarm value. By default, the High Alarm value is +32767 (0x7FFF) and the low alarm value is -32768 (0xFFFF).

#### Al High/Low Alarm Value Table

Channel	High	Alarm Value of Al	Low Alarm Value of Al	
Number	Register	Description	Register	Description
AI0	40296	-32768 ~ 32767	40328	-32768 ~ 32767
Al1	40297	-32768 ~ 32767	40329	-32768 ~ 32767
AI2	40298	-32768 ~ 32767	40330	-32768 ~ 32767
Al4	40300	-32768 ~ 32767	40332	-32768 ~ 32767
AI5	40301	-32768 ~ 32767	40333	-32768 ~ 32767
AI6	40302	-32768 ~ 32767	40334	-32768 ~ 32767
AI7	40303	-32768 ~ 32767	40335	-32768 ~ 32767
AI8	40304	-32768 ~ 32767	40336	-32768 ~ 32767
AI9	40305	-32768 ~ 32767	40337	-32768 ~ 32767

The analog input High/Low Alarm contains two alarm types, Momentary Alarm and Latch Alarm. Address 00700 of the Modbus register can be used to set the High Alarm type of channel 0 and the total number of channels depends on the type of module. Address 00732 of the Modbus register can be used to set the Low Alarm type of channel 0.

#### Al High/Low Type Value Table

Channel	Al	High Alarm Type	А	I Low Alarm Type
Number	Register	Description	Register	Description
AIO	00700	0: Momentary Mode	00732	0: Momentary Mode
Alu	00700	1: Latch Mode	00732	1: Latch Mode
AI1	00701	0: Momentary Mode	00733	0: Momentary Mode
AII	00701	1: Latch Mode	00733	1: Latch Mode
AI2	00702	0: Momentary Mode	00734	0: Momentary Mode
AIZ	00702	1: Latch Mode	00734	1: Latch Mode
AI3	00703	0: Momentary	00735	0: Momentary
AlS	00703	1: Latched	00733	1: Latched
Al4	00704	0: Momentary	00736	0: Momentary
Al4	00704	1: Latched	00730	1: Latched
AI5	00705	0: Momentary	00737	0: Momentary
Als	00703	1: Latched	00737	1: Latched
AI6	00706	0: Momentary	00738	0: Momentary
Alo	00700	1: Latched	00738	1: Latched
AI7	00707	0: Momentary	00739	0: Momentary
Al7	00707	1: Latched	00739	1: Latched
AI8	0: Momentary 00740		00740	0: Momentary
Alo	00708	1: Latched	00740	1: Latched
AIO	00700	0: Momentary	00741	0: Momentary
AI9	00709	1: Latched	00741	1: Latched

The following are the descriptions for two alarm types.

#### **Momentary Alarm**

An alarm will be triggered when the analog input value exceeds alarm limits. When the AI value is back to normal, the alarm status will automatically be cleared.

#### For example:

If analog input value of channel 0 (Address: 30000) > High Alarm value (Address: 40296), the address 10224 is 1, else it is 0.

If the analog input Value of channel 0 (30000) < Low Alarm value (40328), the address 10256 is 1, else it is 0.

The address 10224 to 10255 is used to read the status of the high alarm. If a high alarm occurred, the Register value is 1. Under normal conditions, the value is 0. The address 10256 to 10287 is used to read the status of the low alarm. If a low alarm occurred, the Register value is 1. Under normal conditions, the value is 0.

#### **Latch Alarm**


An alarm will be triggered when the analog input value exceeds alarm limits. When the AI value is back to normal, the alarm status will keep until the clear command is sent to the specific address.

#### For example:


If the analog input value of channel 0 (30000) > High Alarm value (40296), the address 10224 is 1. If the analog input value of channel 0 (30000) < Low Alarm value (40328), the address 10256 is 1.

The address 10224 to 10255 is used to read the status of the high alarm. In normal conditions, the value of the register is 0. If a High alarm occurred, the Register value stays 1 until the status of the address(es) 00764 to 00795 is cleared. The address 10256 to 10287 is used to read the status of the Low alarm. In normal conditions, the value of the register is 0. If a low alarm occurred, the value of the register stays 1 until the status of the address(es) 00796 to 00827 is cleared.

#### **Setting the High Alarm and Low Alarm for a Specific Analog Input Channel**



- **Step 1:** Log into the ET-7x00/PET-7x00 web page, and then click the "**Module I/O Settings**" option in the "**Configuration**" section of the Main Menu.
- **Step 2:** Set the High Alarm and Low Alarm information in the relevant field.
- **Step 3:** Click the "**Submit**" button to complete the configuration of the High Alarm and the Low Alarm.




#### A.5. Al High/Low Latch

The address 30236 to 30267 records the maximum value of analog inputs and stays the value until another maximum input enters. The address 30268 to 30299 records the minimum value of analog inputs and stays the value until another minimum input enters.

#### Monitoring the Alarm Status for a Specific Analog Input Channel

Click the "Web HMI" item from the "Web HMI" menu.



**Step 1:** Log into the ET-7x00/PET-7x00 web page, and then click the "**Module I/O Settings**" option in the "**Configuration**" section of the Main Menu.

**Step 2:** Monitor the alarm status by viewing the "Analog Inputs" group table.

# Appendix B Analog Input Type and Data Format Table

Type Code	Input Range	Data Format	+F.S	-F.S
00	-15 ∼ +15 mA	Engineering Unit	+15000	-15000
00	-15 ~ +15 IIIA	2's comp HEX	7FFF	8000
01	-50 ∼ +50 mA	Engineering Unit	+5000	-5000
01	-50 ~ +50 MA	2's comp HEX	7FFF	8000
02	100 1100\/	Engineering Unit	+10000	-10000
02	-100 ∼ +100 mV	2's comp HEX	7FFF	8000
02	F00 F00 m\/	Engineering Unit	+5000	-5000
03	-500 ∼ +500 mV	2's comp HEX	7FFF	8000
0.4	4 .4 1/	Engineering Unit	+10000	-10000
04	-1 ∼ +1 V	2's comp HEX	7FFF	8000
05	-2.5 ∼ +2.5 V	Engineering Unit	+25000	-25000
05	-2.5 ∼ +2.5 V	2's comp HEX	7FFF	8000
06	20	Engineering Unit	+20000	-20000
06	-20 ∼ +20 mA	2's comp HEX	7FFF	8000
07	14 . 120 m A	Engineering Unit	+20000	+4000
07	+4 ~ +20 mA	2's comp HEX	FFFF	0000
00	10	Engineering Unit	+10000	-10000
08	-10 ∼ +10 V	2's comp HEX	7FFF	8000
00	F F.V	Engineering Unit	+5000	-5000
09	-5 ∼ +5 V	2's comp HEX	7FFF	8000
0.4	4 .4 1/	Engineering Unit	+10000	-10000
0A	-1 ∼ +1 V	2's comp HEX	7FFF	8000
OD	500 · 500 ····\/	Engineering Unit	+5000	-5000
OB	-500 ∼ +500 mV	2's comp HEX	7FFF	8000
00	450 (450)/	Engineering Unit	+15000	-15000
0C	-150 ∼ +150 mV	2's comp HEX	7FFF	8000
OD	20	Engineering Unit	+20000	-20000
0D	-20 ∼ +20 mA	2's comp HEX	7FFF	8000

Type Code	Input Range	Data Format	+F.S	-F.S
1.0	0 ∼ +20 mA	Engineering Unit	+20000	0
1A		2's comp HEX	FFFF	0000
OF	Type J Thermocouple	Engineering Unit	+7600	-2100
0E	-210 ∼ 760°C	2's comp HEX	7FFF	DCA2
OF	Type K Thermocouple	Engineering Unit	+13720	-2700
0F	-270 ∼ 1372°C	2's comp HEX	7FFF	E6D0
10	Type T Thermocouple	Engineering Unit	+4000	-2700
10	-270 ∼ 400°C	2's comp HEX	7FFF	A99A
11	Type E Thermocouple	Engineering Unit	10000	-2700
11	-270 ~ 1000°C	2's comp HEX	7FFF	DD71
4.2	Type R Thermocouple	Engineering Unit	+17680	0
12	0 ~ 1768°C	2's comp HEX	7FFF	0000
4.2	Type S Thermocouple 0 ∼ 1768°C	Engineering Unit	+17680	0
13		2's comp HEX	7FFF	0000
1.4	Type B Thermocouple	Engineering Unit	+18200	0
14	0 ~ 1820°C	2's comp HEX	7FFF	0000
1.5	Type N Thermocouple	Engineering Unit	+13000	-2700
15	-270 ∼ 1300°C	2's comp HEX	7FFF	E56B
1.0	Type C Thermocouple	Engineering Unit	+23200	0
16	0 ~ 2320°C	2's comp HEX	7FFF	0000
17	Type L Thermocouple	Engineering Unit	+8000	-2000
17	-200 ∼ 800°C	2's comp HEX	7FFF	E000
18	Type M Thermocouple	Engineering Unit	+10000	-20000
10	-200 ∼ 100°C	2's comp HEX	4000	8000
19	Type L DIN43710	Engineering Unit	9000	-2000
19	Thermocouple -200 ~ 900°C	2's comp HEX	FFFF	E38E
20	Platinum 100 α=0.00385	Engineering Unit	+10000	-10000
20	-100 ~ 100°C	2's comp HEX	7FFF	8000
21	Platinum 100 α=0.00385	Engineering Unit	+10000	0
21	0 ~ 100°C	2's comp HEX	7FFF	0000

Type Code	Input Range	Data Format	+F.S	-F.S
22	Platinum 100 α=0.00385	Engineering Unit	+20000	0
22	0 ~ 200°C	2's comp HEX	7FFF	0000
23	Platinum 100 α=0.00385	Engineering Unit	+6000	0
23	0 ~ 600°C	2's comp HEX	7FFF	0000
24	Platinum 100 α=0.003916	Engineering Unit	+10000	-10000
24	-100 ~ 100°C	2's comp HEX	7FFF	8000
25	Platinum 100 α=0.003916	Engineering Unit	+10000	0
25	0 ~ 100°C	2's comp HEX	7FFF	0000
26	Platinum 100 α=0.003916	Engineering Unit	+20000	0
26	0 ~ 200°C	2's comp HEX	7FFF	0000
27	Platinum 100 α=0.003916	Engineering Unit	+6000	0
27	0 ~ 600°C	2's comp HEX	7FFF	0000
28	Nickel 120	Engineering Unit	+10000	-8000
20	-80 ~ 100°C	2's comp HEX	7FFF	999A
29	Nickel 120 0 ~ 100°C	Engineering Unit	+10000	0
29		2's comp HEX	7FFF	0000
2A	Platinum 1000 α=0.00385	Engineering Unit	+6000	-2000
ZA	-200 ~ 600°C	2's comp HEX	7FFF	D556
2B	Cu 100 α=0.00421	Engineering Unit	+15000	-2000
26	-20 ~ 150°C	2's comp HEX	7FFF	EEEF
2C	Cu 100 α=0.00427	Engineering Unit	+20000	0
20	0 ~ 200°C	2's comp HEX	7FFF	0000
2D	Cu 1000 α=0.00421	Engineering Unit	+15000	-2000
20	-20 ~ 150°C	2's comp HEX	7FFF	EEEF
2E	Platinum 1000 α=0.00385	Engineering Unit	+20000	-20000
ZL	-200 ~ 200°C	2's comp HEX	7FFF	8000
2F	Platinum 1000 α=0.003916	Engineering Unit	+20000	-20000
<u> </u>	-200 ~ 200°C	2's comp HEX	7FFF	8000
60	PreCon Type III 10K@25°C,	Engineering Unit	+24000	-3000
- 00	-30°F ~ 240°F	2's comp HEX	7FFF	F000
61	Fenwell Type U 2K@25°C,	Engineering Unit	+15000	-5000
01	-50°C ~ 150°C	2's comp HEX	7FFF	D556

Type Code	Input Range	Data Format	+F.S	-F.S
63	Fenwell Type U 2K@25°C,	Engineering Unit	+15000	0
62	0°C ~ 150°C	2's comp HEX	7FFF	0000
62	YSI L Mix 100@25°C,	Engineering Unit	10000	-8000
63	-80°C ~ 100°C	2's comp HEX	7FFF	999A
C.A.	YSI L Mix 300@25°C,	Engineering Unit	+10000	-8000
64	-80°C ~ 100°C	2's comp HEX	7FFF	999A
CE	YSI L Mix 1000@25°C, -70°C ~ 100°C	Engineering Unit	+10000	-7000
65		2's comp HEX	7FFF	A667
	YSI B Mix 2252@25°C,	Engineering Unit	+15000	-5000
66	-50°C ~ 150°C	2's comp HEX	7FFF	D556
67	YSI B Mix 3000@25°C,	Engineering Unit	+15000	-4000
67	-40°C ~ 150°C	2's comp HEX	7FFF	DDDE
<b>C</b> 0	YSI B Mix 5000@25°C,	Engineering Unit	+15000	-4000
68	-40°C ~ 150°C	2's comp HEX	7FFF	DDDE
69	YSI B Mix 6000@25°C,	Engineering Unit	+15000	-3000
69	-30°C ~ 150°C	2's comp HEX	7FFF	E667
6A	YSI B Mix 10000@25°C,	Engineering Unit	+15000	-3000
0A	-30°C ~ 150°C	2's comp HEX	7FFF	E667
6B	YSI H Mix 10000@25°C,	Engineering Unit	+15000	-3000
ОВ	-30°C ~ 150°C	2's comp HEX	7FFF	E667
6C	YSI H Mix 30000@25°C,	Engineering Unit	+20000	-1000
00	-10°C ~ 200°C	2's comp HEX	7FFF	F99A
70	User-defined,	Engineering Unit	+15000	-5000
70	-50°C ~ 150°C	2's comp HEX	7FFF	D556
71	User-defined,	Engineering Unit	+15000	-5000
71	-50°C ~ 150°C	2's comp HEX	7FFF	D556
72	User-defined,	Engineering Unit	+15000	-5000
/ 2	-50°C ~ 150°C	2's comp HEX	7FFF	D556
73	User-defined,	Engineering Unit	+15000	-5000
/3	-50°C ~ 150°C	2's comp HEX	7FFF	D556
74	User-defined,	Engineering Unit	+15000	-5000
/4	-50°C ~ 150°C	2's comp HEX	7FFF	D556

Type Code	Input Range	Data Format	+F.S	-F.S
75	User-defined,	Engineering Unit	+15000	-5000
/5	-50°C ~ 150°C	2's comp HEX	7FFF	D556
76	User-defined,	Engineering Unit	+15000	-5000
76	-50°C ~ 150°C	2's comp HEX	7FFF	D556
77	User-defined, -50°C ~ 150°C	Engineering Unit	+15000	-5000
//		2's comp HEX	7FFF	D556
80	Platinum 100 α=0.00385 -200 ~ 600°C	Engineering Unit	+6000	-2000
80		2's comp HEX	7FFF	D556
81	Platinum 100 α=0.003916 -200 ~ 600°C	Engineering Unit	+6000	-2000
81		2's comp HEX	7FFF	D556
02	Cu 50 -50 ~ 150°C	Engineering Unit	+15000	-5000
82		2's comp HEX	7FFF	D556
83	Nickel 100	Engineering Unit	+18000	-6000
03	-60 ~ 180°C	2's comp HEX	7FFF	D556


# Appendix C Analog Output Type and Data Format Table

Type Code	Output Range	Data Format	+F.S	-F.S
20		Engineering Unit	+20000	0
30	0 ~ +20 mV	2's comp HEX	FFFF	0000
21	4	Engineering Unit	+20000	4000
31	4 ∼ +20 mV	2's comp HEX	FFFF	0000
32	0 ~ +10 V	Engineering Unit	+10000	0
32		2's comp HEX	7FFF	0000
22	10	Engineering Unit	+10000	-10000
33	-10 ∼ +10 V	2's comp HEX	7FFF	8000
24	0 ∼ +5 V	Engineering Unit	+5000	0
34		2's comp HEX	7FFF	0000
25	-5 ∼ +5 V	Engineering Unit	+5000	-5000
35	-3 ~ +3 V	2's comp HEX	7FFF	8000

## Appendix D Convert Modbus Data to the Actual Value

This chapter describes how to convert Modbus raw data read by ET-7000 into actual voltage, current, or temperature values.


On the **Module I/O Settings** page, check the **Range** and **Data Format** settings in the **Analog Input Setting** section.



The following example shows how to convert the Modbus data to a voltage value.


Type Code	Input Range	Data Format	Min.	Max.
08	10 .10 //	Engineering	-10000	+10000
	-10 ~ +10 V	2's Complement	8000	7FFF

The user can get the input voltage with the following formula.



# 10 V Actual value (6.0 V) -32768 (0x8000) Raw Data 32767 (0x7FFF)

For example, if the **Modbus Raw Data** read by the module is **0x200E**, the **Actual Value** of the input voltage is 2.5 (V).





The following example shows how to convert the Modbus data to a **current** value.

Type Code	Input Range	Data Format	Min.	Max.
0.7	4 × 20 ··· 4	Engineering	4000	20000
07	07 <b>4 ~ 20 mA</b>	2's Complement	0x0000	0xFFFF

For example, if the **Modbus Raw Data** read by the module is **0x7FFF**, the **Actual Value** of the input current is 12.0 (mA).





The following example shows how to convert the Modbus data to a **temperature** value.

Type Code	Input Range	Data Format	Min.	Max.
Type K Thermocouple	Engineering	-2700	13720	
UF	OF -270 ~ 1372°C	2's Complement	0xE6D0	0x7FFF

The user can get the input temperature with the following formula.


For example, if the **Modbus Raw Data** read by the module is **0x00EE**, the **Actual Value** of the input current is 23.8 (°C).

### **Appendix E Network Address Translation**

For a computer to communicate with ET-7x00/PET-7x00 modules on the Internet, ET-7x00/PET-7x00 modules must have a public IP address. It works like your street address - as a way to find out exactly where you are and deliver information to you.


Network Address Translation (NAT) allows a single device, such as a router, to act as an agent between the Internet (or "public network") and a local (or "private") network. This means that only a single, unique IP address is required to represent an entire group of computers.

A type of NAT in which a private IP address is mapped to a public IP address, where the public address is always the same IP address (i.e., it has a static address). This allows an internal host, such as an ET-7x00/PET-7x00 module, to have an unregistered (private) IP address and still be reachable over the Internet.



#### Step 1: Configure the Ethernet settings of the ET-7x00/PET-7x00 module.

The Gateway must be set to the IP address of the router (i.e., 10.1.0.1)



Step 2: Connect to the Web Server of the ET-7x00/PET-7x00 module with the public IP address on the Internet.

To access the web page, the port number must be included in the access URL as shown below: <a href="http://210.32.166.58:180">http://210.32.166.58:180</a>



## **Appendix F** Troubleshooting

Several common problems are easy to diagnose and fix if you know the cause.

Symptom/Problem		
Possible cause	Solution	
The Run LED doesn't light		
Internal power has failed	Return the module for repair.	

The Run LED indicator is ON (light), but not flashing.		
The module has possibly crashed.	Reboot the module	

• Cannot communicate via the Ethernet port, but the ET-7x00/PET-7x00 is still operating.		
The IP/Mask/Gateway address isn't within the IP address range of the LAN.	Change the IP/Mask/Gateway address to match the LAN, or ask the MIS administrator for assistance.	
The IP address has restricted by the IP filter settings	Check the IP filter settings using the Web configuration.	
There are more than 30 TCP/IP connections.	Reboot the module.	

<ul> <li>Able to explore the web page through Port 80 using a web browser, but the Web HMI and Modbus/TCP program cannot access the module through Port 502.</li> </ul>		
Port 502 has been restricted by the firewall.	Consult your MIS administrator for assistance.	

<ul> <li>The Web HMI and Modbus/TCP program can access the module through Port 502, but the Web browser cannot explore the web page through Port 80 using a web browser.</li> </ul>		
Port 80 has been restricted by the firewall.	Consult your MIS administrator for assistance.	
The Web server TCP Port has been changed from Port 80, refer to the <u>Basic Settings</u> page.	Change the TCP Port to 80 or reconnect the ET-7x00/PET-7x00 using the specific TCP Port.	