I-8088W API Reference Manual

Version 1.0.2, Oct. 2020

Service and usage information for Linux Platform



Written by Martin Hsu Edited by Cindy Huang

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, not for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright @ 2012 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Contact US

If you have any problem, please feel free to contact us. You can count on us for quick response.

Email: service@icpdas.com

Table of Contents

ble of Contents3

1.	Intro	ductior	٠	.5
	1.1.	Speci	fication	. 6
	1.2. Pin Assignment			
	1.3.	Block	Diagram	. 8
	1.4.	Wire (Connection	. 9
2.	Soft	ware an	d Getting Started	10
	2.1.	Softwa	are	10
	2.2.	Simple	e PWM Operation	11
	:	2.2.1.	Flow Chart	11
		2.2.2.	How to Setup the Standard PWM	12
	2.3.	Using	DI to Trigger PWM	16
		2.3.1.	Flow Chart	16
	:	2.3.2.	How to Setup the Trigger PWM	17
	2.4.	Synch	nronize PWM	21
	:	2.4.1.	Flow Chart	21
	2	2.4.2.	How to Setup the Standard PWM	22
3.	API f	for Linu		24
		3.1.1.	i8088W_Init	24
		3.1.2.	i8088W_GetFirmwareVersion	25
		3.1.3.	i8088W_GetLibVersion	26
		3.1.4.	i8088W_SetPWMDuty	27
		3.1.5.	i8088W_SetPWMDuty_Deci	28
		3.1.6.	i8088W_SetPWMDuty_float	30
		3.1.7.	i8088W_GetRealPWMDuty_Deci	32
		3.1.8.	i8088W_SetPWMCountMode	34
		3.1.9.	i8088W_SetBurstCount	36
		3.1.10.	i8088W_PWM_Start	37
		3.1.11.	i8088W_PWM_Stop	38
		3.1.12.	i8088W_SetSyncChannel	39
		3.1.13.	i8088W_GetSyncChannel	41

3.1.14.	i8088W_Sync_Start	42
3.1.15.	i8088W_Sync_Stop	43
3.1.16.	i8088W_SetHardwareTrigChannel	44
3.1.17.	i8088W_GetHardwareTrigChannel	46
3.1.18.	i8088W_GetPWMActiveState	48
3.1.19.	i8088W_GetDI	50
Appendix. Error	Codes	

1. Introduction

PWM (Pulse width modulation) is a powerful technique for controlling analog circuits. It uses digital outputs to generate a waveform with variant duty cycle and frequency to control analog circuits. I-8088W has 8 PWM output channels and 8 digital inputs. It can be used to develop powerful and cost effective analog control system.

Features:

- > Automatic generation of PWM outputs by hardware, without software intervention.
- > 10 Hz ~ 500 kHz (non-continuous) PWM output frequency with 0.1% ~ 99.9% duty cycle
- Software and hardware trigger mode for PWM output
- Individual and synchronous PWM output Using software trigger mode, you can set configuration for all PWM channels then trigger them one by one or all of them at the same time.
- > Burst mode PWM operation for standby
- DI channel can be configured as simple digital input channel or hardware trigger source of the PWM output.

1.1. Specification

PWM Output			
Channels	8		
Scaling Resolution	16-bit (1 ~ 128 μs for each step)		
Frequency Range	10 Hz ~ 500 kHz (non-continuous)		
Duty Cycle	0.1 % ~ 99.9 %		
PWM Mode	Burst counting, Continuous mode		
Burst Counter	1 ~ 65535		
Hardware Trigger Mode	Trigger Start and Trigger Stop		
Output Type	Source		
Max. Load Current	1 mA		
Intra-module Isolation, Field to Logic	3,750 Vrms		
ESD Protection	4 kV Contact for each channel		
Digital Input			
Input Channels	8 (Sink/Source)		
Input Type	One common for all digital input		
On Voltage Level	+5 V ~ +30 V		
Off Voltage Level	< 0.8 V		
Input Impedance	4.7 kΩ, 1/4 W		
Intra-module Isolation, Field to Logic	3,750 Vrms		
ESD Protection	4 kV Contact for each channel		
LED Display			
1 LED as Power Indicator/16 LED as PWM a	and Digital Input Indicator		
Power			
Power Consumption	40 mA @ 5 V, 2 W ± 5 %		
Environment			
Operating Temperature	-25 °C ~ +75 °C		
Storage Temperature	-30 °C ~ +85 °C		
Humidity	5 % ~ 95 % RH, non-condensing		
Dimensions			
30 mm x 102 mm x 115 mm (W x L x H)			

1.2. Pin Assignment



Terminal	No.	Pin Assignment
C · · (01	PWM0
C a (02	PWM1
200	03	PWM2
Co)	04	PWM3
Co(05	PWM4
Co)	06	PWM5
C = (07	PWM6
C o (08	PWM7
C = (09	PWM.GND
C. = (10	PWM.GND
C.	11	D10
L'a(12	DI1
C o	13	D12
C = (14	D13
G .	15	D14
C ·	16	D15
C. a (17	D16
L .	18	D17
C=(19	DI.COM
C.	20	DI.COM

- > Pin 01 ~ 08: PWM0 ~ PWM7, are designed for PWM output
- > Pin 09 ~ 10: PWM.GND is isolated ground.
- Pin 11 ~ 18: DI0 ~ DI7 are designed for digital input that also capable of setting as an external trigger signal to start or stop its PWM pulse.
- > Pin 19 ~ 20: DI.COM is isolated ground.





1.4. Wire Connection





2. Software and Getting Started

2.1. Software

In this section, we will introduce you one simple program (demo 8080W.exe) which have three setup modes – Normal, Hardware Trigger and Synchronize. We need to check the following steps before running the program.



- First, user need to download LinPAC SDK, which is includes GNU toolchain, Libraries, header, examples files, etc.
- Check the power cable, Ethernet cable, VGA monitor, the communication cable between controller and PC has been connected well, and then check the i-8088W has been plugged in the controller.
- 3. Next, check the communication between controller and PC is fine, and download the demo program files to the controller.

£ 10.1.0.39
linpac-8000 login: root
Password: Distributor ID: ICP DAS
Description: LinPAC-8x4x
Release OS: 1.6
Release bootloader: 1.3
installed modules list
slot 1 8088
pwd
/root
demo8088W.exe

4. User can find the related files in the product CD or below website:

PRRODUCT	CPU	DOWNLOAD LINK
LP-8x4x	PXA270	http://www.icpdas.com/en/download/show.php?num=982&model=LP-8441-EN
LP-8x2x/9x2x	AM335x	http://www.icpdas.com/en/download/show.php?num=915&model=LP-8421
LX-8000/9000	x86/E38xx	http://www.icpdas.com/en/download/show.php?num=904&model=LX-9381

2.2. Simple PWM Operation

2.2.1. Flow Chart



Note: Each time you change the settings of "PWM Duty", you have to re-send the "Start PWM" command to ensure the operation properly.

2.2.2. How to Setup the Standard PWM

Please make sure you have completed the steps in section 2.1 before operating the following steps.

Description of the demo:

In this example, we will use the demo to set I-8088W as "Continuous" mode and its frequency is 10 Hz, PWM duty is 50%. When we send the "Start Normal PWM" commend, the DI0 will blinking per 0.5s.

Wire connection of I-8088W:

To do this, you need to wire PW0 to DI0, DI.COM to External 5V, PWM.GND to External GND. (Please refer to section 1.2 Pin Assignment)

Now, follow the steps to configure the related parameter:

Step 1: Change the authority of "demo8088W.exe"

For example, my LP-8x4x's IP address is 10.1.0.39, and telnet to the LP-8x4x by pietty.exe as below:

```
# 10.1.0.39 [77x16]

installed modules list
slot 1 ... 8088
# pwd
/root
# ls
demo8088W.exe
# chmod 777 demo8088W.exe
#
# ls -al demo8088W.exe
-rwxrwxrwx 1 root root 78064 May 30 10:54 demo8088W.exe
#
#
```

Step 2: Change the authority of "demo8088W.exe"

When you run the program, it will initialize the i-8088W module and obtain the related information as shown below.

Step3: Set PWM Mode

This setting includes two modes - "Burst Count Mode" and "Continuous Mode".

"Burst Count Mode" means it can output multiple fixed pulse in a period time and then stop output. "Continuous Mode" means it can output one fixed pulse in a period time and continue output.

In this example, we enter "1" to set it as "Continuous mode".

```
🛃 10.1.0.39 [77x16]
 ls -al demo8088W.exe
#
                             78064 May 30 10:54 demo8088W.exe
-rwxrwxrwx
           l root
                      root
#
 ./demo8088W.exe
      Demo for i-8088W PWM
******* ~ SET PWM MODE ~ *********
Enter 'O' to Set Burst Count
Enter '1' to Set Continous
Enter '9' to Exit the program.
Type your answer then press ENTER: 1
```

Step 4: Set PWM Duty

There are three options in this setting, if you choose:

- > "0" means you can enter an integer value (ex. input 50 to set it as 50 %)
- "1" means you can enter an integer value to set it as one decimal place value. (ex. input 999 to set it as 99.9 %)
- > "2" means you can enter a one decimal place value. (ex. input 99.9 to set it as 99.9 %)

In this example, please enter "0" to set it as "Normal integer Duty"

🛃 10.1.0.39 [77x16]	
***************** ~ SET PWM DUTY ~ ***********************************	
Enter 'O' to Set Normal integer Duty,for example 50 means 50 Out	ty
Enter '1' to Set x10 integer Duty,for example 500 means 50.0 Out	ty
Enter '2' to Set float Duty,for example 50.0 means 50.0 Outy	
Enter '9' to Exit the program.	

Type your answer then press ENTER: 0	

Then, we will set its frequency as 10 Hz, PWM duty as 50 %.

🛃 10.1.0.39 [77x16]	
***************** ~ SET PWM DUTY ~ ***********************************	ıty ıty
Type your answer then press ENTER: O Choice Set Normal integer Duty First Input Hz 1~450000: 10 Then Input duty 1~99: 50 The PWM will be 10 Hz with 50 % Duty	

Step 5: Start PWM

You will see three modes in below picture, please enter "0" to set it as "Normal PWM"

₽ 10.1.0.39 [77x16]	
******* ~ START OR STOP PWM ~ ******** Enter 'O' to Set Normal PWM Enter '1' to Set Synchronous PWM	
Enter '2' to Set Hardware Trigger PWM Enter '3' to Set PWM Mode	
Enter '9' to Exit the program. ************************************	

Then enter "0" to start the PWM.



If you have completed the correct setup, you will see below picture. In this example, it will send the "start PWM" command to channel $0 \sim 7$, the condition is 10 Hz with 50% duty, and we has connected the PWM0 to DI0, so the DI0 will blink per 0.5 seconds.



2.3. Using DI to Trigger PWM

2.3.1. Flow Chart



2.3.2. How to Setup the Trigger PWM

There are 8 DI pins on I-8088W, normally these DI pin just acts as digital input channels. We can also configure them as external trigger signal pins to start or stop the PWM output.

Step 1: Follow the same way in section 2.2.2 to configure PWM output mode and set PWM duty and frequency.

Step 2: Enter "1" to set "Hardware Trigger PWM"

# 10.1.0.39 [77x16]	
******** ~ START OR STOP PWM ~ *** Enter '0' to Set Normal PWM Enter '1' to Set Synchronous PWM Enter '2' to Set Hardware Trigger H Enter '3' to Set PWM Mode Enter '9' to Exit the program. ************************************	****** PWM ******

There are three options to set the DI channels as PWM trigger signal:

- "0": Normal DI. If you set it as "Normal DI" mode, it will be unrelated to the PWM function.
- ➤ "1": Accept DI signal to start the PWM output.
- > "2": Accept DI signal to stop the PWM output.

₽ 10.1.0.39 [77x16]	
******* ~ Set Hardware Triggered PWM ~ ******** Enter 'O' to Set Hardware Triggered disable Enter '1' to Set Hardware Triggered start Enter '2' to Set Hardware Triggered stop ************************************	
Type your answer then press ENTER:	

There are two ways to configure the DI signal to start or stop the PWM output. One is rising edge to trigger the PWM to start or stop, the wiring like below two pictures.



Rising edge to Start PWM

Rising edge to Stop PWM



The other is falling edge to trigger the PWM to start or stop, the wiring like below two pictures.



Falling edge to Start PWM

Falling edge to Stop PWM



Step 3: Start the PWM

You can enter "1" to start the PWM output. It will start PWM when received an external trigger signal.

₽ 10.1.0.39 [77x16]	
******* ~ Set Hardware Triggered PWM ~ ******** Enter 'O' to Set Hardware Triggered disable Enter '1' to Set Hardware Triggered start Enter '2' to Set Hardware Triggered stop ************************************	
Type your answer then press ENTER: 1 Set Hardware Triggered to start PWM	

Step 4: Stop the PWM:

In Normal PWM mode, the signal will continue transfer until you go back to enter "2" to stop the PWM output.

2.4. Synchronize PWM

2.4.1. Flow Chart



2.4.2. How to Setup the Standard PWM

I-8088W can configure each PWM output channel as synchronous mode.

Step 1: Follow the same way in section 2.2.2 to configure PWM output mode and set PWM duty and frequency.

Step 2: Enter "2" to set "Synchronous PWM"

₽ 10.1.0.39 [77x16]	
******* ~ START OR STOP PWM ~ ******** Enter '0' to Set Normal PWM Enter '1' to Set Synchronous PWM Enter '2' to Set Hardware Trigger PWM	
Enter '3' to Set Maldwale Higgel rwm Enter '3' to Set PWM Mode Enter '9' to Exit the program. ************************************	
Type your answer then press ENTER: 1	

Step 3: Enter"1" to enable

₽ 10.1.0.39 [77x16]	
******* ~ Enable/Disable Synchronous PWM ~ ********* Enter 'O' to Disable Synchronous PWM Enter '1' to Enable Synchronous PWM ************************************	
Set PWM as Synchronous mode	

Step 4: Enter"1" to start Synchronous PWM.

You will see the different between following two pictures.

Start PWM:

In previous sections, we can start PWM by software command or DI trigger signal, but you can see the signal is non-synchronous in below picture.



Start Synchronous PWM:

So, we can call i8088W_Sync_Start or pac_i8088W_Sync_Start to start the PWM output and synchronize the rising edge for each synchronous PWM pulse.



3. API for Linux PAC

3.1.1. i8088W_Init

The function can initialize the I-8088W and then check the hardware ID for each slot. If the return value is "0" that means there is an I-8088W module in that slot. If return "-1" that means there is no I-8088W module.

Syntax

short i8088W_Init(int slot);

Parameters

slot: 1 ~ 8

Return Value

Please refer to Error Code Table.

Example

[C]

int slotIndex err	ł,
	ę
err=i8088W_Init(slotIndex);	j,
Open_Slot(slotIndex);	
if(err==0)	ų,
printf("There is an I-8088W at slot %d\n",slotIndex);	
else	Ż
printf("There is no I-8088W at slot %d\n",slotIndex);	

3.1.2. i8088W_GetFirmwareVersion

The function is used to get the firmware version of I-8088W.

Syntax

short i8088W_GetFirmwareVersion(int slot);

Parameters

slot: 1 ~ 8

Return Value

The firmware version of I-8088W hardware.

Example

[C]

short firmware_version;

Open_Slot(slot);

firmware_version = i8088W_GetFirmwareVersion(int slot);

3.1.3. i8088W_GetLibVersion

The function is used to get the version of library file.

Syntax

short i8088W_GetLibVersion(void);

Parameters

None

Return Value

The versions of library file.

Example

[C]

short version;

Open_Slot(slot);

version = i8088W_GetLibVersion();

3.1.4. i8088W_SetPWMDuty

The function is used to set the related PWM parameters.

Syntax

short i8088W_SetPWMDuty(int slot,int ch,unsigned long hz,unsigned int duty);

Parameters

slot: 1 ~ 8

ch: 0 ~ 7

hz: 0 ~ 450K

duty High part: 0 ~ 99

Low part: 100 - High part

Return Value

Please refer to Error Code Table.

Example

[C]

3.1.5. i8088W_SetPWMDuty_Deci

The function is used to set the PWM parameters precisely.

Syntax

short i8088W_SetPWMDuty_Deci (int slot,int ch,unsigned long deci_Hz,unsigned int deci_duty);

Note

i8088W_SetPWMDuty_Deci is the same as i8088W_SetPWMDuty_float in usage, but the i8088W_SetPWMDuty_Deci will run faster than i8088W_SetPWMDuty_floa for the floating calculation reason

Parameters

slot: 1 ~ 8 ch: 0 ~ 7 deci_Hz example: 10 deci_Hz = 10 Hz deci_duty 0~999, for example: 503 deci_duty = 50.3% High Part Low Part=1000 - 503= 497 => 49.7% Low Duty cycle

Return Value

Please refer to Error Code Table.

Example

[C]

```
int slot,ch;
slot = 1;
Open_Slot(slot);
for(ch=0;ch<8;ch++)
{
    i8088W_SetPWMDuty_Deci(slot,ch,50.3);
}
```

3.1.6. i8088W_SetPWMDuty_float

The function is used to set the PWM parameters precisely

Syntax

short i8088W_SetPWMDuty_Float(int slot,int ch,float f_Hz,float f_Duty);

Note

i8088W_SetPWMDuty_Deci is the same as i8088W_SetPWMDuty_float in usage, but the i8088W_SetPWMDuty_Deci will run faster than i8088W_SetPWMDuty_floa for the floating calculation reason

Parameters

slot: 1 ~ 8

ch: 0 ~ 7

 $f_Hz 100 \text{ means } f_Hz = 10 \text{ Hz}$

f_Duty 0.0~99.9, for example: 50.3 means 50.3% High Part

Low Part =100.0- f_Duty = 49.7 means = 49.7%

Return Value

Please refer to Error Code Table.

Example

[C]

```
int slot,ch;
slot = 1;
Open_Slot(slot);
for(ch=0;ch<8;ch++)
{
    i8088W_ SetPWMDuty_Float (slot,ch,50.3);
}
```

3.1.7. i8088W_GetRealPWMDuty_Deci

The function will get real frequency and duty that can be produced by 8088W.

Syntax

short i8088W_GetRealPWMDuty_Deci (int slot,int ch,unsigned long* deci_hz,unsigned int* deci_duty);

Note

The duty and frequency of 8088W PWM is discrete not continuous, when we use i8088W_SetPWMDuty to configure the duty and frequency, we have to use this function to check the real duty and frequency which can be produced by 8088W normally, at low frequency 10K, the configued frequency will be closer to real frequency can be generated.

Parameters

slot: 1 ~ 8

ch: 0 ~ 7

deci_hz: the real frequency produced by 8088W unit (x10Hz)

deci_duty: the real duty produced by 8088W (x10 %)

Return Value

Please refer to Error Code Table.

Example

[C]

{

}

unsigned long deci_hz; unsigned int deci_duty slot = 1; Open_Slot(slot);

for(ch=0;ch<8;ch++)

i8088W_GetRealPWMDuty_Deci(slot,ch,& deci_hz, & deci_duty); printf("CH[%d] PWM Hz = %lu ; Duty = %u\n", ch, deci_hz, deci_duty);

3.1.8. i8088W_SetPWMCountMode

The function is used to set the count mode of I-8088W.

Syntax

short i8088W_SetPWMCountMode(int slot,int ch,unsigned char countMode);

Parameters

- slot: 1 ~ 8
- ch: 0 ~ 7

count Mode

- 1: Continuos
- 0: Burst count

Return Value

Please refer to Error Code Table.

Example

[C]

int slot,ch; slot = 1; mode=0; //burst mode Open_Slot(slot); for(ch=0;ch<8;ch++) { i8088W_ SetPWMCountMode(slot,ch,mode); }

3.1.9. i8088W_SetBurstCount

The function is used to set the BurstCount of I-8088W.

Syntax

short i8088W_SetBurstCount(int slot,int ch,unsigned int burstCount);

Parameters

slot: 1 ~ 8

ch: 0 ~ 7

burstCount: 0~65536

Return Value

Please refer to Error Code Table.

Example

[C]

int slot=1, ch, burstCount=10000; Open_Slot(slot); for(ch=0;ch<8;ch++) { i8088W_ SetBurstCount (slot, ch, burstCount); }

3.1.10. i8088W_PWM_Start

The function is used to start the PWM pulse.

Syntax

short i8088W_PWM_Start(int slot,int ch);

Parameters

slot: 1 ~ 8

ch: 0 ~ 7

Return Value

Please refer to Error Code Table.

Example

[C]

3.1.11. i8088W_PWM_Stop

The function is used to stop the PWM pulse.

Syntax

short i8088W_PWM_Stop(int slot,int ch);

Parameters

slot: 1 ~ 8

ch: 0 ~ 7

Return Value

Please refer to Error Code Table.

Example

[C]

```
int slot=1, ch;
Open_Slot(slot);
for(ch=0;ch<8;ch++)
{
    i8088W_PWM_Stop(slot, ch);
}
```

3.1.12. i8088W_SetSyncChannel

The function is used to set the specific channel as synchronous.

Syntax

short i8088W_SetSyncChannel(int slot,int ch,int enBit);

Parameters

- slot: 1 ~ 8
- ch: 0 ~ 7

enBit

- 1: define channel as synchronous mode,
- 0: not synchronous mode

Return Value

Please refer to Error Code Table.

Example

[C]

3.1.13. i8088W_GetSyncChannel

The function is used to get the synchronous channel by using array.

Syntax

short i8088W_GetSyncChannel(int slot,int syncArr[]);

Parameters

slot: 1 ~ 8

syncArr[] is an 8 bit array

syncArr[i]=1 means channel[i] is set as synchronous1: define

Return Value

Please refer to Error Code Table.

Example

[C]

int slot, syncArr[]; slot = 1; Open_Slot(slot); i8088W_ GetSyncChannel (slot, syncArr);

3.1.14. i8088W_Sync_Start

The function is used to start the synchronization of PWM pulse.

Syntax

short i8088W_Sync_Start(int slot);

Parameters

slot: 1 ~ 8

Return Value

Please refer to Error Code Table.

Example

[C]

int slot; slot = 1; Open_Slot(slot);

i8088W_Sync_Start (slot);

3.1.15. i8088W_Sync_Stop

The function is used to stop the synchronization of PWM pulse.

Syntax

short i8088W_Sync_Stop(int slot);

Parameters

slot 1 ~ 8

Return Value

Please refer to Error Code Table.

Example

[C]

int slot; slot = 1; Open_Slot(slot);

i8088W_Sync_Stop (slot);

3.1.16. i8088W_SetHardwareTrigChannel

The "DI" pin of I-8088W can be set as hardware trigger pin or simply DI pin. The user can call this function to specify the status of channels.

Syntax

short i8088W_SetHardwareTrigChannel(int slot, int ch, int triggerState);

Parameters

- slot: 1 ~ 8
- ch: 0 ~ 7

triggerState

0, disabled hardware trigger (Normal DI pin)

1, means this DI has been configured as external trigger signal for I-8088W to startup its PWM pulse.

2, this DI has been configured as external trigger signal for I-8088W to stop its PWM pulse.

Return Value

Please refer to Error Code Table.

Example

[C]

{

}

int slot,ch, triggerState; slot = 1; Open_Slot(slot);

triggerState=0; for(ch=0;ch<8;ch++)</pre>

i8088W_SetHardwareTrigChannel (slot,ch, triggerState);

3.1.17. i8088W_GetHardwareTrigChannel

The "DI" pin of I-8088W can be set as hardware trigger pin or simply DI pin. The user can call this function to know the status of channels.

Syntax

short i8088W_GetHardwareTrigChannel(int slot,int ch,int* triggerState);

Parameters

- slot: 1 ~ 8
- ch: 0 ~ 7

triggerState

0, disabled hardware trigger (Normal DI pin)

1, means this DI has been configured as external trigger signal for I-8088W to startup its PWM pulse.

2, this DI has been configured as external trigger signal for I-8088W to stop its PWM pulse.

Return Value

Please refer to Error Code Table.

Example

[C]

```
int slot,ch, triggerState;
slot = 1;
Open_Slot(slot);
triggerState=0;
for(ch=0;ch<8;ch++)
{
    i8088W_GetHardwareTrigChannel(slot,ch,& triggerState);
}
```

3.1.18. i8088W_GetPWMActiveState

The function is used to get PWM status.

Syntax

short i8088W_GetPWMActiveState(int slot,unsigned int *State,int ActiveArr[]);

Parameters

slot: 1 ~ 8

*State: the PWM output status of i-8088 value 0~0xff

ActiveArr[]: the *State value will be parse into Bit Array

When PWM generate pulse output, the state will be 1, we can know which PWM channel is sending PWM output. If we configure PWM as Burst Count mode, the PWM output will be stop when it sends configured count of PWM pulse (for example 1000 pulse) by using this function, we can know the actural PWM output state.

Return Value

Please refer to Error Code Table.

Example

[C]

```
int slot=1,ch,activatedBit[8];
unsigned int activatedState=0;
Open_Slot(slot);
i8088W_GetPWMActiveState (slot,& activatedState, activatedBit);
for(ch=0;ch<8;ch++)
{
    if(activatedBit[ch])
        printf("PWM CH[%d] is activated\n",ch);
}
```

3.1.19. i8088W_GetDI

The function is used to get DI status. The user can view which channels have received the signals.

Syntax

short i8088W_GetDI(int slot, unsigned int *diVal, int diArr[]);

Parameters

slot: 1 ~ 8

diVal: the DI status of i-8088 value 0~0xff

diArr[]: the *DI value will be parse into Bit Array

Return Value

Please refer to Error Code Table.

Example

[C]

```
int slot;
ch,enBit[8];
Slot=1;
unsigned int dival=0;
Open_Slot(slot);
i8088W_GetDI(slot, &diVal,enBit);
printf ("DI Vaule = %02X\n",diVal);
for (ch=0; ch< 8; ch++)
{
    printf ("DI[%d]= %d\n",ch, enBit[ch]);
}
```

Appendix. Error Codes

0	ОК
-1	ID_ERROR
-2	SLOT_OUT_RANGE
-3	CHANNEL_OUT_RANGE
-4	SELECT_CHANNEL_ERROR
-5	HI_DUTY_OUT_RANGE
-6	LO_DUTY_OUT_RANGE