ICP DAS Installation Guide Of PMMS with PMC and Power Meter Ver. 1.0.0 [2015,Nov]

Web Page: http://pmms.icpdas.com

Table of Contents

Introduction
Dimension4
PMC-5151
PM-3033/PM-3133/PM-3112/PM-3114
PMC-43245
Hardware Switch Setting6
Where is the switch located?6
How to setup the switch7
CT (Current Transformer) Diagram of Mechanism8
Dimension
CT Installation9
Wiring Diagram10
Wiring PMC-5151 to Power Meter12
PM-3033/PM-3133/PM-3112/PM-3114 Wiring Diagram
PM-4324 Wiring Diagram
PMC-5151 Network Setting14
Factory defaults14
Factory defaults
Factory defaults14Network Setting14Basic Operation16
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16
Factory defaults 14 Network Setting 14 Basic Operation 16 Setup and Scan Power Meters 16 Verify the Power Data After Installation 19
Factory defaults 14 Network Setting 14 Basic Operation 16 Setup and Scan Power Meters 16 Verify the Power Data After Installation 19 Set the Nickname of the Power Meter and export the UID information 22 DM0 5151 Time Online 25
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Legger27
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28Power Meter Information Overview28Statistics Information Overview28
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28Power Meter Information Overview28Statistics Information Overview29Beset Accumulated Value and Statistics Data of the Power Meter20
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28Power Meter Information Overview28Statistics Information Overview29Reset Accumulated Value and Statistics Data of the Power Meter30Note: Avoid Using IE 8.0 version of the Web Browser32
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28Power Meter Information Overview28Statistics Information Overview29Reset Accumulated Value and Statistics Data of the Power Meter30Note: Avoid Using IE 8.0 version of the Web Browser32Trick: Login via ETP to access data logger file saved on the microSD card33
Factory defaults14Network Setting14Basic Operation16Setup and Scan Power Meters16Verify the Power Data After Installation19Set the Nickname of the Power Meter and export the UID information22PMC-5151 Time Calibration25Enable the Data Logger27Power Meter Information28Power Meter Information Overview28Statistics Information Overview29Reset Accumulated Value and Statistics Data of the Power Meter30Note: Avoid Using IE 8.0 version of the Web Browser32Trick: Login via FTP to access data logger file saved on the microSD card33Accerdin Decument Basician Ulictory25

Introduction

This document gives a brief instruction to implement hardware installation and software configuration of power meter concentrator (PMC-5151) and smart power meters (PM-3xxx and PM-4324 series) in an ICP DAS Power Monitoring & Management Solution application. After completing these steps, the users can remotely view the real-time or historical power information through a web browser on a PC or mobile phone.



Related documents

The following documents can be obtained from http://pmms.icpdas.com/en/download.html

PMC-5151	Quick Start
	Brief User Guide
	User Manual
	Data Sheet
Smart Power Meter	Quick Start
	User Manual
	Data Sheet

Dimension

PMC-5151



Front View

Left Side View

PM-3033/PM-3133/PM-3112/PM-3114



PMC-4324



Front View



Left Side View

Hardware Switch Setting

Where is the switch located?

PM-3033/PM-3133/PM-3112/PM-3114



PM-4324



How to setup the switch

Set up Node-ID by SW1-SW6 Switch (using PM-3133 as an example)

Each power meter on the same RS-485 must use a unique Node-ID; the Node-ID cannot be used repeatedly.

Modbus Address	SW1	SW2	SW3	SW4	SW5	SW6
1	OFF	OFF	OFF	OFF	OFF	OFF
2	ON	OFF	OFF	OFF	OFF	OFF
3	OFF	ON	OFF	OFF	OFF	OFF
4	ON	ON	OFF	OFF	OFF	OFF
5	OFF	OFF	ON	OFF	OFF	OFF
6	ON	OFF	ON	OFF	OFF	OFF
7	OFF	ON	ON	OFF	OFF	OFF
8	ON	ON	ON	OFF	OFF	OFF
9	OFF	OFF	OFF	ON	OFF	OFF
10	ON	OFF	OFF	ON	OFF	OFF
11	OFF	ON	OFF	ON	OFF	OFF
12	ON	ON	OFF	ON	OFF	OFF
13	OFF	OFF	ON	ON	OFF	OFF
14	ON	OFF	ON	ON	OFF	OFF
15	OFF	ON	ON	ON	OFF	OFF
16	ON	ON	ON	ON	OFF	OFF
17	OFF	OFF	OFF	OFF	ON	OFF
18	ON	OFF	OFF	OFF	ON	OFF
19	OFF	ON	OFF	OFF	ON	OFF
20	ON	ON	OFF	OFF	ON	OFF
21	OFF	OFF	ON	OFF	ON	OFF
22	ON	OFF	ON	OFF	ON	OFF
23	OFF	ON	ON	OFF	ON	OFF
24	ON	ON	ON	OFF	ON	OFF

Baud Rate Setting by SW7& SW8

The Baud Rate of each power meter on the same RS485 connection should be the same.

Baud Rate	SW7	SW8
9600 bps	OFF	OFF
19200 bps (default)	ON	OFF
38400 bps	OFF	ON
115200 bps	ON	ON

Wiring Mode Setting by SW9 & SW10

The Wiring Mode setting is in accordance with the circuit to be measured by power meter.

Wiring Mode	SW9	SW10
Software Setting	OFF	OFF
3P3W-2CT	ON	OFF
3P3W-3CT	OFF	ON
3P4W-3CT	ON	ON

Page 7

CT (Current Transformer) Diagram of Mechanism

The package of PM-3133 / PM-3112 / PM-3114 / PM-4324 includes the CTs. The CTs included in the package are in accordance with the module numbers of the product. Using PM-3133 as an example, the module number of PM-3133 shows PM-3133-xxxx; the "-xxxx"

represent the specification of the CT. "-100" indicates the outer diameter of the cable to be clipped is 10mm; "-360P" indicates the outer diameter of the cable to be clipped is 36mm. Please refer to the following for detailed specifications.

Dimension





CT Installation



Wiring Diagram

1P2W-1CT



1P3W-2CT



3P3W-2CT



3P3W-3CT



3P4W-3CT



Note:

The above wirings apply to PM-3033 / PM-3133 / PM-4324 only

Wiring PMC-5151 to Power Meter

PM-3033/PM-3133/PM-3112/PM-3114 Wiring Diagram



PM-4324 Wiring Diagram

The external voltage of PM-4324 is AC Input; the users do not need to add an AC to DC Power Supply.



Instruction and Tips



- 1) Each RS-485 on the PMC-5151 can connect up to 16 power meters, but at most total 24 power meters can be connected to COM2 and COM3.
- 2) At most four PM-4324 can be included among the 24 power meters (the maximum quantity of power meter that a PMC-5151 can handle at once)
- 3) Power Consumption:

PMC-5151: 5W PM-3033/PM-3133/PM-3112/PM-3114: 2W

PMC-5151 Network Setting

Default network settings of LAN1 on PMC-5151 are as follows: IP: 192.168.255.1 Subnet mask: 255.255.0.0 Gateway: 192.168.0.1

Network Setting

Factory defaults

 Modify the network settings of the PC or Notebook to be the same network domain as PMC-5151. For example:

IP: 192.168.255.10 Subnet mask: 255.255.0.0 Gateway: 192.168.0.1

- 2) Connect PMC-5151 LAN1 to PC by network cable (there is no need to use crossover cables)
- 3) Start the browser and in the address bar input: http://192.168.255.1 °
- 4) Input default administrator password "Admin" to log in. Note: PMC-5151 provides one Administrator account (default password: Admin), five user accounts (default password: User). The User account can only view the data without permission to edit settings.
- After login, go to [System Settings] → [Network Setting], modify the LAN1 network settings to fit the current network environment.

	Main Page System Setting	leter / Module Setting Lo	ogger Setting ▶
	System Setting Network Setting		
	Tin e Setting	Network Setting(I	LAN1)
C	Network Setting	IP	192 . 168 . 100 . 250
	VPN Setting	Mask	255 255 255 0
	SNMP Setting		
	Security Setting	Gateway	192 . 168 . 100 . 254
	I/O Interface Setting	DNS	8.8.8.8
	Other Setting		
	Power Meter Group Setting		Save
		Network Setting(I	_AN2)
		IP	192 . 168 . 255 . 2
		Mask	255 . 255 . 0 . 0

6) After pressing the [Save] button, for the network domain of the PMC-5151 and PC are different, the web may not be connected. Please connect PMC-5151 and PC to the actual network environment, and modify the network settings of the PC to the original network settings and then connect it to the PMC-5151again.

Network Setting(I	_AN1)
IP	192 . 168 . 100 . 250
Mask	255 . 255 . 255 . 0
Gateway	192 . 168 . 100 . 254
DNS	8.8.8.8
	Save
Network Setting(l	LAN2)
IP	192 . 168 . 255 . 2
Mask	255.255.0.0
Gateway	192.168.0.1
DNS	8.8.8.8
	Save
A.	
100	~ + -
101100	1011101000101010101010101010101010101010
	101000101000101000101

1011001010100010100

Basic Operation

Setup and Scan Power Meters

 Please complete RS-485 wiring connection between PMC-5151 and the power meter, and then log in PMC-5151 page as Administrator, select [System Setting] → [I/O Interface Setting] and verify if the parameters (Baudrate / Parity / Stop bits) settings of the COM Port (connected to the power meter) are accurate, after finishing editing, click [Save] to save the settings.

Main Lage System Setting	Meter / Module Setting Lo	gger Setting ►				
Statem Setting 🕥 I/O Interface Setting						
Time Setting	I/O Interface Setti	ng Page	COM1	COM2	COM3	LAN
Network Setting	Function	Modbus RTU Master V				
VPN Setting	Baudrate	19200 V bps				
Security Security	Parity	● None ○ Odd ○ Even				
I/O Interface Setting	Stop bits	●1 □2				
Other Setting	Silent Interval	100 millisecond(s)			
Power Meter Group Setting		(Save			

- 2) Select [Meter/Module Setting] \rightarrow [Power Meter Setting] to scan or add power meters by the following steps:
- 3) Scan Modbus RTU Power Meter:
 - 3.1. Scan the power meters on the COM Port interface that is connected to the power meters (in this example, the power meter is connected to COM2).



3.2. After the scanning is completed, the system will show the list of the power meters that are currently connected to the COM Port. Click [Save] to complete Power Meter List setting.

Powe	r Meter I	List (Modbu	ıs RTU)	COM2	СОМЗ І
Q	No.	Address	*Power Meter		Nickname
$\textcircled{\bullet}$	2 •	2 🔻	?		
۲	1	1	ICP DAS PM-3133		PM-3133
4	Setting	Move Up	Move Down Copy Remov	/e	
			Save		

Note



When fail to scan the power meters, please check if the connection of RS-485 series wiring is adequate; then go to Step 1: [System Setting] \rightarrow [I/O Interface Setting] to verify if the settings of the COM Port (connected to the power meters) are correct. After editing the settings, click [Save] to save the settings and repeat Step 3.1. to scan the meter again.

4) Save the settings to the PMC-5151.



5) After saving the settings to the PMC-5151, the connection to the power meter is completed. After the system is initialized, the main page will show the power information of the connected power meters.

ower Data	Classificatio	on					
Data	Classificatio	n1	Data Clas	sification2	Da	ata Classifica	tion3
V		¥	1	•	kWh		•
ower Mete	rs						
ower Mete	rs						
ower Mete PM-3133	rs		0	PM-3033			
Power Mete	rs V		k Wh	PM-3033	V	1	kWh
Power Mete	rs V 0.000	I 0.000	kWh 0.078	PM-3033 Phase A	V 0.000	I 0.000	kWh 0.030
Phase A Phase B	rs V 0.000 0.000	I 0.000 0.000	kWh 0.078 0.085	PM-3033 Phase A Phase B	V 0.000 0.000	I 0.000 0.000	kWh 0.030 0.030
Power Mete PM-3133 Phase A Phase B Phase C	rs V 0.000 0.000 0.000	I 0.000 0.000 0.000	kWh 0.078 0.085 0.085	Phase A Phase B Phase C	V 0.000 0.000 0.000	I 0.000 0.000 0.000	kWh 0.030 0.030 0.030

Verify the Power Data After Installation

Power Data Overview



- 1) Check if the connection status indicator shows in green light, if the indicator shows in red light; please check the following :
 - Check if the wiring connection of RS-485 is connected adequately.
 - Check if the baud rate setting of SW7-SW8 DIP switch (using PM-3133 as an example) is correct
 - Check if webpage settings are correct.

Main Page System Setting	Neter / Module Setting Lo	ogger Setting >			
System Setting / I/O Interface Setting					
Time Setting	I/O Interface Setti	ing Page	COM1	COM2	COM3
Network Setting	Function	Modbus RTU Master V			
VIN Setting	Baudrate	19200 V bps			
SNMP Setting	Parity	● None ○ Odd ○ Even			
VO Interface Setting	Stop bits	● 1 ○ 2		/	
Other Setting	Silent Interval	100 millisecond(s)		
Power Meter Group Setting			Save		

Installation Guide of PMMS with PMC and Power Meter [Ver. 1.0.0] Page | 19

- 2) Check if the values of voltage and current are accurate; if not, check the following:
 - Check if the wiring connection of reference voltage is accurate. You can verify it by multimeter or via PMC-5151 webpage, if it shows "Positive Phase Sequence", it is accurate.
 - If use PM-3033 to connect a general CT, for example: 300A/5A, then the CT ratio should

be adjusted to : $\frac{300}{5}$ = 60.

• Check if the power meter wiring mode settings on SW9-SW10 DIP switch (using PM-3133 as an example) is correct.



3) Active Power (kW) should be greater than zero

If the device is not running, it is possible due to the load is too small, resulting in the kW shows negative value. This situation can be verified by analyzing Active Power (kW) and Reactive Power (kvar); when the value of Reactive Power (kvar) is greater than the value of Active Power (kW); it indicates that the device probably is not running. And then visually check if the wiring connection of reference voltage is accurate (shows "Positive Phase Sequence"); finally; check if the CT is clipped on the wire in the accurate direction or not.



Set the Nickname of the Power Meter and export the UID information

 Login PMC-5151 page as administrator, and select [meter / Module Setting] → [Power Meter Setting] → [Setting], after completing the nickname setting for all power meters that are connected to PMC-5151, click [Save].

Power Monitori	ing & Management Sol	ution		PMC-5	151 📄 🛃	
				Ģ	3651MB ilns	tant Messa
Main Page System Setter	Meter / Module Setting	Logger Settin	lg ⊧			
Meter / Model Setting Power M Power Meter Setting	Power Meter	List (Modbu	ıs RTU)	COM2	СОМЗ	LAN
XW-B ard Setting	No.	Address	*Power Meter		Nickname	
I/O Module Setting	(+ 7 ·	7 🗸	Search ?			
	۰ 📌 ۱	1	ICP DAS PM-4324		PM-4324	
	O 📌 2	2	ICP DAS PM-3133		PM-3133	
	O 📌 3	3	ICP DAS PM-3133		PM-3133	
	○ ▶ 4	4	ICP DAS PM-4324		PM-4324	
	0 📌 5	5	ICP DAS PM-3112		PM-3112	
	•	6	ICP DAS PM-3114		PM-3114	
	Setting	Move Up	Move Down Copy Re	emove		
			Save			

Power Mon	itoring & Management Solution	PMC-5151 📄 🗟 📩 🖈
		G3651MB IInstant Message
Main Page System S	etting Meter / Module Setting Logger Setting >	
Meter / Module Setting Po	wer Meter Setting Power Meter PM-3133 Setting	
Power Meter PM-	3133 Setting	
*Nickname	Module-A09(Pump CH-I)	
Description		
Address	2 *	
Scan Rate	5 second(s)	
Polling Timeout	1000 millisecond(s)	
Retry Interval	5 second(s)	
Power Meter Sett	ina	
Main Power Meter	☑ Set as main power meter	
	Phase A	
Nickname	Phase B	

Noter Mor	itoring & Managemen	t Solution		РМС-5151 📄 📩 🖈
ICP DAS Co., L	td.			G3651MB Dinstant Message
Main Page System S	Meter / Module S	etting Logger S	ietting >	
Meter / Module Setting >> Po	wer Meter Setting 〉 Power Me	eter PM-4324 Setting		
Power Meter PM-	4324 Setting			
*Nickname	Module-A09	>		
Description				
Address	1 ×			
Scan Rate	5 second(s)			
Polling Timeout	1000 millisecond	(s)		
Retry Interval	5 second(s)			
Power Meter Set	ing			
Main Power Meter	Set as main power m	eter		
	Submeter1 3-Phase	e 1-Phase		
	Submeter2 3-Phase	e 1-Phase		
	Submeter3 3-Phase	e 1-Phase		
	Submeter4 3-Phase	e 1-Phase		
Phase Display Mode	Submeter5 3-Phase	e 1-Phase	3 Phase set	
	Submeter6 3-Phase	e 1-Phase	nickname of	submeter
	Submeter7 3-Phase	e 1-Phase		
	Submeter8 3-Phase	e 1-Phase		
	Submeter1		Submeter2	
	Phase A		Phase A	
	Phase B		Phase B	
	Phase C		Phase C	
	Submeter3		Submeter4	
	Phase A		Phase A	
	Phase B		Phase B	
	Phase C		Phase C	
Nickname	Submeter5		Submeter6	
	Phase A		Phase A	
	Phase B		Phase B	
	Phase C		Phase C	
	Submeter7		Submeter8	
	CT19		CT22	
	CT20		CT23	Cinale Dhara and
	CT21		CT24	Single Phase, set

After finishing the installation of the power meter and the nickname settings, the UID information (.csv file) can be exported to a PC. This document records the information of the power meters that are currently managed by the PMC-5151; the information includes: the COM2, COM3, or the IP address that the power meter is installed, the address of RS-485, nickname, UID and UID_EX, etc.. Each Phase (or CT) of three phase power meter (or single phase power meter) is recorded as a record. With this file, the user can easily figure the complete architecture of the power meter installation.



Power Meter (Device) Mapping

30.00	¥20	Ĩ	138952	6170000C7).csv - Microsof	Lettel		- 5
RE SCII	請入 原調書	লে ১০ লগ	1				- @ -
Al		• (*	~~ <				
		5	5				
٨	B		ζζ.	- H	ill	主家	L M
系統名稱	LAN1 IP	LAN2 IP	5	名稱	UID	UID_Ex	
PMC-5151	10.0.9.110	192.168.255.2	4324	Module-A09(Pump CH-A)	01589526170000C7_2[4324 1	0158952617000	0C7_2[4324]1_[3]1
PMC-5151	10.0.9.110	192.168.255.2	-4324	Module-A09(Pump CH-B)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]2
PMC-5151	10.0.9.110	192.168.255.2	C-4324	Module-A09(Pump CH-C)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]3
PMC-5151	10.0.9.110	192.168.255.2	- 32 4	Module-A09(Pump CH-D)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]4
PMC-5151	10.0.9.110	192.168.255.2	3 3324	Module-A09(Pump CH-E)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]5
PMC-5151	10.0.9.110	192.168.255.2	4324	Module-A09(Pump CH-F)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]6
PMC-5151	10.0.9.110	192.168.255.2	432 4	Module-A09(Pump CH-G)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]7
PMC-5151	10.0.9.110	192.168.255.2	> 332	Module-A09(Pump CH-H)	01589526170000C7_2[43241	0158952617000	0C7_2[4324]1_[3]8
PMC-5151	10.0.9.110	192.168.255.2	1-313	Module-A09(Pump CH-I)	01589526170000C7_2[3133 2	0158952617000	OC7_2[3133]2_[3]1
PMC-5151	10.0.9.110	192.168.255.2	313	Module-A09(Pump CH-J)	01589526170000C7_2[31333	0158952617000	0C7_2[3133]3_[3]1
PMC-5151	10.0.9.110	192.168.255.2	324	Module-A09(Pump CH-K)	01589526170000C7_2[4324.4	0158952617000	0C7_2[4324]4_[3]1
PMC-5151	10,2-9,110	192.168.255.2	41-4324	Module-A09(Pump CH-L)	01589526170000C3 2[4324 4	0158952617000	0C7_2[4324]4_[3]2
Vicion	- wen	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	E	41odule-A09(Pump CH + 1			4CZ 21432434 5242

PMC-5151 Time Calibration

There are two ways to perform time calibration of the PMC-5151: manual calibration and time synchronization through a network.

Manual Calibration



Main Page System Set	ting Meter / Module Setting I	Logger	r Setti	ing)	,					
System Setting Time Setting										
Time Setting	Time Setting Pag	е								
Network Setting		<		2	016 /	1		>		
VPN Setting		Sun	Mon	Tue	Wed	Thu	Fri	Sat		
SNMR Setting		0		5	0	7	1	2		
Security Setting	Date	3 10	4	5 12	13	14	o 15	9 16		
I/O Intelface Setting		17	18	19	20	21	22	23		
Other Setting		24	25	26	27	28	29	30		
Dower Motor Croup Soffin		31								
Power Meta Group Settin	Time	11 \	. 54	4 🗸 :	07 🗸	-				
	Time Duplication	Loa	ad (L	.oad	current	time	of this	s comp	uter.)	
	Time Synchroniza	ation								
	Function Status	En	able				\checkmark			
							Sav	re)	

• Time Synchronization through Network

Time Setting Pag	е									
	<		2	016/	1		>			
	Sun	Mon	Tue	Wed	Thu	Fri	Sat			
						1	2			
Data	3	4	5	6	7	8	9			
Date	10	11	12	13	14	15	16			
	17	18	19	20	21	22	23			
	24	25	26	27	28	29	30			
	31									
Time	12 \	. 59		32 >	/					
TIME	12 1	12 ♥ : 59 ♥ : 32 ♥								
Time Duplication Load (Load current time of this computer.)										
ime Synchroniza	ation ⊡En	able								
*SNTP Time Server	pool wate	.ntp.c	org time.	.gov.t	W)			
	time Use	wind	ows. aul s	com SNTP	Time	e Ser	vers			
Port	123									
Sync Interval	12	/ ho	urs							
Time Zone	(GM	T+08	:00)	Taipe	i					
Daylight Saving Time	□En	able								
11110										

Note



After the settings are saved, the PMC-5151 displays "Saved successfully", and will perform time synchronization through network immediately. If the connection to SNTP time server is connected successfully, the time shows on the top region of this page will be accurate. However, if it fails to connect to SNTP time server, the time shows on this page will not be changed and no error message will be shown. In order to make sure the connection between PMC-5151 and SNTP time server is successful or not, when you perform time synchronization, you can manually adjust the time to be 10 minutes further so that you can verify if it connects successfully after saving the settings.

Save

Enable the Data Logger

Login PMC-5151 page as administrator. Select [Data Logger Setting] → [Logger Setting]→
 [Enable]. After complete the setting, click [Save].

Main Page System Setting	Meter Amodule Setting Logg	ger Setting Advanced Setting	Rules Setting	4
Logger Setting Data Logge Setting				
Data Logger Setting	Power Data Logger	Setting		
Event Logger Scang	Function Status	⊡Enable		
FTP Upload Setting	Log Mode	Av rage 🗸		
	Column Header	□ A Id		
	User-Defined Data L	.ogger Setting		
	Function Status	□Enalle		
	Log Attribute Setting			
	Log Interval	1 minute V		
	File Name Format	YYYY-MM-DD.csv Y		
	End of Line Character	CRLF(Windows) V		
	Log File Retention Time	3 ✔ month(s)		
		Save)	

2) If the user wants to send the power data log files back to the FTP server at the control center automatically; please enable the function and complete the settings on the [FTP Upload Setting] page. After complete the setting, click [Save].

Logger Setting FTP Upload Setting		
Data Logger Setting	FTP Upload Setting I	Page
Event Lagger Setting	Function Status	⊡Enable
FTP Upload Setting	Remote FTP Server	*Address ftp:// 192.168.0.1 Port 21 *ID ICPDAS
		Password ••••• Path
	Remote FTP Server Setting Test	Send
	Data Log Upload Function	✓Upload Power Data Log Upload User-Defined Data Log Frequency Every 1 hour ✓
	Event Log Upload Function	Upload Event Log
		Save

 Save the settings to PMC-5151, the data logging function will be enabled. The system will start to save the power data in the MicroSD card by file format.



Power Meter Information

The Power Meter Information page shows detailed information of the specified power meter; the information including an overview of the power meter information and statistics information.

More detailed information is as below:

Power Meter Information Overview

When entering this page the system will read and display the real-time information of the power meter that is currently selected; select from the options of the power meter list to show the information of the desired power meter. This page will refresh every 20 seconds, the user can also click on the "Refresh" button to update the displayed values immediately. The Power Meter Information Overview page shows as follows:

Mann age 🌕 Power Meter Information	n						
Power Meter Information	Power Meter Informat	ion					
Power Data Information	Power Meter List Module-A09	▼ [Pump CH-A 🔻]			
Real-Time Chart		Overview	Statistics	Overview	Other	1//	
Historical Chart		Powe	r Meter Attribute	Overview	Other	1/ \	
Historical Data Report	No.	COM Port	Ado	dress	Module N	ame	
Historical Electricity Analysis	4	COM2		4	DM 422		
PUE Information		COIWZ	····· 1-6((4)	1	F IVI-4324		
O Information		Real-TI	me information(1)				
Event Log	F	hase A	Phase B	Phase C	Total / Averag		
Other Information	V	0.000	0.000	0.000	0.000		
Polling Time Information	I	0.000	0.000	0.000	0.0	0.000	
Modbus Table Information	kW	0.000	0.000	0.000	0.000		
UD Information	kvar	0.000	0.000	0.000	0.0	00	
	kVA	0.000	0.000	0.000	0.0	00	
	PF	0.000	0.000	0.000	0.0	00	
		Real-Tir	me Information(2)			🕽 Re	
	F	'hase A	Phase B	Phase C	Total / A	verag	
	kWh	0.078	0.085	0.085	0.2	47	

Statistics Information Overview

On the Statistics Overview page, the Demand Information Section will list information of Actual Demand, Forecast Demand, Contract Capacity, Hourly Maximum Demand, Daily Maximum Demand and Monthly Maximum Demand, etc.. The Statistics Information Section will list the Daily Accumulated Electricity, Monthly Accumulated Electricity, Yearly Accumulated Electricity and Daily Carbon Emission.

Main Page Neter Information	n									
Power Meter Information	Power Meter Information									
Power Data Information	Power Meter List Morule-A09	▼ Pu	Imp CH-A ▼							
Real-Time Chart		- Niow	Statistics Ov	erview	Other I/					
Historical Chart	Demand Information									
Historical Data Report		Phase A	Phase B	Phase C	Total / Ave					
Historical Electricity Analysis	15 Minutes Actual Demand(kW)	0.000	0.000	0.000	0.000					
PUE Information		0.000	0.000	0.000	0.000					
I/O Information	15 Minutes Forecast Demand(kW)	0.000	0.000	0.000	0.000					
Event Log	Contract Capacity(kW)	N/A	N/A	N/A	N/A					
Polling Time Information	Hourly Maximum Demand(kW)	0.000	0.000	0.000	0.000					
Modbus Table Information	Daily Maximum Demand(kW)	0.000	0.000	0.000	0.000					
UID Information	Monthly Maximum Demand(kW)	0.000	0.000	0.000	0.000					
		Statistic	s Information		🔁 Re					
		Phase A	Phase B	Phase C	Total / Ave					
	Daily Accu. Electricity(kWh)	0.000	0.000	0.000	0.000					
	Monthly Accu. Electricity(kWh)	0.000	0.000	0.000	0.000					
	Yearly Accu. Electricity(kWh)	0.000	0.000	0.000	0.000					
	Daily Carbon Emissions(KG)	0.000	0.000	0.000	0.000					

Reset Accumulated Value and Statistics Data of the Power Meter

After completing the settings of PMC-5151 and power meters, verify all settings are accurate and then reset the accumulated values and statistical data of the power meters to zero.

Accumulated Value: kWh, kvarh and kVAh

	Dowor Motor Inf	formation									
Power Meter Information	Power weter im	ormation									
Power Data Information	Power Meler List M	lodule-A09	Pump CH-A	T							
Real-Time Chart											
Historical Chart		Overview	V Statistic	cs Overview	Other I/C						
Historical Data Report	Power weter Attribute										
Historical Electricity	No.	COMPort	A	Address							
Analysis	1	COMP	1	PM-4324							
PUE Information		Real	Time Information	n(1)							
I/O Information		Phase A	Nhase B	Phase C	Total / Averag						
Event Log											
Other Information	v	0.000	0.000	0.000	0.000						
Polling Time Information	I.	0.000	0.000	0.000	0.000						
Modbus Table Information	kW	0.000	0.000	0.000	0.000						
UID Information	kvar	0.000	0.000	0.000	0.100						
	kVA	0.000	0.000	0.000	0.00						
	PF	0.000	0.000	0.000	0.000						
		Real-1	Time Information	(2)	C Res						
		Phase A	Phase B	Phase 0	Total / Average						
	kWh	0.078	0.085	0.085	0.247						
	kvarh	0.113	0.113	0.114	0.341						
	LAVAN	0.454	0.455	0.455	0.404						

Statistics Data: Daily/Monthly/Yearly Accumulated Electricity

Main Page System Setting	Meter / Module Setting Logger Set	ting ၞ ⊧			
Main Page Power Meter Informat	lion				
Power Meter Information	Power Meter Information				
Power Data Information	Power Meter List Module-A09	• P	ump CH-A 🔻		
Real-Time Chart				·	
Historical Chart	0	erview 0	Other I/O		
Historical Data Report		Deman			
Historical Electricity Analysis		Phase A	Phase B	Phase C	Total / Average
PUE Information	15 Minutes Actual Demand(kW)	0.000	0.000	0.000	0.000
I/O Information	15 Minutes Forecast Demand(kV	0.000	0.000	0.000	0.000
Event Log	Contract Capacity(kW)	N/A	N/A	N/A	N/A
Other Information	Llouth Mavimum Domand (kM)	0.000	0.000	0.000	0.000
Polling Time Information		0.000	0.000	0.000	0.000
Modbus Table Information	Daily Maximum Demand(kW)	0.000	0.000	0.000	0.000
UID Information	Monthly Maximum Demand(kW)	0.000	0.000	0.000	0.0.0
		Statistic	s Information		Reset
		Phase A	Phase B	Phare	Total / Average
	Daily Accu. Electricity(kWh)	0.000	0.000	0.000	0.000
	Monthly Accu. Electricity(kWh)	0.000	0.000	0.000	0.000

Note: Avoid Using IE 8.0 version of the Web Browser

All operations of PMC-5151 are performed on Web Browser, it uses a lot of Java Script syntax, therefore, whether the operations of PMC-5151 can be performed smoothly or not will depend on the effectiveness of Java Script execution on the Web Browser. For some PCs with Windows XP operation only have IE 8.0 Web Browser installed and unfortunately the IE 8.0 Web Browser is with low effectiveness, in this case, the operations on the webpage of PMC-5151 may get stuck, especially when performing historical chart inquiry.

By using IE 11, Google Chrome or Firefox, the operation of PMC-5151 functions can be performed smoothly. In general condition, it takes approximately **10 seconds** to query a historical chart with one-day data log information.



Trick: Login via FTP to access data logger file saved on the microSD card

In general condition, if the web browser operates smoothly, the user can open the historical chart to view the data of a specified date directly. The user can also login PMC-5151 via FTP to access the data logger file in the microSD card. The architecture of the data logger file in the microSD card is saved as: one power meter uses one folder; and for each day, there is one data logger file (yyyy-mm-dd.csv) and one daily report file (Yyyy-mm-dd**Rpt**.csv) being saved. The procedure is as follows:



There are two formats of the data logger file, with a header (Column Header) or without a header.



Without Column Header

X	🖌 🖬 🤊 - 🐑 - 😑 2015-08-11.csv [唯讀] - Microsoft Excel												5
杨	案 常用	插入)	反面配置	公式	資料	校開	檢視						>
	A	1	-	(*	f _x	2015/8/	11						\supset
													ź
	А	В		0	2		D	E	F	G	H	Ι	JĴ
1	2015/8/11	15:15:00	015B952	2617000	0C7_2	[3133]1	213.274	4.448	0.341	0.273	0.44	0.799	0.0
2	2015/8/11	15:20:00	015B952	2617000	0C7_2	[3133]1	213.179	5.295	0.378	0.345	0.519	0.699	0
3	2015/8/11	15:25:00	015B952	2617000	0C7_2	[3133]1	213.058	5.991	0.448	0.448	0.638	0.682	0.05
4	2015/8/11	15:30:00	015B952	2617000	007-2	31332	212.995		0.247	0.378	0.452	0.54	
1 2 3 4	2015/8/11 2015/8/11 2015/8/11 2015/8/11	15:15:00 15:20:00 15:25:00 15:30:00	015B952 015B952 015B952 015B952	2617000 2617000 2617000 2617000 2617000	0C7_2 0C7_2 0C7_2 0C7_2	(3133)1 (3133)1 (3133)1 (3133)1 (3133)1	213.274 213.179 213.058 212.995	4.448 5.295 5.991	0.341 0.378 0.448 0.247	0.273 0.345 0.448 0.378	0.44 0.519 0.638 0.452	0.799 0.699 0.682 0.54	V

With Column Header



After modifying the setting of [Header], the new setting will not take effect and will not apply to new data logger file until next day when a new data logger file is created. To make the setting take effect immediately, the user can delete the already existed logger file of that day; then the new header setting will be applied right away to the new generated data logger file. Note: the deleted data file will be lost forever!

Apendix: Document Revision History

Version	Date	Description
1.0.0	2015,Nov	Initial release.