

tGW-700-UL Series

User Manual

Tiny Modbus/TCP to RTU/ASCII Gateway Ver. 1.0, Jul. 2025



WARRANTY

All products manufactured by ICP DAS are warranted against defective materials for a period of one year from the date of delivery to the original purchaser.

WARNING

ICP DAS assumes no liability for damages consequent to the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

COPYRIGHT

Copyright © 2025 by ICP DAS. All rights are reserved.

TRADEMARKS

Names are used for identification purposes only and may be registered trademarks of their respective companies.

CONTACT US

If you have any questions, please feel free to contact us via email at:

service@icpdas.com

SUPPORT

This manual relates to the following modules:

tGW-715-UL, tGW-715i-UL,

tGW-715-UL-UTA,

tGW-715i-UL-UTA

tGW-718-UL, tGW-718i-UL

tGW-718-UL-UTA,

tGW-718i-UL-UTA



TABLE OF CONTENTS

PACKING LIST	- 1 -
SAFETY INSTRUCTIONS CONSIGNS	- 2 -
MORE INFORMATION	- 3 -
1. INTRODUCTION	- 4 -
1.1 FEATURES	- 6 -
1.2 APPLICATIONS	- 6 -
1.3 ETHERNET SOLUTIONS	- 7 -
1.4 WEB SERVER TECHNOLOGY	- 8 -
2. HARDWARE INFORMATION	- 9 -
2.1 SPECIFICATIONS	- 9 -
2.2 APPEARANCE	- 10 -
<i>PoE and Ethernet RJ-45 Jack</i>	<i>- 10 -</i>
<i>+12 to +48 VDC Jack</i>	<i>- 10 -</i>
<i>Operating Mode Switch</i>	<i>- 11 -</i>
<i>LED Indicator</i>	<i>- 11 -</i>
<i>Serial COM Ports</i>	<i>- 11 -</i>
<i>DIN-Rail Mounting</i>	<i>- 12 -</i>
2.3 DIMENSIONS	- 13 -
<i>tGW-700 Series Module (Unit: mm)</i>	<i>- 13 -</i>
<i>CA-002-UL Cable (Unit: mm)</i>	<i>- 14 -</i>
2.4 PIN ASSIGNMENTS	- 15 -
<i>tGW-715-UL Series</i>	<i>- 15 -</i>
<i>tGW-718-UL Series</i>	<i>- 15 -</i>
2.5 WIRING NOTES FOR RS-232/485/422 INTERFACES	- 16 -
<i>RS-232 Wiring</i>	<i>- 16 -</i>
<i>RS-422 Wiring</i>	<i>- 16 -</i>
<i>RS-485 Wiring</i>	<i>- 17 -</i>
3. GETTING STARTED (FOR IPV4)	- 18 -
3.1 CONNECTING THE POWER AND HOST PC	- 18 -
3.2 CONFIGURING NETWORK SETTINGS	- 21 -
3.3 CONNECTING THE MODBUS DEVICES	- 23 -
3.4 CONFIGURING THE SERIAL PORT	- 24 -
3.5 SELF-TEST	- 26 -

4.	GETTING STARTED (FOR IPV6)	- 27 -
4.1	CONNECTING THE POWER AND HOST PC	- 27 -
4.2	CONFIGURING NETWORK SETTINGS	- 30 -
4.3	CONNECTING THE MODBUS DEVICES	- 32 -
4.4	CONFIGURING THE SERIAL PORT	- 33 -
4.5	SELF-TEST	- 36 -
5.	WEB CONFIGURATION	- 38 -
5.1	LOGGING IN TO THE TGW-700-UL WEB SERVER	- 38 -
5.2	HOME PAGE	- 40 -
5.3	NETWORK PAGE	- 41 -
5.3.1	IP Address Selection	- 41 -
5.3.2	General Settings	- 45 -
5.3.3	Modbus Settings	- 46 -
5.3.4	Restore Factory Defaults	- 48 -
5.3.5	Update by Ethernet	- 50 -
5.4	SERIAL PORT PAGE	- 51 -
5.4.1	Settings (Port1 Settings)	- 51 -
5.4.2	Settings (Pair-Connection Settings)	- 54 -
5.5	FILTER PAGE	- 55 -
5.6	SNMP PAGE	- 56 -
5.6.1	SNMP Configuration Setting	- 57 -
5.6.2	SNMP I/O Example	- 59 -
5.6.3	SNMP Trap Example	- 62 -
5.6.4	SNMP Troubleshooting	- 64 -
5.7	MONITOR PAGE	- 66 -
5.8	PASSWORD PAGE	- 67 -
5.9	LOGOUT PAGE	- 68 -
6.	TYPICAL APPLICATIONS	- 69 -
6.1	MODBUS GATEWAY	- 70 -
6.2	MODBUS NET ID	- 71 -
6.3	PAIR-CONNECTION APPLICATIONS	- 72 -
6.4	TCP CLIENT MODE APPLICATIONS	- 80 -
7.	MODBUS INFORMATION	- 85 -
7.1	MODBUS MESSAGE STRUCTURE	- 85 -
	01(0x01) Read the Status of the Coils (Readback DOs)	- 88 -
	02(0x02) Read the Status of the Input (Read DIs)	- 89 -

03(0x03) Read the Holding Registers (Readback AOs)	- 90 -
04(0x04) Read the Input Registers (Read AIs)	- 91 -
05(0x05) Force a Single Coil (Write DO)	- 92 -
06(0x06) Preset a Single Register (Write AO)	- 93 -
15(0x0F) Force Multiple Coils (Write DOs)	- 94 -
16(0x10) Preset Multiple Registers (Write AOs)	- 95 -
7.2 EXCEPTION CODES	- 96 -
APPENDIX A: TROUBLESHOOTING	- 98 -
A1. HOW DO I RESTORE THE WEB PASSWORD FOR THE MODULE TO THE FACTORY DEFAULT PASSWORD?	- 98 -
APPENDIX B: GLOSSARY	- 100 -
1. ARP (ADDRESS RESOLUTION PROTOCOL)	- 100 -
2. CLIENTS AND SERVERS	- 100 -
3. ETHERNET	- 101 -
4. FIRMWARE	- 101 -
5. GATEWAY	- 101 -
6. ICMP (INTERNET CONTROL MESSAGE PROTOCOL)	- 101 -
7. INTERNET	- 101 -
8. IP (INTERNET PROTOCOL) ADDRESS	- 102 -
9. MAC (MEDIA ACCESS CONTROL) ADDRESS	- 102 -
10. PACKET	- 102 -
11. PING	- 102 -
12. RARP (REVERSE ADDRESS RESOLUTION PROTOCOL)	- 102 -
13. SOCKET	- 103 -
14. SUBNET MASK	- 103 -
15. TCP (TRANSMISSION CONTROL PROTOCOL)	- 103 -
16. TCP/IP	- 103 -
17. UDP (USER DATAGRAM PROTOCOL)	- 103 -
APPENDIX C: ACTUAL BAUD RATE MEASUREMENT	- 104 -
APPENDIX D: REVISION HISTORY	- 105 -

Packing List

The tGW-700-UL shipping package includes the following items:



tGW-700-UL Series



Quick Start



CA-002-UL Cable

Note

If any of these items are missing or damaged, please contact the local distributor for more information. Save the shipping materials and cartons in case you need to ship the module in the future.



Safety Instructions Consigns

To prevent possible electrical shock, fire, or personal injury and for safe operation of the product:



1. Power Supply

- Use only with the voltage and frequency specified on the product label.



2. Important Notes on Operating Environment

- Disconnect the power and network cables during thunderstorms to prevent damage.
- Do not use the product around explosive gas, vapor, or in damp or wet environments.



3. Ventilation and Cooling

- Do not block ventilation openings; ensure adequate space around the device for heat dissipation.



4. Avoid Liquid Contact

- This product is not waterproof; keep it away from liquids and humid environments.



5. Maintenance and Service

- Do not attempt to disassemble or repair the device.
- Do not use the product if it is damaged or operates incorrectly. Contact service centers.



6. Warranty Limitation

- Damages resulting from failure to follow safety instructions are not covered under warranty.
- This product is covered by a limited warranty according to the ICP DAS official warranty policy.

Contact Information

Website: <https://www.icpdas.com/>

Email: service@icpdas.com

Phone: +886-(03)-597 3366

Address: No. 111, Guangfu N. Rd., Hukou Township, Hsinchu County 30351, Taiwan, R.O.C.

More Information

- **Documentation**

tGW-700-UL Series

<https://www.icpdas.com/en/download/index.php?model=tGW-718-UL series>

- **Firmware**

tGW-700-UL Series

<https://www.icpdas.com/en/download/show.php?num=2417>

- **Software**

EtherDOT

<https://www.icpdas.com/tw/download/index.php?nation=TW&kind1=&model=&kw=EtherDOT>


eSearch Utility

https://www.icpdas.com/en/product/guide+Software+Utility_Driver+eSearch_Utility

Modbus Utility


https://www.icpdas.com/en/product/guide+Software+Development_Tools+Modbus_Tool#676

1. Introduction



Modbus has become the de facto standard protocol for industrial communication, and is now the most commonly available means of connecting industrial electronic devices. Modbus allows for communication between many devices connected to the same RS-485 network, for example, a system that measures temperature and humidity and communicates the results to a computer. Modbus is often used to connect a supervisory computer with a remote terminal unit (RTU) in supervisory control and data acquisition (SCADA) systems.

The tGW-700-UL module is a Modbus TCP/UDP to RTU/ASCII gateway that enables a Modbus TCP/UDP host to communicate with serial Modbus RTU/ASCII devices through an Ethernet network, and eliminates the inherent cable length limitations of legacy serial communication devices. The module can be used to create pair-connection applications (as well as serial-bridge or serial-tunnel applications), and can then route data over a TCP/IP connection between two serial Modbus RTU/ASCII devices, which is useful when connecting mainframe computers, servers or other serial devices that use Modbus RTU/ASCII protocols and do not themselves have Ethernet capability. And the tGW-700-UL adopts the dual-stack technology to support the IPv4 and IPv6 simultaneously (version 2.2.0 or later).



In harsh industrial environments, the tGW-700-UL series (for i version) also adds 3000 V_{DC} and +/- 4 kV ESD protection component that diverts the potentially damaging charge away from sensitive circuit to protect the module and equipment from the sudden and momentary electric current.

The tGW-700-UL module features a powerful 32-bit MCU that enables efficient handling of network traffic, and also has a built-in web server that provides an intuitive web management interface that allows users to modify the configuration of the module, including the DHCP/Static IP, the gateway/mask settings and the serial port settings.



The tGW-700-UL module offers true IEEE 802.3af-compliant (classification, Class 1) Power over Ethernet (PoE) functionality using a standard Category 5 Ethernet cable to receive power from a PoE switch, such as the NS-205PSE. If there is no PoE switch on site, the module will also accept power input from a DC adapter. The tGW-700-UL module is designed for ultra-low power consumption, reducing the hidden costs resulting from increasing fuel and electricity prices, especially when a large number of modules are installed. Reducing the amount of electricity consumed by choosing energy-efficient equipment can also have a positive impact on maintaining a green environment.


The tGW-700-UL series modules have obtained UL certification, meeting strict safety standards including fire resistance, electric shock protection, and durability requirements. This ensures stability and safety across various usage environments, providing consumers with reliable quality assurance. The UTA version uses conformal coating technology that offers excellent resistance to moisture and salt spray, making it particularly suitable for coastal and high-humidity environments.

1.1 Features

- Supports Modbus TCP/UDP master and slave
- Supports Modbus RTU/ASCII master and slave
- Max. connections (masters) per serial port: 32
- Read-cache ensures faster Modbus TCP/UDP response
- Supports UDP responder for device discovery (UDP Search)
- Static IP or DHCP network configuration for IPv4
- Link-local Address and SLAAC(Stateless address auto-configuration) for IPv6
- Supports IPv4 and IPv6 simultaneously with dual-stack
- Easy firmware update via the Ethernet (BOOTP, TFTP)
- Tiny Web server for configuration (HTTP)
- Contains a 32-bit MCU that efficiently handles network traffic
- 10/100 Base-TX Ethernet, RJ-45 x1 (Auto-negotiating, auto MDI/MDIX, LED Indicators)
- Includes redundant power inputs: PoE (IEEE 802.3af, Class 1) and DC jack
- Allows automatic RS-485 direction control
- Signal isolation for i versions
- +/- 4 kV ESD protection
- Terminal block connector for easy wiring
- Tiny form-factor and low power consumption
- RoHS compliant with no Halogen
- Cost-effective Modbus Gateway

1.2 Applications

- Factory Automation
- Building Automation
- Home Automation
- Remote Diagnosis and Management




1.3 Ethernet Solutions

Nowadays, the Ethernet protocol has become the foremost standard for local area networks. Connectivity via the Internet snow common in many of the latest applications from home appliances, to vending machines, to testing equipment, to UPS, etc. An Ethernet network can link office automation and industrial control networks, access remote systems and share data and information between machines from multiple vendors, and also provides a cost-effective solution for industrial control networks.



1.4 Web Server Technology

Web server technology enables the tGW-700-UL to be configured via a standard web browser interface, e.g., Google Chrome, Internet Explorer, or Firefox, etc. This means that it is easy to check the configuration of the tGW-700-UL via an Ethernet network without needing to install any other software tools, thereby reducing the learning curve required for maintaining the device.



The screenshot shows the Tiny Modbus Gateway web interface in a browser window. The address bar shows 10.0.8.100. The page title is "Tiny Modbus Gateway" with the ICP DAS logo. Navigation links include Home, Port1, Network, Filter, SNMP, Monitor, Password, and Logout. The configuration is displayed in two columns of tables.

Model Name	tGW-718i-D_RevB	Alias Name	Tiny
Firmware Version	B2.3.9 [Jul.11 2023]	MAC Address	00-0d-e0-f7-18-d0
IP Address	10.0.8.100	TCP Port Timeout (Socket Watchdog, Seconds)	180
Initial Switch	OFF	System Idle (Network Watchdog, Seconds)	300

Current port settings:

Interface Settings		Port 1
Interface		RS-232
Pull-High/Low Resister		-
Terminal Resister		-

Port Settings		Port 1
Baud Rate (bps)		115200,8N1
Flow Control		None
Protocol		RTU
Slave Timeout (ms)		300
Char Timeout (bytes)		4
Silent Time (ms)		0
Read Cache (ms)		980
Connection Idle (Seconds)		180
Local TCP Port		502
Virtual ID Range		0-247
Virtual ID Offset		0

Pair-Connection Settings (Master/Slave Mode)		Port 1
Application Mode		TCP/UDP Server
Remote Server IP		-
Remote TCP Port		-

Copyright © 2023 ICP DAS Co., Ltd. All rights reserved.


2. Hardware Information

This chapter provides a detailed description of the front panel, the hardware specifications, the pin assignments, the wiring notes and the dimensions for the tGW-700-UL series modules.

2.1 Specifications

Model		tGW-715-UL tGW-715i-UL	tGW-715-UL-UTA tGW-715i-UL-UTA	tGW-718-UL tGW-718i-UL	tGW-718-UL-UTA tGW-718i-UL-UTA
Communication Interface					
Ethernet		10/100 Base-TX, 8-pin RJ-45 x 1, (Auto-negotiating, Auto-MDI/MDIX, LED indicator)			
PoE		IEEE 802.3af, Class 1			
COM Port		1 x RS-422/RS-485		1 x RS-232/422/485	
RS-485	Bias Resistor	Yes, 1 KΩ			
	Node	254 (max.)			
UART		16c550 or compatible			
Signal Isolation		3000 V _{DC} for only tGW-715i-UL / tGW-715i-UL-UTA / tGW-718i-UL / tGW-718i-UL-UTA			
COM Port Format					
Baud Rate		115200 bps Max.			
Data Bit		5, 6, 7, 8			
Parity		None, Odd, Even, Mark, Space			
Stop Bit		1, 2			
Power					
Power Consumption		0.07 A @ 24 V _{DC}			
Powered from PoE		IEEE 802.3af, Class 1			
Powered from DC Jack		+12 ~ 48 V _{DC}			
Mechanism					
Connector		10-Pin Removable Terminal Block			
Dimensions (W x L x H)		52 mm x 27 mm x 95 mm			
Installation		DIN-Rail Mounting			
Casing		Plastic			
Environment					
Operating Temperature		-25 ~ +75 °C	-40 ~ +75 °C	-25 ~ +75 °C	-40 ~ +75 °C
Storage Temperature		-30 ~ +80 °C			
Humidity		10 ~ 90% RH, non-condensing			

2.2 Appearance



PoE and Ethernet RJ-45 Jack


The tGW-700-UL module is equipped with an RJ-45 jack that is used as the 10/100 Base-TX Ethernet port and features networking capabilities, supports PoE power supply. When an Ethernet link is detected and an Ethernet packet is received, the **Link/Act LED (Orange)** indicator will be illuminated. When power is supplied via PoE (Power-over-Ethernet), the **PoE LED (Green)** indicator will be illuminated.

+12 to +48 V_{DC} Jack


The tGW-700-UL is equipped with a +12V_{DC} to +48 V_{DC} jack that can be used to connect a power supply. If no PoE switch is available on site, a DC adapter can be used to power the tGW-700-UL module.

Operating Mode Switch

Run Mode: Firmware operation



Init Mode: Configuration mode



For tGW-700-UL series modules, the operating mode switch is in the **Run** position by default. In order to update the firmware for the tGW-700-UL series module, the switch must be moved from the **Run** position to the **Init** position. The switch must be returned to the Run position after the update is complete.

LED Indicator

Once power is supplied to the tGW-700-UL series module, the system LED indicator will illuminate. An overview of the system LED functions is given below:

Function	Color	S1 LED Behavior
Running Firmware		Steady ON
Network Ready	Red	Slow flashing – Once every 3 seconds
Serial Port Busy		Rapid flashing – Once every 0.2 seconds




Serial COM Ports


The number of serial COM Ports available depends on the type of tGW-700-UL module. For more detailed information regarding the pin assignments for the Serial COM ports, refer to [Section 2.4 Pin Assignments](#).

DIN-Rail Mounting


The tGW-700-UL series modules include simple rail clips on the bottom of the chassis that allow them to be reliably mounted on a DIN-Rail or a wall. For more detailed information regarding DIN-Rail Mounting, refer to the illustration in figure below.



Mounting on a DIN-Rail




Dismounting from a DIN-Rail



2.3 Dimensions

The following diagrams provide the dimensions of the tGW-700-UL series module and CA-002-UL cable that can be used as a reference when defining the specifications and the DC power supply plug for any custom enclosures. All dimensions are in millimeters.

tGW-700-UL Series Module (Unit: mm)



2.4 Pin Assignments

tGW-715-UL Series


		tGW-715-UL/tGW-715-UL-UTA		tGW-715i-UL/tGW-715i-UL-UTA	
Terminal No.		Pin Assignment			
		RS-485	RS-422	RS-485	RS-422
	10	F.G.		F.G.	
	09	N/A		N/A	
	08	N/A		N/A	
	07	N/A		N/A	
	06	N/A		N/A	
COM1	05	GND		ISO.GND	
	04	N/A	Rx1-	N/A	Rx1-
	03	N/A	Rx1+	N/A	Rx1+
	02	D1-	Tx1-	D1-	Tx1-
	01	D1+	Tx1+	D1+	Tx1+

tGW-718-UL Series


		tGW-718-UL/tGW-718-UL-UTA		tGW-718i-UL/tGW-718i-UL-UTA	
Terminal No.		Pin Assignment			
	10	F.G.		F.G.	
	09	N/A		N/A	
RS-232	08	GND		ISO.GND	
	07	RxD1		RxD1	
	06	TxD1		TxD1	
RS-485/RS-422	05	GND		ISO.GND	
	04	N/A	Rx1-	N/A	Rx1-
	03	N/A	Rx1+	N/A	Rx1+
	02	D1-	Tx1-	D1-	Tx1-
	01	D1+	Tx1+	D1+	Tx1+

2.5 Wiring Notes for RS-232/485/422 Interfaces


RS-232 Wiring



RS-422 Wiring



RS-485 Wiring



Notes:

1. Usually, you have to connect all signal grounds of RS-422/485 devices together to reduce common-mode voltage between devices.
2. The D+/D- (or Data+/Data-) wiring of RS-485 must use twisted pair cables.
3. Termination resistors (typically 120Ω) may be required at both ends of the wiring, connected across the D+ and D- lines.
4. The D+ and B pins are positive-voltage pins, and D- and A pins are negative-voltage pins in the above figure. The B/A pins may be defined in another way depending on *your* devices, please check it first.


3. Getting Started (for IPv4)

This chapter provides detailed information about the “Self-Test” process, which is used to confirm that the tGW-700-UL series module is operating correctly. Before beginning the “Self-Test” process, the wiring test, Ethernet configuration and search/Modbus utility driver installation procedures must first be fully completed. Follow the procedure described below:

Note: This chapter is based on IPv4 environment.


3.1 Connecting the Power and Host PC

1. Ensure that the network settings on your PC are configured correctly.
Ensure that the Windows firewall or any Anti-Virus firewall software is correctly configured or temporarily disable these functions; otherwise the “**Search Servers**” function in the eSearch Utility may not work as required. You may need to contact your System Administrator for more details of how to do this.
2. Check that the **Init/Run switch** is in the “**Run**” position.




3. Connect both the tGW-700-UL and the Host computer to the same sub-network or the same Ethernet Switch, and then supply power (PoE or +12 to +48 Vdc) to the tGW-700-UL.


PoE Power Supply



+12 to +48 Vdc Jack Power Supply (Non-PoE)



4. Verify that the System (S1) LED indicator is flashing.



3.2 Configuring Network Settings


1. Download the **eSearch Utility** and install it according to the installation instructions.

The eSearch Utility can be obtained from the ICP DAS web site.
The location of the download link is shown below:



 https://www.icpdas.com/en/product/guide+Software+Utility_Driver+eSearch_Utility

2. Double click the **eSearch Utility** shortcut on the desktop.
3. Click the **“Search Servers”** button to search your tGW-700-UL.
4. Once the search process is complete, double-click on the module name to open the **“Configure Server”** dialog box.



Factory Default Settings of tGW-700-UL Series Module:

IPv4 settings		Writable
IP Address	192.168.255.1	✓
Subnet Mask	255.255.0.0	✓
Gateway	192.168.0.1	✓
IPv6 settings		Writable
User-defined	fc00::1	✓
Link-Local	EUI-64 format	✗
SLAAC	Auto-Configure	✗

5. Enter the network settings information, including the **IP, Mask, Gateway addresses**, and then click “**OK**” button. The new settings for the tGW-700-UL will take effect within 2 seconds. If you don’t know the correct network configuration information, contact your Network Administrator to obtain the details.


Note: The DHCP feature is only valid on IPv4.

6. Wait 2 seconds and click “**Search Servers**” button again to ensure the tGW-700-UL is working well with new configuration.

3.3 Connecting the Modbus Devices


Note: The wiring and supply power method vary depending on your Modbus device. Here, the M-7022 module is used as an example. For other Modbus device or third party Modbus device, refer to the product user manual for relevant information.

Connect the tGW-700-UL with Modbus device (e.g., M-7022, optional) and supply power (+10 to +30 V_{DC}) to the Modbus device. For more detailed information related to wiring options for RS-232/422/485, refer to [Section 2.5 “Wiring Notes for RS-232/485/422 Interfaces”](#).




3.4 Configuring the Serial Port


1. Open a web browser, such as Google Chrome, Internet Explorer, or Firefox, enter the IP address of the tGW-700-UL module in the address bar and then click “Enter”, or click the “Web” button in the eSearch Utility.
2. To enhance the security, you are prompted to change the password when you login to the module for the first time. Enter the default password: **admin** in the **Current password** field, and enter your new password in the **New password** and **Confirm new password** fields, then click the “Submit” button.



3. Enter the new password in the **Login password** field, and then click the “Submit” button to enter the configuration web page.



- Click the **"Port1"** tab to display the Port1 Settings page.



- Select the appropriate Baud Rate, Data Format and Modbus Protocol (e.g., 19200, 8N2 and Modbus RTU) from the relevant drop down options.

Notes:

- The Baud Rate, Data Format and Modbus protocol settings depends on your Modbus device.
- Only one protocol can be used for each serial port.


- Click **"Submit"** to save your settings.

Port Settings	Current	Updated	Comment
Baud Rate (bps)	115200	19200 ▼	bits/second
Data Size (bits)	8	8 ▼	bits/character
Parity	None	None ▼	
Stop Bits (bits)	1	2 ▼	
Flow Control	None	None ▼	
Timeout (ms)	300	300	Default: 300

Pair-Connection Settings (Master/Slave Mode)	Current	Updated	Comment
Read Cache (ms)	980	980	10, 20... 65530, Disable: 0
Local TCP Port	502	502	Default: 502
Connction Idle (seconds)	180	180	1 ~ 65535, Default: 180, Disable: 0
Protocol	Modbus RTU	Modbus RTU ▼	
Application Mode	Server	Server ▼	Server=Slave, Client=Master


3.5 Self-Test

1. In the eSearch Utility, select the **“Modbus TCP Master”** item from the **“Tools”** menu to open the Modbus TCP Master Utility.



2. In the Modbus TCP Master Utility, enter the **IP address of tGW-700-UL** in the **“Modbus TCP”** section, and then click the **“Connect”** button to connect to the tGW-700-UL.
3. Refer to **“Protocol Description”** section and type the Modbus command in the **“Command”** field then click the **“Send command”** button.
4. If the response data is correct, it means the test is success.

Note: The Modbus command settings depends on your Modbus device.




4. Getting Started (for IPv6)

This chapter provides detailed information about the “Self-Test” process, which is used to confirm that the tGW-700-UL series module is operating correctly. Before beginning the “Self-Test” process, the wiring test, Ethernet configuration and search/Modbus utility driver installation procedures must first be fully completed. Follow the procedure described below:

Note: This chapter is based on IPv6 environment.


4.1 Connecting the Power and Host PC

1. Ensure that the network settings on your PC are configured correctly.
Ensure that the Windows firewall or any Anti-Virus firewall software is correctly configured or temporarily disable these functions; otherwise the “**Search Servers**” function in the eSearch Utility may not work as required. You may need to contact your System Administrator for more details of how to do this.
2. Check that the **Init/Run switch** is in the “**Run**” position.




3. Connect both the tGW-700-UL and the Host computer to the same sub-network or the same Ethernet Switch, and then supply power (PoE or +12 to +48 Vdc) to the tGW-700-UL.


PoE Power Supply



+12 to +48 Vdc Jack Power Supply (Non-PoE)



4. Verify that the System (S1) LED indicator is flashing.



4.2 Configuring Network Settings


1. Download the **eSearch Utility** and install it according to the installation instructions.



The eSearch Utility can be obtained from the link below:

 https://www.icpdas.com/en/product/guide+Software+Utility_Driver+eSearch_Utility

2. Double click the **eSearch Utility** shortcut on the desktop.
3. Click the **“Search Servers”** button to search your tGW-700-UL.



4. Every IPv6 device has the Link-Local address. You can view the Link-Local address of the tGW-700-UL module in the “Link-Local” field without configuring. If your environment supports Stateless Address Auto-configuration (SLAAC), the SLAAC field will display the SLAAC address when the SLAAC configuration is completed. You can click the “**Search Servers**” button again to update the state.


Factory Default Settings of tGW-700-UL Series Module:

IPv4 settings		Writable
IP Address	192.168.255.1	✓
Subnet Mask	255.255.0.0	✓
Gateway	192.168.0.1	✓
IPv6 settings		Writable
User-defined	fc00::1	✓
Link-Local	EUI-64 format	✗
SLAAC	Auto-Configure	✗

4.3 Connecting the Modbus Devices

Note: The wiring and supply power method vary depending on your Modbus device. Here, the M-7022 module is used as an example. For other Modbus device or third party Modbus device, refer to the product user manual for relevant information.


Connect the tGW-700-UL with Modbus device (e.g., M-7022, optional) and supply power (+10 to +30 V_{DC}) to the Modbus device. For more detailed information related to wiring options for RS-232/422/485, refer to [Section 2.5 “Wiring Notes for RS-232/485/422 Interfaces”](#).



4.4 Configuring the Serial Port

1. Right Click on the Link-Local field and click the **“Copy to Clipboard”** to copy the **“Link-Local address”** of the tGW-700-UL module.
2. Paste the **“Link-Local address”** of the tGW-700-UL module in the address bar of the browser and add the brackets, i.e., [Link-Local address].

Note: The Web button use the IPv4 address to access the Web Server, not IPv6 address.



- To enhance the security, you are prompted to change the password when you login to the module for the first time. Enter the default password: **admin** in the **Current password** field, and enter your new password in the **New password** and **Confirm new password** fields, then click the **“Submit”** button.

Tiny Gateway

[fe80::20d:e0ff:fe80:13]/

ICP DAS Tiny Modbus Gateway

[Home](#) | [Port1](#) | [Network](#) | [Filter](#) | [SNMP](#) | [Monitor](#) | [Password](#) | [Logout](#)

Change Password
The length of the password is 12 characters maximum.

Current password:
New password:
Confirm new password:

Submit

3

admin
New password

- Enter the new password in the **Login password** field, and then click the **“Submit”** button to enter the configuration web page.

ICP DAS Tiny Modbus Gateway

[Home](#) | [Port1](#) | [Network](#) | [Filter](#) | [SNMP](#) | [Monitor](#) | [Password](#) | [Logout](#)

The system is logged out.
To enter the web configuration, please type password in the following field.

Login password:
Submit

4

- Click the **"Port1"** tab to display the Port1 Settings page.



- Select the appropriate Baud Rate, Data Format and Modbus Protocol (e.g., 19200, 8N2 and Modbus RTU) from the relevant drop down options.

Notes:

- The Baud Rate, Data Format and Modbus protocol settings depends on your Modbus device.
- Only one protocol can be used for each serial port.

Port Settings	Current	Updated	Comment
Baud Rate	115200	19200 (select)	bps: bits/second
Data Size	8	8	bits/char
Parity	None	None	
Stop Bits	1	2	
Flow Control	None	None	
Remove Errors	FE BE	☐ Parity Error ☒ Framing Error ☒ Break Error	Clear RX FIFO data when serial errors.

Modbus Settings	Current	Updated	Comment
Slave Timeout	300	300	10 - 65000 ms (step 10), Default: 300
Char Timeout	4	4	4 - 15 bytes, Default: 4
Silent Time	0	0	0 - 65000 ms (step 10), Default: 0
Protocol	Modbus RTU	Modbus RTU	
Virtual ID Range	1 - 247	1 to 247	Range: 1 to 247. Note: Gateway skips the Modbus messages if its ID is NOT in the specified range.
ID Offset	0		Offset: -246 to 246, No change=0. For example: Slave ID 1, offset 10, offset=10, then the Slave ID is 11.

- Click **"Submit"** to save your settings.


Pair-Connection Settings (Master/Slave Mode)	Current	Updated	Comment
Application Mode	Server	Server	Server=Slave, Client=Master

4.5 Self-Test

1. Download and install the “Modbus Poll” test program at below link.

<https://www.modbustools.com/download.html>


2. Double-click the Modbus Poll shortcut to open.




3. Select the “Read/Write Definition...” item from the “Setup” menu to open the “Read/Write Definition” dialog box.

4. Configure the settings for the Slave.


Note: The Modbus Slave settings depends on your Modbus device.



5. Select the “Connect...” item from the “Connection” menu to open the “Connection Setup” dialog box.
6. Configure the IPv6 address and TCP port (default: 502) of tGW-700-UL and click “OK” to connect the tGW-700-UL for testing.



7. If the response data is correct, it means the test is success.



5. Web Configuration

Once the tGW-700-UL series module has been correctly configured and is functioning normally on the network, the configuration details can be retrieved or modified using either the eSearch Utility described above, or via a standard web browser.

5.1 Logging in to the tGW-700-UL Web Server


The embedded tGW-700-UL series web server can be accessed from any computer that has an Internet connection.

Step 1: Open a new browser window

Open a web browser, for example, Google Chrome, Firefox or Internet Explorer, which are reliable and popular Internet browsers that can be used to configure tGW-700-UL series module.


Step 2: Enter the URL for the tGW-700-UL web server

Ensure that you have correctly configured the network settings for the tGW-700-UL series module (refer to [Chapter 3 “Getting Started \(for IPv4\)”](#), [Chapter 4 “Getting Started \(for IPv6\)”](#) for detailed instructions), and then enter the URL for the tGW-700-UL web server in the address bar of the browser.



Step 3: Enter the Password

After connecting to the IP address, the login page is displayed. Enter your password in the **Login password** field, and then click the “**Submit**” button to continue. (If this is the first time you login, refer to [Section 3.4](#) to change the factory default password.)



ICP DAS Tiny Modbus Gateway


[Home](#) | [Port1](#) | [Network](#) | [Filter](#) | [SNMP](#) | [Monitor](#) | [Password](#) | [Logout](#)

The system is logged out.
To enter the web configuration, please type password in the following field.

Login password

Step 4: Log in to the tGW-700-UL Web Server

After logging into the tGW-700-UL web server, the main page will be displayed.



ICP DAS Tiny Modbus Gateway

[Home](#) | [Port1](#) | [Network](#) | [Filter](#) | [SNMP](#) | [Monitor](#) | [Password](#) | [Logout](#)

Model Name	tGW-718i-D_RevB	Alias Name	Tiny
Firmware Version	B2.3.9 [Jul.11 2023]	MAC Address	00-0d-e0-f7-18-d0
IP Address	10.0.8.100	TCP Port Timeout (Socket Watchdog, Seconds)	180
Initial Switch	OFF	System Idle (Network Watchdog, Seconds)	300

Current port settings:

Interface Settings		Port 1
Interface		RS-232
Pull-High/Low Resister		-
Terminal Resister		-
Port Settings		Port 1
Baud Rate (bps)		115200,8N1

5.2 Home Page

The **Home** link connects to the main page, which contains two parts.



The first part of this page provides basic information about the tGW-700-UL hardware and software. The software and hardware information section includes information related to the Model Name, the current Firmware version, the IP Address, the current position of the Initial Switch, the Alias, the MAC Address, and the TCP Port, and the System Timeout values. **If the firmware for the tGW-700-UL module is updated, you can check the version information here.**


Model Name	tGW-718i-D_RevB	Alias Name	Tiny
Firmware Version	B1.6.1 [Oct.23 2017]	MAC Address	00-0d-e0-71-8d-01
IP Address	10.0.8.100	TCP Port Timeout (Socket Watchdog, Seconds)	180
Initial Switch	OFF	System Idle (Network Watchdog, Seconds)	300

The lower section provides information related to the port settings and pair-connection settings.

Current port settings:

Port Settings	Port 1
Baud Rate (bps)	115200,8N1
Flow Control	None
Allow Driver Control	Enable
Local TCP Port	10001
Connexion Idle (Seconds)	180
Prefix String	N/A
Serial Data Packing	Port 1
Slave Timeout (ms)	1000
Packing Length (bytes)	0
Serial Ending Chars (Number[,char1][,char2])	0
Timeout Between Chars (ms)	10
Pair-Connection Settings (Client/Server Mode)	Port 1
Application Mode	Server
Remote Server IP	Disable
Remote TCP Port	Disable

5.3 Network Page



After clicking the **Network** tab, the **Network** page will be displayed, allowing you to verify the current settings, configure the IP Address, and the general parameters, and restore the default settings for the tGW-700-UL module, each of which will be described in more detail below.

5.3.1 IP Address Selection

The **Address Type**, **Static IPv4 Address**, **Subnet Mask** and **Default Gateway** values are the most important network settings and should always correspond to the LAN configuration. If they do not match, the tGW-700-UL module will not operate correctly in IPv4.

The **IPv6 Link Local Address** always effective in the same link layer. The **IPv6 SLAAC Address** will be configured by the Router automatically, and the default router is the link-local address of the router. The **IPv6 User-defined Address** can be defined by the User. It's more convenient for using in the simple application. The **IPv6 User-defined Address** can be routed if its prefix as same as **IPv6 SLAAC Address**.

If the settings are changed while the module is operating, any connection currently in use will be lost and an error will occur. If your environment doesn't support the IPv6, please ignore the **IPv6 Address** fields.

IP Address Selection

Address Type	Static IP		
Static IPv4 Address	192	168	1
Subnet Mask	255	255	0
Default Gateway	192	168	1
MAC Address	00-0d-e0-80-00-13 (Format: FF-FF-FF-FF-FF-FF)		
IPv6 Link Local Address	fe80:0:0:20d:e0ff:fe80:13		
IPv6 SLAAC Address	2003:aaaa:bbbb:cccc:20d:e0ff:fe80:13		
SLAAC Timeout (SLAAC Watchdog)	0 (30 ~ 65535 seconds, Default: 0, Disable: 0)		
IPv6 User-defined Address	fc00:0:0:0:0:0:1		
Update Settings			

The following is an overview of the parameters contained in the **IP Address Selection** section:

Item	Description
Address Type	Static IP: If no DHCP server is installed on the network, the network settings can be configured manually. Refer to Section “Manual Configuration” for more details.
	DHCP: The Dynamic Host Configuration Protocol (DHCP) is a network application protocol that automatically assigns an IPv4 address to each device. Refer to Section “Dynamic Configuration” for more details.
	Note: The DHCP function doesn't effective on IPv6.
Static IPv4 Address	Each tGW-700-UL connected to the network must have its own unique IP address. This parameter is used to assign a specific IPv4 address.
Subnet Mask	This parameter is used to assign the subnet mask for the tGW-700-UL. The subnet mask indicates which portion of the IPv4 address is used to identify the local network or subnet.
Default Gateway	This parameter is used to assign the IPv4 Address of the Gateway to be used by the tGW-700-UL. A Gateway (or router) is a device that is used to connect an individual network to one or more additional networks.
MAC Address	This parameter is used to set a user-defined MAC address, which must be in the format FF-FF-FF-FF-FF-FF.
IPv6 Link Local Address	Each IPv6 device connected to the network must have a link-local address. It always effective in the same link layer. It is auto-configured by EUI-64. If your environment doesn't support the IPv6, please ignore this field.
IPv6 SLAAC Address	The tGW-700-UL supports stateless address auto configuration (SLAAC). It will be configured by the Router automatically, and the default router is the link-local address of the router. The router should provide the prefix and the tGW-700-UL will calculate the Host ID by EUI-64. If your environment doesn't support the SLAAC, please ignore this field.
SLAAC Timeout (SLAAC Watchdog)	This parameter is used to configure the SLAAC timeout value. If the SLAAC address doesn't be configured in the specified time, the system will be rebooted to configure the SLAAC address again. Timeout value range: 30 to 65535 (seconds); Disable = 0;
IPv6 User-defined Address	It can be defined by the User. It's more convenient than using the link-local address in the simple application. This address can be routed if the prefix as same as IPv6 SLAAC Address. If your environment doesn't support the IPv6, please ignore this field.
Update Settings	Click this button to save the revised settings to the tGW-700-UL.

Manual Configuration

When using manual configuration, the network settings should be assigned in the following manner:

Step 1: Select the “Static IP” option from the “Address Type” drop-down menu.

Step 2: Enter the relevant details in the respective **network settings** fields. If your environment doesn't support the IPv6, please ignore the “IPv6 User-defined Address” fields.

Step 3: Click the “Update Settings” button to complete the configuration.

IP Address Selection

Address Type	Static IP ▼ 1			
Static IPv4 Address	192	168	255	1
Subnet Mask	255	255	0	0
Default Gateway	192	168	0	1
MAC Address	00-0d-e0-80-00-13 (Format: FF-FF-FF-FF-FF-FF)			
IPv6 Link Local Address	fe80:0:0:0:20d:e0ff:fe80:13			
IPv6 SLAAC Address	2003:aaaa:bbbb:cccc:20d:e0ff:fe80:13			
SLAAC Timeout (SLAAC Watchdog)	0 (30 ~ 65535 seconds, Default: 0, Disable: 0)			
IPv6 User-defined Address	fc00:0:0:0:0:0:1 2			
Update Settings 3				

Note: The IPv6 Link Local Address is auto-configured by EUI-64.

Note: The IPv6 SLAAC Address is auto-configured by Router. The router should provide the prefix and the tGW-700-UL will calculate the Host ID by EUI-64.

Dynamic Configuration

Dynamic configuration is very easy to perform. If a DHCP server is connected to you network, an IPv4 network address can be dynamically configured by using the following procedure:

Step 1: Select the “DHCP” option from the “Address Type” drop-down menu.

Step 2: Click the “Update Settings” button to complete the configuration.

IP Address Selection

Address Type	DHCP ▼ 1		
Static IPv4 Address	10	0	8 . 100
Subnet Mask	255	255	255 . 0
Default Gateway	10	0	8 . 254
MAC Address	00-0d-e0-80-00-13 (Format: FF-FF-FF-FF-FF-FF)		
IPv6 Link Local Address	fe80:0:0:0:20d:e0ff:fe80:13		
IPv6 SLAAC Address	2003:aaaa:bbbb:cccc:20d:e0ff:fe80:13		
SLAAC Timeout (SLAAC Watchdog)	0	(30 ~ 65535 seconds, Default: 0, Disable: 0)	
IPv6 User-defined Address	fc00:0:0:0:0:0:0:1		
Update Settings 2			

Note: The DHCP is ineffective on IPv6.

Note: The IPv6 Link Local Address is auto-configured by EUI-64.

Note: The IPv6 SLAAC Address is auto-configured by Router. The router should provide the prefix and the tGW-700-UL will calculate the Host ID by EUI-64.

5.3.2 General Settings

General Settings

Ethernet Speed	Auto v (Auto=10/100 Mbps Auto-negotiation)
HTTP port	80 (Default= 80)
Alias Name	Tiny (Max. 18 chars)
System Timeout (Network Watchdog)	300 (30 ~ 65535 seconds, Default: 300, Disable: 0)
Web Auto-logout	10 (1 ~ 65535 minutes, Default: 10, Disable: 0)
UDP Heartbeat	20 (20 ~ 300 seconds, Default: 20, Disable: 0)
UDP Configuration	Enable v (Enable/Disable the UDP Configuration, Enable=default.)
Update Settings	

The following is an overview of the parameters contained in the **General Settings** section:

Item	Description	Default
Ethernet Speed	This parameter is used to set the Ethernet speed. The default value is Auto (Auto = 10/100 Mbps Auto-negotiation).	Auto
HTTP Port	This parameter is used to assign specific a HTTP port of tGW-700-UL. The tGW-700-UL needs to be restarted when the HTTP port is changed. You need manually type the new HTTP port in the address bar of the browser. The default is 80. For example: if the HTTP port is set to 81, then enter the "IP address: HTTP port" (10.0.8.123:81).	80
Alias Name	This parameter is used to assign an alias for each tGW-700-UL to assist with easy identification.	Tiny
System Timeout (Network Watchdog)	This parameter is used to configure the system timeout value. If there is no activity on the network for a specific period of time, the system will be rebooted based on the configured system timeout value. Timeout value range: 30 to 65535 (seconds); Disable = 0;	300
Web Auto-logout	This parameter is used to configure the automatic logout value. If there is no activity on the web server for a certain period of time, the current user account will be automatically logged out. Range: 1 to 65535 (minutes); Disable = 0.	10
UDP Heartbeat	This parameter is used to configure the interval of the UDP heartbeat packet. Interval value range: 20 to 300 (seconds); Disable = 0;	20
UDP Configuration	This parameter is used to enable or disable UDP configuration function.	Enable
Update Settings	Click this button to save the revised settings to the tGW-700-UL.	

5.3.3 Modbus Settings

Modbus Settings	
Gateway Net ID	255 (Default: 255) Note: This is reserved for gateway, NOT for slave devices.
Protocol Exception	1 (Default: 1, Disable: 0, Enable: 1) Reports exception 0x41 when slave response is invalid Modbus message.
CRC Exception	1 (Default: 1) 0: Gateway returns raw data including CRC when CRC error. 1: Gateway reports exception 0x43 when CRC error. 2: Gateway drops packet when CRC error.
Timeout Exception	1 (Default: 1, Disable: 0, Enable: 1) Gateway reports exception 0x0B for slave no response, and 0x4B for data timeout.
Busy Exception	1 (Default: 1, Disable: 0, Enable: 1) Gateway reports exception 0x06 when queued requests are full.
Check TCP Header	1 (Default: 1, Disable: 0, Enable: 1) Drops packet when Modbus TCP header (protocol ID, length) is wrong.
Update Settings	

The following is an overview of the parameters contained in the **Modbus Settings** section:

Item	Description	Default
Gateway Net ID	This is reserved for gateway. (Not used to set the slave device)	255
Protocol Exception	This parameter is used to enable or disable whether the slave response is checked for compatibility with the Modbus RTU format. If the slave response is an invalid Modbus message, a 0x41 exception code will be reported. Enable =1; Disable = 0.	1
CRC Exception	This parameter is used to enable or disable whether the validity of the RTU/ASCII CRC of the slave response is checked. 0 = Returns the raw data, including the CRC, if a CRC error occurs; 1 = Reports a 0x43 exception code if a CRC error occurs; 2 = Drops the packet if a CRC error occurs.	1

Timeout Exception	This parameter is used to enable or disable whether a slave/data timeout exception error is reported by the Gateway. If There is no response from a slave device, a 0x0B exception error will be reported. If serial data is being received, a 0x4B exception will be reported. Enable =1; Disable = 0.	1
Busy Exception	This parameter is used to enable or disable whether a busy exception code (0x06) is reported if the Gateway request queue is full. Enable =1; Disable = 0.	1
Check TCP Header	This parameter is used to enable or disable the drop-packet function when the Modbus TCP header is invalid. Enable = 1; Disable = 0.	1
Update Settings	Click this button to save the revised settings to the tGW-700-UL.	

5.3.4 Restore Factory Defaults


Use the following procedure to reset all parameters to their original factory default settings:

Step 1: Click the “Restore Defaults” button to reset the configuration.

Step 2: Click the “OK” button in the message dialog box.

Step 3: Check whether the module has been reset to the original factory default settings for use with the eSearch Utility. Refer to [Chapter 3 “Getting Started \(for IPv4\)”](#), [Chapter 4 “Getting Started \(for IPv6\)”](#) for more details.


Restore Factory Defaults



The following is an overview of the factory default settings:

IPv4 Network Settings		IPv6 Network Settings		Basic Settings	
IPv4 Address	192.168.255.1	User-defined	fc00::1	Alias	Tiny
Gateway Address	192.168.0.1	Link-Local	Auto-configure		
Subnet Mask	255.255.0.0	SLAAC	Auto-configure		
DHCP	Disabled				

The **Forced Reboot** function: can be used to force the tGW-700-UL to reboot or to remotely reboot the module. After the tGW-700-UL module has rebooted, the original login screen will be displayed requesting that you enter your Login Password before continuing.



5.3.5 Update by Ethernet


Update by Ethernet

If the remote firmware update is failed, then the traditional firmware update (on-site) is required to make the module working again.

Step 1: Refer to firmware update manual first.
 Step 2: Run eSearch Utility to prepare and wait for update.
 Step 3: Click the **[Update]** button to **reboot** the module and start update.
 Step 4: Configure the module again.

Update

Firmware update requires initialization and local network operations. Traditional firmware update requires adjusting the Init/Run Switch and reboots the module manually for the initialization of firmware update, while new firmware allows user to initialize the module via web interface without adjusting the hardware switch. Initialization via web is useful when module is installed in remote site and can be accessed by a remote PC via TeamViewer.



Note:

If the remote firmware update is failed, then the traditional firmware update (Local) is required to make the module working again.

For detailed information regarding how to use this function to update the Firmware for tGW-700-UL series module, refer to the “tGW-700 Firmware Update Manual (EN)”. The download address is shown below:

<https://www.icpdas.com/en/download/show.php?num=2417>

5.4 Serial Port Page



After clicking the **Port1** tab, the serial port settings page will be displayed, allowing you to configure the settings for the tGW-700-UL, including the Baud Rate, Data Format, Slave Timeout, Char Timeout, Silent Time, Read Cache, TCP Timeout, Modbus Protocol and Pair-connection parameters, etc., each of which will be described in more detail below.

5.4.1 Settings (Port1 Settings)

Port 1 Settings

Port Settings	Current	Updated	Comment
Baud Rate	115200	115200 (select)	bps (bits/second)
Data Size	8	8	bits/character
Parity	None	None	
Stop Bits	1	1	bits
Flow Control	None	None	
Allow Driver Control	Enable	Enable	
Prefix String	N/A	N/A	Max. 7 chars added to TCP output.
Remove Errors	FE BE	☐ Parity Error ☒ Framing Error ☒ Break Error	Clear RX FIFO data when serial errors.
Remove Data		☐ Remove RX	Clear RX data when TCP disconnected.
Serial Data Packing	Current	Updated	Comment
Slave Timeout	1000	1000	ms, After last TX
Packing Length	0	0	0 ~ 1024 bytes, 0=default=disable
Serial Ending Chars (Number[char1][,char2])	0	0	e.g.: 2,0x0D,0x0A
Timeout Between Chars	10	10	ms, After last RX 10 ~ 65000, 10=default, 0=disable
TCP/IP	Current	Updated	Comment
Local TCP Port	10001		=TCP Command Port +1
Operation Mode	0	0	0=Data-sharing, 1=Non-sharing
Connction Idle	180	180	1 ~ 65000 seconds, 180=default, 0=disable
Pair-Connection Settings (Client/Server Mode)	Current	Updated	Comment
Application Mode	Server	Server	Server=Slave, Client=Master

The following is an overview of the parameters contained in the **Settings– Port1 Settings** section:

Item	Description	Default
Port Settings		
Baud Rate (bps)	This parameter is used to set the Baud Rate for the COM ports.	115200
Data Size (bits)	This parameter is used to set the Data Size for the COM ports.	8
Parity	This parameter is used to set the Parity for the COM ports.	None
Stop Bits (bits)	This parameter is used to set the Stop Bits for the COM ports.	1
Flow Control	This parameter is used to enable or disable hardware flow control (CTS/RTS) function.	None
Remove Errors	Clear the Rx FIFO when the Parity, Framing, Break Error occurs.	FE, BE
Modbus Settings		
Slave Timeout (ms)	This parameter is used to set the waiting time that should elapse after last character of the request sent to the device before the timeout is activated. The tGW-700-UL will report a 0x0B exception code if there is no response from the slave device before the timeout period expires, or will report a 0x4B exception code if the slave device is still sending data when the timeout is activated. The Slave Timeout value must be set to less than the response timeout configured in the client software.	300
Char Timeout (bytes)	Modbus RTU requires 3.5 char time between messages. This parameter is used to set the waiting time (based on bytes) that should elapse after last byte of data of the response is received from the slave device is activated. If no more data is received before the timeout period expires, then the transmission of this packet is deemed to have been completed and the tGW-700-UL begins processing the packet. Valid range: 4 to 15 (bytes);	4

Item	Description	Default
Silent Time (ms)	This parameter is used to set the idle time that should elapse before sending each request to the serial port. This causes the serial bus to be "silent" for the specified period, and allows slower slave devices more time to process previous requests and responses, thereby reducing communication problems. Valid range: 10, 20 to 65530 (ms);	0
Protocol	This parameter is used to configure the serial port that's used by the Modbus RTU or Modbus ASCII protocol.	Modbus RTU
Virtual ID Range	This parameter is used to set the range for restricting the Device ID. This port only handles the Net ID in the range.	1-247
Virtual ID Offset	This parameter is used to set the offset value for the Device ID. For more detailed information regarding the mapping configuration for the Virtual ID Range and the Virtual ID Offset, refer to "FAQ: How do I access multiple Modbus TCP slave devices from a single Modbus RTU/ASCII master device."	0
Modbus TCP Settings		
Read Cache (ms)	When sharing Modbus RTU/ASCII device/data between several master devices, the read-cache function can be used to reduce the loading on the serial communication and ensure faster TCP responses. Valid range: 10, 20to 65530 (ms); Disable = 0.	980
Local TCP Port	This parameter is used to configure the Modbus TCP port. Note: The default COM1 = TCP Ports 502.	502
MTCP Length Swap	Swap the High/Low byte reading order of Length in the Modbus TCP header.	0
Connection Idle (seconds)	If Modbus TCP communication is idle for a specified period of time, the system will automatically terminate the connection. Valid range: 1to 65535 (seconds); Disable= 0;	180

5.4.2 Settings (Pair-Connection Settings)

Pair-Connection Settings (Master/Slave Mode)	Current	Updated	Comment
Application Mode	Server	Client ▾	Server=Slave, Client=Master
Network Protocol	TCP / IPv4	TCP / IPv4 ▾	
Remote Server IP	0.0.0.0	0.0.0.0	For example : IPv4 = 10.0.8.100 IPv6 = fc00::1000
Remote TCP Port	504	504	
Submit			

The following is an overview of the parameters contained in the **Settings – Pair-Connection Settings (Master/Slave Mode)** section:

Master/Slave Mode, section:

Item	Description	
Pair-Connection Settings (Master/Slave Mode)		
Application Mode	Server (default)	Client
Network Protocol	-	Select the Modbus protocol (Modbus TCP or UDP) and the Internet protocol (IPv4 or IPv6) for the remote device
Remote Server IP	-	The IP address for the remote device
Remote TCP Port	-	The TCP Port number for the remote device
Submit	Click this button to save the revised settings to the tGW-700-UL.	

Note:

For more detailed information regarding pair-connection applications settings, refer to [Section 6.3 “Pair-Connection Applications”](#).

5.5 Filter Page



The **Filter** page is used to query or edit the IP Filter List. The IP Filter List restricts the access of packets based on the IP header. If the filter function is enabled, only clients whose IP is specified in the IP Filter List can access the tGW-700-UL.

Filter Setting:

Accessible IP	IPv4/v6 Address (example: 10.0.8.123, fe80:0:0:a8ee:dc07:1cda:5678)
IP0	
IP1	
IP2	
IP3	
IP4	

☐ **Enable IP Filter** ☐ Check to enable. (Default disabled)

Note: Remember to include the IP address of your configuration computer.

Enable the IP Filter:

Step 1: Enter the IP address that is allowed to access the module in the IP0 ~ IP4 fields.

Step 2: Tick the **Check to enable** checkbox in the Enable IP Filter field.


Step 3: Click the **“Update Setting”** button to update the settings.

Disable the IP Filter:

Step 1: Uncheck the **Check to enable** checkbox in the Enable IP Filter field.

Step 2: Click the **“Update Setting”** button to update the settings.

5.6 SNMP Page



The tGW-700-UL series module supports the standard SNMP v2c protocol. Through this protocol, the tGW-700-UL series module can transmit modules information to the SNMP Network Management Software or device to help administrators to monitor the status of the modules in real-time.

If the Trap function is enabled, the tGW-700-UL module can actively send messages to the SNMP manager terminal when the module restarts. The detailed description is as follows.

Note:

1. **SNMP function is available for Firmware v2.3.8 and later. It is not supported on older versions.**
 2. **The tGW-700-UL module currently supports these MIB-II management items such as sysContact, sysLocation, sysDescr, and sysName.**
-

5.6.1 SNMP Configuration Setting

SNMP v2c Agent Configuration

System Info	Setting	
Contact	User	(Max. 47 chars)
Location	Site	(Max. 47 chars)
Description	Modbus Gateway	(Max. 47 chars)
Name	Device	(Max. 47 chars)
Function	Setting	
Read-Only Community	public	(Max. 47 chars, example: public)
Read-Write Community	private	(Max. 47 chars, example: private)
Trap Community	public	(Max. 47 chars, example: public)
Manager / Trap IP #1	0.0.0.0	(IPv4/v6 Address, example: 10.0.8.123, fe80:0:0:0:a8ee:dc07:1cda:5678)
Manager / Trap IP #2	0.0.0.0	
Generic Trap	☐ Cold Start, ☐ Warm Start	
Enable SNMP	☐ Check to enable. (Default disabled)	
Update Settings		

The following is an overview of the parameters contained in the **System Info** section:

Item	Description	Default Value
Contact	The module contact person	User
Location	The module location	Site
Description	The description of the module	Modbus Gateway
Name	The name of the module	Device

The following is an overview of the parameters contained in the **Function** section:

Item	Description	Default Value
Read-Only Community	Set the community name of the module for read-only data	public
Read-Write Community	Set the community name of the module for read-write data	private
Trap Community	Set the community name of the module for the trap	public
Manager / Trap IP #1	Set the IP address of Trap IP #1	0.0.0.0
Manager / Trap IP #2	Set the IP address of Trap IP #2	0.0.0.0
Generic Trap	Enable the Cold Start or Warm Start function	Disabled
Enable SNMP	Tick the Check to enable checkbox to enable the SNMP communication function or uncheck the item to disable it.	Disabled
Update Settings	Click this button to save the revised settings to the tGW-700-UL. The new settings will take effect after the module is restarted.	


5.6.2 SNMP I/O Example

This article takes iReasoning MIB Browser V14 as an example (hereinafter referred to as MIB Browser). Please download the installer program from its official website and run the installer.


<http://www.ireasoning.com/mibbrowser.shtml>

Step 1: Start the MIB Browser.


Click the **File => Load MIBs** on the menu bar and click the specified MIB file of the module (e.g. ICPDAS-tGW700-MIB_20220711.mib), then click the Open button to open it.



Step 2: Enter the IP address of the tGW-700-UL module in the **Address** field.



Step 3: Click “**Advanced**” to set the parameters of the SNMP agent. Enter the string in the Read/Write Community fields according to the Read-Only Community / Read-Write Community settings on the tGW-700-UL. If these strings are different on both sides, the agent will not work correctly.



Note: If the Write Community field is not set, a Timeout error will occur during execution.

Step 4: Enter the IP address of MIB Browser in the **Manager/Trap IP #1** field, check the **Check to enable** checkbox to enable the SNMP function, then click **Update Settings** to save the changes. Finally, click the **Reboot** button to reboot the tGW-700-UL module.

Function	Setting	
Read-Only Community	public	(Max. 47 chars, example: public)
Read-Write Community	private	(Max. 47 chars, example: private)
Trap Community	public	(Max. 47 chars, example: public)
Manager / Trap IP #1	10.1.0.39	(IPv4/v6 Address, example: 10.0.8.123, fe80:0:0:0:a8ee:dc07:1cda:5678)
Manager / Trap IP #2	0.0.0.0	
Generic Trap	☐ Cold Start, ☐ Warm Start	
Enable SNMP	☒ Check to enable. (Default disabled)	

Update Settings

Reboot is required after SNMP configuration.

Read the information of the tGW-700-UL – The Walk command

Right-click the **iso.org.dod.internet** folder on the left side and click **Walk** to display the information of the tGW-700-UL in the **Result Table**

iReasoning MIB Browser

File Edit Operations Tools Bookmarks Help

Address: 10.1.0.29 Advanced... OID: .1.3.6.1

SNMP MIBs

MIB Tree


- iso.org.dod.internet
 - Find in subtree
 - Export to CSV
 - Export to XML
 - Expand subtree
 - Graph View Ctrl+R
 - Get Next Ctrl+N
 - Get Bulk Ctrl+B
 - Get Subtree Ctrl+E
 - Walk Ctrl+W
 - Table View Ctrl+I

Result Table

Name/OID	Value	Type	IP:Port
snmpInSetRequests.0	0	Counter32	10.1.0.29...
snmpInGetResponses.0	0	Counter32	10.1.0.29...
snmpInTraps.0	0	Counter32	10.1.0.29...
snmpOutTooBigs.0	0	Counter32	10.1.0.29...
snmpOutNoSuchNames.0	0	Counter32	10.1.0.29...
snmpOutBadValues.0	0	Counter32	10.1.0.29...
snmpOutGenErrs.0	0	Counter32	10.1.0.29...
snmpOutGetRequests.0	0	Counter32	10.1.0.29...
snmpOutGetNexts.0	0	Counter32	10.1.0.29...
snmpOutSetRequests.0	0	Counter32	10.1.0.29...
snmpOutGetResponses.0	3	Counter32	10.1.0.29...
snmpOutTraps.0	0	Counter32	10.1.0.29...
snmpEnableAuthenTraps.0	disabled (2)	Integer	10.1.0.29...
.1.3.6.1.2.1.11.31.0	0	Counter32	10.1.0.29...
.1.3.6.1.2.1.11.32.0	0	Counter32	10.1.0.29...
modelName.0	tGW-715/715i_RevB2	OctetString	10.1.0.29...
aliasName.0	Tiny	OctetString	10.1.0.29...
firmwareVersion.0	B2.3.8 [May.11 2023]	OctetString	10.1.0.29...
webServerPort.0	80	Integer	10.1.0.29...
comIndex.1	1	Integer	10.1.0.29...
comName.1	Port1	OctetString	10.1.0.29...
modbusTcpPort.1	502	Integer	10.1.0.29...
modbusTcpPort.1	(Snmp End Of Mib View)	EndOfMi...	10.1.0.29...

5.6.3 SNMP Trap Example

Step 1: Click **Tools => Trap Receiver** on the menu bar to display the window for receiving the Trap messages.



Step 2: The Trap types for the alarms that receive from the tGW-700-UL module are as follows.

1. Cold Start Trap:

The Cold Start Trap will be sent when the module restarts after it has been powered off.

2. Warm Start Trap:

The Warm Start Trap will be sent when the module restarts without turning off the power, for example, the reboot command or the watchdog mechanism.

Click the Trap message to view the details

Description	Source	Time	Severity
warmStart	10.1.0.29	2023-06-13 14:40:31	
Source: 10.1.0.29 Timestamp: 4.5 seconds SNMP Version: 1 Enterprise: snmp Community: public Specific: 0 Generic: warmStart Description: warmStart			


Item	Description
Source	The IP address of the Trap from the module.
Timestamp	The time elapsed since the last startup of the module.
SNMP Version	The version of SNMP
Enterprise	The name of the enterprise
Community	SNMP community name according to the Trap Community setting on the tGW-700-UL
Specific	Specific ID.
Generic	Generic ID.
Description	Trap Information

5.6.4 SNMP Troubleshooting

Unable to receive the Trap message from the module

1. Check the setting of the Windows firewall or the Anti-virus software. These functions can be disabled during the testing
2. Check the setting of the Trap port. Using **iReasoning MIB Browser** as an example:


Click the **Trap Receiver Settings** button on the **Trap Receiver** page to open the window. Then, confirm the **Trap Port**, **Bind IP**, and **Transport** settings. The tGW-700-UL uses the default Trap port 162 according to the SNMP specification.




3. Disable Windows SNMP Trap Service

Note: The configuration screen varies according to the Windows version.
The following screens are on Windows 10.

Step 1: Enter services.msc in the command bar and click to open the Windows service tool.



Step 2: Double-click the SNMP Trap and confirm the Startup type is set to “Disabled” and the Service status is set to “Stopped”.



5.7 Monitor Page



Current Connection Status:

Connection	Port 1
Application Mode	TCP/UDP Server
Connected IP1	-
IP2	-
IP3	-
IP4	-
Available Connections	32
Host Query (Client mode)	Port 1
Query State	-
Last Query Time	-
Remote Server IP	-
Connection State	-
Modbus TCP/UDP	Port 1
Sent Packets	0
Received Packets	0
Dropped Packets	0
Queued Packets	0
(No Buffer) Busy Packets	0
(Queue-Timeout) Busy Packets	0
Last Sent	-
Last Received	-
Modbus RTU/ASCII	Port 1
Sent Packets	0
Received Packets	0
Dropped Packets	0
(No Response) Slave Timeouts	0
(Receiving) Slave Timeouts	0
Buffer Usages	0%
Cache Hits	0%
Last Sent	-
Last Received	-
Communication	Port 1
Maximum Response Time (ms)	0
First Error (Hex)	0,0,0
Last Error (Hex)	0,0,0
Remove PE/FE/BE (bytes)	0

[Clear Last Error](#)

Note:

1. [Click here](#) for error codes and descriptions.
2. The "**Busy Error**" can occur if there are too many Modbus requests in the queue. To resolve this, increase timeout and scan time on all Master (Client) software.
3. The **Maximum Response Time** above is the round trip time between the Gateway and the Slave.

After clicking the **Monitor** tab, the Current Connection Status page will be displayed showing detailed information regarding the current status of the serial port connection settings for the tGW-700-UL.

5.8 Password Page



After clicking the **Password** tab, the **Change Password** page will be displayed.

To change a password,

Step 1: Enter the old password in the “*Current password*” field. (Use the default password “**admin**” for the first login)

Step 2: Enter the new password in the “*New password*” and “*Confirm new password*” fields.

Step 3: Click the “**Submit**” button to update the password.

The image shows the 'Change Password' form. At the top, it says 'Change Password' and 'The length of the password is 12 characters maximum.' Below this are three input fields with labels on the left: 'Current password', 'New password', and 'Confirm new password'. Each field contains four dots representing masked characters. To the right of the 'Confirm new password' field is a small eye icon. At the bottom right of the form is a 'Submit' button. A yellow starburst cursor is pointing at the 'Submit' button.


Note:

If you forgot password, please refer to [Section A1. How do I restore the web password for the module to the factory default password?](#)

5.9 Logout Page




After clicking the **Logout** tab, you will be immediately logged out from the system and be returned to the login page.




6. Typical Applications

This chapter provides some examples of typical scenarios for the tGW-700-UL series module, including applications focused on the Modbus Gateway, Modbus Net ID, Pair-connection and TCP Client Mode, etc...



6.1 Modbus Gateway


The tGW-700-UL series module is a Modbus TCP/UDP to RTU/ASCII gateway that enables a Modbus TCP/UDP host to communicate with serial Modbus RTU/ASCII devices through an Ethernet network, and eliminates the inherent cable length limitations of legacy serial communication devices.



6.2 Modbus Net ID


The tGW-700-UL series module is a gateway that can be used to convert between the Modbus TCP/UDP protocol and the Modbus RTU/ASCII protocol. Consequently, SCADA/HMI applications is able to access each Modbus RTU/ASCII slave device via the tGW-700-UL gateway by specifying correct Net ID of the intended slave device in each Modbus TCP request.

Note that the Net ID of the tGW-700-UL gateway is reserved for specific control purposes, and is not used to access slave devices.



6.3 Pair-connection Applications

The tGW-700-UL Modbus gateway can be used to create a pair-connection applications (as well as serial-bridge or serial-tunnel), and then route Modbus messages between two serial devices via TCP/IP, which is useful when connecting Modbus RTU/ASCII devices that do not themselves have Ethernet capability.



The following are examples of pair-connection tests:

➤ Pair-connection Settings:

Model	Port Settings (default)		Pair-connection Settings		
	Baud Rate	Data Format	Application Mode	Remote Server IP	Remote TCP Port (default)
tGW-700-UL #1	115200	8N1	Client	IP Address of tGW-700-UL #2	502
tGW-700-UL #2	115200	8N1	Server	-	-

Note: The Baud Rate and Data Format settings of the client and server (tGW-700-UL #1 and #2) depend on the COM ports of the PC (or the connected device). The serial port settings between tGW-700-UL #1 and tGW-700-UL #2 can be different.

Step 1: Connecting to a network, PC and Power

1. Confirm that the tGW-700-UL modules are functioning correctly. For detailed information regarding how to install, configure and operate your tGW-700-UL series module, refer to [Chapter 3 “Getting Started \(for IPv4\)”](#), [Chapter 4 “Getting Started \(for IPv6\)”](#).
2. Use an I-7520 module (optional) to connect the COM1 of Host PC with COM1 of tGW-700-UL #1. For detailed information regarding RS-422/485 wiring, refer to [Section 2.5 “Wiring Notes for RS-232/422/485 Interfaces”](#).

(I-7520 product page: <http://www.icpdas.com/en/product/I-7520>)

3. Connect the Modbus device (e.g., M-7055D, optional) to COM1 of tGW-700-UL #2.

(M-7055D product page: <http://www.icpdas.com/en/product/M-7055D-G>)

➤ Refer to [Figure 6-1](#) for an illustration of how to perform [Steps 1-1 to 1-3](#) of the procedure described above.

The image below shows an example of the setup for a pair-connection test:




Figure 6-1

Step 2: Configuring the Ethernet Settings

Contact your Network Administrator to obtain the correct and functioning network configuration for the tGW-700-UL modules (including the **IP Address, Mask and Gateway details**). Also refer to [Chapter 3 “Getting Started \(for IPv4\)”](#), [Chapter 4 “Getting Started \(for IPv6\)”](#) for more details.

eSearch Utility [v1.1.13, Nov.29, 2016]

Name	Alias	IP Address	Sub-net Mask	Gateway	MAC Address
tGW-715_RevB	Tiny	10.0.8.246	255.255.255.0	10.0.8.254	00:0d:e0:8e:07:3
tGW-715_RevB	Tiny	10.0.8.100	255.255.255.0	10.0.8.254	00:0d:e0:68:07:1

Search Server Configuration [UDP] Web Exit

Status

Figure 6-2

Step 3: Configuring the Pair-connection (Client Mode) on the Web Server for tGW-700-UL #1

1. Open the eSearch Utility to search for the tGW-700-UL modules connected to the network. Click the name of the first tGW-700-UL module (tGW-700-UL #1) to select it, and then click the **“Web”** button to launch a browser window to connect to the web server on the tGW-700-UL #1 module. Alternatively, you can enter the URL for tGW-700-UL #1 in the address bar of the browser.
2. When the login screen is displayed, enter the password in the **Login password** field, and then click the **“Submit”** button to display the configuration page.




Figure 6-3

3. Click the **“Port1”** tab to display to the **Port1 Settings** page.



4. Select the appropriate **Baud Rate**, **Data Format** and **Modbus Protocol** settings from the relevant drop down options. The following is an example: Baud Rate (bps) “**115200**”, Data Bits (bits) “**8**”, Parity “**None**”, Stop Bits (bits) “**1**” and Modbus Protocol “**Modbus RTU**”.

Port 1 Settings

Port Settings	Current	Updated	Comment
Baud Rate	115200	115200 (select)	bps (bits/second)
Data Size	8	8	bits/char
Parity	None	None	
Stop Bits	1	1	
Flow Control	None	None	
Remove Errors	FE BE	☐ Parity Error ☒ Framing Error ☒ Break Error	Clear RX FIFO data when serial errors.
Modbus Settings	Current	Updated	Comment
Slave Timeout	300	300	10 - 65000 ms (step 10), Default: 300
Char Timeout	4	4	4 - 15 bytes, Default: 4
Silent Time	0	0	0 - 65000 ms (step 10), Default: 0
Protocol	Modbus RTU	Modbus RTU	

Figure 6-5

5. In the **Pair-connection Settings** area for Port1, check that the configuration details are the same as those shown below.

Field	Application Mode	Network Protocol	Remote Server IP	Remote TCP Port
Pair-connection Settings	Client	TCP / IPv4	10.0.8.246	502
		Modbus Protocol, IP address and TCP port for tGW-700-UL #2		

6. Amend and details as required and then click the “**Submit**” button to complete the configuration.

Pair-Connection Settings (Master/Slave Mode)	Current	Updated	Comment
Application Mode	Client	Client	Server=Slave, Client=Master
Network Protocol	TCP / IPv4	TCP / IPv4	
Remote Server IP	10.0.8.246	10.0.8.246	For example : IPv4 = 10.0.8.100 IPv6 = fc00::1000
Remote TCP Port	502	502	
Submit			

Figure 6-6

Step 4: Configuring the Pair-connection (Server Mode) on the Web Server for tGW-700-UL #2

1. In the eSearch Utility, click the name of the second tGW-700-UL module (tGW-700-UL #2) to select it, and then click the **“Web”** button to launch a browser window to connect to the web server on the tGW-700-UL #2 module. Alternatively, you can enter the URL for tGW-700-UL #2 in the address bar of the browser.
2. When the login screen is displayed, enter the password (use the default password **“admin”**) in the Password field, and then click the **“Submit”** button to display the configuration page.
3. Click the **“Port1”** tab to display the **Port1 Settings** page.
4. Select the appropriate **Baud Rate, Data Format and Modbus Protocol** settings from the relevant drop down options. The following is an example: Baud Rate (bps) **“9600”**, Data Bits (bits) **“8”**, Parity **“None”**, Stop Bits (bits) **“1”** and Modbus Protocol **“Modbus RTU”**.

➦ Refer to **Figures 6-3 to 6-5** for an illustration of how to perform **Steps 4-1 to 4-4** of the procedure described above.

5. In the **Pair-connection Settings** area for Port1, select **“Server”** from the **“Application Mode”** drop down options.
6. Amend any details as required and then click the **“Submit”** button to complete the configuration.

Pair-Connection Settings (Master/Slave Mode)	Current	Updated	Comment
Application Mode	Server	Server ▼	Server=Slave, Client=Master

Figure 6-7

Step 5: Testing the Pair-connection Functions

1. In the eSearch Utility, select the “**Modbus RTU Master**” item from the “**Tools**” menu to open the Modbus TCP Master Utility.




Figure 6-8

2. Select the appropriate COM port, Baud Rate and Data Format (e.g., COM1, 115200, N, 8, 1) settings for the tGW-700-UL, and then click the “**Open**” button.




Figure 6-9

- Refer to the "**Protocol Description**" field in the top right-hand section of the Modbus Utility window. You can **send a request command** and **confirm the response** is correct.

Step 1: Enter the **Modbus command** in the "**Command**" field

Step 2: Click the "**Send Command**" button.

Step 3: If the **response data** is correct, it means the test is success.




Figure 6-10

Notes:

- The response will depend on which Modbus is device connected.
- The Baud Rate and Data Format values depend on the serial port settings configured for the web configuration described above.

6.4 TCP Client Mode Applications

In TCP Client Mode, the tGW-700-UL can actively establish a TCP connection to a specific Modbus TCP slave device. An example of how the complete system should operate is shown below:




Figure 6-11

The following are examples of pair-connection tests:

➤ TCP Client Mode Settings:

Model	Port Settings (default)		Pair-connection Settings		
	Baud Rate	Data Format	Application Mode	Remote Server IP	Remote TCP Port
tGW-700-UL	115200	8, N, 1	Client	10.0.8.10	502
				IP address and TCP port for the tPET-P6 (Slave Device)	
tPET-P6 (Slave Device)	-	-	-	-	-

Step 1: Connecting to a network, a PC and a Power Supply

1. Confirm that the tGW-700-UL device is functioning correctly. For detailed information regarding how to install, configure and operate your tGW-700-UL series module, refer to [Chapter 3 “Getting Started \(for IPv4\)”](#), [Chapter 4 “Getting Started \(for IPv6\)”](#).
2. Connect both the tGW-700-UL, the Slave Device (e.g. a tPET-P6, optional) and your computer to the same sub network or the same Ethernet Switch. For detailed information regarding RS-232/RS-422/485 wiring, refer to [Section 2.5 “Wiring Notes for RS-232/422/485 Interfaces”](#).

The wiring diagram is as follows:




Figure 6-12

Step 2: Configuring the Ethernet Settings

Contact your Network Administrator to obtain a correct and functioning network configuration (including the **IP Address, Mask and Gateway details**) for the tGW-700-UL module. Also refer to [Chapter 3 “Getting Started \(for IPv4\)”](#), [Chapter 4 “Getting Started \(for IPv6\)”](#) for more details.





Figure 6-13

Step 3: Configuring Pair-connection (TCP Client Mode) on the Web Server for the tGW-700-UL module

1. Open the eSearch Utility to search for the tGW-700-UL modules connected to the network. Click the name of the first tGW-700-UL module to select it, and then click the **“Web”** button to launch a browser window to connect to the web server on the tGW-700-UL module. Alternatively, you can enter the URL for tGW-700-UL in the address bar of the browser.
2. When the login screen is displayed, enter the password in the Password field, and then click the **“Submit”** button to display the configuration page.



3. Click the “**Port1**” tab to display the **Port1 Settings** page.



Figure 6-15

4. Select the appropriate **Baud Rate**, **Data Format** and **Modbus Protocol** settings from the relevant drop down options. The following is an example: Baud Rate (bps) “**115200**”, Data Bits (bits) “**8**”, Parity “**None**”, Stop Bits (bits) “**1**” and Modbus Protocol “**Modbus RTU**”.

Port 1 Settings

Port Settings	Current	Updated	Comment
Baud Rate	115200	115200 (select)	bps (bits/second, bits/char
Data Size	8	8	
Parity	None	None	
Stop Bits	1	1	
Flow Control	None	None	
Remove Errors	FE BE	☐ Parity Error ☒ Framing Error ☒ Break Error	Clear RX FIFO data when serial errors.
Modbus Settings	Current	Updated	Comment
Slave Timeout	300	300	10 - 65000 ms (step 10), Default: 300
Char Timeout	4	4	4 - 15 bytes, Default: 4
Silent Time	0	0	0 - 65000 ms (step 10), Default: 0
Protocol	Modbus RTU	Modbus RTU	

Figure 6-16

5. In the **Pair-connection Settings** area of the Port1 Settings page, check that the configuration details are the same as those shown below.

Field	Application Mode	Network Protocol	Remote Server IP	Remote TCP Port
Pair-Connection Settings	Client	TCP / IPv4	10.0.8.10	502
		Modbus Protocol, IP address and TCP port of the slave device (e.g., tPET-P6)		

6. Amend any details as required and then click the **“Submit”** button to complete the configuration.

Pair-Connection Settings (Master/Slave Mode)	Current	Updated	Comment
Application Mode	Client	Client	Server=Slave, Client=Master
Network Protocol	TCP / IPv4	TCP / IPv4	
Remote Server IP	10.0.8.10	10.0.8.10	For example : IPv4 = 10.0.8.100 IPv6 = fc00::1000
Remote TCP Port	502	502	

Figure 6-17

Step 4: Testing the Pair-connection (TCP Client Mode) Functions

➤ For more detailed information regarding the testing procedure, refer to [Step 5 \(Figures 6-8 to 6-10\)](#) in the [Section 6.3 “Pair-connection Applications”](#).

7. Modbus Information

What is Modbus TCP/IP?

Modbus is a communication protocol developed by Modicon in 1979. You can also visit <http://www.modbus.org> to find more valuable information.

The Different versions of Modbus used today include Modbus RTU (based on serial communication interfaces such as RS485 and RS232), Modbus ASCII and Modbus TCP, which is the Modbus RTU protocol embedded into TCP packets.

Modbus TCP is an internet protocol. The protocol embeds a Modbus frame into a TCP frame so that a connection oriented approach is obtained, thereby making it reliable. The master queries the slave and the slave responds with the reply. The protocol is open and, hence, highly scalable.

7.1 Modbus Message Structure

Modbus devices communicate using a master-slave (client-server) technique in which only one device (the master/client) can initiate transactions (called queries). The other devices (slaves/servers) respond by supplying the requested data to the master, or by taking the action requested in the query.

A query from a master will consist of a slave address (or broadcast address), a function code defining the requested action, any required data, and an error checking field. A response from a slave consists of fields confirming the action taken, any data to be returned, and an error checking field.

Modbus/TCP Message Structure

Byte 00~05	Byte 06~11
6-byte header	RTU Data

Leading 6 bytes of Modbus/TCP protocol:

Byte 00	Byte 01	Byte 02	Byte 03	Byte 04	Byte 05
Transaction identifier		Protocol identifier		Length field (upper byte)	Length field (lower byte)

Transaction identifier: Assigned by Modbus/TCP master (client)

Protocol identifier: 0

Length field (upper byte): 0 (since all messages are smaller than 256)

Length field (lower byte): Number of following RTU data bytes

RTU Data Structure

Byte 06	Byte 07	Byte 08-09	Byte 10-11
Net ID (Station number)	Function Code	Data Field	
		Reference number (Address Mapping)	Number of points

- **Net ID (Station Number):** specifies the address of the receiver (Modbus/TCP slave).

The first byte in the message structure of Modbus is the receiver's address. The valid addresses are in the range of 0 to 247. Address 0 is used for broadcast, while addresses 1 to 247 are given to individual Modbus devices.

- **Function Code:** specifies the message type.

The second byte in the frame structure of the Modbus RTU is the function code. The function code describes what the slave is required to do. Valid function codes are between 1 and 255. The slave uses the same function code as the request to answer it. Only when an error occurs in the system will the highest bit of the function code be set to '1'. Hence the master will know whether the message has been transmitted correctly or not.

Code	Function	Reference (Address)
01 (0x01)	Read the Status of the Coils (Readback DOs)	0xxxx
02 (0x02)	Read the Status of the Input(Reads DIs)	1xxxx
03 (0x03)	Read the Holding Registers (Readback AOs)	4xxxx
04 (0x04)	Read the Input Registers (Reads AIs)	3xxxx
05 (0x05)	Force a Single Coil (Writes DO)	0xxxx
06 (0x06)	Preset a Single Register (Writes AO)	4xxxx
15 (0x0F)	Force Multiple Coils (Writes DOs)	0xxxx
16 (0x10)	Preset Multiple Registers (Writes AOs)	4xxxx

➤ **Data Field:** is the data block.

Data is transmitted in 8-, 16- and 32-bit format. The data for 16-bit registers is transmitted in high-byte first format. For example: 0x0A0B ==> 0x0A, 0x0B. The data for 32-bit registers is transmitted as two 16-bit registers, and is low-word first. For example: 0x0A0B0C0D ==> 0x0C, 0x0D, 0x0A, 0x0B.

The data field of messages sent between a master and a slave contains additional information about the action to be taken by the master or any information requested by the slave. If the master does not require this information, the data field can be empty.

Reference (Address)	Description
0xxxx	<u>Read/Write Discrete Outputs or Coils.</u> A 0x reference address is used to output device data to a digital output channel.
1xxxx	<u>Read Discrete Inputs.</u> The ON/OFF status of a 1x reference address is controlled by the corresponding digital input channel.
3xxxx	<u>Read Input Registers.</u> A 3x reference register contains a 16-bit number received from an external source, e.g. an analog signal.
4xxxx	<u>Read/Write Output or Holding Registers.</u> A 4x register is used to store 16bits of numerical data (binary or decimal), or to send the data from the CPU to an output channel.

Note: For details regarding address mapping (Reference Number) depends on your slave device.

01(0x01) Read the Status of the Coils (Readback DOs)

This function code is used to read either the current status of the coils or the current digital output readback value.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x01
02-03	Starting DO Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Number of Points (Channels)	2 Bytes	Byte 04 = high byte Byte 05 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x01
02	Byte Count	1 Byte	Byte Count of the Response ($n = (\text{Points} + 7) / 8$)
03	Data	n Bytes	n= 1; Byte 03 = data bit 7 to 0 n= 2; Byte 04 = data bit 15 to 8 n= m; Byte m+2 = data bit (8m-1) to 8(m-1)

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x81
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details

02(0x02) Read the Status of the Input (Read DIs)

This function code is used to read the current digital input value.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x02
02-03	Starting DI Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Number of Points (Channels)	2 Bytes	Byte 04 = high byte Byte 05 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x02
02	Byte Count	1 Byte	Byte Count of Response ($n = (\text{Points} + 7) / 8$)
03	Data	n Bytes	n= 1; Byte 03 = data bit 7 to 0 n= 2; Byte 04 = data bit 15 to 8 n= m; Byte m+2 = data bit (8m-1) to 8(m-1)

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x82
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details

03(0x03) Read the Holding Registers (Readback AOs)

This function code is used to readback either the current values in the holding registers or the analog output value.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x03
02-03	Starting AO Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Number of 16-bit Registers (Channels)	2 Bytes	Word Count Byte 04 = high byte Byte 05 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x03
02	Byte Count	1 Byte	Byte Count of the Response (n=Points x 2 Bytes)
03~	Register Values	n Bytes	Register Values n= 2; Byte 03 = high byte Byte 04 = low byte n= m; Byte 03 = high byte Byte 04 = low byte Byte m+1 = high byte Byte m+2 = low byte

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x83
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details

04(0x04) Read the Input Registers (Read AIs)

This function code is used to read either the input registers or the current analog input value.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x04
02-03	Starting AI Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Number of 16-bit Registers (Channels)	2 Bytes	Word Count Byte 04 = high byte Byte 05 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x04
02	Byte Count	1 Byte	Byte Count of the Response (n=Points x 2 Bytes)
03~	Register Values	n Bytes	Register Values n= 2; Byte 03 = high byte Byte 04 = low byte n= m; Byte 03 = high byte Byte 04 = low byte Byte m+1 = high byte Byte m+2 = low byte

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x84
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details.

05(0x05) Force a Single Coil (Write DO)

This function code is used to set the status of a single coil or a single digital output value.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x05
02-03	DO Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Output Value	2 Bytes	0xFF 00 sets the output to ON. 0x00 00 sets the output to OFF. All other values are invalid and will not affect the coil. Byte 04 = high byte Byte 05 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x05
02-03	DO Address	2 Bytes	The value is the same as Bytes 02-03 of the Request
04-05	Output Value	2 Bytes	The value is the same as Bytes 04-05 of the Request

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x85
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details.

06(0x06) Preset a Single Register (Write AO)

This function code is used to set a specific holding register to store the configuration values.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x06
02-03	AO Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Register Value	2 Bytes	Register Value Byte 04 = high byte Byte 05 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x06
02-03	AO Address	2 Bytes	The value is the same as Bytes 02-03 of the Request
04-05	Register Value	2 Bytes	The value is the same as Bytes 04-05 of the Request

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x86
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details.

15(0x0F) Force Multiple Coils (Write DOs)

This function code is used to set multiple coils status or write multiple digital output values.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x0F
02-03	Starting DO Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Number of Output Channels (Points)	2 Bytes	Byte 04 = high byte Byte 05 = low byte
06	Byte count	1 Byte	$n = (\text{Points} + 7) / 8$
07	Output value	n Bytes	A bit corresponds to a channel. A value of 1 for a bit denotes that the channel is ON, while a value of 0 denotes that the channel is OFF. n= 1; Byte 07 = data bit 7 to 0 n= 2; Byte 08 = data bit 15 to 8 n= m; Byte m+6 = data bit (8m-1)to 8 (m-1)

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x0F
02-03	Starting DO Address	2 Bytes	The value is the same as Bytes 02-03 of the Request
04-05	Number of Output Channels (Points)	2Bytes	The value is the same as Bytes 04-05 of the Request

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1to 247
01	Function Code	1 Byte	0x8F
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details.

16(0x10) Preset Multiple Registers (Write AOs)

This function code is used to set multiple holding registers that are used to store the configuration values.

[Request]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x10
02-03	Starting AO Address	2 Bytes	Refer to the Modbus address depends on your slave device for more details. Byte 02 = high byte Byte 03 = low byte
04-05	Number of 16-bit Registers (Channels)	2 Bytes	Word Count. Byte 04 = high byte Byte 05 = low byte
06	Byte Count	1 Byte	n = Points x 2 Bytes
07	Register Values	n Bytes	Register Values. n = 2; Byte 03 = high byte Byte 04 = low byte n = m; Byte 03 = high byte Byte 04 = low byte Byte m+1 = high byte Byte m+2 = low byte

[Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x10
02-03	Starting AO Address	2 Bytes	The value is the same as Bytes 02-03 of the Request
04-05	Number of 16-bit Registers (Channels)	2 Bytes	The value is the same as Bytes 04-05 of the Request

[Error Response]

Byte	Description	Size	Value
00	Net ID (Station Number)	1 Byte	1 to 247
01	Function Code	1 Byte	0x90
02	Exception Code	1 Byte	Refer to the Modbus Standard Specifications for more details.

7.2 Exception Codes

If an exception occurs during Modbus communication, the slave device will return an Exception Code in the response message. The following is an explanation of the Exception Codes:

➤ Exception Codes:

Code	Name and Description
0x01	ILLEGAL FUNCTION
	Indicates that the function code received in the query is not an allowable action for the slave. If not an allowable action for the slave. If a Poll Program Complete command was issued, this code indicates that no program function preceded it.
0x02	ILLEGAL DATA ADDRESS
	Indicates that the data address received in the query is not an allowable address for the slave.
0x03	ILLEGAL DATA VALUE
	Indicates that a value contained in the query data field is not an allowable value for the slave.
0x04	SLAVE DEVICE FAILURE
	Indicates that an unrecoverable error occurred while the slave was attempting to perform the requested action.
0x05	ACKNOWLEDGE
	Indicates that the slave has accepted the request and is processing it, but it will take an extended period of time to do so. This response is returned to prevent a timeout error from occurring in the master. The master can issue a Poll Program Complete message later to determine whether the processing is complete.
0x06	SLAVE DEVICE BUSY
	Indicates that the slave is engaged in processing a long-duration program command. The master should retransmit the message later when the slave is free.
0x07	NEGATIVE ACKNOWLEDGE
	Indicates that the extended file area failed to pass a consistency check, and the slave cannot perform the program function received in the query. This code is returned when a programming request using function code 13 or 14 decimal was unsuccessful. The master should request diagnostic or error information from the slave.
0x08	MEMORY PARITY ERROR
	Indicates that the slave attempted to read extended memory, but detected a parity error in the memory. The master can retransmit the request, but maintenance may be required on the slave device.

➤ **Defined Exception Codes for tGW-700-UL:**


Code	Name and Description
0x0B	GATEWAY TARGET DEVICE FAILED TO RESPOND
	Timeout. The slave device does not respond within the timeout value, the tGW-700-UL will return this code.
0x4B	GATEWAY TARGET DATA FAILED TO RESPOND
	Timeout. The slave device is still sending data when timed out, the tGW-700-UL will return this code. Please use larger Slave Timeout value for the serial port of the tGW-700-UL module.
0x41	MODBUS PROTOCOL FORMAT ERROR
	The tGW-700-UL will return this code when slave response is invalid Modbus message.
0x42	WRONG DATA LENGTH
	The tGW-700-UL will return this code when tGW-700-UL received wrong data length. Please use larger Slave Timeout value for the serial port of the tGW-700-UL module.
0x43	CRC ERROR
	The tGW-700-UL will return this code when the CRC of the slave response is wrong.

Appendix A: Troubleshooting


A1. How do I restore the web password for the module to the factory default password?

The instructions below outline the procedure for resetting the web password to the factory default value. **Note: Be aware that ALL settings will be restored to the factory default values after the module is reset.**


Step 1 Locate the Init/Run switch that can be found on the right-hand side of the tGW-700-UL module and set it to the "Init" position. Reboot the module to **load factory default settings** including default web password.



Step 2 Execute the eSearch Utility to search for any tGW-700-UL modules connected to the network. Verify that the tGW-700-UL has been reset to the original factory default settings. For example, the module should be shown as having the default IP address, which is 192.168.255.1.




Step 3 Double-click the name of the module to open the Configure Server (UDP) dialog box, and modify the basic settings as necessary, e.g., the IP, Mask and Gateway addresses, and then click the "OK" button to **save the new settings**.



The dialog box is titled "Configure Server (UDP)". It contains the following fields and values:


- Server Name: tGW-735_RevB
- DHCP: 0: OFF (dropdown menu)
- Sub-net Mask: 255.255.255.0
- Alias: Tiny
- IP Address: 10.0.8.100
- Gateway: 10.0.8.254
- MAC: 00:0d:e0:8e:43:21

Below the fields, there is a warning message: "Warning!! Contact your Network Administrator to get correct configuration before any changing!". At the bottom right, there are "OK" and "Cancel" buttons.



Step 4 Reset the Init/Run switch on the tGW-700-UL module to the "Run" position and reboot the module.

Step 5 Log in to the web configuration pages for the tGW-700-UL module, using the default web password, "admin".



The screenshot shows the web interface of the Tiny Modbus Gateway. The browser address bar shows "10.0.8.100". The page title is "Tiny Modbus Gateway". The navigation menu includes: Home | Port1 | Network | Filter | SNMP | Monitor | Password | Logout. The main content area displays the message: "The system is logged out. To enter the web configuration, please type password in the following field." Below this message is a login form with a text input field labeled "Login password" and a "Submit" button. At the bottom, there is a red note: "When using IE, please disable its cache as follows. Menu items: Tools / Internet Options... / General / Temporary Internet Files / Settings... / Every visit to the page".

Appendix B: Glossary

1. ARP (Address Resolution Protocol)

The Address Resolution Protocol (ARP) is a telecommunication protocol that is used to convert an IP address to a physical address, such as an Ethernet address.

Consider two machines A and B that share the same physical network. Each has an assigned IP address IP_A and IP_B , and a MAC address, MAC_A and MAC_B . The goal is to devise a low-level software application that hides the MAC addresses and allows higher-level programs to work only with the IP addresses. Ultimately, however, communication must be carried out by the physical networks using whatever MAC address scheme the hardware supplies.

Suppose machine A wants to send a packet to machine B across a physical network to which they are both attached, but A only has the Internet address for B, IP_B . The question arises: how does A map that address to the MAC address for B, MAC_B ?

ARP provides a method of dynamically mapping 32-bit IP address to the corresponding 48-bit MAC address. The term dynamic is used since the mapping is performed automatically and is normally not a concern for either the application user or the system administrator.

2. Clients and Servers

The client-server paradigm uses the direction of initiation to categorize whether a program is a client or server. In general, an application that initiates peer-to-peer communication is called a client. End users usually invoke client programs when they use network services.

By comparison, a server is any program that waits for incoming requests from a client program. The server receives a request from a client, performs the necessary action and returns the result to the client.

3. Ethernet

The term Ethernet generally refers to a standard published in 1982 by Digital Equipment Corp., Intel Corp. and Xerox Corp. Ethernet is the most popular physical layer Local Area Network (LAN) technology in use today.

4. Firmware

Firmware is an embedded software program or set of instructions programmed on a device that provides the necessary instructions for how the device communicated with other computer hardware, and is located or stored in a semi-permanent storage area, e.g., ROM, EEPROM, or Flash memory. Firmware can often be updated by downloading a file from the manufacturer's web site or FTP.

5. Gateway

Computers that interconnect two networks and pass packets from one to the other are called Internet Gateways or Internet Routers. Gateways route packets that are based on the destination network, rather than the destination host.

6. ICMP (Internet Control Message Protocol)

ICMP provides a method of communicating between the Internet Protocol software on one machine and the corresponding software on another. It allows a gateway to send error or control messages to other gateways, or allows a host to diagnose problems with the network communication.

7. Internet

Physically, the Internet is a collection of packet switching networks interconnected by gateways that together with the TCP/IP protocol, allows them to perform logically as a single, large and virtual network. The Internet recognizes hosts using 32-bit IP address.

8. IP (Internet Protocol) Address

Each interface on the Internet must have a unique IP address (also called an Internet address). These addresses are 32-bit numbers, and are normally written as four decimal numbers, one for each byte of the address for example “192.168.41.1”. This is called dotted-decimal notation.

9. MAC (Media Access Control) Address

To allow a computer to determine which packets are meant for it, each device attached to an Ethernet network is assigned a 48-bit integer known as its MAC address (also called the Ethernet address, the hardware address or the physical address). A MAC address is normally written as eight hexadecimal numbers, for example “00:71:88: AF: 12:3e:0f:01”. Ethernet hardware manufacturers purchase blocks of MAC addresses and assign them in sequence as they manufacture Ethernet interface hardware. Thus, no two hardware interfaces can have the same MAC address.

10. Packet


A packet is the unit of data sent across a physical network. It consists of a series of bits containing data and control information, including the source and the destination node (host) address, and is formatted for transmission from one node to another.

11. Ping

Ping is a network administration utility used to test the whether a host on an Internet network is active, and to measure the round-trip time for messages sent from the originating host to a destination computer. Ping operates by sending an ICMP echo request message to a host, expecting an ICMP echo reply to be returned. Normally, if a host cannot be pinged, Telnet or FTP cannot be used to connect to the host. Conversely, if Telnet or FTP cannot be used to connect to a host, Ping is often the starting point to determine the nature of the problem.

12. RARP (Reverse Address Resolution Protocol)

RARP provides a method of dynamically mapping 48-bit MAC address to the corresponding 32-bit IP address. RARP has now been replaced by the Bootstrap Protocol (BOOTP) and the modern Dynamic Host Configuration Protocol (DHCP).



13. Socket

Each TCP segment contains a source and destination port number that can be used to identify the sending and receiving application. These two values, along with the source and destination IP addresses in the IP header, uniquely identify each connection. The combination of an IP address and a port number is called a socket.

14. Subnet Mask

A Subnet mask, often simply called the “Mask”, is a 32-bit number that masks an IP address, and divides the IP address into the network address and the host address. Given its own IP address and its subnet mask, a host can determine whether a TCP/IP packet is destined for a host that is (1) on its own subnet, or (2) on a different network. If (1), the packet will be delivered directly; otherwise it, will be delivered via a gateway or a router.

15. TCP (Transmission Control Protocol)

TCP is a set of rules used in combination with the Internet Protocol to send data in the form of message units between computers over the Internet. TCP provides a reliable flow of data between two hosts and is associated with tasks such as dividing the data passed to it from an application into appropriately sized chunks for the network layer below, acknowledging received packets, setting timeouts to make certain that the other end acknowledges packets that are sent, and so on.

16. TCP/IP

The Transmission Control Protocol (TCP) and the Internet Protocol (IP) is standard network protocols that are almost always implemented and used together in a formation are known as TCP/IP. TCP/IP can be used to communicate across any set of interconnected networks.

17. UDP (User Datagram Protocol)

UDP is an internet protocol that provides a much simpler service to the application layer as it only sends packets of data from one host to another, but there is no guarantee that the packets will reach the destination host. UDP is suitable for purposes where error checking and correction is either not necessary or is performed in the application.

Appendix C: Actual Baud Rate Measurement

Ideal Baud Rate (bps)	Actual Baud Rate (bps)	Error
300	298.48	0.51%
600	597.04	0.49%
1200	1197.6	0.20%
2400	2395.2	0.20%
4800	4790.4	0.20%
9600	9568.0	0.33%
14400	14392	0.05%
19200	19136	0.33%
38400	38464	0.17%
57600	57552	0.08%
115200	114960	0.21%
128000	128240	0.18%
230400	229920	0.21%
250000	250000	0.00%
256000	256400	0.15%
460800	459760	0.22%
921600	921600	0.00%

Note:

Recommended max baud rate is 115200 bps or below.

Because the loading of the module, we don't guarantee a proper operation if using a larger baud rate (over 115200 bps).

Appendix D: Revision History

This chapter provides revision history information to this document.

The table below shows the revision history.

Revision	Date	Description
1.0	Jul. 2025	Initial issue