

User Manual

Version 1.0.3 Jan. 2023





Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning!

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2020 ICP DAS Co., Ltd. All rights are reserved.

Trademarks

Names are used for identification purposes only and may be registered trademarks of their respective companies.

Contents

1.	Introduction4				
2.	Spe	Specifications5			
	2.1. Power Module Specifications		r Module Specifications	5	
	2.2. System Specifications		7		
	2.3. Pin Assignments		ssignments	9	
	2.4. DIP S		witch Configuration	11	
		2.4.1.	Normal Mode	11	
		2.4.2.	Initial Mode	12	
		2.4.3.	Hardware Mode	13	
3.	Mod	lbus TC	P/RTU Protocol14		
	3.1.	Modb	ous Address Mapping	15	
4.	Web	Web Setting19			
	4.1.	Confi	guring Network Settings	19	
	4.2.	Home	Page	20	
	4.3.	Port F	Page	22	
	4.4.	Netw	ork Page	23	
	4.5.	Filter	Page	26	
	4.6.	Monit	tor Page	27	
	4.7.	Passw	vord Page	28	
	4.8.	Logou	ıt Page	29	
5.	RPS Utility				
	5.1.	Introd	luction	30	
	5.2.	User i	nterface introduction	31	
6.	Арр	endix A	A: Firmware Update		
7.	Арр	endix E	3: Modbus Protocol		
	7.1.	Funct	ion 01 - Read Coils	40	
	7.2.	Funct	ion 02 - Read Discrete Inputs	41	
	7.3.	Funct	ion 03 - Read Multiple Holding Registers	42	
	7.4.	Funct	ion 04 - Read Multiple Input Registers	43	
	7.5.	Funct	ion 05 – Write Single Coil	44	
	7.6.	Funct	ion 06 – Write Single Holding Register	45	
	7.7.	Funct	ion 15 – Write Multiple Coils	46	
	7.8.	Funct	ion 16 – Write Multiple Holding Registers	47	
8.	FAQ				
9.	Revision History49				

1. Introduction

In response to the requirements of lots of digital DC power supplies in the industry, ICP DAS has developed the RPS series of redundant power supply, which not only adopts the N+1 parallel-connection and load-sharing technology to implement power redundancy, but also adds communication functions to enable that information of power supply can be monitored in real time. Through the communication functions, user can monitor the working status of the power supply of the whole factory in the monitoring center. When the power module is abnormal, it can be found and dealt with in real time. There is no need to send people to inspect and ensure that the power supply is safe. In particular, the equipment in some important industries such as finance, medical treatment and power plants needs stable power supplies to ensure that the equipment keeps working.

Features

- 90 ~ 264 VAC to 24 VDC
- Each slot can be installed a 100 W power module
- The power module supports hot swap
- 4-slot design, realize N+1 redundancy
 - When 4 power modules are fully inserted, it can provide the load capacity of 3 power modules.
 - When one power module fails, it can still guarantee the normal power supply.
- Load Balancing

The current of the built-in "load balancing" will be evenly distributed to each Power Module to avoid overuse and premature failure of a certain power module.

- Built-in power module diagnosis function
 - Temperature
 - Output current
 - Whether it is faulty
 - > The used time of each power module
- Supports Modbus RTU/TCP communication. The messages of the diagnostic function can be read via Modbus RTU/TCP.
- If the communication module is faulty, it will only affect the communication and won't affect power input/output





2. Specifications

2.1. Power Module Specifications

Electrical Specification			
	DC Voltage	24V	
	Rated Current	4.17A	
	Current Range	0~4.17A	
	Rated Power	100W	
Quitout	Ripple & Noise(max.)	50mVp-p	
Output	Voltage Tolerance	±1.0%	
	Line Regulation	±1.0%	
	Load Regulation	±5.0%	
	Setup, Rise Time	1300ms,120ms at full load	
	Hold Up Time(Typ.)	40ms at full load	
	Voltage Range	90~264VAC	
	Frequency Range	47 ~ 63Hz	
	Power Factor(Typ.)	PF=0.961/230VAC at full load, PF=0.985/115VAC	
loput		at full load	
input	Efficiency(Typ.)	86%	
	AC Current(Type)	1.01A/115VAC 0.51A/230VAC	
	Inrush Current	COLD START 30A/115VAC 60A/230VAC	
	Leakage Current	Earth<3.5mA,Touch<0.25mA	
Protection	Overload	110%~200% (Automatic recovery)	
FIOLECLION	Over Voltage	26.4~31.2 VDC (Automatic recovery)	
	Working Temperature	-20~50°C	
	Working Humidity	5~95%RH Non-condensing.	
	Storage Temperature,	-4085°C	
	Humidity	-40~00 C	
Environment		0.26~6.09 G	
Environment		Frequency Type: Sweep Frequency	
	Vibration	Frequency Range: 10~55 Hz	
		Displacement: 1.0mm	
		Sweep Rate: 60 minute / cycle	
		Number of cycle: 1 cycle / axis	

		Direction: X ,Y and Z axis
	MTBF	100K (hours @ 25°C)
	Safety Standards	Design to meet IEC 62368-1
	Withstand Voltage	I/P-O/P:3KVAC I/P-FG:1.8KVAC O/P-FG:0.5KVAC
	Isolation Resistance	I/P-O/P, I/P-FG, O/P-FG:>100M Ohms / 500VDC
		EN 55032
Safety	EMC Emission	CISPR 32 & FCC Part 15 B
&		CLASS B : System with 4 module in parallel
EMC	EMC Immunity	EN 55022, CISPR 22 & FCC Part 15, EN
		61000-3-2, EN 61000-3-3, EN 61204-3
		IEC 61000-4-2, IEC 61000-4-3, IEC 61000-4-4,
		IEC 61000-4-5, IEC 61000-4-6, IEC 61000-4-8,
		IEC 61000-4-11

Note: This hardware specification is only for one RPS-100 power module. RPS-4M can insert Max. 4 RPS-100 power module.

2.2. System Specifications

COM Port			
Interface		RS-485	
Protocol		Modbus RTU	
Data Format		N,8,1 / O,8,1 / E,8,1 / N,8,2	
Roud Poto		Hardware Configuration: Fixed 9600 bps	
Dauu Kale		Software Configuration: 1200 ~ 115200 bps	
		1 ~ 64 for hardware configuration	
Node Address		1 ~ 255 for software configuration	
		* For Modbus RTU, address 0 is auto become to 1	
Connector		4-pin screw terminal	
Ethernet			
Interface		1 x RJ-45, 10/100 Base-TX	
Protocol		Modbus RTU or DCON	
Security		Password and IP Filter	
Measurement			
Current	Range	0A ~ 5 A	
Current	accuracy	±0.25A	
Tomporaturo	Range	0°C ~ 100°C	
Temperature	accuracy	±5°C	
Communicati	on Module	LED Indicators	
Power (Green)		1 LED as power indicator (Normal : Light up)	
Communicatio	n (Green)	1 LED as Modbus Rx indicator (Communicating : Light up)	
Status (Orange	e)	1 LED as <u>Software Modbus WDT</u> (Timeout : Light up)	
Power Module LED Indicators			
Power (Green)		1 LED as power indicator (Normal : Light up)	
Status (Red)		1 LED as status indicator (Error : Light up)	
EMS Protection	on		
ESD (IEC 610	00-4-2)	±4 kV Contact, ±4 kV Air	
EFT (IEC 6100)0-4-4)	±2 kV for power line	
Surge (IEC 61	000-4-5)	±2 kV for power line	
Power Requir	ements		
Input Voltage F	Range	90~264VAC, 47 ~ 63Hz	
Connector		3-pin screw terminal	
Mechanical			

Dimensions (W x L x H)	133 mm x 266 mm x 177 mm	
Installation	DIN-Rail	
Environment		
Operating Temperature	-20°C ~ +50°C	
Storage Temperature	-40°C ~ +85°C	
Humidity	10 to 90% RH, Non-condensing	

2.3. Pin Assignments



1. DC Output



Pin	Description
1	Power output +24 VDC
2	Power output +24 V _{DC}
3	Ground
4	Ground

2. <u>Relay Output</u>

When any power module fails, this relay will be turn on.



Pin	Description	
1	Relay output: NO.	
2	Relay output: COM	
Form A, 5A		

3. A.C. Power Input



Pin	Description
1	Live Wire (L)
2	Naught wire (N)
3	Earth Wire (G)

4. RS-485 Interface



Pin	Description
1	Data+ (D+)
2	Data- (D-)
3	Data+ (D+)
4	Data- (D-)

2.4. DIP Switch Configuration

2.4.1. Normal Mode



When the RPS-4M DIP is powered on and the DIP switch 1 and 2 are OFF, this is in Normal mode. In this mode, the DIP switch 3 ~ 8 can be ignored, and all communication parameters are specified by the software. The factory default parameters are as follows:

Protocol:	Modbus RTU/TCP
IP address:	192.168.255.1
Mask:	255.255.0.0
Gateway:	192.168.0.1
Modbus TCP Port:	502
Address:	01
Baud Rate:	9600 bps
Data Format:	N, 8, 1
Web Password:	admin

In this mode, the parameters are configurable via the web but Modbus commands.

2.4.2. Initial Mode



When the RPS-4M is powered on and the DIP switch position 1 is OFF and position 2 is ON, this is in Initial mode. In this mode, the DIP switch positions 3 ~ 8 will be ignored and the communication parameters will be set as shown in the following table:

Modbus RTU/TCP
192.168.255.1
255.255.0.0
192.168.0.1
502
01 (0x01)
9600 bps
N,8,1
admin

In this mode, the communication parameters can be set through the web page or Modbus commands, and they will take effect the next time it is started in Normal Mode.

2.4.3. Hardware Mode



When the RPS-4M DIP is powered on and the DIP switch position 1 and 2 are ON, it is in Hardware mode. In this mode, the Modbus station number is set by the DIP switch positions $3 \sim 8$, and other communication parameters apply the original software settings:

Protocol:	Modbus RTU/TCP
IP address:	Configured by software
Mask:	Configured by software
Gateway:	Configured by software
Modbus TCP Port:	Configured by software
Address:	01 + Pin 3 to 8 of DIP switch (01 to 64)
Baud Rate:	Configured by software
Data Format:	Configured by software
Web Password:	admin

In this mode, communication parameters can only be set via the web page, and communication parameters cannot be set via Modbus commands.

3. Modbus TCP/RTU Protocol

The RPS-4M module supports the Modbus TCP/RTU protocol, with communication baud rates ranging from 1200 bps to 115200 bps. The data bits, parity and stop bits are supported 8N1, 8N2, 8E1 and 8O1. The following Modbus functions are supported.

Function Code	Description
0x01	Read the coils (DO)
0x02	Read the discrete inputs (DI)
0x03	Read multiple holding registers (AO)
0x04	Read multiple input registers (AI)
0x05	Write a single coil (DO)
0x06	Write a single holding register (AO)
0x0F	Write multiple coils (DO)
0x10	Write multiple holding registers (AO)

Error Response

Byte	Description	Length (Byte)	Value
00	Address	1	1 ~ 247
01	Function Code	1	Function Code + 0x80
02	Execution Code	1	02: Register not support
02			03: Modbus format invalid

Note: If a CRC mismatch occurs, the module will not respond.

3.1. Modbus Address Mapping

The 0xxxx address of DO can be used to read/write the value, and the 1xxxx address
of DI can only be used to read the value.

Address		Description	Attributo		
DO	DI	Description	Allinbule		
00001	10001	Power module exists in slot 1 (1: exist, 0: not)	R		
00002	10002	Power module exists in slot 2 (1: exist, 0: not)	R		
00003	10003	Power module exists in slot 3 (1: exist, 0: not)	R		
00004	10004	Power module exists in slot 4 (1: exist, 0: not)	R		
00009	10009	Power module working status in slot 1	R		
00000	10000	(1: normal, 0: abnormal)			
00010	Power module working status in slot 2		R		
00010	10010	(1: normal, 0: abnormal)	IX I		
00011	10011	Power module working status in slot 3	R		
00011		(1: normal, 0: abnormal)	IX IX		
00012	10012	Power module working status in slot 4	P		
00012	10012	(1: normal, 0: abnormal)	K		
00021	10021	Whole power supply units working status	D		
00021	10021	(1: all power modules are normal, 0: abnormal)	K		
00101	10101	Host WDT (1: enable, 0 disable)			
00101	10101	This is used to monitor if the host is alive.			
		Host WDT timeout flag.			
00102	10102	If the WDT is timeout, sending a Modbus command	R / W		
		or write 1 to this register address to clear flag.			
Note: Wh	Note: When the watchdog timeout occurs, the STA indicator will start to flash				
00501	10501	Reboot (1: reboot, 0: N/A)	W		

The 4xxxx address of AO can be used to read/write the value, and the 1xxxx address of AI can only be used to read the value.

Address		Description	Attributo
AI	AO	Description	Allibule
30001	40001	Current time: Year	R
30002	40002	Current time: Month	R
30003	40003	Current time: Day	R
30004	40004	Current time: Day of week (1~7: Mon. ~ Sun.)	R
30005	40005	Current time: Hour	R

30006	40006	Current time: Minute	R	
30007	40007	Current time: Second	R	
Note: If	the use	r wants to correct the time, use the function code 0x10 to	write values into	
the 7 re	gisters a	at the same time		
30011	40011	Power supply unit 0 current load, Unit: 10 mA	R	
30012	40012	Power supply unit 1 current load, Unit: 10 mA	R	
30013	40013	Power supply unit 2 current load, Unit: 10 mA	R	
30014	40014	Power supply unit 3 current load, Unit: 10 mA	R	
30019	40019	Power supply unit 0 temperature, Unit: 0.1 °C	R	
30020	40020	Power supply unit 1 temperature, Unit: 0.1 °C	R	
30021	40021	Power supply unit 2 temperature, Unit: 0.1 °C	R	
30022	40022	Power supply unit 3 temperature, Unit: 0.1 °C	R	
20007	40007	Power supply unit 0 current running time,	D	
30027	40027	Unit: 1 hour	ĸ	
20020	40000	Power supply unit 1 current running time,	D	
30028	40028	Unit: 1 hour	ĸ	
20020	40020	Power supply unit 2 current running time,	D	
30029	40029	Unit: 1 hour	ĸ	
20020	40020	Power supply unit 3 current running time,	D	
30030	40030	Unit: 1 hour	IX	
Note: T	he curre	ent running time is the accumulation from the start of the	e module to the	
current	time, les	s than 1 hour will not be included in the calculation		
30035	40035	Power supply unit 0 total running time, Unit: 1 hour	R	
30036	40036	Power supply unit 1 total running time, Unit: 1 hour	R	
30037	40037	Power supply unit 2 total running time, Unit: 1 hour	R	
30038	40038	Power supply unit 3 total running time, Unit: 1 hour	R	
Note: T	he total i	running time is the sum of the usage time of each time the	module is turned	
on, less	s than 1 l	hour will not be included in the calculation		
30051	40051	Power supply unit 1 start date (year)	R	
30052	40052	Power supply unit 1 start date (month)	R	
30053	40053	Power supply unit 1 start date (day)	R	
30054	40054	Power supply unit 1 start date (hour)	R	
30055	40055	Power supply unit 1 start date (minute)	R	
30056	40056	Power supply unit 1 start date (second)	R	
30057	40057	Power supply unit 2 start date (year)	R	
30058	40058	Power supply unit 2 start date (month)	R	
30059	40059	Power supply unit 2 start date (day)	R	

30060	40060	Power supply unit 2 start date (hour)	R			
30061	40061	Power supply unit 2 start date (minute)	R			
30062	40062	Power supply unit 2 start date (second)	R			
30063	40063	Power supply unit 3 start date (year)	R			
30064	40064	Power supply unit 3 start date (month)	R			
30065	40065	Power supply unit 3 start date (day)	R			
30066	40066	Power supply unit 3 start date (hour)	R			
30067	40067	Power supply unit 3 start date (minute)	R			
30068	40068	Power supply unit 3 start date (second)	R			
30069	40069	Power supply unit 4 start date (year)	R			
30070	40070	Power supply unit 4 start date (month)	R			
30071	40071	Power supply unit 4 start date (day)	R			
30072	40072	Power supply unit 4 start date (hour)	R			
30073	40073	Power supply unit 4 start date (minute)	R			
30074	40074	Power supply unit 4 start date (second)	R			
Note: T	he start	date will be recorded when the power module is used for the	ne first time after			
leaving	the facto	ory				
30401	40401	IP0	R			
30402	40402	IP1	R			
30403	40403	IP2	R			
30404	40404	IP3	R			
Note: T	he curre	nt IP of the module is read as "IP0. IP1. IP2. IP3"				
30405	40405	MACO	R			
30406	40406	MAC1	R			
30407	40407	MAC2	R			
30408	40408	MAC3	R			
30409	40409	MAC4	R			
30410	40410	MAC5	R			
Note: T	he curre	nt MAC of the module is read as				
"MAC0	"MAC0. MAC1. MAC2. MAC3. MAC4. MAC5"					
30481	40481	Firmware version(High word HHHH)	R			
30482	40482	Firmware version(Low word LLLL)	R			
Note: The Firmware version of the module is read as "HHHH.LLLL"						
(Ex: HHHH=0001, LLLL=0100 => 1.01)						
30483	40483	Module name (High word)	R			
30484	40484	Module name (Low word)	R			
Note: The name of the module is read as "HHHHLLLL"						

(Ex: 0x52505300 = "RPS")				
30501	40501	Node ID (writable only for Initial Mode)	R/W	
30502 40	40502	RS-485 Communication Parameters (writable only for	R / W/	
	40002	Initial Mode)		
30505	40505	Host WDT timeout, unit: 100ms	R/W	

RS-485 Communication Parameters

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Rese	erved	Data Bit, F	Parity, Stop	Reserved	Buad Rate		
		В	lit				

Buad Rate (Bit 0 ~ Bit 2)

Code	0	1	2	3	4	5	6	7
Baud	1200	2400	4800	9600	19200	38400	57600	115200

Data Bit, Parity and Stop Bit (Bit 4 ~ Bit 5)

Code	0	1	2	3
Format	8, N, 1	8, N, 2	8, E, 1	8, O, 1

For example, if set configuration 0x37, it means Data rate is 115200 bps, Data bits are 8 bits, Parity is odd and Stop bit is 1 bit.

Note: All Reserved bits should be zero.

4. Web Setting

4.1. Configuring Network Settings

1. Downloaded the eSearch Utility and installed according to the installation instructions. The eSearch Utility can be obtained from the ICP DAS web site. The location of the download addresses is shown below:

https://www.icpdas.com/en/download/index.php?nation=US&kind1=&model=&kw=eSearch

- 2. Double click the eSearch Utility shortcut on the desktop.
- 3. Click the "Search Servers" button to search your RPS-4M •
- 4. Once the search process is complete, double-click the name of the RPS-4M to open the "Configure Server" dialog box.



Factory	/ Default	Settinas	of RPS-4M	Module:
i aotor	, Donaan	Counigo		modulo.

IP Address	192.168.255.1
Subnet Mask	255.255.0.0
Gateway	192.168.0.1
Web password	admin

5. Enter the network settings information, including the IP, Mask and Gateway addresses, and then click "OK" button.

Configure Server (U	DP)		_		×
Server Name :	iRPS-R4M100W2-MT	СР	5		
DHCP:	0: 0FF 🔹	Sub-net Mask :	255.255.0.0	Alias:	iRPS
IP Address :	192.168.255.15	Gateway :	192.168.0.1		00:0d:e0:44:55:66
Warning!! Contact your Ne	twork Administrator to g	et correct configura	ation before any chan	ging!	OK Cancel

4.2. Home Page

1. Press the "Web" button

🥩 eSearch Utility [v1.2.3, Ju	n.17, 2020]			-	
File Server Tools					
Name	Alias	IP Address	Sub-net Mask	Gateway	MAC Add
iRPS-R4M100W2-MTCP	iRPS	192.168.255.15	255.255.0.0	192.168.0.1	00:0d:e0
<					>
Search Server	Configuratio	n (UDP)	Web	Exi	t
Status					

2. Enter a password (the factory default password is "admin"), and then click the "Submit" button to continue.



3. The Home link connects to the main page. The software and hardware information section includes information related to the Model Name, the current Firmware version, the IP Address, the current position of the Initial Switch, the Alias, the MAC Address, and the TCP Port, and the Serial Port.



4.3. Port Page

1. Click the "Port1" tab to display the Port1 Settings page.



- 2. Select the appropriate Baud Rate, Data Format (e.g., 19200, 8N1) from the relevant drop down options.
- 3. Click "Submit" to save your settings.

4.4. Network Page

1. Click Network tab to enter Network page.

IoT Power Supply	× +			0	_			×
← → C ▲ 不安全 1	2.168.255.160	0 . 7	۲ (9 (*	≡J	明陽	:
ICP DAS Redunda Home Port	nt Power Supply (RPS)							
Model N	me RPS-4M Alias Nar	me RPS	;					Î
Firmware Ver	ion B1.0.1 [Jun.25 2021] MAC Addre	ess 00-0	d-e0-	16-4	6-06			
IP Add	TCP Port Time 192.168.255.160 (Socket Watchdog, Second)	out ds) 180						
Initial Sv	tch OFF System I (Network Watchdog, Second	dle ds) ⁰						
IP Address Selection							2	
Address	ype Static IP 🗸							
Static IP Add	ess 192 . 168 . 255 . 160							
Subnet N	ask 255 . 255 . 0 . 0							
Default Gate	vay 192 . 168 . 0 . 1							
MAC Add	ess 00-0d-e0-16-46-06 (Format: FF-FF-FF-FF-FF)							
	Update Settings							

2. The following is an overview of the parameters contained in the IP Address Selection section:

Item	Description
Address Type	Static IP: If no DHCP server is installed on the network, the network
	settings can be configured manually.
	DHCP: The Dynamic Host Configuration Protocol (DHCP) is a network
	application protocol that automatically assigns an IP address to each
	device
Static Address	This parameter is used to assign a specific IP address.
Subnet Mask	This parameter is used to assign the subnet mask for the RPS-4M. The
	subnet mask indicates which portion of the IP address is used to identify
	the local network or subnet.
Default	This parameter is used to assign the IP Address of the Gateway.
Gateway	
MAC Address	This parameter is used to set a user-defined MAC address.

	X
See Tot Power Supply X	T U
← → C ▲ 不安全 192.168.2	.55.160 •• 🖈 🙂 🕐 🗄
ICP Redundant Po	ower Supply (RPS)
DAS Home Port1 Netwo	ork Filter Monitor Password Logout
General Settings	3
Ethernet Speed	uto V (Auto=10/100 Mbps Auto-negotiation)
HTTP port	(Default= 80)
Alias Name R	PS (Max. 18 chars)
TCP Port Timeout (Socket Watchdog)	0 (0 ~ 86400 seconds, Default: 180, Disable: 0)
Web Auto-logout 10	(1 ~ 65535 minutes, Default: 10, Disable: 0)
UDP Configuration: E	nable (Enable/Disable the UDP Configuration, Enable=default.)
	Update Settings
Time Synchronization	
	4
20	Copy from this PC 121/06/25, 16:06:54.639, Fri
User define time	User keyin
20	21 / 01 / 03 , 00 ; 00 ; 00 , <u>Sun ▼</u>
	21/06/25,16:06:53,1rn
Modbus Settings	
	5
Drops packet when Modbus TCP he	ader (protocol ID, length) is wrong.
Node ID 1	(Default: 255)
	Update Settings

3. The following is an overview of the parameters contained in the General Settings section:

Item	Description
HTTP Port	This parameter is used to assign specific a HTTP port of RPS-4M.
	The RPS-4M needs to be restarted when the HTTP port is changed.
	You need manually type the new HTTP port in the address bar of the
	browser. The default is 80.
Alias Name	This parameter is used to assign an alias for each RPS-4M to assist
	with easy identification.
TCP Port Timeout	This parameter is used to configure the TCP Port timeout value. If
	there is no activity on the network for a specific period of time,
	RPS-4M will close the connection to the client.
Web Auto-logout	This parameter is used to configure the automatic logout value. If
	there is no activity on the web server for a certain period of time, the
	current user account will be automatically logged out.
UDP Configuration	This parameter is used to enable or disable UDP configuration

function

- 4. Time Synchronization section can correct the time with the computer or customize the time
- 5. User can change the Modbus node ID in Modbus Setting section.

S loT Power Supply × +	• - □ ×
← → C ▲ 不安全 192.168.255.160	⊶ ☆ 🤨 🏚 🗊 🙉 :
Redundant Power Supply (RPS) Home Port1 Network Filter Monitor Passwe	ord Logout
Restore Factory Defaults	6)^
Restore all options to their factory default states:	Restore Defaults
Forced Reboot	Reboot
Update by Ethernet	
If the remote firmware update is failed, then the traditional firmware update (on-site) is required to make the module working again. Step 1: Refer to firmware update manaul first. Step 2: Run eSearch Utility to prepare and wait for update. Step 3: Click the [Update] button to reboot the module and start update. Step 4: Configure the module again.	Update
	Copyright © 2020 ICP DAS Co., Ltd. All rights reserved.

6. Restore Factory Defaults section include two part:

Item	Description
Restore Defaults	Reset all parameters to their original factory default settings
Reboot	Force the RPS-4M to reboot or to remotely reboot the
	device.

7. Update by Ethernet function can update firmware remotely. Traditional firmware update requires adjusting the Init/Run Switch and reboots the module manually for the initialization of firmware update, while new firmware allows user to initialize the module via web interface without adjusting the hardware switch. Initialization via web is useful when module is installed in remote site and can be accessed by a remote PC via TeamViewer

For more details, refer to appendix A.

4.5. Filter Page

The Accessible IP (filter is disabled when all zero) Settings page is used to query or edit the IP Filter List. The IP Filter List restricts the access of packets based on the IP header. If one or more IP address are saved to the IP Filter table, only clients whose IP is specified in the IP Filter List can access the RPS-4M.



The following is an overview of the parameters contained in the Accessible IP section:

Item	Description
Add "IP" to the list	Add an IP address to the IP Filter List.
Delete IP# "Number"	Delete a specific IP# (Number = 0 to 4) address from the IP
	Filter List
Delete All	Delete all items from the IP Filter List.
Save	Save a new IP Filter List to the Flash memory
Configuration(finish)	

4.6. Monitor Page

User can check of the IPs which connect to RPS-4M.



4.7. Password Page

After clicking the Password tab, the Change Password page will be displayed. The following are the steps for changing password.

Step 1: Enter the old password in the "Current password" field

(Note: Use the default password "admin", when change password for the first time.)

Step 2: Enter a new password in the "New password" field $\,\circ\,$

Step 3: Re-enter the new password in the "Confirm new password" field.

Step 4: Click the "Submit" button to update the password.



4.8. Logout Page

After clicking the Logout tab, you will be immediately logged out from the system and be returned to the login page.



5.RPS Utility

5.1. Introduction

This chapter describes how to use the RPS_Utility developed by ICP DAS. This tool needs to be used with a redundant power supply developed by ICP DAS (such as RPS-4M). This tool is installed on the PC side, and collects the data of the redundant power supply through COM Port or Ethernet. RPS_Utility displays the data on the screen, and provides on-site engineers to inspect the redundant power supply and set the system parameters.

At present, ICP DAS's RPS-4M provides RS-485 and Ethernet communication interfaces. When PC-side users connect with RPS-4M through RS-485 communication, they need to use a conversion module (e.g., ICP DAS's I-7561, I-7520, etc.) convert the RS-232 or USB communication interface on the PC to the RS-485 communication interface. When connecting to the RPS-4M through the Ethernet interface, the user need to use the network cable and correctly set the IP related information.

The software features are as follows:

- Communicate with ICP DAS redundant power supply via Modbus RTU or Modbus TCP protocol
- Instantly view the measured value of the redundant power supply
- Instantly set the parameters of the redundant power supply system
- Provide data recording function

5.2. User interface introduction

Redundant Power Supply Utility v1.01	- 🗆 X
Connection Config View Cursor Language Power Unit Info	
Start / Stop ModuleInfo 3 Slot 1 Slot 2 4 Slot 3 Slot 4 Displa Node 1 Firware Version: Module: RPS-4M 1.01 Working Working Working Working Slot 3 Slot 4 Displa	ay Slot pt 1-4 pt 5-8 弘格科技 icP DAS CO., LTD.
Slot 1 382 °C 6 Slot 3 Slot 4 100 5 90 90 80 90 70 90 60 90 70 90 60 90 90 90	Slot 1 Current: 0 A 2 h Temperature: 38.2 °C 4 h Slot 2 Current: 0 A 2 h Temperature: 0 A 2 h Slot 2 Current: Runtime: 36 °C 4 h Slot 3 Current: 0 A 2 h Temperature: 0 A 2 h Temperature: 0 A 2 h Current: 0 A 0 h Current: 0 A Current: 0 A 0 h Current: 0 A Current: 0 A Current: 0 A 0 h Current: 0 A 0 h
Temperature 0 6/30 01/35 00 11:55:00 11:57:00 11:57:00	0 °C 0 h 2021//06//30-11:58:14

1. [Toolbar]:

Configure Utility and Module

2. [Start/End Monitoring]:

Start/stop real-time monitoring function

3. [Module Basic Information]:

Get the module type and firmware version after connecting with the module

4. [Real-time power module status 1]:

After starting the real-time monitoring function, you can check if there is a power module in the slot and if this power module is broken.

5. [Choose which run chart to be display]:

Select which slot and which run chart type to be displayed in block 6

6. [Run chart]:

Run chart of power module current and temperature

7. [Real-time power module status 2]:

After starting the real-time monitoring function, you can view the current, temperature, and usage time of the power module in the slot.

[Toolbar]

[Connection]:

The user can choose to use Modbus RTU or Modbus TCP and needs to fill in the corresponding parameters to connect to RPS-4M.

Redundant Power Supply Utility v1.01 Connection Config View Cursor Lang RTU Connect TCP Disconnect Module:	COM Port Setting COM Port Setting COM Port: COM1 ~ Connect BAUD: 9600 ~ Connect Other: 8,n,1 Node: 1	- C X
Redundant Power Supply Utility v1.01	u 💀 TCP_Con − 🗆 X	- 🗆 X
RTU ModuleInfo TCP Connect Disconnect Module:	IP 192.168.255.1 Port 502 Node 1	ICP DAS 泓格科技
	Connect	

[Config]:

When RPS-4M is in Initial mode, the RS-485 parameters of the module can be set through this function on the left side of the interface. In addition, the Modbus watchdog function can be set in any mode on the right side fo the interface (and the unit is 100ms).



[View]:

Set the run chart display mode, which can display the run chart for a single slot or four slots





[Language]:



Choose the language of the interface



[Power Unit Info]:

The date when the power module was used and the accumulated running time.

💀 Redundant P	ower Suppl	ly Utility v	v1.01									- 🗆	\times
Connection	Config	View	Cursor	r Language	Power Unit Info								
Start / Stop	M	oduleInfo	0	🖳 Power Uni	t Info	_	- 🗆	×	Slot 4	Di	isnlav Slot		>
		Node	1	- Date of fi	rst use	Total Ru	ntime		Detected 🔴	۲	Slot 1~4		
	M	fodule:	RP	Slot 1	2021/06/25-15:32:12	Slot 1	4	7	Working 🔴		Slot 5~8	込格科技	ż
Slot 1	A O	-									Slot 1	ICF DAS CO., EI	0.
Slot 2				Slot 2	2021/06/25-15:32:12	Slot 2	4				Current:	Runtime:	
Slot 3				Slot 3	0000/00/00-00:00:00	Slot 3	0				0 A	2 հ	4
Slot 4				Slot 4	0000/00/00-00-00-00	Slot 4	0				Temperature:	Total Runtin	ne:
	4.5-			3101 4	0000/00/00-00:00:00	3101 4	U				38.2 °C	4 h	4

6. Appendix A: Firmware Update

Name	Alias	IP Address	Sub-net Mask	Gateway	MAC Ad
iRPS-R4M100W2		Ping Server	Server (UDP)	192.168.0.1	00:0d:e
		Firmware U	pdate	3	
		Locate Copy to Clip	> pboard		
.1				-	>

Step 1: In the eSearch Utility, click the "Search Servers" button to search the for any RPS-4M modules connected to the network .

- Step 2: Right click on the name of the RPS-4M module to be updated.
- Step 3: Select the "Firmware Update" item from the popup menu and the "Open" dialog box will be displayed.



Step 4: In the "Open" dialog box, select the firmware file that will be used to update the module and then click the "Open" button.

Firm	nware Update (Tin	y Module only)	×
5	File Name ir Note: This IP / while the MAC	mware\iRPS_M4FW_v1.00 Address is depending on ye C address in depending	RevB.dat
	IP Address	192.168.255.15	
	MAC Address	00:00:20:44:55:66	Factory-default MAC Address
	6	OK Cancel	

Step 5: Assign a valid IP Address (can be different with the current IP) and the factory-default MAC Address for the RPS-4M module. If this

IP address is invalid (e.g. IP Address: 0.0.0.0) or a user-defined MAC address is assigned. Refer to note 2 and note 3 for more details.

Step 6: Click the "OK" button.



C:\WINDOWS\system32\cmd.exe



Step 7: You are now ready to update the firmware. A Command Prompt windows will be displayed the progress of the update.

Step 8: Click the "Network Setting" tab to display the Network Settings page

Step 9: Click the "Update" button in the "Remote Firmware Update" section to start the update

S loT Power Supply × +	×
← → C ▲ 不安全 192.168.255.15	☆ 🗾 🧿 💷 🗎 🕶 🥮 🗄
Redundant Power Supply (i 8 Home Port1 Network Filter Monitor	RPS-xxxx) Password Logout
Restore all options to their factory default states:	Restore Defaults
Forced Reboot	Reboot
Update by Ethernet	
If the remote firmware update is failed, then the traditional firmware update (on-site) is required to make the module working again. Step 1: Refer to firmware update manaul first. Step 2: Run eSearch Utility to prepare and wait for update. Step 3: Click the [Update] button to reboot the module and start update. Step 4: Configure the module again.	9 Update

Step 10: Confirm that the two MAC addresses (factory-default) listed in the Command Prompt window, "Waiting request from MAC x.x.x.x" and "BOOTPREQ from MAC: x.x.x.x", are the same, as indicated in the image below. If these addresses do not match, the update cannot proceed. Refer to note4 below for more details.

Step 11: Once the update is complete (i.e., when the progress indicator reaches 100%), close the Command Prompt window.



Note 1: If the IP address settings do not work correctly (e.g. there is no response to a ping command), please contact your network administrator to obtain a valid IP address for the RPS-4M module.

.....

Note 2: If the settings displayed in the IP address field of the firmware update window is incorrect or invalid (e.g. IP address: 0.0.0.0), then a valid IP address must be manually specified for the RPS-4M in order to process the update operation. Please contact your network administrator to obtain a valid IP address before proceeding.

.....

Note 3: When updating the firmware, the factory-default MAC address is used rather than the user-defined MAC address. Thus, the MAC address (user-defined) displayed in the firmware update window may not be the one required. If this is the case, the factory-default MAC address should be manually entered into the MAC Address field, or restore the MAC address to the factory-default settings via the web configuration pages.

.....

Note 4: The "BOOTPREQ from MAC: xx-xx-xx-xx-xx" message indicates there is a module with the factory-default MAC address "xx-xx..." that is asking for the firmware to be updated. The update process will not begin if you assign a user-defined MAC address in the firmware update window, since the addresses do not match. If this situation occurs, repeat the update procedure and manually enter the factory-default MAC address in the firmware update window, as described in Step 5. The firmware update procedure is illustrated in the figure below



7. Appendix B: Modbus Protocol

7.1. Function 01 - Read Coils

This function code is used to read the value at addresses 0xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x01
02 – 03	Reference Address	Refer to section 3.1 – Address 0xxxx
04 – 05	Bit Count	Number of bit (B) to read

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x01
02	Byte Count	Response data byte N = B/7
03 – (N+ 2)	Bit Value	Response bit data

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x81
02	Exception Code	Refer to section 3 – Error Response

7.2. Function 02 - Read Discrete Inputs

This function code is used to read the value at addresses 1xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x02
02 – 03	Reference Address	Refer to section 3.1 – Address 1xxxx
04 – 05	Bit Count	Number of bit (B) to read

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x02
02	Byte Count	Response data byte N = B/7
03 – (N +2)	Bit Value	Response bit data

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x82
02	Exception Code	Refer to section 3 – Error Response

7.3. Function 03 - Read Multiple Holding Registers

This function code is used to read the value at addresses 4xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x03
02 - 03	Reference Address	Refer to section 3.1 – Address 4xxxx
04 – 05	Word Count	Number of word (W) to read

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x03
02	Byte Count	Response data byte N = W*2
03 – (N +2)	Word Value	Response word data

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x83
02	Exception Code	Refer to section 3 – Error Response

7.4. Function 04 - Read Multiple Input Registers

This function code is used to read the value at addresses 3xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x04
02 – 03	Reference Address	Refer to section 3.1 – Address 3xxxx
04 – 05	Word Count	Number of word (W) to read

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x04
02	Byte Count	Response data byte N = W*2
03 – (N +2)	Word Value	Response word data

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x84
02	Exception Code	Refer to section 3 – Error Response

7.5. Function 05 – Write Single Coil

This function code is used to write a value to addresses 0xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x05
02 – 03	Reference Address	Refer to section 3.1 – Address 0xxxx
04 – 05	Output Value	Output ON: 0xFF00
		Output OFF: 0x0000

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x05
02 – 03	Reference Address	The same as byte 02 – 03 of request
04 – 05	Output Value	The same as byte 04 – 05 of request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x85
02	Exception Code	Refer to section 3 – Error Response

7.6. Function 06 – Write Single Holding Register

This function code is used to write a value to addresses 4xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x06
02 – 03	Reference Address	Refer to section 3.1 – Address 0xxxx
04 – 05	Output Value	A word value

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x06
02 – 03	Reference Address	The same as byte 02 – 03 of request
04 – 05	Output Value	The same as byte 04 – 05 of request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x86
02	Exception Code	Refer to section 3 – Error Response

7.7. Function 15 – Write Multiple Coils

This function code is used to write values to addresses 0xxxx.

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x0F
02 – 03	Reference Address	Refer to section 3.1 – Address 0xxxx
04 – 05	Bit Count	Number of bit (B) to write
06	Byte Count	Byte number N = B/7
		A bit corresponds to a channel.
07 – (N+ 6)	Write Data	Output ON: The bit = 1
		Output OFF: The bit = 0

Request

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x0F
02 – 03	Reference Address	The same as byte 02 – 03 of request
04 – 05	Output Value	The same as byte 04 – 05 of request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x8F
02	Exception Code	Refer to section 3 – Error Response

7.8. Function 16 – Write Multiple Holding Registers

This function code is used to write values to addresses 4xxxx.

Request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x10
02 – 03	Reference Address	Refer to section 3.1 – Address 0xxxx
04 – 05	Word Count	Number of word (W) to write
06	Byte Count	Byte number N = W*2
07 – (N+ 6)	Write Data	Multiple word data

Response

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x10
02 – 03	Reference Address	The same as byte 02 – 03 of request
04 – 05	Output Value	The same as byte 04 – 05 of request

Byte	Description	Value
00	Module ID	1 ~ 247
01	Function Code	0x90
02	Exception Code	Refer to section 3 – Error Response

8.FAQ

9. Revision History

Revision	Date	Description of Change
1.03	2023/01/06	Add Communication Module (RPS-4M) and Power
		Module (RPS-100) LED definitions.
		Add Power Module (RPS-100) MTBF.
		Add Chapter 8 & 9.
1.00	2021/06/16	Document release.