

iKAN Series Message Display

User Manual

V 1.1.0, Dec. 2022



iKAN-116(A)/iKAN-116S/iKAN-124(A)/iKAN-124S

iKAN-208(A)/iKAN-216(A)/iKAN-224(A)



Technical Support: service@icpdas.com Author: Tony Lee Editor: Anna Huang All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright @ 2021 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

Names are used for identification only and may be registered trademarks of their respective companies.

Contact US

If you have any problem, please feel free to contact us by email at: <u>Service@icpdas.com</u>. You can count on us for quick response.

Contents

1.		Introd	luction	6
1	.1.	Featur	es	7
1	.2.	Specifi	ication	9
1	.3.	Overvi	ew	.12
1	.4.	Wire C	Connection	. 15
1	.5.	Dimen	sion	. 17
2.		Gettin	ng Started	21
2	.1.	Checki	ng the Package	.21
2	.2.	Assem	bling the iKAN	.24
	2.	2.1.	Installing a Single-Panel iKAN Display	.24
	2.	2.2.	Installing a Two-Panel iKAN Display	.25
	2.	2.3.	Installing Three-Panel iKAN Display	.27
2	.3.	Conne	cting to the Power and PC	.30
2	.4.	Conne	cting the iKAN to a Network	.31
2	.5.	Editing	g Your First iKAN Message	.33
3.		Config	guration	36
3	.1.	Web Ir	nterface	.37
	3.	1.1.	Editing and Managing Messages	.38
	3.	1.2.	Applying the Variable Maps	.39
		3.1.2.1	Mapping Physical Values to Integer-Type Variables	.41
		3.1.2.2	Changing the Number of Decimal Places for the Value of a Float-type Variable	.42
		3.1.2.3	8. Assigning Strings to Coil Variables	.43
	3.	1.3.	DIO	.44
	3.	1.4.	DL Status	.45
	3.	1.5.	System	.46

3.2. Syste	m Configuration	49
3.2.1.	Exporting pre-configured messages	50
3.2.2.	Ethernet Configuration	54
3.2.3.	Serial Port Configuration	56
3.2.4.	MISC	58
3.3. eSea	rch Utility	63
3.3.1.	Configuring the IP Address	64
3.3.2.	Sending the Modbus Command to iKAN	66
3.3.2	.1. Sending Modbus RTU Command to the iKAN Display	67
3.3.2	.2. Send Modbus TCP Command to the iKAN display	69
4. Mess	sages	71
4.1. Editir	ng and Managing Messages	71
4.2. Displ	aying Messages with Variables	75
4.2.1.	Inserting System Variables into a Message	80
4.2.1	.1. Displaying the IP Address	80
4.2.1	.2. Displaying the Current Date and Time	83
4.2.2.	Inserting Integer-type Variables into a Message	86
4.2.3.	Inserting float-type Variables into a Message	89
4.2.4.	Inserting Coil –type Variables into a Message	92
4.2.5.	Inserting ASCII Strings into a Message	95
4.2.6.	Inserting Unicode Strings into a Message	99
4.3. Displ	aying a Value Applied using a Variable Map1	03
4.3.1.	Displaying Mapping Data for Integer-type Variables1	04
4.3.2. Variable	Displaying a Value with a Specified Number of Decimal Places for Float-type es 107	
4.3.3.	Displaying the Value of a Coil Variable using Replacement Text1	09

5.	Displaying Data from CL/DL series modules	112
5.1	l. Displaying Data from CL/DL Modules Connected to Ethernet	114
5.2	2. Displaying Data from CL/DL Modules Connected to RS-485	123
Арре	endix. Variable Types and Modbus Register Map	132
Revis	sion History	138

1. Introduction

The iKAN series is a family of industrial Modbus LED display devices that deliver industrial-grade anti-noise capabilities, as well as reliability and stability. ASCII characters and Unicode characters, which can be used to display multiple languages like Thai, Arabic, Hebrew, Hindi or Japanese, are supported for presenting formatted messages. Support for the popular Modbus industrial protocol is provided meaning that the iKAN display device can be easily integrated into existing PLC and SCADA environments.

Messages can be edited using a standard web browser, such as Google Chrome, Firefox, or IE on a PC, mobile device, or smartphone without any limitations related to specific control tools or programs. Each model in the iKAN series provides storage space for up to 128 messages with user-defined priority. In addition, 168 variables allow data on a PC, PLC or other controller to be automatically integrated into a message and then displayed. With an open user interface and the ability to display real-time data from other devices, the iKAN series message displays can be applied in shopping malls, railway stations, industrial areas, or in situations where visual display is the easiest way of delivering your message.



1.1. Features

The following is a brief summary of the features and capabilities of iKAN displays.

PLC HMI

The iKAN series can be employed as a large HMI with a memory storage of up to 128 messages with user-defined priority, each of which can be used to display information generated by a PLC. Message text can be displayed in a range of seven colors, including red, blue, yellow, green, light blue, purple, and white, which can be used to indicate warnings or alarms, as well as increasing the readability of a message.



Support for Multiple Languages

The iKAN series of display device supports Unicode input, meaning that messages can be configured to be displayed in multiple languages.

Message Editing

A maximum of 128 messages with user-defined priority can be preconfigured from the first moment that the iKAN series display is switched on. When the display is in operation, the focus needs only be on message management rather than the need to frequently update the messages.

Message Priority

Instant messages have a higher priority than common messages. Once an instant message is enabled, the common message currently being displayed will be suspended until the instant message is disabled. This feature allows the most important information to be displayed in an emergency situation.

Integer-type variables enable data mapping

The iKAN series of display devices provide the ability to perform data mapping by translating a value of integer-type variable to a readable physical quantity, such as the voltage, temperature, or relative humidity, etc. In the industrial field, this is a commonly performed task when a host computer reads data from a data-acquisition device via the Modbus protocol, the function of data mapping enables a reduction in the resources and programming required for the host computer

Import/Export the message configuration

The iKAN series allows a message and the parameters of the variables to be saved as a configuration file, which can then be loaded onto another iKAN series device to avoid the need to repeat the configuration.

Smartphone Application

Users can manage messages via a regular smartphone without requiring a specific connection device, meaning that emergency information can be quickly sent to the display using the smartphone.

1.2. Specification

The table below summarizes the specifications of the iKAN series of displays.

iKAN-116/iKAN-116S/iKAN-124/iKAN-124S

Model		iKAN-116	iKAN-116S	iKAN-124	iKAN-124S	
Display					<u></u>	
Color		Red, Blue, Yellow	w, Green, Light Blu	ue, Purple or Whit	te	
Character Sets	5	16 x 16 Unicode	or 8 x 16 ASCII			
	Line	1				
Display Size	ASCII	16 characters	16 characters		24 characters	
	Unicode	8 characters		12 characters		
Message Pool		128 common m Up to 20 Unicoc	essages with user le characters or 50	-defined priority 0 ASCII characters	evels each	
Data Pool		40 Coil values, 6	4 Float values, an	d 64 Integer value	es	
RTC (Real-time Clock)		Date and time, 24 hour format, including hours, minutes, seconds, day of the week, date, month, year				
Ethernet						
Port		2 x RJ-45, 10/100 Base-TX				
Protocol		Modbus TCP Master/Slave, Max. 8/8 connections				
Configuration		Web-based User Interface				
COM Port						
Interface		2 x RS-485				
Baud rate (bp:	s)	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200				
Data Format		N81, E81, O81				
Protocol		Modbus RTU Master/Slave				
Mechanical						
Dimensions (W x H x D, unit: mm)		1346 x 160 x 49	835 x 115 x 37.5	1986 x 160 x 49	1218 x 115 x 37.5	
Weight		4.0 Kg	2.0 Kg	4.6 Kg	2.5 Kg	
Installation		Wall mounting				
Casing		Aluminum				

Model	iKAN-116	iKAN-116S	iKAN-124	iKAN-124S
Power				
Input Range	100 to 240 VAC			
Consumption	0.3A @ AC 120 V		0.35 A @ AC 120 V	
Environment				
Operating Temperature	0 to 60°C			
Storage Temperature	-10 to 75°C			
Humidity	10 to 90% RH, Non-condensing			

iKAN-208/iKAN-216/iKAN-224

Model		iKAN-208	iKAN-216	iKAN-224	
Display					
Color		Red, Blue, Yellow, Green, Light Blue, Purple or White			
Character Sets	S	16 x 16 Unicode or 8 x	k 16 ASCII		
	Line	2			
Display Size	ASCII	16 characters 32 characters		48 characters	
	Unicode	8 characters	16 characters	24 characters	
Message Pool		128 common messag Up to 20 Unicode cha	es with user-defined pri racters or 50 ASCII char	ority acters each	
Data Pool		40 Coil values, 64 Floa	at values, and 64 Integer	r values	
RTC (Real-time	e Clock)	Date and time, 24 hou day of the week, date	ur format, including hou , month, year	rs, minutes, seconds,	
Ethernet					
Port		2 x RJ-45, 10/100 Bas	e-TX		
Protocol		Modbus TCP Master/Slave, Max. 8/8 connections			
Configuration		Web-based User Interface			
COM Port					
Interface		2 x RS-485			
Baud rate (bps)		1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200			
Data Format		N81, E81, O81			
Protocol		Modbus RTU Master/Slave			
Mechanical					
Dimensions (W x H x D, un	it: mm)	707 x 320 x 50	1346 x 160 x 49	1986 x 160 x 49	
Weight		4 Kg	8 Kg	12 Kg	
Installation		Wall mounting			
Housing Mate	rial	Aluminum			
Power					
Input Range		100 to 240 VAC			
Consumption		0.3 A @ AC 120 V	0.4 A @ AC 120 V	0.5 A @ AC 120 V	
Environment					
Operating Temperature		0 to 60°C			
Storage Temp	erature	-10 to 75°C			
Humidity		10 to 90% RH, Non-condensing			

1.3. Overview

The iKAN series display is equipped with a number of interfaces and peripherals that can be integrated with external systems. Here is an overview of the components and a description of each.



The details of these items are as follows:

Reset Button

The reset button is used to check the IP address and restore all settings to the factory default.

By pressing the Reset button for 5 seconds, the IP address for the iKAN series device will be shown on the display. This is very useful, especially when you have forgotten the IP address needed to access the iKAN series display.

By pressing the Reset button for 8 seconds, all messages and variable configuration settings will be reset to the factory defaults.

• LED Indicator

The iKAN series display contains six LED indicators that display the status of the iKAN series display. The details are:

LED Indicator/Label	State	Meaning	
	Red	The power is on.	
	Red-Blinking	The OS is functioning.	
Reset	Red	The Reset button is activated.	
	Orango	These LED indicators are used to indicate the status	
	Orange	of the Digital I/O.	
	Groop	These LED indicators are used to indicate the status	
DI0, DO0	Green	of the Digital I/O.	

• Ethernet Port (E1 and E2)

The iKAN series display contains two Ethernet ports that can be used to connect a router to the Internet, or to other devices.

Each Ethernet port provides two LED indicators that display the connection status. The details are:



LED Indicator/Label	Label	State	Meaning
	Link/Act	Green	The Link is active.
E1 \ E2		-	The Link is inactive.
		Green-Blinking	Network activity.

• Terminal Block

The iKAN series display contains a terminal block with 20 poles, as illustrated below. For more information related to the identification of the wiring connections, refer to **Section 1.4. Wire Connection**.



COM Ports	
COM1: RS-485	D1+ and D1-
COM2: RS-232	TxD, RxD and GND
COM3: RS-485	D2+ and D2-

Digital Input/Digital Output			
Digital Input 1	DIO and DI.GND		
Digital Input 2	DI1 and DI. GND		
Digital Output 1	DO.PWR, DO0 and DO.GND		
Digital Output 2 DO.PWR, DO1 and DO.GND			

1.4. Wire Connection

The iKAN series display contains a terminal block which provides access to a number of communication formats. The following illustrates the wiring information for the terminal block.

RS-232 Wiring



RS-485 Wiring



DI Wiring



DO Wiring

Input Type	On State Readback as 1	OFF State Readback as 0	
	+5 to +24 VDC	Open	
DO (Sink, NPN)	DO.PWR O DOx O DO.GND O	DO.PWR O X DOx O DO.GND O	

1.5. Dimension

The diagrams below provide details of the dimensions for the iKAN series of displays that can be used when defining the specifications for any enclosures to be installed. All dimensions are in millimeters.

iKAN-116S



iKAN-124S





iKAN-124

iKAN-116









iKAN-216



iKAN Series Display User Manual





iKAN Series Display User Manual

Page: 20

2. Getting Started

If you are new to iKAN, you should read this chapter first, as it provides a description of the basic procedures that need to be followed when installing, configuring, and activating the iKAN system, before operating the iKAN for the first time.

2.1. Checking the Package

Before starting any task, check the contents of the shipping package. If any of the following items are missing or damaged, contact your dealer or distributor.

• For Single-Panel iKAN Display: iKAN-116S, iKAN-124S and iKAN-208

<u>iKAN-116S/iK</u>	<u>AN-124S/iKAN-208</u>		Quick Start Guide
+ + +		/	T T T
Wall Mounting Kit * 2	<u>CA-0910</u>	Screw Driver	M4x6L Screw
	RS-232 Cable		iKAN-116S: Screw * 8
			iKAN-124S: Screw * 8

iKAN-208: Screw *16

• For Two-Panel iKAN Display: iKAN-116 and iKAN-216



<u>iKAN-116/iKAN-216</u>



Quick Start Guide



Wall Mounting Kit * 2



<u>CA-0910</u> RS-232 Cable



Screw Driver



<u>M4x6L Screw</u> iKAN-116: Screw * 8 iKAN-216: Screw *16



<u>M3x6L Screw</u> iKAN-116: Screw * 6 iKAN-216: Screw *8 • For Three-Panel iKAN Display: iKAN-124 and iKAN-224



<u>iKAN-124/iKAN-224</u>



Quick Start Guide



Wall Mounting Kit * 2

<u>CA-0910</u> RS-232 Cable



Screw Driver



<u>M4x6L Screw</u> iKAN-124: Screw * 8 iKAN-224: Screw *16



<u>M3x6L Screw</u> iKAN-124: Screw * 12 iKAN-224: Screw *16

2.2. Assembling the iKAN

Before installation, ensure that the surface dedicated for installation is suitable for supporting the weight of the device. We do not recommend soft and fragile surfaces, such as polystyrene foam, mineral wool, plaster boards, or wooden walls with a thickness of less than 30 mm.

2.2.1. Installing a Single-Panel iKAN Display

Fasten the left and right mounting plates to each side of the iKAN display with the 8/16 screws supplied.

iKAN-116S/iKAN-124S



iKAN-208



2.2.2. Installing a Two-Panel iKAN Display

Both the iKAN-116 and iKAN-216 consist of two modules, the left hand module and the right hand module. Each line of the module contains two connectors that can be used to connect the iKAN display.

1. Remove the connectors from the opening on the side of the module:



Right Side View



2. Connect the connectors and attach the modules



3. Fasten the modules together using the 6/8 (M3 x 6L) screws supplied



4. Fasten the left and right mounting plates to each side of the iKAN display with the 8/16 (M4 x 6L) screws supplied

iKAN-116



iKAN-216



2.2.3. Installing Three-Panel iKAN Display

Both the iKAN-124 and iKAN-224 consist of three modules, the left hand module, the middle module, and the right hand module. Each row of the module contains two connectors that can be used to connect the iKAN display.

1. Remove the connectors from the opening on the side of the module:





2. Connect the connectors and attach the modules



3. Fasten the modules together using the 12/16 (M3x 6L) screws supplied



4. Fasten the left and right mounting plates to each side of the iKAN display with the 8/16 (M4 x 6L) screws supplied

iKAN-124



iKAN-224



2.3. Connecting to the Power and PC

The iKAN series display includes two standard Ethernet ports (RJ-45) which provide access to the iKAN via a PC. To configure the iKAN using the PC, you must first establish a connection between the iKAN and the PC.

- 1. Connect the AC power to the iKAN device.
- 2. Connect the Ethernet cable to the Ethernet port, and then connect the other end of the cable to an available port on the network router, switch, or hub, as illustrated below



Power Supply

2.4. Connecting the iKAN to a Network

The factory default IP address for each iKAN device is **192.168.255.1**.

Before integrating an iKAN series display into your network, you should configure the IP, Subnet Mask, and Gateway addresses for the device by setting the values that are valid for your network system.

The eSearch Utility has been developed to allow you to search for ICP DAS Ethernet I/O modules based-on MiniOS7 which are connected to the same subnetwork as the Host PC, and then you can configure the Ethernet parameters such as the IP Address, Subnet Mask and Gateway.

1. Download the latest version of the eSearch Utility



The eSearch Utility can be obtained from: <u>https://www.icpdas.com/en/download/index.php?nation=TW&kw=esearch</u> Default Installation Path:

C:\ICPDAS\eSearch

2. Launch the eSearch utility and click the Search Server button

	🥩 eSea, /U	Itility [v1.3.0, Jul.2	5, 2022]		_		
	<u>File</u> Server	<u>T</u> ools					
	Name	Alias	IP Address	Sub-net Mask	Gatev	way	
I							
	*						
	\$						
	<				[

3. Once the search process has completed, double-click the name of iKAN display to open the

🥩 eSearch Utili	ty [v1.3.0, Jul.25, 20	22]		- 0	×
<u>F</u> ile <u>S</u> erver <u>T</u> o	pols				
Name	Alias	IP Address	Sub-net Mask	Gateway	
iKAN-124	LED Display	192.168.255.1	255.255.0.0	10.1.0.254	
<					>
Search S	erver Configur	ation (UDP)	Web	Exit	
Status					11.

Configure Server (UDP) dialog box

4. Enter the relevant values for the IP Address, Subnet Mask and Gateway, etc., and then click the **OK** button. The new settings for the iKAN display will take effect within 2 seconds.

Configure Server	r (UDP)				×
Server Name :	iKAN-124				
DHCP:	0: OFF 🗸	Sub-net Mask :	255.255.0.0	Alias:	LED Display
IP Address :	10.1.0.120	Gateway :	10.1.0.254	MAC:	00:0d:e0:65:0b:23
Contact your Ne	twork Administrator to g	et correct configura	ation before any changing	ı!	OK Cancel

2.5. Editing Your First iKAN Message

A message can be configured using the built-in web interface. To edit your first message, follow the instructions given below.

- 1. Open a web browser such as Google Chrome, Firefox or IE, etc.
- 2. Type the IP address of the iKAN display in the address bar, and then press **Enter** to display the web interface



3. Select the language (English or Traditional Chinese) you wish to use by clicking the icon at the right hand side of the navigation bar at the top of the iKAN web interface.



- 4. Click the **MESSAGE POOL** menu at the top of the page, select the message number you wish to add, and then click the \bigoplus button
- 5. Click the 🖉 button



- 5. In the form for message No. 1, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the Message text field:

Hello World!

iv. Click the **Update** button

Display Status 🗹 Instant 🗆	
Message Moving Mode 1 🗸	
Row(s) 1 ×	
Color Yellow 🗸	
Message	
Hello World!	
	Update

6. The message will be shown on the display.



3. Configuration

The iKAN series device can be accessed and configured using a standard web-browser, such as Google Chrome, Firefox, or IE, etc., or Safari on a Mac, or via an Internet-enabled mobile device.
3.1. Web Interface

The iKAN display contains a built-in web interface that provides a range of functions needed to manage all messages displayed on the iKAN, as well as to set up the parameters, variables, and operational behavior. The majority of common operations can be carried out using the iKAN Web Interface.

The following is an overview of the major functions of the web interface, and provides a link to more information about the function.

Menu	Sub-Menu	This menu is used to	Refer to section
			3.1.1
	-	Allows you to edit and manage messages.	4.1
POOL			4.2
DATA	INTEGER		3.1.2
	FLOAT	Allows you to specify a value for a variable and	4.2
POOL	COIL	define the data type mapping	0
סוס	_	Allows you to control the DO and read the status	215
	-	of DI/DO channels	5.1.5
		Allows you to get the information regarding	
DI Status		connection status, real-time data and Modbus	3.1.4
DL Status	-	address for measured substance on the DL/CL	5
		series module.	
		Allows you to import/export pre-configured	3.1.5
		messages and variables.	3.2.1
	ETHEDNET	Allows you to set the network address and add	3.1.5
		DL/CL series modules connected via Ethernet.	3.2.2
SYSTEM		Allows you to set the communication	215
	SERIAL PORT	parameters for the serial port and add DL/CL	3.1.5
		series modules connected via RS-485.	3.2.3
	MICC	Allows you to adjust the brightness, moving	3.1.5
	IVIISC.	speed, or reset the device.	3.2.4

3.1.1. Editing and Managing Messages

A maximum of 128 messages with user-defined priority can be stored on the iKAN series device, and each message can contain a maximum of 20 Unicode characters or 50 ASCII characters. The contents of each message can be pre-configured individually via the MESSAGE POOL page on the web interface.



For more detailed information on how to edit and manage the messages displayed, refer to <u>Chapter 4. Messages</u>

3.1.2. Applying the Variable Maps

Variable maps provide a mechanism for mapping data to a variable regardless of the data source, and are listed on the DATA POOL page. The value of most variables can be individually specified via a variable map.

To specify a value for a variable, follow the instructions given below.

- 1. Click the **DATA POOL** menu item, and then click the item in the menu for the variable type you want to edit
- 2. Click the address of the variable you would like to configure.

		Messa	ge Poo		Data	Pool	DIC	C	DL Sta	tus	Syst	em		(EN
					CP	r p	IA(Ŋ	IK						
												1			
INTE	GER	FLOAT	r cc	DIL)										
	Mari	00100													
tege i igned	r Vari v	ables Displa													
tegei igned 0	r Vari ~ 0	ables Displa	0	2	0	3	0	4	0	5	0	6	0	7	0
teger igned 0 8	r Vari v 0	ables Displa	0	2	0	3	0	4	0	5	0	6	0	7	0
teger igned 0 8 16	r Vari V O O O	ables Displa	0 0 0	2 10 18	0 0	3 11 19	0 0 0	4	0 0 0	5 13 21	0 0 0	6 14 22	0 0	7 15 23	0 0 0
tegel igned 0 8 16	r Vari v 0 0	ables Displa	0 0 0	2 10 18	0 0	3 11 19	0 0 0	4	0 0	5 13 21	0 0 0	6 14 22	0	7 15 23	0

The configuration area will be registered depending on the selected address. The configuration area provides the following functions:



• Assign a value to a variable

In the text box, enter the relevant values for the selected variable, and then click the **Update** button

Specify the color of a variable displayed in the message
 From the drop-down menu, select the desired color for the variable, and then click the
 Update button

For more details about displaying values using a variable map, refer to <u>Section 4.3. Displaying a</u> <u>Value Applied using a Variable Map</u>

3.1.2.1. Mapping Physical Values to Integer-Type Variables

Most industrial measuring devices use 16-bit integers to convert a value from a data source to a real physical value, such as the voltage, temperature, or relative humidity. For example, using the range -32768 to 36767 to convert to -10V to +10V. The iKAN series device is able to perform data mapping to translate an integer value that has been read from a remote data source to a readable physical value.

For more detailed information on how to enable data mapping for the value of an integer-type variable, please refer to <u>Section 4.3.1. Displaying Mapping Data for Integer-type Variables</u>

3.1.2.2. Changing the Number of Decimal Places for the Value of a Float-type Variable

The number of decimal places to be displayed for a float-type variable can be set from the FLOAT VARIABLES page. Each variable contains two numbers as shown in the figure below. The first number is its Modbus address, and the second number is the value of a variable. For example, 128 in front of variable 0 indicates that the Modbus address for it is 40128, and 0.0 is its value.

Note that the address interval is 2, because each of float-type variables uses 2 registers.

For more detailed information about how to change the number of decimal places for the value of a float-type variable, refer to <u>Section 4.3.2. Displaying a Value with a Specific Number of Decimal</u> <u>Places for Float-type Variables</u>



3.1.2.3. Assigning Strings to Coil Variables

iKAN series devices provide a string mapping function that allows the value of a coil variable to be mapped in order to make the coil value more meaningful when reading the message. The text mapping function allows a maximum of 10 Unicode characters or 30 ASCII characters to be entered to represent a value of 0 or 1.

For more detailed information about how to assign the replacement text for displaying the value of a coil variable, refer to <u>Section 4.3.3. Displaying the Value of a Coil Variable using Replacement</u> <u>Text</u>

3.1.3. DIO

iKAN series devices have two DI and two DO channels, the DI channels can be used to connect physical buttons or signals from devices in the field, as well as the DO channels can be used to connect sound and light alarm devices. If an emergency event occurs, the host in the control center can turn on alarm devices or read the status of button/switch connected to the iKAN device.



3.1.4. DL Status

iKAN series devices can directly connect with the DL/CL series air box modules via Ethernet or RS-485 interface without a host PC, obtain the real-time data from these modules, and refresh the data when it is displayed on the iKAN series device. Up to 8 DL/CL series modules can be connected via Ethernet, as well as up to 16 modules can be connected to each RS-485 port. That is to say, one iKAN display can connect up to 40 modules, and display the field measurement data in text message without a PC involved.

For more detailed information about how to set DL/CL series modules and hot to display measured data in message, refer to <u>Section 5. Displaying Data from CL/DL series modules</u>



3.1.5. System

The System page provides a variety of settings including adjusting brightness and message moving speed, modifying system time, network or serial communication parameters, etc. All the setting steps are described in detail in <u>Section 3.2. System Configuration</u>



Import/Export

The contents of a message and/or variable can be exported to a CSV file, and then imported to other iKAN series devices. It is helpful to simplify and speed up the repetitive operations of setting up multiple devices.





The **Ethernet** page displays the current IP address, DHCP setting, Modbus TCP Slave and Master communication parameters. You can modify the communication parameters or add information for connecting DL/CL module linked on the Ethernet.

Import/Exp	port E	thernet	Serial	Port Misc.		
Local Etherne	t				Modbus TCP Slave	
DHCP	Disabl	ed 🗸			Port	502
IP Address	10	.0	. 30	. 182	NetID	1
Mask	255	. 255	. 255	. 0	Modbus TCP Master	
Gateway	10	. 0	. 30	. 254		Connect to DL series module 🗸

Serial Port

The **Serial Port** page displays the configuration for COM 1 and COM3. You can also add information for connecting DL/CL module connected to the RS-485 port for displaying measured data in text messages.

Import/Export	Ethernet Serial Port Mi	SC:	
			COM 1 COM 3
Serial port > COM1		Modbus RTU Master	
Baud Rate	115200	Mode	Connect to DL series modules 🗸
Data Bits	8	Timeout	300
Stop Bit(s)	1		
Parity	None 🗸	Delay Between Polls	200

MISC

The functions of setting the brightness, message moving speed and system time, restoring factory defaults and software reset are given on the **MISC** page.

mport/Export	Ethernet	Serial Por	Misc.				
Misc.							
LED Brightness							
This function is use	d to set the L	ED brightness.					
Message Moving	Speed						
This function is use	d to set the n	nessage moving	g speed.				
Delay Between Me	essage Swit	ch (second)					
4	Up	date					
Update Date & Tir	ne						
Time Duplication							Ψ.
This function is use	d to reset the	RTC on the mo	odule, based on the (urrent date and ti	me of the local r	nachine. Upo	late
Time Synchronizatio	on Setting						v
Function Status							
SNTP Time Server	pool.ntp.or	g	time.windows.com	time.nist.go	v		
Use Default SNT	P Time Serve	rs					
Sync Interval	12 Hours	•					
Time Zone	(UTC+08:0	0) 🗸					
Update							

3.2. System Configuration

The following sections describe the details of the configuration items on the System page.

3.2.1. Exporting pre-configured messages

If your system includes more than one iKAN series device, it could take a lot of time to individually configure each one. To simplify this process, the Import/Export function can be used to pre-configure the contents of a message or variable on the iKAN series device before using Modbus TCP/RTU commands to manage the message pool, thereby reducing the need to repeat the configuration tasks multiple times.



Importing a configuration file

The contents of a messages, variables and configuration for CL/DL series modules can be imported from a CSV file. The following is a description of how to import a previously stored configuration file. Note that the Import function will only load configuration information related to messages, variables and configuration for CL/DL series modules.

- 1. Click the SYSTEM menu item, and then click the IMPORT/EXPORT menu item
- 2. Click the **Choose File** button to select the desired CSV file, and then click the **Import** button to load the contents of the configuration file into the system

	Message Pool	Data Pool	DIO DL Status	System	English
	1	TOD D			
port/Ex	port Ethernet Serial	Port Misc.			
nport			Export		
nport he impo etails as	rt function allows you to load pr well as the variable information	e-configured message from an external file.	Export The export function messages as well additional IKAN d	on allows you to save the curre as the associated variables to a isplays.	intly configured a file for use with
nport he impo etails as top 1	rt function allows you to load pr well as the variable information select a msg_con.csv file for im	e-configured message from an external file. port Choose F	The export function messages as well additional IKAN of Step L/Click Save	on allows you to save the curre as the associated variables to isplays. button Save	ently configured a file for use with
nport he impo etails as tep 1 tep 2	rt function allows you to load pr well as the variable information select a msg_con.csv file for im Import	e-configured message from an external file. port	Export The export function messages as well additional IKAN of Step 1.Click Save Step 2.Click Export	on allows you to save the curre as the associated variables to a isplays. button Save t button Export	ntly configured a file for use with
nport he impoi etails as tep 1 tep 2	rt function allows you to load pr well as the variable information select a msg_con.csv file for im Import	e-configured message from an external file. port	Export The export function messages as well additional IKAN of Step 1.Click Save Step 2.Click Export	on allows you to save the curre as the associated variables to a isplays. button Save t button Export	ntly configured a file for use with

Exporting a configuration file

The contents of messages, variables and configuration for CL/DL series modules can be exported as a CSV file. The default file name is msg_con.csv, which can be changed to a preferred file name if desired.

- 1. Click the SYSTEM menu item, and then click the IMPORT/EXPORT menu item
- 2. Click the **Save** button to save the configuration, and then click the **Export** button to export configuration to the msg_con.csv file in the default download location in your browser.

	Message Pool	Data Pool	DIO	DL Status	System	English
	1	TOD 1	2no	- IK P	NB	
nport/Expo	rt Ethernet Serial	Port Misc.				
Import				Export		
Import The import fu details as wel	unction allows you to load pr Il as the variable information	e-configured messa from an external file	ge	Export The export functio messages as well a additional IKAN di	n allows you to save the cum is the associated variables to splays.	ently configured a file for use with
Import The import fu details as well Step 1 sel	unction allows you to load pr Il as the variable information lect a msg_con.csv file for imp	e-configured messa from an external file port Choo	ge se File	Export The export function messages as well a additional IKAN di Step 1.Click Save b	n allows you to save the cum is the associated variables to splays. utton Save	ently configured a file for use with
Import The import fu details as wel Step 1 sei Step 2 I	unction allows you to load pr Il as the variable information lect a msg_con.csv file for im import	e-configured messa from an external file port	ge se File	Export The export function messages as well a additional IKAN di Step 1.Click Save b Step 2.Click Export	n allows you to save the cum is the associated variables to splays. utton Save button Export	ently configured a file for use with
Import The import fu details as wel Step 1 sel Step 2 I	unction allows you to load pr Il as the variable information lect a msg_con.csv file for imp mport	e-configured messa from an external file port Choo	ge - se File	Export The export function messages as well a additional IKAN di Step 1.Click Save b Step 2.Click Export	n allows you to save the curr is the associated variables to splays. utton Save button Export	ently configured a file for use with

The content of the msg_con.csv is encoded, so you cannot modify it in text editor or Excel. Once the file is imported into another iKAN device, the configuration for messages, variables and CL/DL series modules will automatically be applied to the new one.

	A	В	С	D	E	F	G	Н	Ι	J	K
1	ikan led	Display Pre	-Configurat	ion file							
2	1	1	1	1	1	1	0	0	0	0	0
3	1	1	1	1	1	1	0	0	0	0	0
4	1	1	1	1	1	0	0	0	0	0	0
5	1	1	1	1	1	0	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1
7	6	6	6	6	6	6	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0	0	0
9	0	0	0	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0	0	0
11	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0

3.2.2. Ethernet Configuration

Changing the IP Address

The IP address for the iKAN device can be changed if necessary. To change the IP address, follow the instructions given below.

- 1. Click the System menu item, and then click the Ethernet menu item
- 2. Enter the IP address for the iKAN device in the relevant fields
- 3. Click the **Update Settings** button to save your changes.

	Message Pool	Data Pool	DIO	DL Status	System	English
		ICP I	<u>)ac</u>			
	1					
Import/Exp	oort Ethernet	erial Port Mis	ic.			
Local Ethernet	1		M	lodbus TCP Slave		
DHCP	Disabled 🗸		P	ort		502
IP Address	10 . 0 .	30 . 182	N	letID		1
Mask	255 . 255 .	255 . 0	M	lodbus TCP Mast	er	
Gateway	10 . 0 .	30 . 254			Conne	ct to DL series module 🗸
			т	imeout		2000
DINS	8.8.	5.8	P	elay etween olls		2000
Lindola Calu			2			
Opdate Setti						

NOTE

If the NTP time synchronization is enabled, it is necessary to specify a DNS server for resolving the domain name and getting the IP address of NTP server.

Page: 54

Setting NetID and Port number for Modbus TCP communication

- 1. Enter the port number or NetID in the relevant fields.
- 2. Click the **Update Settings** button to save your changes.

Local Ethernet					Modbus TCP Slave	
DHCP	Disable	ed 🗸			Port	502
IP Address	10	. 0	. 30	. 182	NetID	1
Mask	255	. 255	. 255	. 0	Modbus TCP Master	
Gateway	10	. 0	. 30	. 254	Co	nnect to DL series module 🗸
					Timeout	2000
ONS	8	. 8	. 8	. 8	Delay Between Polls	2000

Adding information for DL/CL series modules connected to the network

For more detailed description, please refer to <u>Section 5.1. Displaying Data from CL/DL Modules</u> <u>Connected to Ethernet</u>

				Modbus TCP Slave	
Disable	ed 🗸			Port	502
10	. 0	. 30	. 182	NetID	1
255	. 255	. 255	. 0	Modbus TCP Master	
10	. 0	. 30	. 254	Coni	nect to DL series module 🗸
8	. 8	. 8	. 8	Delay Between	2000
	Disable 10 255 10 8	Disabled	Disabled 10 0 30 255 255 255 30 8 8 8 8 8	Disabled 10 0 30 182 255 255 255 255 0 10 0 30 254 8 8 8 8 8 8 8 8 8 8 8 8 8	Disabled Port Port NetID 255 255 255 0 Modbus TCP Master Coni Timeout 8 8 8 8 8 0 Delay Between Polls

3.2.3. Serial Port Configuration

The two RS-485 serial ports on the iKAN display can be used to connect to a PC, a PLC or CL/DL series modules. It allows the PC or PLC to control the message display using Modbus RTU protocol. Alternatively, connect to the DL/CL series modules series modules for displaying measured data in text messages, without the intervention of a host PC.

The default parameters are:

Baud Rate:115200Data Bits:8Stop Bit(s):1Parity:None

nport/Export	Ethernet Serial Port	Misc.	
			COM 1 COM 3
ial port > COM1		Modbus RTU Master	
ud Rate	115200	Mode	Connect to DL series modules 🗸
ta Bits	8	Timeout	300
p Bit(s)	1		
ity	None 🗸	Delay Between Polls	200
Catto			
p BIT(s) ity ave Settings	None V	Delay Between Polls	200

Configuring the serial port

- 1. Click the COM Port to be configured on the upper right corner of the Serial Port page,.
- 2. Configure the relevant parameters for the serial port.
- 3. Click the Save Settings button to complete the process

Import/Export Et	hernet Serial Port Misc.	8	1	
Serial port > COM1		Modbus F	COM 1 CO)M 3
Baud Rate	115200			
Data Bits	8	Mode	Disable 🗸	
Stop Bit(s)	1			
Parity	None 🗸			
Save Settings	3			

Adding information for DL/CL series modules connected to the RS-485 port

For more detailed description, please refer to <u>Section 5.2. Displaying Data from CL/DL Modules</u> <u>Connected to RS-485</u>

				COM 1	COM 3
Serial port > COM1		Modbus R	TU Master		
Baud Rate	115200				
Data Bits	8		Contra antes		
		Mode	Disable	~	
Stop Bit(s)	1		Disable		
Parity	None 🗸	Ļ	Connect to DL ser	les modules	
Save Settings					

3.2.4. MISC

The functions of setting the brightness, message moving speed and system time, restoring factory defaults and software reset are given on the MISC page.

Message I	Pool	Data Pool	DIO	DL Status	System	(English) (文中)
					~	
		TOP	nac			
Import/Export	Ethernet	Serial Port	Misc.			
Misc.						
LED Brightness						
This function is use	d to set the	LED brightness.				
4 🗸 Update						
Message Moving	Speed					
This function is use	d to set the	message movin	g speed.			
1 🗸 Update						
Delay Between Me	essage Sw	itch (second)	l.			
4	U	pdate				
Undata Data & Ti						
Opdate Date & Th	ne					
Time Duplication						V
This function is use	d to reset th	e RTC on the m	odule, based on	the current date	and time of the loc	al machine. Update
Time Synchronizati	on Setting					v
Function Status						
SNTP Time Server	pool.ntp.c	org	time.windows.c	om time.r	nist.gov	
Use Default SNT	P Time Serv	ers				
Sync Interval	12 Hours	~				
Time Zone	(UTC+08:	00) 🗸				
Update						
Restore the defau	lt settings					
This function allows	s you to rest	ore the configur	ation of the moc	ule to the factory	y default values.	
Restore						

Adjusting the Brightness and Motion Speed

There are 5 levels of brightness and 10 levels of message motion speed on the iKAN display. Higher values indicate a brighter setting for the LED, as well as a slower scrolling speed. To adjust the parameters for displaying messages, follow the instructions given below.

LED Brightness
This function is used to set the LED brightness.
4 Vpdate
Message Moving Speed
This function is used to set the message moving speed.
1 Vpdate
Delay Between Message Switch (second)
4 Update

Item	Description
LED Brightness	1. Select a value from the LED Brightness drop-down menu.
	Higher values indicate a brighter setting for the display.
	2. Click the Update button to save your changes
Message Moving Speed	1. Select a value from the Message Moving Speed drop-down menu.
	Lower values indicate a higher scrolling speed.
	2. Click the Update button to save your changes
Delay Between	1. Enter the delay time for message switch in the text box of Delay
Message Switch	Between Message Switch (second). The range of valid values is 1
(second)	to 32 (s).
	2. Click the Update button to save your changes

Updating Date and Time

The iKAN device has a built-in real-time clock (RTC), which can be applied to display the accurate time in the message, and supports NTP for clock synchronization. You can specify the domain name of a NTP server, and the synchronization period here.

 Before enabling the NTP function, you need to go to the Ethernet page to set a DNS server IP address. Then click the Update Settings button to complete the settings.

ocal Ethernet	t			Modbus TCP Slave	
ОНСР	Disablec 🗸			Port	502
P Address	10 0	. 30	. 182	NetiD	1
/lask	2,5 . 255	. 255	. 0	Modbus TCP Master	
iateway	10 . 0	. 30	. 254	1	Connect to DL series module
				Timeout	2000
NS	8.8	. 8	. 8	Delay Between Polls	2000

 Slide the button next to Function Status to the right (turn green) in the Update Data & Time field on the MISC page to enable the Time Synchronization function. Enter the domain name of the NTP server; select the synchronization interval and Time Zone from the respective drop-down menus. Then click the Update button to complete the setup.

This function is use	d to reset th <mark>e</mark> RTC on	the module, based on the cur	rent date and time of the	e local machine. Update
Time Synchronization	on Setting			
Function Status				
Function Status SNTP Time Server	pool.ntp.org	time.windows.com	time.nist.gov	Use Default SNTP Time Server
Function Status SNTP Time Server Sync Interval	pool.ntp.org	time.windows.com	time.nist.gov	Use Default SNTP Time Server

Synchronizing Date and Time with PC

You can also synchronize the date and time values on the iKAN display with those on the PC. To synchronize the date and time values with the PC, follow the instructions given below.

- 1. Slide the button next to Function Status to the left.
- 2. Click the **Update** button. The date and time values will then be synchronized with the PC.



Restoring the Default Settings

This function provides the ability to perform a safe reset for the iKAN display. All messages and variable configuration settings will be reset to the factory defaults. To restore the default settings, follow the instructions given below.

- 1. Scroll down the MISC page to see the **Restore the default setting** section.
- 2. Click the **Restore** button to complete the setting.

Restore the default settings	
This function allows you to restore the configuration of the module to the factory default values.	

Resetting the Display

This function provides a safe reset option for the iKAN display. To reset the display, follow the instructions given below.

- 1. Scroll down the MISC page to see the Software Reset section.
- 2. Click the **Reset** button to complete the setting.



Viewing the Module Name and Firmware Version

The module name and firmware version are located at the bottom of the MISC page. You can confirm the firmware version here if you need to update the firmware.

Module Name	
iKAN-124	
Firmware Version	
3.0.1	

3.3. eSearch Utility

The eSearch utility is an application specifically designed for use with products embedded with the ICP DAS MiniOS7 operating system. It has been developed so that you can search for ICP DAS Ethernet I/O modules which are connected to the same subnetwork as the Host PC, configuring the Ethernet parameters, such as IP address, subnet mask and gateway etc., or updating firmware.



The eSearch Utility can be obtained from: https://www.icpdas.com/en/download/index.php?nation=TW&kw=esearch

Default Installation Path C:\ICPDAS\eSearch

3.3.1. Configuring the IP Address

The IP address can be changed using the eSearch utility. To change the IP address, follow the instructions given below.

1. Launch the eSearch utility and click the Search Server button

File Serve Name	er Tools Alias	IP Address				
Name	Alias	IP Address				
			Sub-net Mask	Gateway	MAC Address	DHCP
Seat	ch Server	Configuration	(UDP)	Web	Ex	it
ð	Sear	Search Server	Search Server Configuration	Search Server Configuration (UDP)	Search Server Configuration (UDP) Web	Search Server Configuration (UDP) Web Ex

2. Once the search process has completed, double-click the name of iKAN display to open the **Configure Server (UDP)** dialog box

ſ	🥩 eSearch Utility [v1.1.13, Nov	v.29, 2016]		
	File Server Tools			
	Name Alias	IP Address	Sub-net Mask	Gateway
U	iKAN-124 LED Display	192.168.255.1	255.255.0.0	10.1.0.254
	Status	ion (UDP)	Web	Exit

3. Enter the relevant values for the IP Address, Subnet Mask and Gateway, etc., and then click the **OK** button. The new settings for the iKAN display will take effect within 2 seconds.

Configure Serve	r (UDP)				X
Server Name :	iKAN-124				
DHCP:	0: OFF 🗨	Sub-net Mask :	255.255.0.0	Alias:	LED Display
IP Address :	10.1.0.120	Gateway :	10.1.0.254	MAC:	00:0d:e0:65:0b:23
Warning!! Contact your Ne	etwork Administrator to ge		OK Cancel		

3.3.2. Sending the Modbus Command to iKAN

The eSearch Utility includes two embedded configuration tools, the Modbus RTU Master and the Modbus TCP Master, which can be used to send Modbus commands to the iKAN display.

eSearch Utility	eSearch Utility [v1.1.13, Nov.29, 2016]	
	Status	

The **Modbus RTU Master** tool can be used to send a Modbus message to either read or write I/O values via the COM port.



The **Modbus TCP Master** tool can be used to send a Modbus message to either read or write I/O values via the Ethernet.



3.3.2.1. Sending Modbus RTU Command to the iKAN Display

- 1. Select the Modbus RTU Master option from the Tools menu
- 2. Select the COM Port and Baud Rate from the respective drop-down menus, and then click the **Open** button

File Server Tools Name A Modbus RTU Master Addbus TCP Master System Information System Information COM Status Protocol Description FC1 Read multiple coils status (0xxxx). for D Request] Byte 0: Net D (Station number) Byte 1: FC-01 Byte 1: FC-01 Byte 2: Reference number Byte 1: FC-01 Byte 2: Byte 1: Deen Close Polling Mode (No Waiting) Statistics Timeout 200 ms Statt Stop Timer Mode (Fixed Period) 0 Interval 50 ms	eSearch Utility [v1.1.1	<u>3. Nov.29, 2016]</u>	
Name Modbus RTU Master Modbus TCP Master System Information System Information COM Status Protocol Description COM Status Protocol Description COM Status Protocol Description COM 1 FC1 Read multiple coils status (0xxxx) for DO Request Byte 0: Net D (Station number) Byte 1: FC-OIT Byte 1: FC-OIT Status Open Close Byte 4-5: Bit count Polling Mode (No Waiting) Statistics Different in Packet Size (Bytes) O Timer Mode (Fixed Period) Interval So ms Other Timer Mode (Date/Time) O Polling or Timer Mode (Date/Time) Yea Chait Stati Time Time Chait Time Chait	File Server Tools		
System Information	Name A Modbe Modbe	us RTU Master	ateway MAC Address DHCP
COM Status Protocol Description COM1 Inscription FC1 Read multiple coils status (0xxxx) for D0 Request] Byte 0: Net D (Station number) Byte 1: FC=01 Byte 2-3: Reference number Byte 4-5: Bit count Polling Mode (No Waiting) Statistics Time out 200 ms Start Stop Timer Mode (Fixed Period) 0 Interval 50 ms Start Timer Mode (Fixed Period) 0 Polling or Timer Mode (Date/Time) Statt Time	System	MBRIU V. 1.0.9 Covil	
Polling Mode (No Waiting) Statistics Time out 200 Start Stop Timer Mode (Fixed Period) 0 Interval 50 Start Timer Mode (Fixed Period) 0 Interval 50	Search Server	COM Status Pro COM1 FC1 115200 V Line control : N,8,1 Open Close	tocol Description Read multiple coils status (0xxxx) for DO uest] te 0: Net ID (Station number) te 1: FC=01 te 2-3: Reference number te 4-5: Bit count
Timer Mode (Fixed Period) Packet Quantity Sent 0 Interval 50 ms Start Time Time Start		Polling Mode (No Waiting) Statis Timeout 200 ms Start Stop	tics mands ent Packet Size (Bytes) Packet Size (Bytes) 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
		Timer Mode (Fixed Period) Interval 50 ms Pol	ing or Timer Mode (Date/Time)

3. Enter a command in the command line field and then click the Send Command button to

transmit the command

Polling Mode (No Waiting) Start Stop Timer Mode (Fixed Period)	Statistic Diffe Commands Qua Total Packet Size (Bytes) 0 0 Packet Quantity Sent 0	Clear Statistic 'acket antity 100 % 0 Clear Statistic
Interval 100 ms Set Start Stop [Byte0] [Byte1] [Byte2] [Byte3] [Byte4] [Byte4]	Polling or Timer Mode (Date/Time) Start Time Start Time Stop Time Stop Time 5]	Polling Mode Timing (ms) Max 000 Average Min 000 000
[Byte0] [Byte1] [Byte2] [Byte3] [Byte4] [Byte	5] [Byte0] [Byte1] [Byte2	2] [Byte3]
Clear L	EXIT Program	

4. The command will be displayed on the left-hand side of the text box area, and the response will be shown on the right-hand side

3.3.2.2. Send Modbus TCP Command to the iKAN display

- 1. Select the Modbus TCP Master option from the Tools menu
- 2. Enter the IP address and the Port number in the respective text fields and then click the **Connect** button

🥩 eSearch Utility [v1.1.13, Nov.29, 2016]					
File Server Tools					
Name A Mo Mo Sys	dbus RTU Master dbus TCP Master tem Information	ray MAC Address DHCP			
Search Server Status	MBTCP Ver 1.1.5 HodbusTCP IP 10.1.0.102 Port 502 Connect Disconnect	Protocol Descript FC1 Read multiple coils [Prefixed 6 bytes for Mon Byte 0: Transaction in Byte 1: Transaction in Byte 2: Protocol ident Byte 3: Protocol ident Byte 4: Freidel			
	Polling Mode (No Waiting) Start Stop	Byte 4: Field Length () Statistic Commands Total Packet Size (Byten Packet Quantity Sent			

3. Enter a command in the command line field and then click the Send Command button to

transmit the command

Polling Mode (No Waiting) Start Stop Timer Mode (Fixed Period) Interval 100 ms Set Start Stop	Statistic Diffe Commands Diffe Total Packet Size (Bytes) 0 Packet Quantity Sent 0 Polling or Timer Mode (Date/Time) Start Time Start Time Stop Time Stop Time	Clear Statistic acket Responses ntity Total Packet Size (Bytes) 00 % Packet Quantity Received 0 Polling Mode Timing (ms) Max 000 Min 000
[Byte0] [Byte1] [Byte2] [Byte3] [Byte4] [Byte 120006 1400040	:5]	Send Command
[byte0] [Byte1] [Byte2] [Byte3] [Byte4] [Byte	5] [Byte0] [Byte1] [Byte2] [Byte3]
Clear L	EXIT Program	

4. The command will be displayed on the left-hand side of the text box area, and the response will be shown on the right-hand side

4. Messages

The iKAN web configuration interface provides a convenient and simple method to easily manage the message contents and its effects.

A maximum of 128 messages with user-defined priority can be stored on the iKAN series device, and each message can contain a maximum of 20 Unicode characters or 50 ASCII characters.

4.1. Editing and Managing Messages

The contents of each common message or instant message can be individually pre-configured via the **MESSAGE POOL** page on the web interface.

Select the number of the message that you would like to add, and then click the \bigcirc button. The message item will be added to the message queue.



There are two buttons for each message item.



The **fin** button is used to delete the message.



By default, any message that is added has no effect until you add parameters to the message form.

Click the 🖉 button to enter the message form.

•	No. 1 💙	Display Status	Display Row(s)	Message		
0	1		1			
I						
	-No. 1					
	Display Status	ing Mode 🕕	~			
	Row(s) 1 V	ing mode [0	<u> </u>			
	Color Yellow	~				
	Message				15	
					Update	
					Cance	d.
The following is a summary of the items contained in the message form:

Item	Function
Display Status	Check this checkbox to enable the contents of the message to be
	displayed on the iKAN series device.
Instant	Check this checkbox to set this message as an instant message.
Message Moving Mode	Select a value from the drop-down menu to specify the message
	moving mode.
	0: Display a message statically
	1: Scroll a message when the message length exceeds the maximum
	character length within a line of iKAN, otherwise, hold the message
	statically.
	2: Hold the message on the first line and scroll the message on the
	second line. (For two-line model only)
	3: Display one scrolling message in two lines on the iKAN device,
	when the message length exceeds the maximum character length
	within a line of iKAN. (For two-line model only)
Row(s)	Select a value from the drop-down menu to specify the row where
	the message will be displayed.
Color	Select a value from the drop-down menu to specify the color for the
	message to be displayed.
Message	Enter the contents of the message.
Update	Click this button to allow the settings to take effect.
Cancel	Click this button to cancel this editing operation.

Tips & Warnings



 Instant messages have a higher priority than common messages, meaning that if any of the instant messages have been enabled, any scheduled common messages in the sequence will be ignored until all instant messages have been disabled.

2. Each time the settings for a message are changed, you will need to click the respective Update button for that message.

In the form for message No. 1, specify the following parameters:

- i. Check the **Display Status** checkbox
- ii. Select the desired color from the Color drop-down menu
- iii. Enter the following string in the Message text field:

Hello World!

iv. Click the **Update** button

Display Status 🗹 Instant 🗔	
Message Moving Mode 0 🗸	
Row(s) 1 🗸	
Color Vellow 🗸	
Message	
Hello World!	
	Update

The text message will be shown on the display.



4.2. Displaying Messages with Variables

The iKAN series device allows data related to items such as the Ethernet configuration, the RTC value, and other information, to be inserted into a message as a system variable. The format for using a system variable in a message that has a length of 5 bytes is as follows:

1	2		3 to 5	
Delimiter Character	er Variable Type ter		lodbus Addres ;it decimal nui	s: nber
	y: System variable			
	a: ASCII string			
07	b: Coil	V	V	V
%	u: Unsigned integer (0 to 65535)	X	Х	X
	23 to 5Variable TypeModbus Addressy: System variable3-digit decimal na: ASCII string			
	f: Float (-3.4E+38 to +3.4E+38)			

The following describes the Modbus register map for the iKAN device that can be used on the iKAN display.

Coil-type variables (0xxxx, 0 based)

Modbus	Address	Loweth	Description	Value	Attribute
Decimal	Hex.	Length	Description	Range	Attribute
00000	0000				
:	:	40	Coil-type variables	-	R/W
00039	0027				
00100	0064		The state of the s	0 Dischlad	
:	:	128	Enables or disables the display of	U: Disabled	R/W
00227	00E3		common messages 0 to 127.	1: Enabled	

System variables (3xxxx, 0 based)

Modbus	Address	Loweth	Description		A+++-:
Decimal	Hex.	Length	Description	value kange	Attribute
30000 : 30003	0000 : 0003	4	The IP address for the iKAN series device	0 to 255	R
30004 : 30007	0004 : 0007	4	The Mask address for the iKAN series device	0 to 255	R
30008 : 30011	0008 : 000B	4	The Gateway address for the iKAN series device	0 to 255	R
30012	000C	1	Year	0 to 9999	R
30013	000D	1	Month	1 to 12	R
30014	000E	1	Day	1 to 31	R
30015	000F	1	Abbreviated day of the week: SUN, MON, TUE, WED, THU, FRI, SAT	0 to 6	R
30016	0010	1	Day of the week: Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday	0 to 6	R
30017	0011	1	Day of the week in Chinese characters: 日、一、二、三、四、 五、六	0 to 6	R
30018	0012	1	Hours (24-hour format)	0 to 23	R
30019	0013	1	Minutes	0 to 59	R
30020	0014	1	Seconds	0 to 59	R

Integer-type variables/Float-type variables/misc. (4xxxx, 0 based)

Modbus A	Address	Loueth	Description		A 44 11 14 14 14 14
Decimal	Hex.	Length	Description	value kange	Attribute
40000	0000				
:	:	64	Integer-type variables	0 to 65535	R/W
40063	003F				
40128	0080			2 45,29 +0,12	
:	:	64	Float-type variables	3.4E+30 (0 +3.	R/W
40255	00FF			46730	
40384	0180		Data manning arguments: Source		
:	:	64		0 to 65535	R/W
40447	01BF		LOW		
40512	0200		Data manning arguments: Source		
:	:	64	High	0 to 65535	R/W
40475	023F				
40640	0280		Data manning arguments:		
:	:	64	Target Low	0 to 65535	R/W
40703	02BF				
40768	0300		Data manning arguments:		
:	:	64	Target High	0 to 65535	R/W
40831	033F				
40896	0380		Data manning arguments: Decimal		
:	:	64	Places	0 to 2	R/W
40959	03BF				
41024	0400		Decimal Places for float-type		
:	:	64	variables	1 to 3	R/W
41087	043F				
				1: Blue	
				2: Green	
41408	0580			3: Sky Blue	
:	:	128	Color for common messages 0 to	4: Red	R/W
41535	05FF		127 in the first row.	5: Purple	.,
				6: Yellow	
				7: White	
				8: Random	

41600	0640	1	Brightness for the display, a smaller number means a brighter screen	0 to 4	R/W
41601	0641	1	Message scrolling speed. A smaller value denotes a greater speed.	0 to 9	R/W
41602	0642	1	Modbus Station ID	1 to 254	R/W
41604	0644	1	Modbus TCP Slave port	0 to 65535	R/W
41612	0652	1	The response timeout value for Modbus TCP communication	0 to 65535	R/W
41613	0653	1	The delay between polls for Modbus TCP communication	0 to 65535	R/W
41632 : 41759	0660 : 06DF	128	The priority for messages 0 to 127	0: Common 1: Instant	R/W
41800 : 41831	0708 : 0727	32	The contents of ASCII string 0	ASCII	R/W
41832 : 41863	0728 : 0747	32	The contents of ASCII string 1	ASCII	R/W
41864 : 41895	0748 : 0767	32	The contents of ASCII string 2	ASCII	R/W
41896 : 41927	0768 : 0787	32	The contents of ASCII string 3	ASCII	R/W
41928 : 41959	0788 : 07A7	32	The contents of ASCII string 4	ASCII	R/W
41960 : 41991	07A8 : 07C7	32	The contents of ASCII string 5	ASCII	R/W
41992 : 42023	07C8 : 07E7	32	The contents of ASCII string 6	ASCII	R/W

Page: 78

42024 : 42055	07E8 : 0808	32	The contents of ASCII string 7	ASCII	R/W
42100 : 42227	0834 : 08B3	128	The color of messages 0 to 127 on the second row.	1: Blue 2: Green 3: Sky Blue 4: Red 5: Purple 6: Yellow 7: White 8: Random	R/W
42300 : 42427	08FC : 097B	128	The message moving type for messages 0 to 127	0 to 3	R/W
42500 : 42539	08FC : 09EB	40	The color for the coil variables 0 to 39	1: Blue 2: Green	R/W
42700 : 42763	0A8C : 0ACB	64	The color for integer variables 0 to 63	3: Sky Blue 4: Red 5: Purple	R/W
42700 : 42763	0A8C : 0ACB	64	The color for float variables 0 to 63	5: Yellow 7: White 8: Random	R/W

4.2.1. Inserting System Variables into a Message

The iKAN series device allows data related to items such as the Ethernet configuration, the RTC value, and other information, to be inserted into a message as a system variable. The format for using a system variable in a message that has a length of 5 bytes is as follows:

1	2	3 to 5		
Delimiter Character	Variable Type	Modbus Address: 3-digit decimal number		
%	y: System variable	Х	Х	Х

4.2.1.1. Displaying the IP Address

Modbus register addresses 30000 to 30011 can be used to read the current IP, Mask, and Gateway address values. The following is an overview of how to read these addresses.

Modbus	Modbus Address		Description		
Decimal	Hex.	Length	Description	value Range	Attribute
30000	0000		The IP address for the iKAN	0.1. 255	2
: 30003	: 0003	4	series device	0 to 255	К
30004	0004		The Mask address for the iKAN		
:	:	4		0 to 255	R
30007	0007				
30008	0008		The Catoway address for the		
:	:	4	iKAN series device	0 to 255	R
30011	000B		INAN SELIES UEVILE		

For example, the following explains how to configure a message to display the IP address for the iKAN series device in message 1.

1. Select message **No. 1** from the message pool, and then click the 🕀 button

Message Pool	Data Poo	I DIO	DL Status	System
	ICP	DAS	- IKA	
Display	Display Pow(c)	Massaga		

2. Click the 🖉 button

•	No. 1 💙	Display Status	Display Row(s)	Message	
0	1		1		

- 3. In the form for message No. 1, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the Message text field:

IP: %y000.%y001.%y002.%y003

iv. Click the **Update** button

Display Status 🗷 Instant 🔲	
Message Moving Mode 2 •	
Row(s) 1 •	
Color Yellow •	
Message	
IP: %y000.%y001.%y002.%y003	
Update	-M

The IP address for the iKAN series device will be shown on the display.



4.2.1.2. Displaying the Current Date and Time

Modbus register addresses 30012 to 30020 can be used to read the current date and time value. The following is an overview of how to read these values.

Modbus Address		Lesselle.	Description	Value	
Decimal	Hex.	Length	Description	Range	Attribute
30012	000C	1	Year	0 to 9999	R
30013	000D	1	Month	1 to 12	R
30014	000E	1	Day	1 to 31	R
30015	000F	1	Abbreviated day of the week: SUN, MON, TUE, WED, THU, FRI, SAT	0 to 6	R
30016	0010	1	Day of the week: Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday	0 to 6	R
30017	0011	1	Day of the week in Chinese characters: 日、一、二、三、四、五、六	0 to 6	R
30018	0012	1	Hours (24-hour format)	0 to 23	R
30019	0013	1	Minutes	0 to 59	R
30020	0014	1	Seconds	0 to 59	R

For example, the following explains how to configure a message to display the current date for the iKAN series device in message 1:



1. Select message No. 1 from the message pool, and then click the 🕀 button

2. Click the 🖉 button

•	No. 1 💙	Display Status	Display Row(s)	Message	
O	1		1		

- 3. In the form for message No. 1, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the Message text field:

%y012/%y013/%y014 %y018 : %y019

iv. Click the Update button

NO. 1	
Display Status 🗷 Instant 🗆	
Message Moving Mode 2 •	
Row(s) 1 •	
Color Yellow •	
Message	
%y012/%y013/%y014 %y018:%y019	
	Undata

The date and time for the iKAN series device will be shown on the display.



4.2.2. Inserting Integer-type Variables into a Message

iKAN display devices provide Modbus registers for 64 integer variables, allowing the Host PC or a PLC to read or write data via the Modbus TCP/ RTU protocol. These values can also be inserted into a message. If these inserted values are modified via a remote Host or a PLC, the value will be automatically refreshed when it is displayed on the iKAN series device.

The format for using a variable in a message is a 5-byte string as follows:

1	2	3 to 5		
Delimiter Character	Variable Type	Modbus Address: 3-digit decimal number		
04	u: Unsigned integer (0 to 65535)	Y	N.	Y
%	i: Signed integer (-32768 to 32767)	Х	Х	X

A maximum of 64 integer variables can be stored on the iKAN series device, and are accessed using Modbus register addresses 40000 to 40063.

Modbus Address		Loweth	Description		
Decimal	Hex.	Length	Description	value Range	Attribute
40000	0000				
:	:	64	Integer-type variables	0 to 65535	R/W
40063	003F				

For example, the following explains how to insert a signed type integer variable into Modbus register 40001 using message address 1.



1. Select message No. 1 from the message pool, and then click the 🕀 button

2. Click the 🖉 button

•	No. 1 🛩	Display Status	Display Row(s)	Message	
Pū	1		1		

- 3. In the No. 1 form, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the Message text field:

Input Voltage: %i001 V

iv. Click the **Update** button

NO. 1	
Display Status 🗹 Instant 🔲	
Message Moving Mode 2 •	
Row(s) 1 •	
Color Yellow •	
Message	
Input Voltage: %i001 V	
	Update,

The message contains the value for integer variable 1 will be shown on the iKAN display.



The iKAN series device provides a data mapping function for Integer-type variables. Refer to **Section 4.3.1. Displaying Mapping Data for Integer-type Variables** for more details

4.2.3. Inserting Float-type Variables into a Message

The iKAN display device provides Modbus registers for 64 float variables, allowing the Host PC or a PLC to read or write data via the Modbus TCP/ RTU protocol. These values can also be inserted into a message. If these values are modified via a remote Host or a PLC, the value will be automatically refreshed when it is displayed on the iKAN series device.

The format for using a variable in a message is a 5-byte string, as follows:

1	2		3 to 5	
Delimiter Character	Variable Type	M 3-dig	odbus Addre it decimal nu	ss: mber
%	f: Float variable (-3.4E+38 to +3.4E+38)	Х	х	Х

A maximum of 64 float variables can be stored on the iKAN series device, and are accessed using Modbus register addresses 40128 to 40254.

Modbus Address		Loweth	Description		Attributo	
Decimal	Hex.	Length	Description	value kange	Attribute	
40128	0080					
:	:	64	Float-type variables	3.4E+38 to +3.4E+38	R/W	
40255	00FF					

For example, the following explains how to insert a float-type variable into Modbus register 40130 using message address 1.



1. Select message No. 1 from the message pool, and then click the 🕀 button

2. Click the 🖉 button

•	No. 1 💙	Display Status	Display Row(s)	Message	
O	1		1		

- 3. In the No. 1 form, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the Message text field:

Pressure: %f130 bars

iv. Click the **Update** button

-NO. 1	
Display Status 🗷 Instant 🔲	
Message Moving Mode 2 •	
Row(s) 1 •	
Color Yellow •	
Message	
Pressure: %f130 bars	
	2
	Update
	Update

The value for float-type variable 1 will be shown on the iKAN display.



The iKAN series device allows the number of decimal places to be modified for Float-type variables. Refer to <u>Section 4.3.2. Displaying a Value with a Specified Number of Decimal Places</u> for Float-Type Variables for more details

4.2.4. Inserting Coil-type Variables into a Message

The iKAN display device provides Modbus registers for 40 coil variables, allowing the Host PC or a PLC to read or write data via the Modbus TCP/ RTU protocol. These values can also be inserted into a message. If these values are modified via a remote Host or a PLC, the value will be automatically refreshed when it is displayed on the iKAN series device.

The format for using a variable in a message is a 5-byte string, as follows:

1	2		3 to 5	
Delimiter Character	Variable Type	Modbus Add	lress: 3-digit dec	imal number
%	b: Coil	х	х	х

A maximum of 40 Coil type variables can be stored on the iKAN series device, and are accessed using Modbus register addresses 00000 to 00039.

Modbus	Address	Loweth	Description	Value	A + + + + + + + + + + + + + + + + + + +
Decimal	Hex.	Length	Description	Range	Attribute
00000	0000				
:	:	40	Coil-type variables	-	R/W
00039	0027				

For example, the following explains how to insert a coil variable into Modbus register 00000 using message 1:

- 1. Select message No. 1 from the message pool, and then click the 🕀 button

2. Click the 🖉 button

•	No. 1 💙	Display Status	Display Row(s)	Message	
O	1		1		

- 3. In the No. 1 form, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the Message text field:

Coil variable 1 = %b001

iv. Click the **Update** button

NO. 1	
Display Status 🗷 Instant 🔲	
Message Moving Mode 2 🔻	
Row(s) 1 •	
Color Yellow •	
Message	
Coil variable 1 = %b001	
	Update

The value for Coil variable 1 will be shown on the iKAN display.



The iKAN series device provides a string mapping function that allows the value of the coil variable to be mapped. Refer to <u>Section 4.3.3. Displaying the Value of a Coil using Replacement</u> <u>Text</u> for more details

4.2.5. Inserting ASCII Strings into a Message

iKAN display devices provide Modbus registers for 8 ASCII strings, allowing the Host PC or a PLC to read or write data via the Modbus TCP/ RTU protocol. Each ASCII string is up to 64 characters (32 Modbus registers with 2 ASCII characters in each). These strings can be displayed in a similar way to display variables. If these strings are modified via a remote Host or a PLC, the text will be automatically refreshed when it is displayed on the iKAN series device.

The format for using a variable in a message is a 3-byte string as follows:

1	2	3
Delimiter Character	Variable Type	ASCII String Number: 1-digit decimal number
%	a: ASCII string	0 to 7

A maximum of 8 ASCII strings can be stored on the iKAN series device, and are accessed using Modbus register addresses 41800 to 42055.

Modbus Address		1	Develoption		Attailente
Decimal	Hex.	Length	Description	value Range	Attribute
41800	0708				
:	:	32	ASCII string 0 contents	ASCII	R/W
41831	0727				
41832	0728				
:	:	32	ASCII string 1 contents	ASCII	R/W
41863	0747				
41864	0748				
:	:	32	ASCII string 2 contents	ASCII	R/W
41895	0767				
41896	0768				
:	:	32	ASCII string 3 contents	ASCII	R/W
41927	0787				

41928	0788				
:	:	32	ASCII string 4 contents	ASCII	R/W
41959	07A7				
41960	07A8				
:	:	32	ASCII string 5 contents	ASCII	R/W
41991	07C7				
41992	07C8				
:	:	32	ASCII string 6 contents	ASCII	R/W
42023	07E7				
42024	07E8				
:	:	32	ASCII string 7 contents	ASCII	R/W
42055	0808				

For example, the following explains how to configure a message to display the contents of an ASCII string in a message at address 1:

1. Select message **No. 1** from the message pool, and then click the 🕀 button



2. Click the 🖉 button



3. In the **No. 1** form, specify the following parameters:

- i. Check the **Display Status** checkbox
- ii. Select the desired color from the Color drop-down menu
- iii. Enter the following string in the **Message** text field:

%a0

iv. Click the Update button

NO. 1	
Display Status 🗷 Instant 🔲	
Message Moving Mode 2 •	
Row(s) 1 •	
Color Yellow •	
Message	
%a0	1
	Update

4. Use any software that supports Modbus RTU/TCP ASCII protocol to send the following value to the iKAN Modbus registers from 41800 to 41806.

	01800	01810	01820	01830
0	1800 = (AS) 0x4153	1810 = (??) 0x0000	1820 = (??) 0x0000	1830 = (??) 0x0000
1	1801 = (CI) 0x4349	1811 = (??) 0x0000	1821 = (??) 0x0000	1831 = (??) 0x0000
2	1802 = (I) 0x4920	1812 = (??) 0x0000	1822 = (??) 0x0000	
3	1803 = (st) 0x7374	1813 = (??) 0x0000	1823 = (??) 0x0000	
4	1804 = (ri) 0x7269	1814 = (??) 0x0000	1824 = (??) 0x0000	
5	1805 = (ng) 0x6E67	1815 = (??) 0x0000	1825 = (??) 0x0000	
6	1806 = (?!) 0x0021	1816 = (??) 0x0000	1826 = (??) 0x0000	
7	1807 = (??) 0x0000	1817 = (??) 0x0000	1827 = (??) 0x0000	
8	1808 = (??) 0x0000	1818 = (??) 0x0000	1828 = (??) 0x0000	
9	1809 = (??) 0x0000	1819 = (??) 0x0000	1829 = (??) 0x0000	

The message sent to ASCII string 0 will be shown on the iKAN display.



4.2.6. Inserting Unicode Strings into a Message

iKAN display devices provide Modbus registers for 1 Unicode strings, allowing the Host PC or a PLC to read or write data via the Modbus TCP/ RTU protocol. The Unicode string is up to 32 characters (32 Modbus registers with 1 Unicode character in each). The string can be displayed in a similar way to display variables. If the string is modified via a remote Host or a PLC, the text will be automatically refreshed when it is displayed on the iKAN series device.

The format for using a variable in a message is a 3-byte string as follows:

1	2	3
Delimiter Character	Variable Type	Unicode String Number: 1-digit decimal number
%	n: Unicode string	0

One Unicode strings can be stored on the iKAN series device, and can be accessed using Modbus register addresses 43000 to 43031.

Modbus Address		Lougth	Description		A 44 - 16 - 14 -
Decimal	Hex.	Length	Description	value Range	Attribute
43000	OBBB				
:	:	32	Unicode string 0 contents	00A0 ~ FFFF	R/W
43031	0BD7				

The color of each character in the Unicode string can be set individually, but the color will use up one Modbus register space. If the total length of the Unicode string is less than 32 characters, fill in 0 at the end address of the string as an end character. The valid range of values that can be represented as characters in ASCII and Unicode strings:

Value Range	Descriptions					
0	End C	haracter				
0 x 0001 to 0 x	Chara	Character Color				
0008		Small Size	Normal Size			
	1	Blue	Red			
	2	Green	Green			
	3	Sky Blue	Yellow			
	4	Red	Blue			
	5	Purple	Purple			
	6	Yellow	Sky Blue			
	7	White	White			
	8	Auto	Auto			
0x0020~0x007F	ASCII Character					
0x00A0~0xFFFF	Unicode Character					

For example, the following explains how to configure a message to display the contents of an ASCII string in a message at address 1:

1. Select message No. 1 from the message pool, and then click the 🕀 button



2. Click the 🖉 button



- 3. In the **No. 1** form, specify the following parameters:
 - i. Check the **Display Status** checkbox
 - ii. Select the desired color from the Color drop-down menu
 - iii. Enter the following string in the **Message** text field:

%n0

iv. Click the **Update** button

NO. 1	
Display Status 🗹 Instant 🗔	
Message Moving Mode 2 •	
Row(s) 1 •	
Color Yellow •	
Message	
%n0	
	Update

4. Use any software that supports Modbus RTU/TCP ASCII protocol to send the following value to the iKAN Modbus registers from 43000 to 43018.

	Alias	03000	Alias	03010
0	Set Color	(??) 0x0001	s	(?s) 0x0073
1	U	(?5) 0xFF35	t	(?t) 0x0074
2	n	(?N) 0xFF4E	r	(?r) 0x0072
3	i	(?l) 0xFF49	Ĩ	(?i) 0x0069
4	с	(?C) 0xFF43	n	(?n) 0x006E
5	o	(?O) 0xFF4F	g	(?g) 0x0067
6	d	(?D) 0xFF44	Set Color	(??) 0x0004
7	e	(?E) 0xFF45	1	(?!) 0x0021
8		(?) 0x0020	End	(??) 0x0000
9	Set Color	(??) 0x0006		(??) 0x0000

The stored value for Unicode string will be shown on the iKAN display.

Unicode string!

4.3. Displaying a Value Applied using a Variable Map

Sometimes, displaying raw data from Modbus protocol in message is not easy to understand intuitively. For example, uses a value of 0 or 1 of a Coil variable to indicate the status of a button or a digital signal, or the value range -32768 to 36767 to denote the voltage range -10 V to +10 V. Therefore, iKAN provides the function of variable map to convert raw data to a readable physical value or easy-to-understand text.

Current variable maps are listed on the DATA POOL page. The value of most variables can be individually pre-configured via the variable maps page.



4.3.1. Displaying Mapping Data for Integer-type Variables

Most industrial measuring devices use 16-bit integers to convert a value from a data source to a real physical value, such as the voltage, temperature, or relative humidity, etc. For example, using the value range -32768 to 36767 to convert to the voltage range -10 V to +10 V. The iKAN series device is able to perform data mapping to translate an integer value that has been read from a remote data source to a readable physical value.

For example, the following explains how to configure the data mapping function for an integer-type variable at address 1.

Note that this example is a continuation of the example given in Section 4.2.2.

1. On the INTEGER page, click the variable at address 1, and then click the Adv. Config button

	Message	e Pool	Data	Pool	DIO	D	L Status	S	ystem				(
			TCF	ı r		-	IKČ						
NTEGER FLOAT	COIL												
eger Variables	-												
igned 💙 Display													
0 -3 1	0	2	0	3	0	4	0	5	0	6	0	7	0
	11				100	1							
8 0 9	0	10	0	11	0	12	0	13	0	14	0	15	0
8 0 9 16 0 17	0	10	0	11 19	0	12 20	0	13 21	0	14 22	0	15 23	0
8 0 9 16 0 17 24 0 25	0 0 0	10 18 26	0	11 19 27	0 0 0	12 20 28	0	13 21 29	0 0 0	14 22 30	0	15 23 31	0 0 0
8 0 9 16 0 17 24 0 25 32 0 33	0 0 0	10 18 26 34	0 0 0	11 19 27 35	• • •	12 20 28 36	0 0 0 0	13 21 29 37	0 0 0 0 0	14 22 30 38	0	15 23 31 39	0 0 0
8 0 9 16 0 17 24 0 25 32 0 33 40 0 41	0 0 0 0	10 18 26 34 42	0 0 0 0	11 19 27 35 43	0 0 0 0	12 20 28 36 44	0 0 0 0	13 21 29 37 45	0 0 0 0	14 22 30 38 46	0 0 0 0	15 23 31 39 47	0 0 0 0
8 0 9 16 0 17 24 0 25 32 0 33 40 0 41 48 0 49	0 0 0 0 0	10 18 26 34 42 50	0 0 0 0 0	11 19 27 35 43 51	0 0 0 0 0	12 20 28 36 44	0 0 0 0 0	13 21 29 37 45 53	0 0 0 0	14 22 30 38 46 54	0 0 0 0 0	15 23 31 39 47 55	0 0 0 0

2. Consider the arguments for data mapping



For example, to convert a 16-bit unsigned integer (0 to 65535) to the voltage 0 to 10 V, set the following arguments:

Argument	Value	Description
Source Low	0	The minimum value of the integer
Target Low	0	The minimum value of the physical value
Source High	65535	The maximum value of the integer
Target High	10	The maximum value of the physical value
Decimal Places	-	The number of decimal places to be used for the converted value

- 3. Enter the following value, and then click the **Update** button
 - i. In the **Source Low** column, enter the minimum value of the integer value.
 - ii. In the Source High column, enter the maximum value of the integer value.
 - iii. In the **Target Low** column, enter the minimum value of the physical value.
 - iv. In the **Target High** column, enter the maximum value of the physical value.
 - v. From the **Decimal Places** column, select the desired number of decimal places to be used for the converted value.

No.	Source Low	Source High	Target Low	Target High	Decimal Places	Update
1	0	65535	0	10	2 🔻	Update
L						

The value for integer variable 1 will be shown on the iKAN display, but will now use the scaled value text rather than the integer value.

Input Voltage: 32767 V	
Input Voltage: 5.00 V	

4.3.2. Displaying a Value with a Specified Number of Decimal Places for Float-type Variables

The number of the decimal places to be used for a float-type variable can be set from the FLOAT page. The offset value of Modbus address for float-type variables is 40128, which means variable 0 uses address 40128 and variable1 uses address 40130, and so on. A maximum of three decimal places can be set.

For example, the following explains how to set the number of decimal places for float-type variable 40130.

Note that this example is a continuation of the example given in Section 4.2.3.

1. On the FLOAT page, click the option for address 130, and then click the Adv. Config button

					**			-							
					11				IIX						
ITEG	ER F	LOAT	COIL				Мо	dbus A	ddress	;		Value	e of va	riable	
it Va	riables									/	/	/			
!8	0.0	130	0.0	132	0.0	134	0.0	136	0.0	138	0.0	140	0.0	142	0.0
4	0.0	146	0.0	148	0.0	150	0.0	152	0.0	154	0.0	156	0.0	158	0.0
0	0.0	162	0.0	164	0.0	166	0.0	168	0.0	170	0.0	172	0.0	174	0.0
6	0.0	178	0.0	180	0.0	182	0.0	184	0.0	186	0.0	188	0.0	190	0.0
2	0.0	194	0.0	196	0.0	198	0.0	200	0.0	202	0.0	204	0.0	206	0.0
8	0.0	210	0.0	212	0.0	214	0.0	216	0.0	218	0.0	220	0.0	222	0.0
4	0.0	226	0.0	228	0.0	230	0.0	232	0.0	234	0.0	236	0.0	238	0.0
0	0.0	242	0.0	244	0.0	246	0.0	248	0.0	250	0.0	252	0.0	254	0.0
130		0				Ye	llow 🗸		Update		>	Adv. Config		Ca	ncel
			/				/								

2. From the **Decimal Places** drop-down menu, select the desired number of decimal places to be used, and then click the **Update** button



The value for float-type variable 1 will be shown on the iKAN display using the specified number of decimal places.


4.3.3. Displaying the Value of a Coil Variable using Replacement Text

The contents of a coil variable can be either 0 or 1, which is usually used to indicate the status of the Digital Output, i.e., ON or OFF.

On the **COIL** page, click the number for the address of the coil variable which you would like to configure. The configuration area has been populated based on the number of the address selected.

			Messag	e Pool	Data	a Pool	D	10	DL Status	5 5	System				(
					ICF	2 (14	S-	·JK/						
INTEC) ER	FLOAT	COIL)		M	odbu	ıs Add	ress			Value	of var	riable	
o <mark>il V</mark> ar	iables									\setminus	/				
0	0	1	0	2	0	3	0	4	0	5	0	6	0	7	0
8	0	9	0	10	0	11	0	12	0	13	0	14	0	15	0
16	0	17	0	18	0	19	0	20	0	21	0	22	0	23	0
24	0	25	0	26	0	27	0	28	0	29	0	30	0	31	0
32	0	33	0	34	0	35	0	36	0	37	0	38	0	39	0
1		0				Red	~		Update		Adv	/. Config		Ca	ncel
	*********					/		********							
	Chang	ge the v	value			Ch	ange	e the c	olor for	displa	aying t	he va	lue on	the iK	AN

The iKAN series device provides a string mapping function that allows the value of the coil variable to be mapped in order to make it more meaningful when reading the message. The text mapping function allows a maximum of 10 Unicode characters or 30 ASCII characters to be entered to represent a value of 0 or 1.

For example, the following explains how to configure the text mapping for the Coil variable at address 1. Note that this example is a continuation of the example given in Section 4.2.4.

1. On the COIL page, click the option for address 1, and then click the Adv. Config button

		1	Messag	je Pool	Da	ta Pool	DIO	DL St	atus	System				
					TP	P ſ	ac							
				1										
ITEGEF	R FL	.OAT	COIL)										
il Varia	bles	1	0	2	0	3	0	1 0	5	0	6	0	7	0
il Varia 0 8	o 0	1	0	2	0	3	0	4 0	5	0	6	0	7	0
il Varia 0 8 16	o o o	1 9 17	0 0 0	2	0 0 0	3 11 19	0 1 0 1	4 0 2 0	5 13 21	0 0 0	6 14 22	0 0	7 15 23	0 0 0
il Varia 0 8 16 24	o o o o	1 9 17 25	0 0 0	2 10 18 26	0 0 0	3 11 19 27		4 0 2 0 0 0 8 0	5 13 21 29	0 0 0	6 14 22 30	0 0 0	7 15 23 31	0 0 0

- 2. Enter the following mapping text, and then click the **Update** button
 - i. In the ON Text column, enter the mapping text in the text field for when the status of the coil-type variable is set to ON status.
 - ii. In the OFF Text column, enter the mapping text in the text field for when the status of the coil-type variable is set to OFF status.

10.	ON Text	OFF Text	Indate	Cancel
1	Operating	Stop	Update	Cancel

The value for coil variable 1 is now replaced by the mapping text on the display.

Coil variable 0 = 1
Coil variable 0 = Operating

5. Displaying Data from CL/DL series modules

iKAN series devices can directly display measured data from DL/CL series air box modules connected to Ethernet or RS-485 interface. Up to 8 DL/CL series modules can be connected via Ethernet, as well as up to 16 modules can be connected to each RS-485 port. That is to say, one iKAN device can connect to up to 40 modules, and display the field measurement data in text message without a PC involved.

Support Modules

Product	Model
DL series	DL-100-E, DL-101-E, DL-110-E, DL-120-E DL-301, DL-302, DL-303
CL series	CL-201-E, CL-202-E, CL-203-E, CL-204-E, CL-205-E CL-206-E, CL-207-E, CL-208-E, CL-210-E, CL-211-E CL-212-E, CL-213-E

Once the information for connecting to a CL/DL module is added via the System page, the Modbus address for each measurement item will be created automatically. It allows these measured values can be inserted into a message and updated to the latest value when they are displayed on the iKAN series device. It also allows remote host to access data from multiple modules with a Modbus TCP/RTU command.

/	Modbus address	Variable symbol	\mathbf{X}
	Modbus Register	Table for DL Value (3xxxx)	
Address (Base J)	Desi	ription	Message Pool Symbol
512	DL-303(CC	M1->ID:4)CO	%y512
513	DL-303(CO	M1->ID:4)CO2	%y513
514	DL-303(COM1->I	D:4)Relative Humidity	%y514
515	Descriptio	n content ame (COM port->Modbi	us ID) measured item or
	Module Na	ame (LAN: Module IP/M	odbus ID) measured item

The measured data related to items such as temperature, relative humidity and concentration of CO/CO2 to be inserted into a message as a variable. The format for using a variable in a message is a 5-byte string, as follows:

1	2		3 to 5	
Delimiter Character	Variable Type	Modbus Add	lress: 3-digit dec	imal number
%	y: System variable	х	Х	х

Simply enter the information for the connected modules and put the variable symbol for the measurement item into a message, and then the value of measurement data can be displayed in the message and be automatically refreshed when it is displayed on the iKAN series device.

0	7	1	CO: %y512 ppm Insert variable symbol
0	8	1	CO2: %513 ppm

Before starting the configuration process, make sure that your CL/DL series device(s) is well configured and connected to the Ethernet or RS-485 port on the iKAN device. Also, confirm that the power of each device is turned on.

5.1. Displaying Data from CL/DL Modules Connected to Ethernet

Enabling the Modbus TCP Master mode

1. Select **Connect to DL series module** from the drop-down menu in the Modbus TCP Master section on the Ethernet subpage of System, and then click Update Settings.

	Message Pool	Data Pool	DIO	DL Status	System)	Er
		ICP	DAS	- IKA			
nport/Expo	ort Ethernet Serial Po	ort Misc.					
ocal Ethernet			2	Modbus TCP Slave			
ЭНСР	Disabled 💙			Port			502
P Address	10 . 0 . 30	. 182		NetID			1
Mask	255 . 255 . 255	. 0		Modbus TCP Master			
Sateway	10 . 0 . 30	. 254				-	
ONS	8.8.8	. 8			1	Disable Disable Connect to	DL series modul
Update Settin	nas						
2							
	†				\checkmark		
		Modbus T	CP Master	i.	, in the second s		6
					Connect	to DL series n	nodule 🗸
		Timeout					2000
		Delay Between Polls					2000

If necessary, you can adjust the values of the Timeout and Delay Between Polls parameters

	Connect to DL series module 🗸
Timeout	2000
Delay	
Between	2000

- Timeout: Set a timeout in ms to stop waiting and end the communication if the iKAN device does not receive data from the CL/DL series module within the time interval.
- Delay Between Polls: Set the delay time in ms for two Modbus TCP commands. The setting value needs be greater than 50ms.
- **2.** Click the OK button on the pop-up dialog box.



Adding information for connecting CL/DL series module

3. Click the icon for adding CL/DL series module in the title bar of DL Configuration Table.

HCP Disabled Port Address 10 0 30 182 NetID Iask 255 255 0 Modbus TCP Master ateway 10 0 30 254 NS 8 8 8 8	Port 502 NetID 1 Modbus TCP Master Connect to DL series module Timeout 2000 Delay Between Polls 2000	LICD	Basela				-		1
Address 10 0 30 182 NetID ask 255 255 255 0 Modbus TCP Master ateway 10 0 30 254 NS 8 8 8 8	NetID 1 Modbus TCP Master Connect to DL series module Timeout 2000 Delay Between Polls	нср	Disable	• •			Port		502
ask 255 255 255 0 teway 10 0 30 254 Timeout JS 8 8	Modbus TCP Master Connect to DL series module Timeout Delay Between Polls	Address	10	• 0	. 30	. 182	NetID		1
teway 10 0 30 254 Connect to DL serie Timeout	Connect to DL series module Timeout 2000 Delay Between Polls	isk	255	255	255	0	Modbus TCP Master		
Timeout	Timeout 2000 Delay Between 2000 Polls	teway	10	. 0	. 30	. 254		Connect to DI	. series module
S 8 8 8 8 8	Delay Between 2000 Polls	-		1.	1		Timeout		2000
Between	Polls	IS	8	8	. 8	· 8	Delay Between		2000
Polls							Polls		
Jpdate Settings		Jpdate Settir							
Jpdate Settings		Ipdate Settir							
pdate Settings Configuration Table		pdate Settir Configi	uration T	able					
Polate Settings Configuration Table No. 1 V ID Module Name IP Port	IP Port Update	Configu	uration 1	T <mark>able</mark>	Module N	ame	IP	Port	Update

4. Enter the information into the relevant fields.



Item	Description
1	Checks the Module Number
2	Enters the Modbus ID for the module
3	Selects the model name
4	Enters the IP address of the module
5	Enters the port number for Modbus TCP communication. The standard port number is 502.
6	Clicks the Save button

 Click the Reset button on the MISC page and wait the iKAN display to restart (about 8 seconds) to make the configuration take effect.



Obtaining real-time data of the monitoring module

6. Click the reload icon to reload the entire page, and click LAN item on the **DL status** page to expand the list of module(s) connected over Ethernet.



iKAN Series Display User Manual	v 1.1.0	Page: 118	
---------------------------------	---------	-----------	--

7. Click the module in list to view the real-time data from the module.



Checking the variable symbol for measured items

8. Click **Modbus Table** to view the table of contents for measurement items, their Modbus addresses and the variable symbols used to be inserted into a message.



 Modbus Register Table for DL Value (3xxxx)

 Address (Base 0)
 Description
 Message Pool Symbol

 519
 DL-100-E(LAN IP:0.0.0.0/ID:1)Relative Humidity
 %y519

 520
 DL-100-E(LAN IP:0.0.0.0/ID:1)Temperature (°C)
 %y520

 521
 DL-100-E(LAN IP:0.0.0.0/ID:1)Temperature (°F)
 %y521

 522
 DL-100-E(LAN IP:0.0.0.0/ID:1)Dew Point Temperature (°C)
 %y522

 Modbus address
 Variable symbol

Description for measurement item:

Module name (LAN Interface: Module IP/Modbus ID) Measurement item

icon to add a message and click the 🦉 icon to edit the message on the 9. Click the Message Pool page. Message Pool Data Pool DIO EN K **DL** Status System 1 2 Display Status Display Row(s) 0.9 * Instant Message 1 1 2 3 1 5 6

Editing a message with a variable symbol

Item	Description
1	1 The page number in Message Pool
2	The icon for adding a message
3	The icon for editing a message
4	Clicks the icon to delete a message
5	Message number
6	To Enable/ Disable the display of a message
7	The content of a message

10. Insert the desired variable symbol into a message such as **Temperature: %y520 C** and click the Update button.

No. 1	
Display Status 🗹 Instant 🗆	
Message Moving Mode 🛛 🗸	
Row(s) 1	
Color Yellow ~	
Message	
Temperature: %y520 C	
	Update
	Cancel

11. Check the message is correctly displayed with measured value from the CL/DL series module.



5.2. Displaying Data from CL/DL Modules Connected to RS-485

Enabling the Modbus RTU Master mode

- **1.** Select the COM port used to connect the CL/DL series module.
- Select Connect to DL series modules from the drop-down menu in the Modbus RTU Master section on the Serial Port subpage of System, and then click the Save Settings button.

Message Pool	Data Pool	DIO DL	Status	System	En	glish)(繁⊄
	ICP		XA			
Import/Export Ethern	et Serial Port	Misc.			1 COM 1	COM 3
Serial Port > COM1		Modb	us RTU Master			
Baud Rate	115200					
Data Bits	8	Mode	Disable			
Stop Bit(s)	1	Mode	Disable	t to DL series r	nodules	
Parity	None 🗸					
Save Settings			/			
~**	Modbus RTU Mas	ster				
	Mode	Connect to	DL series modu	ıles 🗸		
	Timeout	300				
	Delay Between P	olls 200				

If necessary, you can adjust the values for Timeout and Delay Between Polls parameters

Modbus RTU Master	
Mode	Connect to DL series modules 🗸
Timeout	300
Delay Between Polls	200

- Timeout: Set a timeout in ms to stop waiting and end the communication if the iKAN device does not receive data from the CL/DL series module within the time interval.
- Delay Between Polls: Set the delay time in ms for two Modbus TCP commands. The setting value needs be greater than 50ms.
- **3.** Click the OK button on the pop-up dialog box.



Adding information for connecting CL/DL series module

4. Click the **title** icon for adding CL/DL series module in the title bar of DL Configuration Table.

Import/Export Ethern	et Serial Port Misc.		
			COM 1 COM 3
Serial por > COM1		Modbus RTU Master	
Baud Rate	115200	Mode	Connect to DL series modules 🗸
Data Bits	8	Timeout	300
Stop <mark>B</mark> it(s)	1		
Parity	None 🗸	Delay Between Polls	200
Save Settings			
DL Configuration Ta	ble The configuration will be update	ed the next time you reset th	e iKAN display
🕀 No. 1 🗸	ID	Module Name	Update
· ·	Module Number		

5. Enter the information into the relevant fields.

DL Configuration Table The configuration will be updated the next time you reset the iKAN display.



Item	Description
1	Checks the Module Number
2	Enters the Modbus ID for the module
3	Selects the model name
4	Clicks the Save button

6. Click the Reset button on the MISC page and wait the iKAN display to restart (about 8 seconds) to make the configuration take effect.

Message Pool	Data Pool	DIO	DL Status	System
	ICP [) <u>A</u> 8	- <u>IK</u> (
Import/Export Ethernet	Serial Port	Misc.		
Software Reset	eset the splay module	e by clicking t	he Reset button.	
Reset				

Obtaining real-time data of the monitoring module

 Click the reload icon to reload the entire page, and click COM Port item on the DL status page to expand the list of module(s) connected over Ethernet.



8. Click the module name in list to view the real-time data from the module.



Checking the variable symbol for measured items

9. Click **Modbus Table** to view the table of contents for measurement items, their Modbus addresses and the variable symbols used to be inserted into a message.



Modbus Register Table for DL Value (3xxxx)

Address (Base 0)	Description	Message Pool Symbol
518	CL-202-E(COM1->ID:193)CO2	%y518
519	CL-202-E(COM1->ID:193)Relative Humidity	%y519
520	CL-202-E(COM1->ID:193)Temperature (°C)	%y520
521	CL-202-E(COM1->ID:193)Temperature (°F)	%y521
522	CL-202-E(COM1->ID:193)Dew Point Temperature	%y522
Modbus address		Variable symbol

Description for measurement item: Module name (COM Port Interface: Modbus ID) Measurement item

Editing a message with a variable symbol

10. Click the ficon to add a message and click the ficon to edit the message on the Message Pool page.



Item	Description
1	1 The page number in Message Pool
2	The icon for adding a message
3	The icon for editing a message
4	Clicks the icon to delete a message
5	Message number
6	To Enable/ Disable the display of a message
7	The content of a message

 Insert the desired variable symbol into a message such as CO2: %y518 ppm and click the Update button.

No. 1	
Display Status 🗹 Instant 🗆	
Message Moving Mode 🛛 🗸	
Row(s) 1	
Color Yellow ~	
Message	
CO2: %y518 ppm	
	Update
	Cance

12. Check the message is correctly displayed with measured value from the CL/DL series module.



Appendix. Variable Types and Modbus Register Map

Variable Types

The iKAN series device allows data related to items such as the Ethernet configuration, the RTC value, and other information, to be inserted into a message as a system variable.

The format for using a system variable in a message has a length of 5 bytes, as follows:

1	2	3 to 5		
Delimiter Character	Variable Type	Modbus Address: 3-digit decimal number		
	y: System variable h: Coil			
%	u: Unsigned integer (0 to 65535)	х	х	х
	i: Signed integer (-32768 to 32767)			
	f: Float (-3.4E+38 to +3.4E+38)			

The valid range for each type of variable is:

Variable Type	Range
Coil Variables	%b000 to %b039
	%u000 to %u063
Integer Variables	%i000 to %i063
Float Variables	%f128 to %f254
System Variables	%y000 to %y026

Modbus	Address	Lough	Description	Value	A 44 - 16 - 14 -
Decimal	Hex.	Length		Range	Attribute
00000	0000				
:	:	40	Coil-type variables	-	R/W
00039	0027				
00100	0064				
:	:	128	Enables or disables the display of	0: Disabled	R/W
00227	00E3		common messages 0 to 127.	1: Enabled	

Coil-type variables (0xxxx, 0 based)

System variables (3xxxx, 0 based)

Modbus	Address	Longth	Description	Value	مغبينانين
Decimal	Hex.	Length	Description	Range	Attribute
30000 : 30003	0000 : 0003	4	The IP address for the iKAN series device	0 to 255	R
30004 : 30007	0004 : 0007	4	The Mask address for the iKAN series device	0 to 255	R
30008 : 30011	0008 : 000B	4	The Gateway address for the iKAN series device	0 to 255	R
30012	000C	1	Year	0 to 9999	R
30013	000D	1	Month	1 to 12	R
30014	000E	1	Day	1 to 31	R
30015	000F	1	Abbreviated day of the week: SUN, MON, TUE, WED, THU, FRI, SAT	0 to 6	R
30016	0010	1	Day of the week: Sunday, Monday, Tuesday, Wednesday, Thursday,	0 to 6	R

			Friday, Saturday		
30017	0011	1	Day of the week in Chinese characters: 日、一、二、三、四、五、六	0 to 6	R
30018	0012	1	Hours (24-hour format)	0 to 23	R
30019	0013	1	Minutes	0 to 59	R
30020	0014	1	Seconds	0 to 59	R

Integer-type variables/Float-type variables/misc. (4xxxx, 0 based)

Modbus A	Address	Length	Develotion		A.L. 31
Decimal	Hex.		Description	Value Range	Attribute
40000	0000				
:	:	64	Integer-type variables	0 to 65535	R/W
40063	003F				
40128	0080			2 45+29 +0	
:	:	64	Float-type variables		R/W
40255	00FF			+3.4L+30	
40384	0180		Data manning arguments: Source		
:	:	64	Low	0 to 65535	R/W
40447	01BF		LOW		
40512	0200		Data manning arguments: Source		
:	:	64		0 to 65535	R/W
40475	023F				
40640	0280		Data manning arguments: Target		
:	:	64		0 to 65535	R/W
40703	02BF		LOW		
40768	0300		Data manning arguments: Target		
:	:	64		0 to 65535	R/W
40831	033F				
40896	0380		Data manning arguments:		
:	:	64		0 to 2	R/W
40959	03BF				

41024 : 41087	0400 : 043F	64	Decimal Places for float-type variables	1 to 3	R/W
41408 : 41535	0580 : 05FF	128	Color for common messages 0 to 127 in the first row.	1: Blue 2: Green 3: Sky Blue 4: Red 5: Purple 6: Yellow 7: White 8: Random	R/W
41600	0640	1	Brightness for the display, a smaller number means a brighter screen	0 to 4	R/W
41601	0641	1	Message scrolling speed. A smaller value denotes a higher speed.	0 to 9	R/W
41602	0642	1	Modbus Station ID	1 to 254	R/W
41604	0644	1	Modbus TCP Slave port	0 to 65535	R/W
41612	0652	1	The response timeout value for Modbus TCP communication	0 to 65535	R/W
41613	0653	1	The delay between polls for Modbus TCP communication	0 to 65535	R/W
41632 : 41759	0660 : 06DF	128	The priority for messages 0 to 127	0: Common 1: Instant	R/W
41800 : 41831	0708 : 0727	32	The contents of ASCII string 0	ASCII	R/W
41832 : 41863	0728 : 0747	32	The contents of ASCII string 1	ASCII	R/W

Page: 135

41864 : 41895	0748 : 0767	32	The contents of ASCII string 2	ASCII	R/W
41896 : 41927	0768 : 0787	32	The contents of ASCII string 3	ASCII	R/W
41928 : 41959	0788 : 07A7	32	The contents of ASCII string 4	ASCII	R/W
41960 : 41991	07A8 : 07C7	32	The contents of ASCII string 5	ASCII	R/W
41992 : 42023	07C8 : 07E7	32	The contents of ASCII string 6	ASCII	R/W
42024 : 42055	07E8 : 0808	32	The contents of ASCII string 7	ASCII	R/W
42100 : 42227	0834 : 08B3	128	The color of messages 0 to 127 on the second row.	1: Blue 2: Green 3: Sky Blue 4: Red 5: Purple 6: Yellow 7: White 8: Random	R/W
42300 : 42427	08FC : 097B	128	The message moving type for messages 0 to 127	0 to 3	R/W

Page: 136

42500 : 42539	08FC : 09EB	40	The color for coil variables 0 to 39	1: Blue 2: Green	R/W
42700 : 42763	0A8C : 0ACB	64	The color for integer variables 0 to 63	3: Sky Blue 4: Red 5: Purple	R/W
42700 : 42763	0A8C : 0ACB	64	The color for float variables 0 to 63	6: Yellow 7: White 8: Random	R/W

Revision History

The table below shows the revision history.

Revision	Date	Description
1.0.1	September 2019	Initial issue
1.0.2	February 2021	Modify the workflow of iKAN updates in chapter 5.
1.1.0	December 2022	Description update for user interface and new functions.