

PIR-234 Series

User Manual

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, or for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2023 ICP DAS Co., Ltd. All rights are reserved.

Trademarks

Names are used for identification purposes only and may be registered trademarks of their respective companies.

Contact Us

If you have any problems, please feel free to contact us by email at:
service@icpdas.com.

Table of Contents

1. Introduction	6
2. Hardware Information	7
2.1. Specifications	7
2.2. Appearance	9
2.3. Pin Assignments	10
2.4. Wiring Connections.....	10
2.5. Hardware Configuration	11
2.6. Hardware Installation	13
3. Configuration via Web Browser	15
3.1 Connecting the Power and the Host PC.....	15
3.2. Network Configuration	18
3.3. Logging into the PIR-234(L).....	20
3.4. Home.....	21
3.5. Network	22
3.5.1. IP Address Configuration	22
.....	24
3.5.2. General Settings.....	25
3.5.3. Restore Factory Defaults.....	26
3.5.4. Forced Reboot.....	27
3.5.5. Firmware Update	27
3.6. PIR Settings	28
3.6.1. Read I/O Status	28
3.6.2. PIR Settings	28
3.6.3. Temperature Alarm Settings.....	30
3.7 Filter	31
3.7.1. Filter Settings	31
3.8. Monitor	33
3.9. Change Password	34
3.10. Logout	35


3.11. Wi-Fi (for PIR-234-WF / PIR-234L-WF only)	36
3.11.1. Wi-Fi Status	36
3.11.2. Wi-Fi Settings	37
4. Configuration via Wi-Fi (for PIR-234-WF / PIR-234L-WF only)	39
4.1. Building the Wi-Fi Connection	39
4.2. Configuring the Wi-Fi Settings	41
4.3. Configuration via RS-485.....	42
5. DCON Protocol	48
5.1. Overview	48
5.2. %AANNTTCCFF	52
5.3. #AA	55
5.4. #AA0	56
5.5. #AA1	57
5.6. #AA2	58
5.7. \$AA2	59
5.8. \$AA5	61
5.9. \$AAF	62
5.10. \$AALC2C0NNNN	63
5.11. \$AALC3	65
5.14. \$AALC7C0NN	66
5.15. \$AALC8C0	68
5.16. \$AALC9C0NN	70
5.17. \$AALCAC0	72
5.20. \$AAM	74
5.21. \$AAP	75
5.22. \$AAPN	77
5.23. ~AARD	79
5.24. ~AARDVV	80
5.25. @AADI	82

5.26. @AADONN	84
5.27. ~AAD	86
5.28. ~AADVV	88
5.29. @AACHC0.....	90
5.30. @AADA.....	91
5.31. @AAEAT	92
5.32. @AAHI(Data).....	94
5.33. @AAHO	96
5.34. @AAHO(Data)	97
5.35. @AARH.....	98
5.36. @AARAO	99
5.37. @AATO.....	100
5.38. @AATO(Data).....	101
6. Modbus RTU Protocol.....	102
6.1. Modbus Address Mapping (Base 1)	103
6.2. Function 01 (0x01) Read Coils.....	111
6.3. Function 02 (0x02) Read Discrete Input	112
6.4. Function 03 (0x03) Read Multiple Registers	113
6.5. Function 04 (0x04) Read Multiple Input Registers	114
6.6. Function 05 (0x05) Write Single Coil.....	115
6.7. Function 06 (0x06) Write Single Register	116
6.8. Function 15 (0x0F) Write Multiple Coils	117
6.9. Function 16 (0x10) Write Multiple Registers.....	118
Appendix: FAQ.....	119
A. How to update the firmware via Ethernet	119

1. Introduction

The PIR-234(L) series module includes 4-channel passive infrared (PIR) sensor that is able to detect infrared waves generated by human within a range of approximately 9 and 14 meters in diameter with a 360° coverage area. The PIR-234(L) series is used for indoor motion detection, and can be configured to automatically switch on a light if motion is detected.

1-channel temperature sensor is provided for measuring room temperature, it can also be used as a heat detector to activate the fire alarm system.



The PIR-234(L) series contains RS-485, Ethernet and PoE communication interfaces, the most common communication interfaces in industrial network. With additional Wi-Fi interface, the PIR-234-WF / PIR-234L-WF series provides a WLAN connection which makes an easy way to incorporate wireless connectivity into monitoring and control systems.

The PIR-234-WF / PIR-234L-WF modules are complied with IEEE 802.11b/g/n standard from 2.4~2.5 GHz. It can be used to provide up to 11 Mbps for IEEE 802.11b and 54 Mbps for IEEE 802.11g to connect to your wireless LAN.

2. Hardware Information


2.1. Specifications

Model		PIR-234-E / PIR-234L-E	PIR-234-WF/PIR-234L-WF
PIR			
Time-delay	Hardware	8-step Switch-selectable (seconds): 6, 16, 33, 66, 131, 262, 524, 1049	
	Software	16-step (seconds): 2, 4, 6, 8, 16, 33, 49, 66, 131, 262, 393, 524, 1049, 2097, 3146, 4194	
Sensor		4 (SW/HW Configure)	
Detection Height		4 m Max.	
Detection Field of View		360°; Diameter 9 meters Max. (PIR-234 Series) 360°; Diameter 14 meters Max. (PIR-234L Series)	
Temperature			
Measurement Range		-40 ~ +120°C	
Fire Alarm		65°C (Programmable)	
Resolution		0.01°C	
Accuracy		± 0.5°C	
Relative Humidity			
Range		0 to 100% RH	
Resolution		0.01% RH	
Accuracy		± 5% RH	
Relay Output			
Channel		2	
Type		Power Relay, Form A (SPST N.O.)	
Max. Load Current		16 A @ 250 VAC or 16 A @ 30 VDC	
Load Wattage		(1).Incandescent Lamp: 40W/ 220VAC * 8 Sets (2).LED(Electronic ballast): 40W/ 220VAC *10 Sets	


Model	PIR-234-E / PIR-234L-E		PIR-234-WF/PIR-234L-WF	
Communication				
Node Address	Hardware: 160 to 191 / Software:1 to 255			
Protocol	DCON, Modbus RTU, Modbus TCP			
Wireless interface	-		Wi-Fi	
Standard Supported	-		IEEE 802.11 b/g/n	
Wireless Mode	-		Infrastructure/ Limited AP	
Wireless Security	-		WEP, WPA, WPA2	
Transmission Range	-		50 M(LOS)	
LED Display				
System LED Indicator	1 LED as Power/Communication Indicator			
I/O LED Indicator	1 LED as Alarm Indicator			
PIR LED Indicator	1 LED as PIR Indicator			
EMS Protection				
ESD (IEC 61000-4-2)	±4 kV Contact for each Terminal, ±8 kV Air for Random Point			
EFT (IEC 61000-4-4)	±4 kV for Power Line			
Power Requirements				
Reverse Polarity Protection	Yes			
Powered from Terminal Block	+10 to +48 VDC			
Powered from PoE	Yes, IEEE 802.3af, Class1			
Consumption	2 W		3 W	
Mechanical				
Installation	Ceiling mounting			
Protection Class	IP20			
Dimensions (D x H)	Ø 150 mm x 53 mm			
Environment				
Operating Temperature	0 to +75°C			
Storage Temperature	-30 to +80°C			
Humidity	10 to 90% RH, Non-condensing			

2.2. Appearance

Front




Rear



2.3. Pin Assignments


PIR-234(L)	Pin	Description
COM0	COM0	Relay's Common Contact
NO0	NO0	Relay's Normally Open Contact
COM1	COM1	Relay's Common Contact
NO1	NO1	Relay's Normally Open Contact
D-	D-	RS-485 Serial Communication Interface
D+	D+	
GND	GND	Ground
+Vs	+VS	Power Input (+10 to +48 VDC)

2.4. Wiring Connections



2.5. Hardware Configuration

DIP switches located on the rear side of the PIR-234(L) series module allow for configuration options. The switches are numbered 1~4 and 1~10 and can be set to ON or OFF. All the configuration will only take effect when the DIP[2] is set to OFF(Hardware) position. Following is more information on the DIP switch settings.



DIP [1:4]	PIR1~4: Used to specify the configuration settings for the PIR1~4 Sensors ON: PIR Enable (default) OFF: PIR Disable
DIP [1]	Protocol: Used to specify the communication protocol to be used by the module ON: DCON OFF: Modbus RTU (default)
DIP [2]	Configuration: Used to specify the configuration settings for the module ON: Configure the module using DCON/Modbus commands (Software) OFF: Configure the module via DIP switch (Hardware, default)
DIP [3]	Address: Used to specify the module address when DIP [2] is set to OFF ON: Use rotary switch positions 0 to F for node addresses 176 to 191 OFF: Use rotary switch positions 0 to F for node addresses 160 to 175 (default)

DIP [4]	<p>Mode:</p> <p>Used to specify the operating mode</p> <p>ON: Operating in INIT mode</p> <p>OFF: Operating in Normal mode (default)</p>																																													
DIP [5:7]	<p>DO Control:</p> <p>Used to specify the DO0 and DO1 by PIR, Temperature or CMD.</p> <table><tr><th>DIP 5</th><th>DIP 6</th><th>DIP 7</th><th>DO0 by</th><th>DO1 by</th></tr><tr><td>OFF</td><td>OFF</td><td>OFF</td><td>PIR(default)</td><td>PIR(default)</td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>PIR</td><td>TEM</td></tr><tr><td>OFF</td><td>ON</td><td>OFF</td><td>TEM</td><td>PIR</td></tr><tr><td>ON</td><td>ON</td><td>OFF</td><td>TEM</td><td>TEM</td></tr><tr><td>OFF</td><td>OFF</td><td>ON</td><td>PIR</td><td>CMD</td></tr><tr><td>ON</td><td>OFF</td><td>ON</td><td>TEM</td><td>CMD</td></tr><tr><td>OFF</td><td>ON</td><td>ON</td><td>CMD</td><td>PIR</td></tr><tr><td>ON</td><td>ON</td><td>ON</td><td>CMD</td><td>CMD</td></tr></table> <p>* CMD: Configure the module using DCON/Modbus commands (Software)</p>	DIP 5	DIP 6	DIP 7	DO0 by	DO1 by	OFF	OFF	OFF	PIR(default)	PIR(default)	ON	OFF	OFF	PIR	TEM	OFF	ON	OFF	TEM	PIR	ON	ON	OFF	TEM	TEM	OFF	OFF	ON	PIR	CMD	ON	OFF	ON	TEM	CMD	OFF	ON	ON	CMD	PIR	ON	ON	ON	CMD	CMD
DIP 5	DIP 6	DIP 7	DO0 by	DO1 by																																										
OFF	OFF	OFF	PIR(default)	PIR(default)																																										
ON	OFF	OFF	PIR	TEM																																										
OFF	ON	OFF	TEM	PIR																																										
ON	ON	OFF	TEM	TEM																																										
OFF	OFF	ON	PIR	CMD																																										
ON	OFF	ON	TEM	CMD																																										
OFF	ON	ON	CMD	PIR																																										
ON	ON	ON	CMD	CMD																																										
DIP [8:10]	<p>ON Time Control:</p> <p>Used to specify the ON time for the relay after the PIR sensor has been triggered.</p> <table><tr><th>DIP 8</th><th>DIP 9</th><th>DIP 10</th><th>ON Time</th></tr><tr><td>OFF</td><td>OFF</td><td>OFF</td><td>6 seconds (default)</td></tr><tr><td>OFF</td><td>OFF</td><td>ON</td><td>16 seconds</td></tr><tr><td>OFF</td><td>ON</td><td>OFF</td><td>33 seconds</td></tr><tr><td>OFF</td><td>ON</td><td>ON</td><td>66 seconds</td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>131 seconds</td></tr><tr><td>ON</td><td>OFF</td><td>ON</td><td>262 seconds</td></tr><tr><td>ON</td><td>ON</td><td>OFF</td><td>524 seconds</td></tr><tr><td>ON</td><td>ON</td><td>ON</td><td>1049 seconds</td></tr></table>	DIP 8	DIP 9	DIP 10	ON Time	OFF	OFF	OFF	6 seconds (default)	OFF	OFF	ON	16 seconds	OFF	ON	OFF	33 seconds	OFF	ON	ON	66 seconds	ON	OFF	OFF	131 seconds	ON	OFF	ON	262 seconds	ON	ON	OFF	524 seconds	ON	ON	ON	1049 seconds									
DIP 8	DIP 9	DIP 10	ON Time																																											
OFF	OFF	OFF	6 seconds (default)																																											
OFF	OFF	ON	16 seconds																																											
OFF	ON	OFF	33 seconds																																											
OFF	ON	ON	66 seconds																																											
ON	OFF	OFF	131 seconds																																											
ON	OFF	ON	262 seconds																																											
ON	ON	OFF	524 seconds																																											
ON	ON	ON	1049 seconds																																											


2.6. Hardware Installation

Installation Tips


- Avoid installing the PIR-234(L) in areas where it will face direct or reflected sunlight.
- Avoid installing the PIR-234(L) in areas where the environmental temperature may change rapidly.
- Ensure that the PIR-234(L) is located at least one meter away from the nearest fluorescent light so as to avoid interference.
- Ensure that there are no obstructions in the field of view.

Installation Instructions


1. Position the Mounting Plate in the desired location. Mark the positions of the two screw holes and a 10 mm hole, as indicated below.




2. Secure the Mounting Plate to the ceiling using the M4x12 drywall screws and the optional octagonal box.



3. Feed the wires through the wiring hole.





4. Connect all the wires to the appropriate locations on the connector.
5. Align the marks on the PIR-234(L) with the marks on the mounting Plate.
6. Rotate the PIR-234(L) clockwise until it locks into place.



3. Configuration via Web Browser

3.1 Connecting the Power and the Host PC





For connecting with PC via Wi-Fi

The PIR-234-WF / PIR-234L-WF logger can connect to the PC through Wi-Fi with power input requirement of +12 ~ +48 V_{DC}.

The PIR-234-WF / PIR-234L-WF device can be configured as station mode, such that the PC/Laptop can be connected through Wi-Fi AP.






The PIR-234-WF / PIR-234L-WF device can be configured as AP mode, such that the PC/Laptop can be connected through Wi-Fi directly. Only one device is allowed to be connected to the PIR-234-WF / PIR-234L-WF module in AP mode.




A tip for connecting the wire to the connector

1. Use the blade of the flat-head screwdriver to push down the wire clamp.
2. While holding the screwdriver in place, insert the wire into the terminal block.
3. Release the screwdriver.



A tip for removing the wire from the connector

1. Use the blade of the flat-head screwdriver to push down the wire clamp.
2. While holding the screwdriver in place, remove the wire from the terminal block.
3. Release the screwdriver.



3.2. Network Configuration


Step 1: Get the eSearch Utility

Download the eSearch Utility from

<http://ftp.icpdas.com/pub/cd/iiot/utility/esearch/>



Step 2: Install the eSearch utility




After the installation has been completed, a new short cut for the eSearch Utility will be displayed on your desktop.



Step 3: Search the PIR-234(L) series module on the Ethernet


Launch eSearch Utility and click the “Search Servers” button to search for the PIR-234(L) module



Step 4: Double-click the name of the module to open the “Configure Server (UDP)” dialog box


Factory Default Settings:

IP	192.168.255.1
Gateway	192.168.0.1
Mask	255.255.0.0




Step 5: Assign a new IP address

Enter valid **IP Address**, **Subnet Mask** and **Gateway** for your network, and then click the “OK” button. The new settings for the PIR-234(L) module will take effect within 2 seconds. If the correct network configuration information is unknown, contact the Network Administrator to obtain the relevant details.




Step 6: Wait for 2 seconds and then click the “Search Servers” button again to ensure that the PIR-234(L) module is operating correctly using the new configuration




3.3. Logging into the PIR-234(L)

Step 1: Open a new browser windows

Open a standard web browser. For example, Mozilla Firefox, Google Chrome and Internet Explorer are reliable and popular internet browsers that can be used to configure the PIR-234(L) module.

 *If you intend to use Internet Explorer, ensure that the cache to functions is disabled in order to avoid browser access errors. Detailed information how to do this can be found in “FAQ_General_001: How to avoid a browser access error that causes a blank page to be displayed when using Internet Explorer”.*

Step 2: Enter the new IP address for the PIR-234(L) and press the Enter key




Step 3: Enter the password to login to the web interface

Enter the password in the login password field (default is “Admin”), and then click the “Submit” button to enter the configuration web page.



3.4. Home

The first page displayed is Home, it shows the main **Status & Configuration** page.




This section provides basic information related to the PIR-234(L) series module including the Model Name, Firmware version, IP Address, Initial Switch position, Alias Name, MAC Address, and the TCP Port and System Timeout values. If the firmware for the PIR-234(L) module is updated, you can check the version information here.

Model Name:	PIR230E	Alias Name:	EtherIO
Firmware Version:	A0.1 [Dec.29, 2015]	MAC Address:	00-0d-e0-ff-ff-ff
IP Address:	192.168.255.1	Initial Switch:	OFF
TCP Port Timeout (Socket Watchdog, Seconds):	180	System Timeout (Network Watchdog, Seconds):	0

3.5. Network

Clicking the **Network** tab to go to the page allowing you to verify the current settings, configure the IP Address and general parameters, and restore the default settings for the PIR-234(L) module, each of which will be described in more detail below.



PIR-230-E

[Home](#) | [Network](#) | [PIR Settings](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)

Model Name:	PIR230E	Alias Name:	EtherIO
Firmware Version:	A0.1 [Dec.29, 2015]	MAC Address:	00-0d-e0-ff-ff-ff
IP Address:	192.168.255.1	Initial Switch:	OFF
TCP Port Timeout (Socket Watchdog, Seconds):	180	System Timeout (Network Watchdog, Seconds):	0

3.5.1. IP Address Configuration

Address Type:	DHCP ▾		
Static IP Address:	255	255	255
Subnet Mask:	0	0	0
Default Gateway:	0	0	0
MAC Address:	00-0d-e0-ff-ff-ff	(Format: FF-FF-FF-FF-FF-FF)	
	Modbus TCP Slave		
Local Modbus TCP port	502	(Default= 502)	
Local Modbus NetID	1	(Default= 1)	Enable ▾ (Default= Enable)
<button>Update Settings</button>			

The following table provides an overview of the parameters contained in the **IP Address Configuration** section:

Item	Description
Address Type	Static IP: If there is no DHCP server installed in your network, you can configure the network settings manually. Refer to Section “Manual Configuration” below for more details.
	DHCP: Dynamic Host Configuration Protocol (DHCP) is a network application protocol that automatically assigns an IP address to each device. Refer to Section “DHCP Configuration” below for more details.
Static IP Address	Each PIR-234(L) module connected to the network must have its own unique IP address. This parameter is used to assign a specific IP address if there is no DHCP server on the network.
Subnet Mask	This parameter is used to assign the subnet mask for the PIR-234(L) module. The subnet mask indicates which portion of the IP address is used to identify the local network or subnet.
Default Gateway	This parameter is used to assign the IP Address of the Gateway to the PIR-234(L) module. A Gateway (or router) is a device that is used to connect an individual network to one or more additional networks.
MAC Address	This parameter is used to set the User-defined MAC address, which must be in the format FF-FF-FF-FF-FF-FF.
Modbus TCP Slave	
Local Modbus TCP port	This parameter is used to set the local port for Modbus communication. The default value is 502.
Local Modbus NetID	This parameter is used to set the Network ID for Modbus communication. The default value is 1.
	<p>Enable option: the NetID will be checked when the PIR-234(L) module receives a Modbus command for identifying if to respond to this command.</p> <p>Disable option: the NetID will not be checked when the PIR-234(L) module receives a Modbus command. The PIR-234(L) module will respond to every command it receives.</p>
Update Settings	Click this button to save the revised settings to the PIR-234(L) module.

DHCP Configuration

DHCP configuration is very easy to perform. If a DHCP server is connected to your network, network addresses will be dynamically configured after the following setting:

Step 1: Select “**DHCP**” from the **Address Type** drop-down menu

Step 2: Click the “**Update Settings**” button to complete the configuration

1

Address Type:	DHCP ▼			
Static IP Address:	10	0	8	102
Subnet Mask:	255	255	255	0
Default Gateway:	10	0	8	254
MAC Address:	00-0d-e0-c7-8a-9f (Format: FF-FF-FF-FF-FF-FF)			
Local Modbus TCP port	502			(Default= 502)
Local Modbus NetID	1			(Default= 1) Enable ▼ (Default= Enable)
2 Update Settings				

Manual Configuration

When using manual configuration, the network settings should be assigned as follows:

Step 1: Select “**Static IP**” from the **Address Type** drop-down menu

Step 2: Enter the relevant details in the respective network settings fields.

Step 3: Click the “**Update Settings**” button to complete the configuration

1

Address Type:	Static IP ▼			
Static IP Address:	10	0	8	102
Subnet Mask:	255	255	255	0
Default Gateway:	10	0	8	254
MAC Address:	00-0d-e0-c7-8a-9f (Format: FF-FF-FF-FF-FF-FF)			
Local Modbus TCP port	502			(Default= 502)
Local Modbus NetID	1			(Default= 1) Enable ▼ (Default= Enable)
3 Update Settings				

3.5.2. General Settings

Ethernet Speed:	Auto ▼ (Auto=10/100 Mbps Auto-negotiation)
System Timeout (Network Watchdog)	0 (30 ~ 65535 s, Default= 0, Disable= 0) Action:Reboot
TCP Timeout	180 (5 ~ 65535 s, Default= 180, Disable= 0) Action:Cut-off
UDP Configuration:	Enable ▼ (Enable/Disable the UDP Configuration, Enable=default.)
Web Auto-logout	10 (1 ~ 65535 minutes, Default= 10, Disable= 0)
Alias Name:	EtherIO (Max. 18 chars)
Update Settings	

The following table provides an overview of the parameters contained in the **General Settings** section:

Item	Description
Ethernet Speed	This parameter is used to set the Ethernet speed. The default value is Auto (Auto = 10/100 Mbps Auto-negotiation).
System Timeout (Network Watchdog)	This parameter is used to configure the system timeout value. If there is no activity on the network for a certain period of time, the system will be rebooted based on the configured system timeout value.
TCP Timeout (Seconds)	This parameter is used to configure the TCP timeout value. If Modbus TCP communication is idle for a certain period of time, the system will cut off the connection.
UDP Configuration	This parameter is used to enable or disable UDP configuration function.
Web Auto-logout	This parameter is used to configure the automatic logout value. If there is no activity on the web server for a certain period of time, the current user account will automatically logged out.
Alias Name	This parameter is used to assign an alias name for each PIR-234(L) module to assist with easy identification.
Update Settings	Click this button to save the revised settings to the PIR-234(L) module.

3.5.3. Restore Factory Defaults


After performing the following operation, items will be restored to factory default settings as below:

Factory Default Settings	
IP Address	192.168.255.1
Gateway Address	192.168.0.1
Subnet Mask	255.255.0.0

Step 1: Click the **“Restore Defaults”** button to reset the configuration.


Step 2: Click the **“OK”** button in the message dialog box.

Step 3: Refer to step 3 and step 4 in Section **“3.2. Network Configuration”**, to check whether the settings are restored to factory defaults.



3.5.4. Forced Reboot


The **Forced Reboot** function can be used to force the PIR-234(L) module to reboot or to remotely reboot the device. After the PIR-234(L) module has rebooted, the original login screen will be displayed and your Login Password will be requested.



3.5.5. Firmware Update

Click the Update button and then select the firmware file to update the firmware.

Firmware Update



The firmware can be obtained from web site:



[http://ftp.icpdas.com/pub/cd/pir/PIR-234\(L\)-e/firmware/](http://ftp.icpdas.com/pub/cd/pir/PIR-234(L)-e/firmware/)

3.6. PIR Settings



PIR-234-E Motion, Temperature, and Humidity Sensor Module

[Home](#) | [Network](#) | [PIR Settings](#) | [MQTT](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)

Clicking the **PIR Settings** tab to go to the **PIR Settings** page where you can configure the PIR sensor settings, temperature alarm settings and relay output, which will be described in more detail below.

3.6.1. Read I/O Status

DO Value	0x1
PIR Status	Active

3.6.2. PIR Settings

Configuration	Hardware	
	Software Settings	Hardware Settings
PIR Output On Time	6 (Seconds)	6 (Seconds)
PIR Sensor 1	Enabled	Enabled
PIR Sensor 2	Enabled	Enabled
PIR Sensor 3	Enabled	Enabled
PIR Sensor 4	Enabled	Enabled
PIR Off Time On Start (s)	6 (0 ~ 30 s)	
Active Delay Time (ms)	0 (0 ~ 3000 ms)	
Buzzer Operation	Inactive	
Digital Output 0	By PIR	
Digital Output 1	By Temperature	
<button>Update Settings</button>		

The following table provides an overview of the parameters contained in the **PIR Settings** section:

Item	Description
Configuration	<p>The configuration for PIR-234(L) module can refer to either hardware or software, and is optional via the DIP[2] switch on the rear side of the module.</p> <p>This field is read only; it shows the current setting on the module.</p>
PIR Output ON Time	The delay time of sensor status after PIR sensor is triggered. (Refer to Section 5.15. \$AALC8C0 for details)
Active Delay Time (ms)	The delay time of PIR active after power on. (0~3000ms)
Buzzer Operation	Buzzer is active or inactive when the PIR sensor is triggered.
Digital Output 0, 1	Digital output is selected as PIR enable, disable or temperature enable when the PIR sensor is triggered.

3.6.3. Temperature Alarm Settings

Temperature Alarm Settings

Temperature Alarm Option	Disabled ▼		
Temperature	2674 (0.01°C) / 8013 (0.01°F)	Offset	0 (0.01°C)
Relative Humidity	5617 (0.01%)	Offset	0 (0.01%)
Temperature Alarm Value	6500 (0.01°C)		
Alarm Type	Momentary ▼		
Update Settings			

The following table provides an overview of the parameters contained in the **Temperature Alarm** section:

Item		Description	Attribute
Temperature Alarm Option		Enable/Disable the temperature high alarm function	R/W
Temperature		The value of Centigrade(unit 0.01°C) and Fahrenheit (unit 0.01°F)	R
	Offset	The temperature offset value sets all the measured temperature plus a constant offset to close to room temperature.	R/W
Relative Humidity		The value of relative humidity (unit 0.01%)	R
	Offset	The humidity offset value sets all the measured humidity plus a constant offset to close to room humidity.	R/W
Temperature Alarm Value		The value of temperature high alarm (unit 0.01°C)	R/W
Alarm Type		Momentary alarm / Latch alarm	R/W

3.7 Filter



PIR-234-E Motion, Temperature, and Humidity Sensor Module

[Home](#) | [Network](#) | [PIR Settings](#) | [MQTT](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)



Clicking the **Filter** tab to go to the **Filter Settings** page where you can configure the IP Filter for the PIR-234(L) module, which will be described in more detail below.

3.7.1. Filter Settings

The **Filter Settings** page is used to query or edit the IP Filter List for the PIR-234(L) module. The IP filter list restricts the access of incoming packets based on the IP header. If one or more IP addresses are saved to the IP Filter table, only Clients whose IP address is specified in the IP Filter List will be able to access the PIR-234(L) module.

Filter Settings:

Available IP List	IP Address
IP1:	10.0.8.20
IP2:	0.0.0.0
IP3:	0.0.0.0
IP4:	0.0.0.0
IP5:	0.0.0.0

☐ Add . . . To The List

☒ Delete IP#

☐ Delete ALL

☐ Save to Flash

The following table provides an overview of the parameters contained in the IP Address Configuration section:

Item	Description
Add "IP" to the List	This parameter is used to add an IP address to the IP filter List.
Delete IP # "number"	This parameter is used to delete IP# address from the IP filter List.
Delete All	This parameter is used to delete all IP address current contained in the IP filter List.
Save to Flash	This parameter is used to save the updated IP filter List to the flash memory. Check the checkbox before clicking the Submit button of you wish to store the most recent list.
Submit	Click this button to save the revised settings to PIR-234(L) module.

3.8. Monitor



PIR-234-E Motion, Temperature, and Humidity Sensor Module

[Home](#) | [Network](#) | [PIR Settings](#) | [MQTT](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)



After clicking the **Monitor** tab, the Current Connection Status page will be displayed showing detailed information regarding the current status of the serial port connection settings for the PIR-234(L) module.

Current Connection Status:

Server Mode	Server
Connected IP1:	0.0.0.0
IP2:	0.0.0.0
IP3:	0.0.0.0
IP4:	0.0.0.0
IP5:	0.0.0.0
IP6:	0.0.0.0
Available Connections:	32

3.9. Change Password



PIR-234-E Motion, Temperature, and Humidity Sensor Module

[Home](#) | [Network](#) | [PIR Settings](#) | [MQTT](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)



To change the p default password:

Step 1: Go to the **Change Password** page by clicking the **Change Password** tab.

Step 2: Enter the old password in the textbox next to “**Current password**”. (Default: **Admin**)

Step 3: Enter a new password in the textbox next to “**New password**”.

Step 4: Re-enter the new password in textbox next to “**Confirm new password**”.

Step 5: Click the “**Submit**” button to update the password.

Change Password

The length of the password is 12 characters maximum.

The diagram illustrates the 'Change Password' form. A red box labeled '1' encloses the three input fields: 'Current password:', 'New password:', and 'Confirm new password:'. Each field contains four dots representing masked text. A blue box labeled '2' highlights the 'Submit' button. A large grey curved arrow points from the input fields towards the 'Submit' button. A yellow starburst icon is positioned next to the 'Submit' button.

3.10. Logout



PIR-234-E Motion, Temperature, and Humidity Sensor Module

[Home](#) | [Network](#) | [PIR Settings](#) | [MQTT](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)



Clicking the **Logout** tab will immediately log you out from the system and return you to the login page.

The system is logged out.

To enter the web configuration, please type password in the following field.

Login password:

Note: This web configuration requires JavaScript enabled in your browser (Firefox, IE...).
If the web configuration does not work, please check the JavaScript settings first.

When using IE, please disable its cache as follows.

Menu items: Tools / Internet Options... / General / Temporary Internet Files / Settings... / Every visit to the page

3.11. Wi-Fi (for PIR-234-WF / PIR-234L-WF only)



For PIR-234-WF / PIR-234L-WF module, the Wi-Fi related parameters can be set via the Wi-Fi page. This page including Wi-Fi Status and Wi-Fi Settings, each of which will be described in more detail below.

3.11.1. Wi-Fi Status

Connection Status	Connected
Signal Strength	High
MAC Address	D0-5F-B8-1C-0C-56
IP Address	192.168.0.100

Update Wi-Fi Status

The following table provides an overview of the parameters contained in the Wi-Fi Status section:

Item	Description
Connection Status	The Wi-Fi connection status of the PIR-234-WF / PIR-234L-WF device.
Signal Strength	The Wi-Fi signal strength of the PIR-234-WF / PIR-234L-WF device in station mode. It can be High, Medium, Low, or Not Connected.
MAC Address	The MAC address of the Wi-Fi interface of the PIR-234-WF / PIR-234L-WF device.
IP Address	The IP address of the Wi-Fi interface of the PIR-234-WF / PIR-234L-WF device.
Update Wi-Fi Status	Click this button to update the Wi-Fi status of the PIR-234-WF / PIR-234L-WF device.

3.11.2. Wi-Fi Settings

Wi-Fi Settings	Current	New
Mode	Station	<input type="button" value="Station"/> Default: AP
Wireless Security	WPA/WPA2, *****	<input type="button" value="WPA/WPA2"/> Password: <input type="password" value="....."/> (Max. 63 chars)
DHCP Server (AP Mode)	On, 192.168.255.2	<input type="button" value="On"/> Start IP: <input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="255"/> <input type="text" value="2"/>
Wi-Fi Channel (AP Mode)	11	<input type="button" value="11"/>
IP Address Type (Station Mode)	DHCP	<input type="button" value="DHCP"/>
IP Address	192.168.0.100	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="255"/> <input type="text" value="1"/>
Subnet Mask	0.0.0.0	<input type="text" value="255"/> <input type="text" value="255"/> <input type="text" value="0"/> <input type="text" value="0"/>
Gateway	192.168.0.1	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="255"/> <input type="text" value="254"/>
SSID	WR841NV13	<input type="text" value="WR841NV13"/> (Max. 32 chars)
Modbus TCP port	502	<input type="text" value="502"/> (Default= 502)
<input type="button" value="Update Settings"/>		

The column of Current shows the current Wi-Fi settings. You can change the settings by changing the column of New. The following table provides an overview of the parameters contained in the Wi-Fi Settings section:

Item	Description
Mode	This parameter is used to specify the Wi-Fi mode of the PIR-234-WF / PIR-234L-WF device. It can be station or AP. For AP mode, only one device can be connected.
Wireless Security	This parameter is used to specify which security protocol is used to secure wireless computer network. It can be open, WEP, or WPA/WPA2. It is recommended to use WPA/WPA2 if possible.
DHCP Server (AP Mode)	This parameter is used to specify whether to turn on the DHCP server function. It is only available to the AP mode.
Wi-Fi Channel (AP Mode)	This parameter is used to specify which channel is used for Wi-Fi transmission. It can be 1 to 11. It is only available to the AP mode.
IP Address Type (Station Mode)	This parameter is only available to the station mode and it can be Static IP or DHCP. If DHCP is supported by the AP you would like to connect, then DHCP should be selected. Otherwise, select Static IP and the following three parameters IP Address, Subnet Mask and Gateway should be set, too.

IP Address	Each PIR-234-WF / PIR-234L-WF device connected to the Wi-Fi network must have its own unique IP address. This parameter is used to assign a specific IP address.
Subnet Mask	This parameter is used to assign the subnet mask for the PIR-234-WF / PIR-234L-WF device. The subnet mask indicates which portion of the IP address is used to identify the local network or subnet.
Gateway	This parameter is used to assign the IP address of the gateway to be used by the PIR-234-WF / PIR-234L-WF device. A gateway (or router) is a device that is used to connect an individual network to one or more additional networks.
SSID	This parameter is used to specify the Service Set Identifier. For station mode, specify the SSID of the AP you would like to connect. For AP mode, the SSID will be used by the device to be connected.
Modbus TCP Port	This parameter is used to set the local port of the Wi-Fi interface to be used by the Modbus slave device. The default value is 502.
Update Settings	Click this button to save the revised settings to the PIR-234-WF / PIR-234L-WF device.

The following table provides an overview of the factory default Wi-Fi settings:

Factory Default Wi-Fi Settings	
Mode	AP
Wireless Security	WPA/WPA2, "00000000"
DHCP Server (AP Mode)	DHCP Server on, start IP: 192.168.255.2
Wi-Fi Channel (AP Mode)	11
IP Address	192.168.255.1
Gateway Address	192.168.255.254
Subnet Mask	255.255.0.0
SSID	PIR-234-WF / PIR-234L-WF
Modbus TCP Port	502

4. Configuration via Wi-Fi (for PIR-234-WF / PIR-234L-WF only)

The factory default settings for Wi-Fi communication of the PIR-234-WF / PIR-234L-WF are as follows.

- Mode: AP
- Wireless Security: WPA/WPA2, "00000000"
- DHCP Server (AP Mode): DHCP Server on, start IP: 192.168.255.2
- Wi-Fi Channel (AP Mode): 11
- IP Address: 192.168.255.1
- Gateway Address: 192.168.255.254
- Subnet Mask: 255.255.0.0
- SSID: PIR-234-WF / PIR-234L-WF
- Modbus TCP Port: 502

The Wi-Fi IIOT Utility is provided to configure and test the PIR-234-WF / PIR-234L-WF module through the Wi-Fi interface.

4.1. Building the Wi-Fi Connection


1. Install Wi-Fi IIOT Utility


The installation file location of the Wi-Fi IIOT Utility is at:

<http://ftp.icpdas.com/pub/cd/iiot/utility/>


2. Search and Find the Module

Click on the search button to find the modules via the Wi-Fi interface.






3. Select the Wi-Fi network interface and click on the **OK** button.



4. When the module is found, click on the module name to enter the configuration form.



4.2. Configuring the Wi-Fi Settings

In the Configuration form, you can change the Wi-Fi related settings. Click on the Set Module Configurations button to save the changes to the module.

The screenshot shows the 'PIR230E WF Firmware[0B23]' window with the 'Configuration' tab active. The settings are as follows:

Parameter	Value
Wi-Fi Mode	AP
Wi-Fi Channel	11
SSID	PIR-230-WF
Encryption	WPA
Password	00000000
Modbus TCP Port	0
DHCP Server	On
Start IP	192.168.255.2
IP Address Type	DHCP
Static IP	192.168.255.1
Subnet Mask	255.255.0.0
Gateway	192.168.255.254

The 'Set' button is highlighted with a red box.

The followings show the detailed description of each setting.

Item	Description
WiFi Mode	This parameter is used to specify the Wi-Fi mode of the SL device. It can be Station or AP. For AP mode, only one device can be connected.
Encryption	This parameter is used to specify which security protocol is used to secure wireless computer network. It can be open, WEP, or WPA. It is recommended to use WPA if possible.
DHCP Server	This parameter is used to specify whether to turn on the DHCP server function. It is only available to the AP mode.
WiFi Channel	This parameter is used to specify which channel is used for Wi-Fi transmission. It can be 1 to 11. It is only available to the AP mode.
IP Address Type	This parameter is only available to the station mode and it can be Static or DHCP. If DHCP is supported by the AP you would like to connect, then DHCP should be selected. Otherwise, select Static and the following three parameters Static IP, Subnet Mask and Gateway should be set, too.
Static IP	Each SL device connected to the Wi-Fi network must have its own unique IP address. This parameter is used to assign a specific IP address.

Subnet Mask	This parameter is used to assign the subnet mask for the SL device. The subnet mask indicates which portion of the IP address is used to identify the local network or subnet.
Gateway	This parameter is used to assign the IP address of the gateway to be used by the SL device. A gateway (or router) is a device that is used to connect an individual network to one or more additional networks.
SSID	This parameter is used to specify the Service Set Identifier. For station mode, specify the SSID of the AP you would like to connect. For AP mode, the SSID will be used by the device to be connected.
Modbus TCP Port	This parameter is used to set the local port of the Wi-Fi interface to be used by the Modbus slave device. The default value is 502.

4.3. Configuration via RS-485

The factory default settings for RS-485 communication

Address: 1

Protocol: Modbus/RTU

Baudrate: 9600

Parity: N,8,1

Response Delay (ms): 0


Note If there are multiple PIR-234(L) connected to the same RS-485 network, each module needs be set with a unique RS-485 address. More than one module having the same address will cause communication failure

Testing RS-485 Communication

1. Download the DCON Utility Pro from


https://www.icpdas.com/en/product/guide+Software+Utility_Driver+DCON_Utility_Pro

2. Launch the DCON_Utility_Pro.exe.




3. Click the icon  to configure the COM port.


4. Select the COM Port number used to connect the PIR-234(L) logger.




5. The Baud Rate is factory default to 9600 bps.



6. Select the Protocol tab.




7. Select the Format tab and check the parity that set in the logger.




8. Click the Start Search icon.



9. The PIR-234 logger searched out will be listed as below.



10. Click the module name to configure the logger.




Note

The Protocol/Baud Rate/Parity/Checksum items marked with "(INIT*)" means that when any of those items needs be modified, the pin 4.INIT needs to be set in ON position and power cycle the logger, then the item can be modified. After complete setting, set the pin 4.INIT back to OFF position and power cycle the logger again to take the setting effect.

In the AI tab and PIR/Relay Output, you can configure the temperature alarm settings, PIR sensor settings and relay output.

➤ AI tab



➤ PIR / Relay Output

Enable PIR, PIR Status

Adjust PIR Output Settings

The screenshot shows the 'PIR / Relay Output' configuration page of the PIR234E Firmware. The page has tabs for Configuration, AI, PIR / Relay Output, Host WDT, Commands Log, and Summary. The 'PIR / Relay Output' tab is active. It is divided into two main sections: PIR Status and DO Control.

PIR Status Section:

- PIR Status:** A toggle switch set to 'OFF'.
- PIR Sensor:** A list of four sensors (PIR Sensor 1 to 4) with checkboxes. All are checked.
- PIR Sensor Status:** Four circular indicators corresponding to the sensors, all showing a grey dot.
- PIR Output Settings:**
 - PIR Output ON Time:** A dropdown menu set to '6'.
 - PIR Active Delay Time After Power On:** A text input field set to '0'.
 - PIR Inactive Time After Power On:** A text input field set to '0'.
 - Buttons:** 'Apply PIR Output Settings' and 'Set [Power-on Value]'.

DO Control Section:

- DO 0 Triggered:** A dropdown menu set to 'By PIR Output'.
- DO 1 Triggered:** A dropdown menu set to 'By PIR Output'.
- Buzzer Enabled:** A dropdown menu set to 'Disable'.
- Buttons:** 'Set [Power-on Value]' and 'Set [Safe Value]'.
- Radio Buttons:** 'Read' (selected), 'Read Power-on Value', and 'Read Safe Value'.
- Apply DO Output Settings:** A button at the bottom.

DO Control:

Used to specify the DO0 and DO1 by PIR, Temperature or CMD.

DO Status (On/Off)

When the buttons are clicked,

DO Status will be set as the Power On Value or Safe Value.

The followings show the detailed description of each setting.

Item	Description
Temperature	This parameter is sensor readings temperature
High Alarm Limit	Sets the High alarm limit conditions for Temperature (unit 0.01°C)

Alarm Mode	<ul style="list-style-type: none"> - Disabled: Disables alarm function. - Momentary: If a measurement value higher than the High Alarm Limit or lower than the Low Alarm Limit, the alarm occurs until the measurement value is within a range from Low Alarm Limit to High Alarm Limit. - Latched: If a measurement value higher than the High Alarm Limit or lower than the Low Alarm Limit, the alarm occurs.
------------	---


Relative Humidity	This parameter is sensor readings relative humidity
PIR Output ON Time	The delay time of sensor status after PIR sensor is triggered. (Refer to Section 5.15. \$AALC8C0 for details)
PIR Active Delay Time After Power ON	Active delay time for PIR output after power on in milliseconds, 0 to 3000
PIR Inactive Time After Power ON	PIR sensor off time on power on in seconds, 0 to 30
Buzzer Operation	Buzzer is active or inactive when the PIR sensor is triggered.
DO0, DO1 Triggered	Digital outputs are CMD, PIR or temperature when the PIR sensor is triggered.

➤ Host Watchdog

Host Watchdog is used to monitor the RS-485 communication status; if the host (PC) does not send command “~**” in the time period of WDT Timeout setting, the enabled Host Watchdog will announce the timeout error and turn the relay output to Safe value to avoid an unsafe act. Users can not control the relay until the command “~AA1” is sent to clear the WDT timeout status.

On this tab:

1. Set the time period for WDT timeout, check the checkbox next to Enable WDT and click the Set WDT button to enable the Host watchdog.
2. Check the checkbox next to Send Host OK to send the “~**” command.
3. Uncheck the checkbox next to Send Host OK to stop sending ~** command, the Host watchdog timeout will occur and relay will turn to Safe value.
4. Click the Reset WDT button to clear the Host watchdog timeout status.
5. Uncheck the checkbox next to Enable WDT and click the Set WDT button to disable the Host watchdog.



5. DCON Protocol

5.1. Overview

All communication with the PIR-234(L) module consists of commands generated by the Host and responses transmitted by the PIR-234(L) module. Each module has a unique ID number that is used for addressing purposes and is stored in non-volatile memory. The module ID number is set to 01 by default and can be changed by sending a user command. All commands to the modules contain the ID number as the address, meaning that only the addressed module will respond.

Command Format:

Delimiter Character	Module Address	Command	Checksum	CR
---------------------	----------------	---------	----------	----

Response Format:

Delimiter Character	Module Address	Data	Checksum	CR
---------------------	----------------	------	----------	----

CR = End of command character, carriage return (0x0D), used to end a frame.

Note 1: All characters should be in upper case.

Note 2: The DCON Utility Pro can be downloaded from:

<http://ftp.icpdas.com/pub/cd/iiot/utility/>

DCON Command Sets

General Command Sets			
Command	Response	Description	Section
%AANNTTCCFF	!AA	Set configuration, NN: new address, TT = 00, CC: new baud rate, FF: data format	5.2
\$AA2	!AANNTTCCFF	Reads the Configuration of the Module	5.7
\$AA5	!AAS	read reset status !AA1 first after power on, !AA0 others	5.8
\$AA5HH	!AA	Enable/disable PIR sensors, bit 0 for PIR sensor 1, bit 1 for PIR sensor 2, etc. When the bit is 1, it denotes that the PIR sensor is enabled, and 0 denotes that the PIR sensor is disabled.	
\$AA6	!AAHH	Read the enabled/disabled status of the PIR sensors	
\$AAF	!AA(Data)	Reads the Firmware Version of the Module	5.9
\$AAI	!AAS	read INIT status response: !AA0 -> INIT short to GND !AA1 -> else	
\$AAM	!AA(Data)	Reads the Name of the Module	5.20
\$AAP	!AASC	Read Modbus RTU/DCON protocol response: !AA10 -> DCON !AA11 -> Modbus RTU	5.21
\$AAPN	!AA	Set Modbus RTU/DCON protocol N-> 0: DCON, 1: Modbus RTU	5.22
~AARD	!AAHH	read response delay time in ms in hex format	5.23
~AARDHH	!AA	set response delay time in ms, HH in hex format, 00 - 1E	5.24
~**		clear host watchdog timeout counter	
~AA0	!AASS	read host watchdog status	
~AA1	!AA	clear host watchdog timeout status	
~AA2	!AAEVV	read host watchdog enable/disable status and timeout value	

~AA3ETT	!AA	enable/disable host watchdog and set timeout value E-> 0: disable host watchdog, 1: enable host watchdog TT: host watchdog timeout in 0.1s in hex format	
~AA4	!AA0P0S	read DO power on and safe value	
~AA50P0S	!AA	set DO power on and safe value P-> 0 ~ 3: power on value in hex format S-> 0 ~ 3: safe value in hex format	

PIR Input/Relay Output Status Command Sets			
Command	Response	Description	Section
@AADI	!AAS0OPP	read alarm mode and DO status, S: alarm mode, 0 for disabled, 1 for momentary alarm and 2 for latched alarm, O: 0 ~ 3, DO value in hex format, PP: PIR status	5.25
@AADO0V	!AA	set DO, V-> 0 ~ 3 DO value in hex format, bit 0 for DO0, bit 1 for DO1, etc.	5.26
~AAD	!AAVV	Reads the current active state of the digital output	5.27
~AADVV	!AA	Sets the active state of the digital output	5.28

PIR Argument Command Sets			
Command	Response	Description	Section
\$AALC2C0NNNN	!AA	Sets the PIR output delay time after power on	5.10
\$AALC3	!AANNNN	Reads the PIR output delay time after power on	5.11
\$AALC7C0NN	!AA	Sets the PIR output ON time when the PIR sensor is triggered	5.14
\$AALC8C0	!AANN	Reads the current PIR output ON time when the PIR Sensor is triggered	5.15
\$AALC9C0NN	!AA	Sets the PIR output configuration, Bit 0 for buzzer Bit 1 and 2 for DO0 Bit 3 and 4 for DO1	5.16

		For each two bits of DO, 0 for by command, 1 for by PIR and 2 for by temperature alarm	
\$AALCAC0	!AANN	Reads the current PIR output configuration	5.17
\$AALCDHH	!AA	Sets the PIR off time on start in seconds in hex format, 00 to 1E	
\$AALCE	!AAHH	Reads the PIR off time on start in seconds in hex format	

High Alarm Command Sets			
Command	Response	Description	Section
#AA	>(Data)	Read the value of temperature and humidity	5.3
#AA0	>(Data)	Read the value of Centigrade	5.4
#AA1	>(Data)	Read the value of Fahrenheit	5.5
#AA2	>(Data)	Read the value of relative humidity	5.6
#AA3	>(Data)	Read dew point temperature in 0.01°C	
#AA4	>(Data)	Read dew point temperature in 0.01°F	
@AACH	!AA	Clear all high latched analog inputs to the current values	
@AACHN	!AA	Clear channel high latched analog input to the current value, N = 0 for temperature in 0.01°C, 1 for temperature in 0.01°F, 2 for relative humidity in 0.01%, 3 for dew point temperature in 0.01°C, 4 for dew point temperature in 0.01°F	
@AACHC0	!AA	Clear high latched temperature alarm	5.29
@AACL	!AA	Clear all low latched analog inputs to the current values	
@AACLN	!AA	Clear channel low latched analog input to the current value, N = 0 for temperature in 0.01°C, 1 for temperature in 0.01°F, 2 for relative humidity in 0.01%, 3 for dew point temperature in 0.01°C, 4 for dew point temperature in 0.01°F	
@AADA	!AA	Disable temperature alarm	5.30
@AAEAT	!AA	Enable temperature alarm, T->M: momentary alarm, L: latched alarm	5.31
@AAHI(Data)	!AA	Set high alarm limit of temperature in 0.01°C	5.32

@AAHO	!AA(Data)	Reads the value of humidity offset	5.33
@AAHO(Data)	!AA	Set humidity offset, data in format of -100.00 ~ +100.00	5.34
@AARH	!AA(Data)	Read high alarm limit of temperature in 0.01°C	5.35
@AARHN	!AA(Data)	Read channel high latched value of analog input	
@AARLN	!AA(Data)	Read channel low latched value of analog input	
@AARAO	!AAHH00	Read AI alarm status	5.36
@AATO	!AA(Data)	Read temperature offset in 0.01°C	5.37
@AATO(Data)	!AA	Set temperature offset in 0.01°C, -100.00 ~ +100.00	5.38

5.2. %AANNTTCCFF

Description:

This command is used to set the configuration of a specified module.

Syntax:

%AANNTTCCFF[CHKSUM](CR)

- %** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- NN** The new address of the module in hexadecimal format (00 to FF)
- TT** The Type Code, which should be set to 40 for DIO modules
- CC** The new Baud Rate and data format settings. See the following tables for detailed information.
- FF** The new Checksum setting. See the following tables for detailed information.

Note: The DIP switch #4(Init) must be set to ON position before sending this command. It needs be set back to OFF after finishing the configuration settings. See Section 1.5 for more details.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid

- ? Delimiter character to indicate that the command was invalid. If an attempt is made to change the Baud Rate or Checksum setting without putting the DIP switch position #4 in the ON position, the module will return a response indicating that the command was invalid. See Section 1.5 for more details.

AA The address of the responding module in hexadecimal format (00 to FF)

Note: There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Configuration Data Format

Baud Rate Settings (CC)

7	6	5	4	3	2	1	0	
Parity		Baud Rate Code						
Baud Rate Code (Bits 0 to 5)								
Code	03	04	05	06	07	08	09	0A
Baud Rate	1200	2400	4800	9600	19200	38400	57600	115200
Parity (Bits 6 and 7)								
Code	00		01		10		11	
Parity	N,8,1		N,8,2		E,8,1		O,8,1	

Data Format Settings (FF)

7	6	5	4	3	2	1	0
Reserved	CS	Reserved					

Key	Description
CS	Checksum Settings 0: Disabled 1: Enabled

Note: All Reserved bits should be zero.

Examples:

Command: %0102400600

Response: !02

Changes the address of module 01 to 02. The module returns a response indicating that the command was valid and includes the new address of the module.

Command: %0101200A00

Response: ?01

Attempts to change the Baud Rate of module 01 to 115200 bps, but the module returns a response indicating that the command was invalid. It maybe because that the DIP switch #4 is not in the ON position. See Section 1.5 for more details.

Command: %0101200A00

Response: !01

Changes the Baud Rate of module 01 to 115200 bps with putting the DIP switch #4 in the ON position. The module returns a response indicating that the command was valid.

Command: \$012

Response: !01400600

Reads the configuration of module 01 and returns a response indicating that the command was valid. The response showing that the Type Code is 40, the Baud Rate is 9600 bps, the Checksum is Disabled.

Related Commands:

Section 5.7. \$AA2

Related Topics:

Section 2.5. Hardware Configuration

Notes:

Changes to the address settings take effect immediately after a valid command is received. Changes to the Baud Rate and Checksum settings take effect on the next power-on reset.

5.3. #AA

Description:

This command is used to read the value of temperature and relative humidity for a special module.

Syntax:

#AA[CHKSUM](CR)

Delimiter character

AA The address of the module to be configured in hexadecimal format (00 to FF)

Response:

Valid Command: **>(Data) (CR)**

Invalid Command: **?AA[CHKSUM](CR)**

> Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

(Data) The value of the Centigrade, Fahrenheit and relative humidity

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: #01

Response: >+030.00+086.00+050.00

Reads the temperature and humidity of module 01 and returns a response indicating that the command was valid, and temperature is +30°C/+86°F and the relative humidity is +50%.

Related Commands:

Section 5.4. #AA0, Section 5.5. #AA1, Section 5.6. #AA2

5.4. #AA0

Description:

This command is used to read the Centigrade of a specified module.

Syntax:

#AA0[CHKSUM](CR)

- #** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- 0** The command to read the value of Centigrade

Response:

Valid Command: **#AA0[CHKSUM](CR)**

Invalid Command: **>(Data)[CHKSUM](CR)**

- >** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- (Data)** The value of the Centigrade

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: #010

Response: >+030.00

Reads the temperature of module 01 and returns a response indicating that the command was valid, and the temperature is +30°C.

Related Commands:

Section 5.3. #AA, Section 5.5. #AA1, Section 5.6. #AA2

5.5. #AA1

Description:

This command is used to read the Fahrenheit of a specified module.

Syntax:

#AA1[CHKSUM](CR)

- | | |
|----|---|
| # | Delimiter character |
| AA | The address of the module to be configured in hexadecimal format (00 to FF) |
| 1 | The command to read the Fahrenheit. |

Response:

Valid Command: **>(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- | | |
|--------|---|
| > | Delimiter character to indicate that the command was valid |
| ? | Delimiter character to indicate that the command was invalid |
| AA | The address of the responding module in hexadecimal format (00 to FF) |
| (Data) | The value of the Fahrenheit |

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: #011 Response: >+086.00

Reads the temperature of module 01 and returns a response indicating that the command was valid, and the temperature is +86°F.

Related Commands:

Section 5.3. #AA, Section 5.4. #AA0, Section 5.6. #AA2

5.6. #AA2

Description:

This command is used to read the relative humidity of a specified module.

Syntax:

#AA2[CHKSUM](CR)

- #** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- 2** The command to read the relative humidity.

Response:

Valid Command: **>(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- >** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- (Data)** The value of the relative humidity

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: #012

Response: >+050.00

Reads the relative humidity of module 01 and returns a response indicating that the command was valid, and temperature is +50%.

Related Commands:

Section 5.3. #AA, Section 5.4. #AA0, Section 5.5. #AA1

5.7. \$AA2

Description:

This command is used to read the current configuration of a specified module.

Syntax:

\$AA2[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- 2** The command to read the module configuration

Response:

Valid Command: **!AATCCFF[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- TT** The Type Code for the module, which should be 40 for DIO modules
- CC** The Baud Rate for the module. See Section 2.1 for details.
- FF** The Checksum status. See Section 2.1 for details.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: %0101000600

Response: !01

Changes the Baud Rate of module 01 to 9600 bps, the DIP switch #4 is in the ON position and disable the checksum function. The module returns a response indicating that the command was valid.

Command: \$012

Response: !01000600

Reads the configuration of module 01 and returns a response indicating that the command was valid, and showing that the Baud Rate is 9600 bps and the Checksum is Disabled.

Related Commands:

Section 5.2. %AANNTTCCFF

Related Topics:

Section 2.5. Hardware Configuration

5.8. \$AA5

Description:

This command is used to read the current reset status for a specified module.

Syntax:

\$AA5[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- 5** The command to read the reset status of the module

Response:

Valid Command: **!AAS[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- S** The reset status of the module:
 - 0: This is **NOT** the first time the command has been sent since the module was powered on, which denotes that there has been no module reset since the last \$AA5 command was sent.
 - 1: This is the first time the \$AA5 command has been sent since the module was powered on.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$015

Response: !011

Reads the reset status for module 01 and returns a response indicating that the command was valid, and that it is the first time the \$AA5 command has been sent since the module was powered on.

Command: \$015

Response: !010

Reads the reset status for module 01 and returns a response indicating that the command was valid, and that there has been no module reset since the last \$AA5 command was sent.

Related Commands:

None

5.9. \$AAF

Description:

This command is used to read the current firmware version of a specified module.

Syntax:

\$AAF[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- F** The command to read the current firmware version

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- (Data)** A string indicating the current firmware version of the module

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01F

Response: !01A1.0

Reads the current firmware version of module 01, and returns a response

indicating that the command was valid, and that the firmware is version A1.0.

Related Commands:

None

5.10. \$AALC2CONNNN

Description:

This command is used to set the PIR output delay time on a specified module after power on.

Syntax:

\$AALC3CONNNN[CHKSUM](CR)

\$ Delimiter character

AA The address of the module to be configured in hexadecimal format (00 to FF)

LC2 The command to set the PIR output delay time after power on

C The command to set the PIR output channel

0 Specifies the PIR output channel to be set, zero based.

Note that as there is only one PIR sensor channel on the PIR-234(L) module, the only valid value is 0.

NNNN A four-digit hexadecimal value representing the PIR output delay time in milliseconds. The maximum delay time is 0x0BB8 (3000 milliseconds).

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01LC2C003E8

Response: !01

Sets the PIR output delay time of module 01 to 0x03E8 (1000 milliseconds) after power on and the module returns a response indicating that the command was valid. The PIR output will be active for 1000 milliseconds after powered on.

Command: \$01LC3

Response: !010BB8

Reads the PIR output delay time of module 01 after power on and returns a response indicating that the command was valid, with a value of 0BB8 meaning that the PIR output delay time is 3000 milliseconds. The PIR output will be active for 3000 milliseconds after power on.

Command: \$01LC2C00BB9

Response: ?01

Attempts to set the PIR output delay time of module 01 to 0x0BB9 (3001 milliseconds) after power on, but the module returns a response indicating that the command was invalid because the value for the PIR output delay time was not within the valid range.

Related Commands:

Section 5.11 \$AALC3

5.11. \$AALC3

Description:

This command is used to read the PIR output delay time on a specified module after power on.

Syntax:

\$AALC3CONNNN[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- LC3** The command to read the PIR output delay time after power on

Response:

Valid Command: **!AANNNN[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- NNNN** A four-digit hexadecimal value representing the PIR output delay time in milliseconds after power on. The maximum delay time is 0x0BB8 (3000 milliseconds).

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01LC2C003E8

Response: !01

Sets the PIR output delay time of module 01 to 0x03E8 (1000 milliseconds) after power on and the module returns a response indicating that the command was valid. The PIR output will be active for 1000 milliseconds after powered on.

Command: \$01LC3

Response: !0103E8

Reads the PIR output delay time of module 01 after power on and returns a response indicating that the command was valid, with a value of 0BB8 meaning that the PIR output delay time is 1000 milliseconds. The PIR output will be active for 1000 milliseconds after power on.

Related Commands:

Section 5.10 \$AALC2CONNNN

5.14. \$AALC7CONN

Description:

This command is used to set the PIR output ON time on a specific module when PIR sensor is triggered.

Syntax:

\$AALC70NN[CHKSUM](CR)

\$ Delimiter character

AA The address of the module to be configured in hexadecimal format (00 to FF)

LC7 The command to set the PIR output ON time when the PIR sensor is triggered

C The command to set the PIR output channel

0 Specifies the PIR output channel to be set, zero based.

Note that as there is only one PIR sensor channel on the PIR-234(L) module, the only valid value is 0.

NN The command to set the PIR output ON time for when the PIR sensor is triggered in hexadecimal format. This value will be stored inside, and the valid range is 00 to 0F.

NN	Seconds	NN	Seconds	NN	Seconds	NN	Seconds
00	2	01	4	02	6	03	8
04	16	05	33	06	49	07	66
08	131	09	262	0A	393	0B	524
0C	1049	0D	2097	0E	3146	0F	4194

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01LC7C000

Response: !01

Sets the PIR output ON time value for channel 0 of module 01 to 00, meaning that the output ON time will be 2 seconds, and the module returns a response indicating that the command was valid.

Command: \$01LC8C0

Response: !0100

Reads the PIR output ON time value for channel 0 of module 01, and the module returns a response indicating that the command was valid, with a value of 00 meaning that the output ON time will be 2 seconds.

Command: \$01LC7C100

Response: ?01

Attempts to set the PIR output ON time value for channel 1 of module 01 to 00, but the module returns a response indicating that the command was invalid because channel 1 does not exist on the PIR-234(L) module.

Related Commands:

Section 5.15 \$AALC8C0

5.15. \$AALC8C0

Description:

This command is used to read the current PIR output ON time when the PIR sensor is triggered on a specific module.

Syntax:

\$AALC1[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- LC8** The command to read the PIR output ON time when the PIR sensor is triggered
- C** The command to read the PIR output channel
- 0** Specifies the PIR output channel to be read, zero based. Note that as there is only one PIR sensor channel on the PIR-234(L) module, the only valid value is 0.

Response:

Valid Command: **!AANN[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- NN** The PIR output ON time value when the PIR sensor is triggered in hexadecimal format. This value will be stored inside, and the valid range is 00 to 0F.

NN	Seconds	NN	Seconds	NN	Seconds	NN	Seconds
00	2	01	4	02	6	03	8
04	16	05	33	06	49	07	66
08	131	09	262	0A	393	0B	524
0C	1049	0D	2097	0E	3146	0F	4194

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01LC7C000

Response: !01

Sets the PIR output ON time value for channel 0 of module 01 to 00, meaning that the output ON time will be 2 seconds, and the module returns a response indicating that the command was valid.

Command: \$01LC8C0

Response: !0100

Reads the PIR output ON time value for channel 0 of module 01, and the module returns a response indicating that the command was valid, with a value of 00 meaning that the output ON time will be 2 seconds.

Command: \$01LC7C100

Response: ?01

Attempts to set the PIR output ON time value for channel 1 of module 01 to 00, but the module returns a response indicating that the command was invalid because channel 1 does not exist on the PIR-234(L) module.

Related Commands:

Section 5.14 \$AALC7C0NN

5.16. \$AALC9C0NN

Description:

This command is used to set the PIR output configuration for a specific channel on a specified module.

Syntax:

\$AALC9C0N[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- LC9** The command to set the output configuration
- C** The command to set the PIR output channel
- 0** Specifies the PIR output channel to be set, zero based. Note that as there is only one PIR sensor channel on the PIR-234(L) module, the only valid value is 0.
- NN** The command to set the PIR output configuration, where:
 - Bit 0: Enable/Disable the Buzzer be activated
 - Bit 1: Enable/Disable the relay output be activatedThis value will be stored inside.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01LC9C003

Response: !01

Sets the PIR output configuration of module 01 and the module returns a response indicating that the command was valid and the relay output and buzzer will be active when the PIR sensor is triggered.

Command: \$01LCAC0

Response: !0103

Reads the PIR output configuration of module 01 and the module returns a response indicating that the command was valid and the relay output and buzzer will be active when the PIR sensor is triggered.

Command: \$01LC9C103

Response: ?01

Attempts to read the PIR output configuration for channel 1 of module 01, but the module returns a response indicating that the command was invalid because channel 1 does not exist on the PIR-234(L) module.

Related Commands:

Section 5.17 \$AALCAC0

5.17. \$AALCAC0

Description:

This command is used to read the PIR output configuration for a specific channel on a specified module.

Syntax:

\$AALC9C0N[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- LCA** The command to read the PIR output configuration
- C** The command to read the PIR output channel
- 0** Specifies the PIR output channel to be read, zero based. Note that as there is only one PIR sensor channel on the PIR-234(L) module, the only valid value is 0.

Response:

Valid Command: **!AANN[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- NN** The command to set the output configuration, where:
 - Bit 0: Enable/Disable the Buzzer be activated
 - Bit 1: Enable/Disable the relay output be activatedThis value will be stored inside.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01LC9C003

Response: !01

Sets the PIR output configuration of module 01 and the module returns a response indicating that the command was valid and the relay output and buzzer will be active when the PIR sensor is triggered.

Command: \$01LCAC0

Response: !0103

Reads the PIR output configuration of module 01 and the module returns a response indicating that the command was valid and the relay output and buzzer will be active when the PIR sensor is triggered.

Command: \$01LC9C103

Response: ?01

Attempts to read the PIR output configuration for channel 1 of module 01, but the module returns a response indicating that the command was invalid because channel 1 does not exist on the PIR-234(L) module.

Related Commands:

Section 5.16 \$AALC9C0NN

5.20. \$AAM

Description:

This command is used to read the name of a specified module.

Syntax:

\$AAM[CHKSUM](CR)

\$ Delimiter character

AA The address of the module to be configured in hexadecimal format (00 to FF)

M The command to read the name of the module

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

(Data) A string indicating the name of the module

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$02M

Response: !02PIR234E

Reads the name of module 02 and returns a response indicating that the command was valid, and that the name of the module is "PIR234E".

Related Commands:

None

5.21. \$AAP

Description:

This command is used to read the current communication protocol information configured for a specified module.

Syntax:

\$AAP[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- P** The command to read the current communication protocol information

Response:

Valid Command: **!AASC[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- S** The communication protocol(s) supported by the module:
 - 0: Only the DCON protocol is supported
 - 1: Both the DCON and Modbus RTU protocols are supported
- C** The communication protocol currently saved inside that will be used at the next power-on reset:
 - 0: The communication protocol currently saved inside is DCON
 - 1: The communication protocol currently saved inside is Modbus RTU

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01P1

Response: !01

Sets the communication protocol to be used for module 01 to Modbus RTU and the module returns a response indicating that the command was valid.

Command: \$01P

Response: !0110

Reads the current communication protocol information configured for module 01, and returns a response indicating that the command was valid, with a value of 10, which denotes that the module supports both the DCON and Modbus RTU protocols and that the DCON protocol will be used at the next power-on reset.

Related Commands:

Section 5.22. \$AAPN

Related Topics:

Section 2.5. Hardware Configuration

5.22. \$AAPN

Description:

This command is used to set the communication protocol to be used by a specified module.

Syntax:

\$AAPN[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- P** The command to set the communication protocol
- N** The communication protocol to be used:
 - 0: DCON Protocol
 - 1: Modbus RTU Protocol

Note that the INIT DIP Switch (DIP 4) must be set to the ON position before using this command. See Section 1.5 for more details. The new protocol information will be saved inside and will become effective after the next power-on reset.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01P1

Response: ?01

Attempts to set the communication protocol to be used by module 01 to Modbus RTU, but the module returns a response indicating that the command was invalid because the INIT DIP Switch (DIP 4) has not been set to the ON position. See Section 1.5 for more details.

Command: \$01P1

Response: !01

Sets the communication protocol to be used for module 01 to Modbus RTU and the module returns a response indicating that the command was valid.

Command: \$01P

Response: !0110

Reads the current communication protocol information configured for module 01 returns a response indicating that the command was valid, with a value of 10, which denotes that the module supports both the DCON and Modbus RTU protocols and that the DCON protocol will be used at the next power-on reset.

Response: ?01

Command: \$01P1

Attempts to set the current communication protocol into Modbus RTU for module 01, but the module returns a response indicating that the command was invalid because the INIT DIP Switch (DIP 4) hasn't been set to the ON position. See Section 1.5 for more details.

Related Commands:

Section 5.21. \$AAP

Related Topics:

Section 2.5. Hardware Configuration

5.23. ~AARD

Description:

This command is used to read the response delay time for a specified module.

Syntax:

~AARD[CHKSUM](CR)

~ Delimiter character

AA The address of the module to be read in hexadecimal format (00 to FF)

RD The command to read the response delay time

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

(Data) A two-digit hexadecimal value representing the response delay time. The valid range is 00 to 1E in 1ms intervals.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~03RD1E

Response: !03

Sets the response delay time for module 03 to 1E (30ms), and returns a response indicating that the command was valid.

Command: ~03RD

Response: !031E

Reads the response delay time for module 03 and returns a response indicating that the command was valid, with a value of 1E (30ms).

Related Commands:

Section 5.24 ~AARDVV

5.24. ~AARDVV

Description:

This command is used to set the response delay time for a specified module.

Syntax:

~AARDVV[CHKSUM](CR)

~ Delimiter character

AA The address of the module to be read in hexadecimal format (00 to FF)

RD The command to set the response delay time.

VV A two-digit hexadecimal value representing the response delay time in milliseconds. The valid range is 00 to 1E in 1ms intervals.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~03RD1E

Response: !03

Sets the response delay time for module 03 to 1E (30 ms), and returns a response indicating that the command was valid.

Command: ~03RD

Response: !031E

Reads the response delay time for module 03 and returns a response indicating that the command was valid, with a value of 1E (30 ms).

Command: ~03RD1F

Response: ?03

Attempts to set the response delay time for module 03 to 1F (31 ms), but the module returns a response indicating that the command was invalid because the value specified for the response delay time was not within the valid range.

Related Commands:

Section 5.23. ~AARD

5.25. @AADI

Description:

This command is used to read digital input status and the current status of the PIR relay output channel and PIR active status on a specified module.

Syntax:

@AADI[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- DI** The command to read the digital input status and the current status of the PIR relay output channel and PIR active status

Response:

Valid Command: **!AASOOII[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- S** High temperature alarm enable status
 - 0=alarm disable
 - 1=momentary alarm enabled
 - 2=latch alarm enabled.
- OO** The status of the PIR relay output channel represented by a two-digit hexadecimal value. 00: relay output is inactive; 01: relay output is active.
- II** The status represented by a two-digit hexadecimal value.
 - Bit 0: The status of the PIR trigger
 - Bit 1: The status of the digital input

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01DI

Response: !100101

Reads the status of the Relay Output channel for module 01 and returns a response indicating that the command was valid, and that both the PIR Relay Output channel and the status of the PIR are active.

Related Commands:

Section 5.26 @AADONN

5.26. @AADONN

Description:

This command is used to set the relay output to on/off on a specified module.

Syntax:

@AADI[CHKSUM](CR)

- \$** Delimiter character
- AA** The address of the module to be configured in hexadecimal format (00 to FF)
- DO** The command to set the relay output
- NN** The status of the relay output channel represented by a two-digit hexadecimal value.
 - 00: Set the relay output to off
 - 01: Set the relay output to on

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01DO01

Response: ?01

Attempts to set the relay output channel 0 to on for module 01 and returns a response indicating that the command was invalid, because the relay output is set to link to PIR sensor.

Command: @01LC9C000

Response: !01

Disable the linking of relay output and buzzer to PIR sensor of module 01, and the module returns a response indicating that the command was valid.

Command: @01DO01

Response: !01

Sets the relay output channel 0 to on for module 01, and the module returns a response indicating that the command was valid.

Command: @01DI

Response: !0100100

Reads the status of the relay output channel for module 01 and returns a response indicating that the command was valid, and that both the relay output channel and the status of the PIR are active.

Related Commands:

Section 5.16. @AALC9CONN, 4.25. @AADI

Notes:

Enable the relay output when PIR sensor is triggered. Relay output cannot use this command to set.

5.27. ~AAD

Description:

This command is used to read whether the relay output signal for a specified module is active or inactive.

Syntax:

~AAD [CHKSUM](CR)

~ Delimiter character

AA The address of the module to be read in hexadecimal format (00 to FF)

D The command to read whether the relay output signal is active or inactive

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

VV A two-digit hexadecimal value representing the status of the relay output signal. See below for details.

7	6	5	4	3	2	1	0
Reserved						OAS	Reserved

Key	Description
OAS	Specifies the status of the PIR Relay Output signal 0: An output value of 0 indicates that the relay is inactive An output value of 1 indicates that the relay is active 1: An output value of 0 indicates that the relay is active An output value of 1 indicates that the relay is inactive

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~02D02

Response: !02

Sets the relay output signal for module 02 to 02, which denotes that the relay output channel is in inactive mode, and returns a response indicating that the command was valid.

Command: ~02D

Response: !0202

Reads the status of the relay output signal for module 02 and returns a response indicating that the command was valid, with a value of 02, which denotes that the relay output channel is in inactive mode.

Related Commands:

Section 5.28. ~AADVV

5.28. ~AADVV

Description:

This command is used to set the relay output signal for a specified module to active or inactive.

Syntax:

~AADVV[CHKSUM](CR)

~ Delimiter character

AA The address of the module to be read in hexadecimal format (00 to FF)

D The command to set the relay output to active or inactive

VV A two-digit hexadecimal value representing the status of the relay output signal. See below for details.

7	6	5	4	3	2	1	0
Reserved						OAS	Reserved

Key	Description
OAS	Specifies the status of the PIR Relay Output signal 0: An output value of 0 indicates that the relay is inactive An output value of 1 indicates that the relay is active 1: An output value of 0 indicates that the relay is active An output value of 1 indicates that the relay is inactive

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~02D02

Response: !02

Sets the relay output signal for module 02 to 02, which denotes that the relay output channel is in inactive mode, and returns a response indicating that the command was valid.

Command: ~02D

Response: !0202

Reads the status of the relay output signal for module 02 and returns a response indicating that the command was valid, with a value of 02, which denotes that the relay output channel is in inactive mode.

Command: ~02D07

Response: ?02

Attempts to set the relay output signal for module 02 to 07, but returns a response indicating that the command was invalid because the output value was not within the valid range.

Related Commands:

Section 5.27. ~AAD

5.29. @AACHC0

Description:

This command is used to clear the status of a latched high alarm for a specified module.

Syntax:

@AACHC0[CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- CHC0** The command to clear the status of the latched high alarm.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @03CHC0

Response: !03

Clears the status of the latched high alarm for module 03, and returns a response indicating that the command was valid.

Related Commands:

Section 5.31. @AAEAT, Section 5.32. @AAHI(Data), Section 5.30. @AADA,
Section 5.35. @AARH, Section 5.36. @AARAO

5.30. @AADA

Description:

This command is used to disable the high alarm function for a specified module.

Syntax:

@AAHI(Data)[CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- DA** The command to disable the high alarm function

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01EAM Response: !01
Enables the high alarm function for module 01 and sets the alarm type to momentary, and returns a response indicating that the command was valid.

Command: @03DA Response: !03
Disables the high alarm function for module 03, and returns a response indicating that the command was valid.

Related Commands:

Section 5.31. @AAEAT, Section 5.32. @AAHI(Data), Section 5.29. @AACHC0,
Section 5.35. @AARH, Section 5.36. @AARAO

5.31. @AAEAT

Description:

This command is used to enable the high alarm function for a specified module and set the alarm type.

Syntax:

@AAEAT[CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- EA** The command to enable the high alarm function
- T** The Alarm Type:
 - M: Momentary Alarm
 - L: Latch Alarm

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command:@01EAM

Response:!01

Enables the high alarm function for module 01 and sets the alarm type to momentary, and returns a response indicating that the command was valid.

Command:@03DA

Response:!03

Disables the high alarm function for module 03, and returns a response indicating that the command was valid.

Related Commands:

Section 5.32. @AAHI(Data), Section 5.30. @AADA, Section 5.29. @AACHC0,
Section 5.35. @AARH, Section 5.36. @AARAO

5.32. @AAHI(Data)

Description:

This command is used to set the high alarm limits for a specified module.

Syntax:

@AAHI(Data)[CHKSUM](CR)

@ Delimiter character

AA The address of the module to be read in hexadecimal format (00 to FF)

HI The command to set the high alarm limits

(Data) A signed value representing the high alarm limits in degrees Celsius in the format xxx.xx. The valid range is +000.00 to +999.99 degrees Celsius.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01HI+086.00

Response: !01

Sets the high alarm limits for module 01 to +86.00 degrees Celsius, and returns a response indicating that the command was valid.

Command: @01RH

Response: !03+086.00

Reads the high alarm limits for module 01, and returns a response indicating that the command was valid, with a value of +086.00, which denotes that the high alarm limits is +86.0 degrees Celsius.

Command: @01HI+1000.00

Response: ?01

Attempts to set the high alarm limits for module 01 to +1000.00 degrees Celsius, but returns a response indicating that the command was invalid because the specified value was not within the valid range.

Related Commands:

Section 5.31. @AAEAT, Section 5.30. @AADA, Section 5.29. @AACHC0,
Section 5.35. @AARH, Section 5.36. @AARAO

5.33. @AAHO

Description:

This command is used to read the offset of the relative humidity for a specified module.

Syntax:

@AAHO [CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- HO** The command to read the offset of relative humidity

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- (Data)** A two-digit hexadecimal value to represent the offset of relative humidity

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01HO+001.00 Response: !01

Sets the offset +1% of relative humidity, and returns a response indicating that the command was valid.

Command: @01HO Response: !01+001.00

Reads the offset of relative humidity for module 01, and returns a response indicating that the command was valid, with a value of +001.00, which denotes that the offset value is +1%.

Related Commands:

Section 5.34. @AAHO(Data)

5.34. @AAHO(Data)

Description:

This command is used to set the offset of the relative humidity for a specified module.

Syntax:

@AAHO(Data) [CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- HO** The command to set the offset of relative humidity
- (Data)** A signed value representing the offset of relative humidity in the format xxx.xx.
The valid range is -100.00% to +100.00%.

Response:

Valid Command: **!AA [CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01HO+001.00 Response: !01

Sets the offset +1% of relative humidity, and returns a response indicating that the command was valid.

Command: @01HO Response: !01+001.00

Reads the offset of relative humidity for module 01, and returns a response indicating that the command was valid, with a value of +001.00, which denotes that the offset value is +1%.

Related Commands:

Section 5.33. @AAHO

5.35. @AARH

Description:

This command is used to read the current high alarm limits for a specified module.

Syntax:

@AARH[CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- RH** The command to read the current high alarm limits.

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- (Data)** A signed value representing the high alarm limits in degrees Celsius in the format xxx.xx. The valid range is +000.00 to +999.99.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @03HI+090.50 Response: !03
Sets the high alarm limits for module 03 to +90.5 degrees Celsius, and returns a response indicating that the command was valid.

Command: @03RH Response: !03+090.50
Reads the high alarm limits for module 03, and returns a response indicating that the command was valid, with a value of +090.50, which denotes that the high alarm limits is +90.5°C.

Related Commands:

Section 5.31. @AAEAT, Section 5.32. @AAHI(Data), Section 5.30. @AADA,
Section 5.29. @AACHC0, Section 5.36. @AARAO

5.36. @AARAO

Description:

This command is used to read the currently activated alarm for a specified module.

Syntax:

@AARAO [CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- RAO** The command to read the currently activated alarm.

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- HH** A two-digit hexadecimal value to represent the currently activated high alarms
 - 00: High alarm is not active.
 - 01: High alarm is active.
- 00** Reserved.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @03RAO Response: !030000

Reads the currently activated high alarm, and returns a response indicating that the command was valid.

Command: @03RH Response: !03+090.50

Reads the High Alarm limits for module 03, and returns a response indicating that the command was valid, with a value of +090.50, which denotes that the High Alarm limits is +90.5 degrees Celsius.

Related Commands:

Section 5.31. @AAEAT, Section 5.32. @AAHI(Data), Section 5.30. @AADA,
Section 5.29. @AACHC0

5.37. @AATO

Description:

This command is used to read the offset of the temperature for a specified module.

Syntax:

@AAHO [CHKSUM](CR)

- @** Delimiter character
- AA** The address of the module to be read in hexadecimal format (00 to FF)
- TO** The command to read the offset of temperature

Response:

Valid Command: **!AA(Data)[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid
- ?** Delimiter character to indicate that the command was invalid
- AA** The address of the responding module in hexadecimal format (00 to FF)
- (Data)** A two-digit hexadecimal value to represent the offset of Centigrade

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01TO+001.00 Response: !01
Sets the offset +1°C, and returns a response indicating that the command was valid.

Command: @01TO

Response: !01+001.00

Reads the offset of temperature for module 01, and returns a response indicating that the command was valid, with a value of +001.00, which denotes that the offset value is +1°C.

Related Commands:

Section 5.38. @AATO(Data)

5.38. @AATO(Data)

Description:

This command is used to set the offset of the temperature for a specified module.

Syntax:

@AAHO(Data) [CHKSUM](CR)

@ Delimiter character

AA The address of the module to be read in hexadecimal format (00 to FF)

TO The command to set the offset of temperature

(Data) A signed value representing the offset of Celsius in the format xxx.xx. The valid range is -100.00°C to +100.00°C.

Response:

Valid Command: **!AA [CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid

? Delimiter character to indicate that the command was invalid

AA The address of the responding module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01TO+001.00

Response: !01

Sets the offset +1°C, and returns a response indicating that the command was valid.

Command: @01TO

Response: !01+001.00

Reads the offset of temperature for module 01, and returns a response indicating that the command was valid, with a value of +001.00, which denotes that the offset value is +1°C.

Related Commands:

Section 5.37. @AATO

6. Modbus RTU Protocol

The Modbus protocol was originally developed for Modicon controllers by Modicon Inc. Detailed information related to the Modbus RTU protocol can be found at:

<http://www2.schneider-electric.com/sites/corporate/en/products-services/automation-control/automation-control.page>.

You can also visit <http://www.modbus.org> for more valuable information.

The PIR-234(L) module supports the Modbus RTU protocol, with communication Baud Rates ranging from 1200 bps to 115200 bps. The parity, data bits and stop bits are fixed as no parity, 8 data bits and 1 stop bit. The following Modbus functions are supported.

Function Code	Description	Section
0x01	Reads the Coils	3.1
0x02	Reads the Discrete Inputs	3.2
0x03	Reads Multiple Registers	3.3
0x04	Reads Multiple Input Registers	3.4
0x05	Writes a Single Coil	3.5
0x06	Writes a Single Register	3.6
0x0F	Writes Multiple Coils	3.7
0x10	Writes Multiple Registers	3.8

Error Response

If the function specified in the message is not supported, then the module responds as below.

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247

01	Function Code	1	Function Code + 0x80
02	Exception Code	1	01

Note:

1. If a CRC mismatch occurs, the module will not respond.
2. The address mapping for the Modbus protocol is 0-Based.

6.1. Modbus Address Mapping (Base 1)

General Commands

Address	Description	Attribute																				
00257	Reads/sets the Communication Protocol 0: DCON 1: Modbus RTU	R/W																				
10273	Reads the Reset Status: 0: This is NOT the first time the module has been read since being powered on 1: This is the first time the module has been read since being powered on	R																				
30485	Reads/sets the Module address. The valid range is 1 to 247.	R/W																				
30486	Reads/sets the Baud Rate and the Data Format: Bits 5:0 (Baud Rate) <table border="1"><tr><td>Code</td><td>0x03</td><td>0x04</td><td>0x05</td><td>0x06</td></tr><tr><td>Baud</td><td>1200</td><td>2400</td><td>4800</td><td>9600</td></tr><tr><td>Code</td><td>0x07</td><td>0x08</td><td>0x09</td><td>0x0A</td></tr><tr><td>Baud</td><td>19200</td><td>38400</td><td>57600</td><td>115200</td></tr></table> Baud Rate, valid range: 0x03 to 0x0A Bits 7:6 (Data Format) 00: no parity, 1 stop bit 01: no parity, 2 stop bits 10: even parity, 1 stop bit 11: odd parity, 1 stop bit	Code	0x03	0x04	0x05	0x06	Baud	1200	2400	4800	9600	Code	0x07	0x08	0x09	0x0A	Baud	19200	38400	57600	115200	R/W
Code	0x03	0x04	0x05	0x06																		
Baud	1200	2400	4800	9600																		
Code	0x07	0x08	0x09	0x0A																		
Baud	19200	38400	57600	115200																		
30488	Reads/sets the Response Delay Time in milliseconds. The valid	R/W																				

	range is 0 to 30 ms (00 to 1E in 1 ms intervals).	
40481-40482	Reads the Firmware Version	R
40483-40484	Reads the Name of the Module	R

PIR-related Commands

Address	Description	Attribute
30001 ~ 30005 40001 ~ 40005	Analog input value of channel 0 to 4. channel 0: temperature in 0.01°C, channel 1:temperature in 0.01°F, channel 2: relative humidity in 0.01%, channel 3: dew point temperature in 0.01°C, channel 4: dew point temperature in 0.01°F	R
40226	High temperature alarm limit in 0.01°C	R/W
40272	Modbus NetID Only for Modbus TCP protocol	R/W
30352 40352	Firmware version in hex format Only for Modbus TCP protocol	R
40450	Relative humidity offset in 0.01%	R/W
40451	Temperature offset in 0.01°C	R/W
40481	Firmware version (low word)	R
40482	Firmware version (high word)	R
40483	Module name (low word), 0x0234	R
40484	Module name (high word), 0x5049	R
40485	RS-485 module address, 1 to 247 Only for Modbus RTU protocol	R/W
40486	RS-485 baud rate and parity settings Bits 5:0 Baud rate, valid range: 3 ~ 10 Bits 7:6 00: no parity, 1 stop bit 01: no parity, 2 stop bit 10: even parity, 1 stop bit 11: odd parity , 1 stop bit Only for Modbus RTU protocol	R/W
40488	RS-485 response delay time in ms, valid range, 0 ~ 30 Only for Modbus RTU protocol	R/W

Address	Description	Attribute																																								
40489	RS-485 host watchdog timeout value, 0 ~ 255, in 0.1s Only for Modbus RTU protocol	R/W																																								
40490	Enable PIR sensors, bit 0 for PIR sensor 1, bit 1 for PIR sensor 2, etc.	R/W																																								
40492	RS-485 host watchdog timeout count, write 0 to clear Only for Modbus RTU protocol	R/W																																								
40513	PIR output on time, 0x00 to 0x0F	R/W																																								
	<table><tr><th>Hex</th><th>Secs</th><th>Hex</th><th>Secs</th><th>Hex</th><th>Secs</th><th>Hex</th><th>Secs</th></tr><tr><td>00</td><td>2</td><td>01</td><td>4</td><td>02</td><td>6</td><td>03</td><td>8</td></tr><tr><td>04</td><td>16</td><td>05</td><td>33</td><td>06</td><td>49</td><td>07</td><td>66</td></tr><tr><td>08</td><td>131</td><td>09</td><td>262</td><td>0A</td><td>393</td><td>0B</td><td>524</td></tr><tr><td>0C</td><td>1049</td><td>0D</td><td>2097</td><td>0E</td><td>3146</td><td>0F</td><td>4194</td></tr></table>		Hex	Secs	Hex	Secs	Hex	Secs	Hex	Secs	00	2	01	4	02	6	03	8	04	16	05	33	06	49	07	66	08	131	09	262	0A	393	0B	524	0C	1049	0D	2097	0E	3146	0F	4194
	Hex		Secs	Hex	Secs	Hex	Secs	Hex	Secs																																	
	00		2	01	4	02	6	03	8																																	
	04		16	05	33	06	49	07	66																																	
	08		131	09	262	0A	393	0B	524																																	
0C	1049	0D	2097	0E	3146	0F	4194																																			
40516	Active delay time for PIR output after power on in milliseconds, 0 to 3000	R/W																																								
40518	PIR sensor off time on power on in seconds, 0 to 30	R/W																																								
40521 ~ 40522	Trigger source of digital output channel 0 to 1, 0 for command, 1 for PIR, and 2 for temperature alarm.	R/W																																								
30545 ~ 30549 40545 ~ 40549	Low latched analog input value of channel 0 to 4	R																																								
30556 40556	Module reset status, 1: power-on, 2: watchdog, 3: software reset command Only for Modbus TCP protocol	R																																								
40558	Ethernet host watchdog timeout value, 5 to 65535, in second, 0 to disable. Only for Modbus TCP protocol	R/W																																								
30559 40559	Ethernet host watchdog timeout count. Only for Modbus TCP protocol	R																																								
30560 40560	Module name, 0x0234 Only for Modbus TCP protocol	R																																								

Address	Description	Attribute
40564	TCP disconnection timeout value, 5 to 65535, in second, 0 to disable. Only for Modbus TCP protocol	R/W
40565	Module reset timeout value, 30 to 65535, in second, 0 to disable. Only for Modbus TCP protocol	R/W
30577 ~ 30581 40577 ~ 40581	High latched analog input value of channel 0 to 4	R
00001 ~ 00002	Digital output value of channel 0 to 1	R/W
00033	PIR status	R
00034	PIR sensor 1 status	R
00035	PIR sensor 2 status	R
00036	PIR sensor 3 status	R
00037	PIR sensor 4 status	R
00129 ~ 00130	Safe value of digital output channel 0 to 1	R/W
00161 ~ 00162	Power on value of digital output channel 0 to 1	R/W
00227	Write 1 to reload default TCP settings and reboot module Only for Modbus TCP protocol	W
00234	Write 1 to reboot module Only for Modbus TCP protocol	W
00257	RS-485 Protocol, 0: DCON, 1: Modbus RTU Only for Modbus RTU protocol	R/W
00261	RS-485 host watchdog mode, 1: enable, 0: disable. Only for Modbus RTU protocol	R/W
00262	Enable/disable high temperature alarm	R/W
00263	High temperature alarm type, 0 for momentary and 1 for latched	R/W

Address	Description	Attribute
00270	Host watch dog timeout status, write 1 to clear host watch dog timeout status Only for Modbus RTU protocol	R/W
00273	Reset status, 1: first read after powered on, 0: not the first read after powered on Only for Modbus RTU protocol	R
00274	The status of buzzer	R/W
00278	Enable/disable buzzer output when PIR sensor is triggered	R/W
00280	Write 1 to clear all high latched analog input values	W
00281	Write 1 to clear all low latched analog input values	W
00305	High temperature alarm status, write 1 to clear latched alarm status	R/W
00385 ~ 00389	Write 1 to clear high latched analog input value of channel 0 to 4	W
00417 ~ 00421	Write 1 to clear low latched analog input value of channel 0 to 4	W

Modbus RTU Function Description:

(0xxxx): 0x05, 0x0F Function Code

(1xxxx): 0x01 Function Code

(3xxxx): 0x06, 0x10 Function Code

(4xxxx): 0x03 Function Code

Wi-Fi Related Modbus Address Mappings (Base 1) (for PIR-234-WF / PIR-234L-WF only)

Address	Description	Attribute
40642	This parameter is used to specify the Wi-Fi mode of the PIR-234-WF/PIR-234L-WF device. It can be 0 for station mode or 2 for AP mode. For AP mode, only one device can be connected.	R/W
40643	This parameter is used to specify which security protocol is used to secure wireless computer network. It can be 0 for open, 1 for WEP, or 2 for WPA/WPA2. It is recommended to use WPA/WPA2 if possible.	R/W
40644 ~ 40650	WEP password Byte 0: password length Byte 1 ~ 13: password	R/W
40651 ~ 40682	WPA/WPA2 password Byte 0: password length Byte 1 ~ 63: password	R/W
40683	This parameter is used to specify whether to turn on the DHCP server function. It can be 0 for turning off and 1 for turning on. It is only available to the AP mode.	R/W
40684 ~ 40685	This parameter is used to specify the start IP address of the allocated IP by the DHCP server when the DHCP server function is turned on. It is only available to the AP mode.	R/W
40687	IP address type in station mode, 0 for static type, 1 for DHCP This parameter is only available to the station mode and it can be 0 for Static IP or 1 for DHCP. If DHCP is supported by the AP you would like to connect, then DHCP should be selected. Otherwise, select Static IP and the following three parameters IP Address, Subnet Mask and Gateway should be set, too.	R/W
40688 ~ 40689	Each SL device connected to the Wi-Fi network must have its own unique IP address. This parameter is used to assign a specific IP address.	R/W
40690 ~ 40691	This parameter is used to assign the subnet mask for the PIR-234-WF/PIR-234L-WF device. The subnet mask indicates which portion of the IP address is used to identify the local network or subnet.	R/W

Address	Description	Attribute
40692 ~ 40693	This parameter is used to assign the IP address of the gateway to be used by the SL device. A gateway (or router) is a device that is used to connect an individual network to one or more additional networks.	R/W
40694 ~ 40709	This parameter is used to specify the Service Set Identifier, SSID. For station mode, specify the SSID of the AP you would like to connect. For AP mode, the SSID will be used by the device to be connected.	R/W
40710	This parameter is used to specify which channel is used for Wi-Fi transmission. It can be 1 to 11. It is only available to the AP mode.	R/W
40711	This parameter is used to set the local port of the Wi-Fi interface to be used by the Modbus slave device. The default value is 502.	R/W
40715	Write 1 to let the new Wi-Fi settings take effect.	W
40716 ~ 40718	Wi-Fi module MAC address	R
40719	Firmware version of the Wi-Fi module	R
40720	Wi-Fi module status High byte 0: not configured 1: not connected 2: connected 3: reconnecting Low byte 0: not connected 1: high signal strength 2: medium signal strength 3: low signal strength	R

6.2. Function 01 (0x01) Read Coils

This function code is used to read the values at addresses 0xxxx and 1xxxx.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x01
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	Number of Addresses Requested	2	0x0001 to 0x0001 + *N

*N = Number of addresses requested

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x01
02	Byte Count	1	*N
03	Value from the Requested Address	*N	

*N = (Number of addresses requested / 8)

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x81
02	Exception Code	1	Refer to the Modbus standard for more details.

6.3. Function 02 (0x02) Read Discrete Input

This function code is used to read the value at address 1xxxx.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x02
02 - 03	Starting Address	2	0x0020 to 0x003F
04 - 05	Number of Addresses Requested	2	0x0001 to 0x0001 + *N

*N = Number of addresses requested

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x02
02	Byte Count	1	*N
03	Value from the Requested Address	*N	

*N = (Number of addresses requested / 8)

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x82
02	Exception Code	1	Refer to the Modbus standard for more details.

6.4. Function 03 (0x03) Read Multiple Registers

This function code is used to read the values at addresses 3xxxx and 4xxxx.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x03
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	Number of Addresses Requested	2	0x0001 to 0x0001 + *N

*N = Number of addresses requested

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x03
02	Byte Count	1	*N x 2
03 -	Value from the Requested Address	*N x 2	.

*N = Number of addresses requested

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x83
02	Exception Code	1	Refer to the Modbus standard for more details.

6.5. Function 04 (0x04) Read Multiple Input Registers

This function code is used to read the values at address 4xxxx.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x04
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	Number of Addresses Requested	2	0x0001 to 0x0001 + *N

*N = Number of addresses requested

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x04
02	Byte Count	1	*N x 2
03 -	Value from the Requested Address	*N x 2	

*N = Number of addressee requested

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x84
02	Exception Code	1	Refer to the Modbus standard for more details.

6.6. Function 05 (0x05) Write Single Coil

This function code is used to write a value to address 0xxxx.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x05
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	Value to be written	2	A value of 0xFF00 will set the output to ON. A value of 0x0000 will set it to OFF. All other values are invalid and will not affect the coil.

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x05
02 - 03	Requested Address	2	The value is the same as bytes 02 and 03 of the Request
04 - 05	Value from the Requested Address	2	The value is the same as bytes 04 and 05 of the Request

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x85
02	Exception Code	1	Refer to the Modbus standard for more details.

6.7. Function 06 (0x06) Write Single Register

This function code is used to write a value to address 3xxxx.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x06
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	The value to be written	2	

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x06
02 - 03	Requested Address	2	The value is the same as bytes 02 and 03 of the Request
04 - 05	Value from the Requested Address	2	The value is the same as bytes 04 and 05 of the Request

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x86
02	Exception Code	1	Refer to the Modbus standard for more details.

6.8. Function 15 (0x0F) Write Multiple Coils

This function code is used to write multiple values.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x0F
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	Number of Addresses Requested	2	0x0001 to 0x0001 + *N
06	Byte Count	1	*N/8
07	The values to be written	1	A bit corresponds to a channel. If the bit is 1, it denotes that the channel that was set is ON. If the bit is 0, it denotes that the channel that was set is OFF.

*N = Number of addresses requested

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x0F
02 - 03	Starting Address	2	The value is the same as bytes 02 and 03 of the Request
04 - 05	Value from the Requested Address	2	The value is the same as bytes 04 and 05 of the Request

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x8F
02	Exception Code	1	Refer to the Modbus standard for more details.

6.9. Function 16 (0x10) Write Multiple Registers

This function code is used to write multiple values.

Request

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x10
02 - 03	Starting Address	2	Refer to the Modbus Address Mapping Table for details.
04 - 05	Number of Addresses Requested	2	0x0001 to 0x0001 + *N
06	Byte Count	1	*N x 2
07	The values to be written	*N x 2	

*N = Number of addresses requested

Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x10
02 - 03	Starting Address	2	The value is the same as bytes 02 and 03 of the Request
04 - 05	Number of Addresses Requested	2	The value is the same as bytes 04 and 05 of the Request

Error Response

Byte	Description	Length (in Bytes)	Value
00	Address	1	1 to 247
01	Function Code	1	0x90
02	Exception Code	1	Refer to the Modbus standard for more details.

Appendix: FAQ

A. How to update the firmware via Ethernet

If the module is not functioning correctly (e.g. there is no response to a search request, or if the system LED is continuously displayed as either OFF or ON), download a new image of the firmware from the ICPDAS web site and then update the firmware.

The firmware of the PIR-234(L) Series module is located at:


<http://ftp.icpdas.com/pub/cd/iiot/PIR-200/firmware/>

To update the firmware for your PIR-234(L) Series module, connect the module and PC in the same sub-network. Please note that there should be only one network card in the PC.


Download and install the eSearch utility.

<http://ftp.icpdas.com/pub/cd/iiot/utility/esearch/>


Run the eSearch utility. Click on the **Search Server** button and it should find the PIR-234(L) Series module.




Right click on the **PIR-234(L) Series** module name then select **Firmware Update**.




Select the firmware file and click on the **Open** button.




Make sure the IP address and MAC address are correct. Click on the **OK** button.



A command prompt window will be displayed to show the progress.



Log in the PIR-234(L) Series web page. Click on the **Network** tab then click on the **Update** button.



The screenshot displays the web interface for the PIR-230-E device. At the top left is the ICP DAS logo. The title "PIR-230-E" is centered. Below it is a navigation bar with links: Home, Network (highlighted with a red box), PIR Settings, Filter, Monitor, Change Password, and Logout. Below the navigation bar is a form with a "Firmware Name" field and an "Update Settings" button. The "Restore Factory Defaults" section contains a red warning message and a "Restore Defaults" button. The "Forced Reboot" section contains a "Reboot" button. The "Firmware Update" section contains a red warning message, a list of four steps, and an "Update" button (highlighted with a red box). The footer contains the copyright notice: "Copyright © 2015 ICP DAS Co., Ltd. All rights reserved."

ICP DAS

PIR-230-E

Home **Network** PIR Settings | Filter | Monitor | Change Password | Logout

Firmware Name: [Field] (Max: 10 chars)

Update Settings

Restore Factory Defaults

Restore all options to their factory default states:

Restore Defaults

Forced Reboot

Reboot

Firmware Update

If the remote firmware update is failed, then the traditional firmware update (on-site) is required to make the module working again.

Step 1: Refer to firmware update manual first.
Step 2: Run eSearch Utility to prepare and wait for update.
Step 3: Click the [Update] button to **reboot** the module and start update.
Step 4: Configure the module again.


Update

Copyright © 2015 ICP DAS Co., Ltd. All rights reserved.

When it shows “% Complete: 100%”, the update is finished. You can close the command prompt window.

```
C:\Windows\system32\cmd.exe
Waiting request from MAC 00-0d-e0-ff-ff-fd <IP:10.0.11.13>
Starting BOOTP/TFTP Server ...
BOOTPREQ from MAC: 00-0D-E0-FF-FF-FD
% Complete: 100%
Press any key to continue . . .
```

If the original firmware version is B1.0 and later, then you can re-log in the PIR-234(L) Series web page and check the firmware version.



PIR-230-E Motion, Temperature, and Humidity Sensor Module

[Home](#) | [Network](#) | [PIR Settings](#) | [MQTT](#) | [Filter](#) | [Monitor](#) | [Change Password](#) | [Logout](#)


Status & Configuration

Model Name:	PIR-230-E	Alias Name:	EtherIO
Firmware Version:	B2.4 [Jan.15, 2019]	MAC Address:	00-0D-E0-60-00-08
IP Address:	10.0.11.11	TCP Port Timeout: (Socket Watchdog, Seconds):	180
Initial Switch:	OFF	System Timeout: (Network Watchdog, Seconds)	0

For module with older firmware version, please proceed as follows.

Power off the PIR-234(L) Series module. Turn the INIT switch to ON position, then power on the PIR-234(L) Series module.

Run the eSearch utility to configure the network settings as shown in Section 3.2 Network Configuration.



Log in the PIR-234(L) Series web page. Click on the **Network** tab then click on the **Restore Defaults** button.

PIR-230-E Motion, Temperature, and Humidity Sensor Module

[Home](#)
[Network](#)
[PIR Settings](#)
[Filter](#)
[Monitor](#)
[Change Password](#)
[Logout](#)

Web Auto-logout	20 (1 ~ 65535 minutes, Default= 10, Disable= 0)
Alias Name	EtherIOtest (Max. 30 chars, part of the MQTT topic name)
<button>Update Settings</button>	

Restore Factory Defaults

Restore all options to their factory default states:	<button>Restore Defaults</button>
Forced Reboot	<button>Reboot</button>

Firmware Update

If the remote firmware update is failed, then the traditional firmware update (on-site) is required to make the module working again.

Step 1: Refer to firmware update manual first.
 Step 2: Run eSearch Utility to prepare and wait for update.
 Step 3: Click the **[Update]** button to **reboot** the module and start update.
 Step 4: Configure the module again.

Update

Copyright © 2016 ICP DAS Co., Ltd. All rights reserved.

Turn the INIT switch to OFF position. Run the eSearch utility to configure the network settings as shown in Section 3.2 Network Configuration. Log in the PIR-234(L) Series web page to configure other settings