

GW-7472-UL / GW-7473-UL SERIES

EtherNet/IP to Modbus RTU/TCP Gateway

User Manual



Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, starting from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for damages resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information published by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, not for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2025 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Table of Contents

Packing List.....	6
1. Introduction	8
2 Hardware Information.....	13
2.1 Specifications.....	13
2.2 Features	14
2.3 Front View.....	17
2.4 Dimensions.....	19
2.5 Pin Assignment.....	21
2.6 Wiring Note	22
2.6.1 RS-422 Wire Connections.....	22
2.6.2 RS-485 Wire Connections.....	22
3. Setup and Test the GW-7472-UL SERIES module.....	23
3.1 Install the GW-7472-UL SERIES Utility	23
3.2 Setting up the GW-7472-UL SERIES module.....	26
3.3 Setting up the GW-7473-UL SERIES module.....	29
4. GW-7472-UL SERIES Utility Functionalities	31
4.1 Network Scan.....	31
4.2 Module Configuration.....	32
4.2.1 Network Settings	34
4.2.2 Modbus RTU Serial Port Settings	36
4.2.3 Modbus TCP Server IP Setting.....	37
4.2.4 Setting File Management.....	38
4.2.5 Byte Order Setting	38
4.2.6 Modbus Request Settings	39
4.2.7 Electronic Data Sheet	41
4.3 Module Diagnostic.....	42
4.3.1 UCMM/Forward Open Class 3 Behavior.....	43
4.3.2 Forward Open Class 1 Behavior	44
4.3.3 Modbus TCP Server Status	45
4.4 Firmware Update	46
5. -7472 Utility Functionalities	48
5.1 Communication interface.....	48

5.2	Communication interface.....	48
5.2.1	Modbus TCP Server Status	48
5.2.2	EtherNet/IP Adapter	49
5.2.3	Modbus Command	51
5.3	GW-7473-UL SERIES Address Mapping.....	51
5.4	Vendor Defined Function Code	52
5.4.1	Function Code 100(0x64): Write IP Address	52
5.4.2	Function Code 102(0x65): Read IP Address	53
5.4.3	Function Code 103(0x66): Write Adapter Information.....	54
5.4.4	Function Code 104(0x67): Read Adapter information.....	56
5.5	Firmware Update	57
6.	R/W Modbus devices from EtherNet/IP.....	59
6.1	Object Model	59
6.2	Explicit Message.....	61
6.3	Implicit Message.....	61
6.4	UCMM.....	61
6.5	Assembly Object	61
7.	Supported Modbus Communication.....	64
	Appendix A: EtherNet/IP Object Model.....	65
1.	Device Object Model.....	65
2.	Identity Object (01 _{hex}).....	66
3.	Message Router Object (02 _{hex})	67
4.	Assembly Object (04 _{hex})	68
5.	Connection Manager Object (06 _{hex})	71
6.	TCP/IP Interface Object (F5 _{hex})	72
7.	Ethernet Link Object (F6 _{hex})	74
8.	CIP General Status Code	75
9.	Connection Manager Service Request Error Codes	76
	Appendix B: Glossary	78
1.	ARP (Address Resolution Protocol)	78
2.	Clients and Servers.....	78
3.	Ethernet.....	79
4.	Firmware.....	79
5.	Gateway.....	79
6.	ICMP (Internet Control Messages Protocol).....	79
7.	Internet	79

8. IP (Internet Protocol) address.....	79
9. MAC (Media Access Control) address.....	80
10. Packet.....	80
11. Ping.....	80
12. RARP (Reverse Address Resolution Protocol).....	80
13. Socket.....	80
14. Subnet Mask	81
15. TCP (Transmission Control Protocol)	81
16. TCP/IP.....	81
17. UDP (User Datagram Protocol)	81
Appendix C: FAQ.....	82

Patch Note

Patch Version	Note	Date
V1.0	1、GW-7472-UL / GW-7473-UL Series Manual	2025/12/10

Packing List

The shipping package includes the following items:

- One GW-7472-UL /GW-7473-UL SERIES module
- CA-002-UL



GW-7472-UL
SERIES
or
GW-7473-UL
SERIES



CA-002-UL

Note!!

If any of these items is missed or damaged, contact the local distributor for more information. Save the shipping materials and cartons in case you want to ship in the future.



Safety Instructions Consigns

To prevent possible electrical shock, fire, or personal injury and for safe operation of the Product:



1. Power Supply

- Use only with the voltage and frequency specified on the product label.



2. Important Notes on Operating Environment

- Disconnect the power and network cables during thunderstorms to prevent damage.
- Do not use the Product around explosive gas, vapor, or in damp or wet environments.



3. Ventilation and Cooling

- Do not block ventilation openings; ensure adequate space around the device for heat dissipation.



4. Avoid Liquid Contact

- This product is not waterproof; keep it away from liquids and humid environments.



5. Maintenance and Service

- Do not attempt to disassemble or repair the device.
- Do not use the Product if it is damaged or operates incorrectly. Contact service centers.



6. Warranty Limitation

- Damages resulting from failure to follow safety instructions are not covered under warranty.
- This product is covered by a limited warranty according to the ICP DAS official warranty policy.

Contact Information

 Website: <https://www.icpdas.com/>

 Email: service@icpdas.com

 Phone: +886-(03)-597 3366

 Address: No. 111, Guangfu N. Rd., Hukou Township, Hsinchu County 30351, Taiwan, R.O.C.

1. Introduction

■ GW-7472-UL SERIES


The GW-7472-UL SERIES (EtherNet/IP adapter to Modbus RTU and Modbus TCP Master Gateway) is helpful for data-exchanging between the Modbus RTU along with Modbus TCP network and the EtherNet/IP network. The words “**Modbus**” described later are referring to Modbus RTU and Modbus TCP both, the words “**Modbus slave**” are also referring to Modbus RTU slave and Modbus TCP server both if there is not extra explanation. It reads the register data from the Modbus RTU/TCP slaves (server) and publishes these data to the input register data of the EtherNet/IP scanner. The output data transmitted by the EtherNet/IP scanner are updated to the register data of Modbus slaves via the GW-7472-UL SERIES. Through the GW-7472-UL SERIES, all of the Modbus slaves can be regard as one EtherNet/IP adapter. The GW-7472-UL SERIES allows maximum 6 connections for the Explicit Messages and 1 connection for the Implicit Messages at the same time. It means that 7 EtherNet/IP scanners can connect to one GW-7472-UL SERIES at the same time. Otherwise, the GW-7472-UL SERIES also allows maximum 10 Modbus TCP servers to communicate with it.

The Modbus master functions of the GW-7472-UL SERIES can scan up to 30 Modbus RTU commands and 80 Modbus TCP commands (8 for each Modbus TCP slave). After configuring the Modbus master behavior of the GW-7472-UL SERIES and the mapping status between the Modbus registers and EtherNet/IP registers by using the GW-7472-UL SERIES Utility tool, the input/output registers of the Modbus slaves are mapping to the output/input registers of the EtherNet/IP adapter. While booting up, the GW-7472-UL SERIES scans the pre-defined register addresses in all of the Modbus slaves according to the sequence defined in the utility tool. The input and output register data of the Modbus devices are updated as soon as the GW-7472-UL SERIES could.


In order to save the installation space, the GW-7472-UL SERIES is offered in an amazing tiny form-factor that makes it easy to install in anywhere, even directly attached to a serial device or embedded into a machine. The GW-7472-UL SERIES features a powerful 32-bit MCU to handle efficient network traffic and it provides the IEEE 802.3af-compliant (classification, Class 1) Power over Ethernet (PoE) with a standard category 5 Ethernet cable. Through the NS-205PSE, Poe switch, the GW-7472-UL SERIES can be powered via the Ethernet cable. When there is no PoE switch on site, the GW-7472-UL SERIES provide another way to be powered from DC adapters. These two power interfaces are redundant. If one fails, another will

take it over to supply the proper power to the GW-7472-UL SERIES.

The following figure briefs the concept of the data exchange between the EtherNet/IP and the Modbus network. In this system, there are two Modbus RTU slaves along with two Modbus TCP servers connected to the Modbus master(client) provided by the GW-7472-UL SERIES. The EtherNet/IP adapter interface of the GW-7472-UL SERIES is connected to an EtherNet/IP scanner through an Ethernet switch. Register data of the three Modbus slaves is presented to the EtherNet/IP scanner as the I/O data.



The following figure illustrates how to deploy the register data of the Modbus devices in the previous example to the EtherNet/IP scanner. Assume that there are 3, 2, 2, and 4 input registers data in the Modbus slaves No.1, No.2, No.3 and No.4 respectively. The data format of the register in the Modbus slave No.1, and No.3 is WORD, and that in the Modbus slave No.2, and No.4 is BYTE. All of these input registers are mapping to the corresponding input registers of the EtherNet/IP adapter of the GW-7472-UL SERIES sequentially by using the BYTE format.



The output register data of the Modbus slaves are mapping in exactly the same way. The Modbus slave output registers are mapping as the output registers of the EtherNet/IP adapter of the GW-7472-UL SERIES. Users can set the maximum 500 bytes for input data and 500 bytes for output data which are mapping to the EtherNet/IP adapter of the GW-7472-UL SERIES. All of these configurations are defined by using the GW-7472-UL SERIES Utility tool. While the GW-7472-UL SERIES gets the EtherNet/IP commands from the EtherNet/IP scanner, it collects the input register data from Modbus slaves and updates the output register data to the Modbus slaves as soon as possible.


We have confirmed that GW-7472-UL SERIES can operate normally with Allen-Bradley “ControlLogix Logix 5563” through “1756-ENBT ControlLogix EtherNet/IP Module” setup by “RSLogix 5000 software”.

■ GW-7473-UL SERIES

The GW-7473-UL SERIES (Modbus TCP/RTU Slave to EtherNet/IP Scanner Gateway) is helpful for data-exchanging between Modbus Master and EtherNet/IP adapter. It reads the register data from the EtherNet/IP adapter and publishes these data to the input register data of the Modbus TCP client as well as Modbus RTU Master. The output data transmitted by the Modbus TCP/RTU Master are updated to the register data of EtherNet/IP adapter.

We provide 200 bytes data buffer for I/O data. GW-7473-UL SERIES can save all the I/O data which is received or sent by EtherNet/IP in their own buffer. For example, GW-7473-UL SERIES receives one or more EtherNet/IP adapter packets. The GW-7473-UL SERIES can import input status(DI, AI, ..., etc) from EtherNet/IP adapter packets, and save them into input buffer(DI buffer, AI buffer, ..., etc). We provide 200 bytes for every input or output buffer.

In order to save the installation space, the GW-7473-UL SERIES is also offered in an amazing tiny form-factor that makes it easy to install in anywhere, even directly attached to a serial device or embedded into a machine. The GW-7473-UL SERIES features a powerful 32-bit MCU to handle efficient network traffic and it provides the IEEE 802.3af-compliant (classification, Class 1) Power over Ethernet (PoE) with a standard category 5 Ethernet cable. Through the NS-205PSE, Poe switch, the GW-7473-UL SERIES can be powered via the Ethernet cable. When there is no PoE switch on site, the GW-7473-UL SERIES provide another way to be powered from DC adapters. These two power interfaces are redundant. If one fails, another will take it over to supply the proper power to the GW-7473-UL SERIES.



2. Hardware Information

2.1 Specifications

Model		GW-7472-UL/GW-7473-UL SERIES
System		
CPU		32-bit MCU
Communication Interface		
Ethernet		10/100 Base-TX, 8-pin RJ-45 x 1, (Auto-negotiating, Auto-MDI/MDIX, LED indicator) PoE (IEEE 802.3af, Class 1)
COM1		2-wire RS-485 / 4-wire RS-422
Self-Tuner		Yes, automatic RS-485 direction control
UART		16c550 or compatible
COM Port Format		
Baud Rate		1200 to 115200 bps.
Data Bit		7, 8
Parity		None, Odd, Even
Stop Bit		1, 2
General		
Power Input		PoE: IEEE 802.3af, Class 1 DC jack: +12 ~ 48 V _{DC}
Power Consumption		0.05 A @ 24 VDC
Connector		10-Pin Removable Terminal Block x 1
Mounting		DIN-Rail
Flammability		Fire Retardant Materials (UL94-V0 Level)
Operating Temperature		GW-747x-UL: -25 ~ +70 °C GW-747x-UL-UTA: -40 ~ +70 °C
Storage Temperature		-30° ~ 80°C
Humidity		10 ~ 90% RH, non-condensing

2.2 Features

GW-7472-UL SERIES

General Features:

- Powerful 32-bit MCU handles efficient network traffic
- 10/100 Base-TX Ethernet, RJ-45 x1
(Auto-negotiating, auto MDI/MDIX, LED Indicators)
- Redundant power inputs: PoE (IEEE 802.3af, Class 1) and DC jack
- Automatically RS-485 direction control
- Support ARP, TCP, UDP, ICMP, DHCP, BOOTP and TFTP protocols
- Easy firmware update via Ethernet
- Removable terminal block connector-
- Tiny form-factor and low power consumption
- RoHS compliant with Halogen-free
- Fire retardant materials (UL94-V0 Level)

EtherNet/IP Features:

- Ethernet Protocol: EtherNet/IP adapter
- Maximum number of connections for Explicit Messages: 6
- Maximum number of connections for Implicit Messages: 1
- Supported I/O connection methods:
 - Transport and trigger: Exclusive-Owner, Cyclic
 - Originator to Target Type: POINT2POINT
 - Target to Originator Type: POINT2POINT, MULTICAST
- Device Configuration Option: EDS, Utility tool
- Address Configuration: DHCP, Utility tool
- EtherNet/IP Input/Output command data size: maximum 500 bytes
- The numbers of the Modbus slave input registers mapping to the input registers of the EtherNet/IP adapter of the GW-7472-UL SERIES: maximum 500 bytes
- The numbers of the Modbus slave output registers mapping to the output registers of the EtherNet/IP adapter of the GW-7472-UL SERIES: maximum 500 bytes

Modbus Features:

- Modbus Protocol: Modbus RTU Master and Modbus TCP Client
- Maximum support 30 Modbus RTU commands
- Maximum support 10 Modbus TCP servers
- Maximum support 8 Modbus RTU commands for each one Modbus TCP server
- Supported Modbus Function Codes:
 - 01_{hex}: Read Output Status
 - 02_{hex}: Read Input Status
 - 03_{hex}: Read Multiple Data Registers
 - 04_{hex}: Read Input Registers
 - 0F_{hex}: Write Multiple Bits
 - 10_{hex}: Write Multiple Data Register
- Maximum data size of one Modbus command: 240 bytes

GW-7473-UL SERIES

General Features:

- Powerful 32-bit MCU handles efficient network traffic 10/100 Base-TX Ethernet, RJ-45 x1
- Redundant power inputs: PoE (IEEE 802.3af, Class 1) and DC jack Support ARP, TCP, UDP, ICMP, DHCP, BOOTP and TFTP protocols Easy firmware update via Ethernet
- Removable terminal block connector
- Tiny form-factor and low power consumption RoHS compliant with Halogen-free

EtherNet/IP Features:


- Supported Objects according to CIP Standard
 - Assembly Object
 - Connection Manager Object
 - Ethernet Link Object
 - Message Router Object
 - TCP/IP Interface Object
- Ethernet Protocol: EtherNet/IP Scanner
 - Class 1 (connected) I/O Server and Client
 - Maximum support 5 EtherNet/IP adapter connections
 - EtherNet/IP I/O command data size: 200 bytes

Modbus Features:

- Modbus Protocol: Modbus TCP Server/RTU Slave protocols Maximum support 5 Modbus TCP clients
- Supported Modbus Function Codes :


- 01 hex: Read Output Status
- 02 hex: Read Input Status
- 03 hex: Read Multiple Data Registers
- 04 hex: Read Input Registers
- 0F hex: Write Multiple Bits
- 10 hex: Write Multiple Data Register

2.3 Front View



1. PoE and Ethernet RJ-45 Jack:


The GW-7472-UL SERIES is equipped with a RJ-45 jack for the 10/100 Base-TX Ethernet port and features networking capability. When the Ethernet link is detected and Ethernet packet is received, the **Link/Act LED (Orange)** indicator will be turned on. When the power is supplied via PoE (Power-over-Ethernet), the **PoE LED (Green)** indicator will be turned on.



2. +12~+48 V_{DC} Jack:

The GW-747x-UL SERIES is equipped with a +12~+48 V_{DC} jack for the power supply. When there is no PoE switch on site, the GW-747x-UL SERIES accepts the power from the DC adapter. Please refer to the following web site for more details.

http://www.icpdas.com/products/Accessories/power_supply/fra05-s12-su.htm



3. S1: System LED indicator:

After power on the GW-747x-UL SERIES, the system LED indicator is as follows:

Function	System LED Action
Running Firmware	Flashing per second
Hardware checking error	Flashing per 0.3 seconds
Hardware error	blank

4. Operating Mode Selector:

Init Mode: Configuration mode

Run Mode: Firmware running mode




Generally, the switch is always in the Run position while the GW-747x-UL SERIES works. Only when updating the GW-747x-UL SERIES, the switch needs to be set to the Init position. Move the switch to the Run position and then re-power on the GW-747x-UL SERIES after the update is completed.


Mode	Firmware Running	Flash Protection	Firmware Update	Configuration
Init	No	No	Yes	Allowed
Run	Yes	Yes	No	Allowed

2.4 Dimensions

- GW-747x-UL SERIES/GW-7473-UL SERIES dimensions:



■ CA-002-UL Cable (Unit: mm)




Pin Assignment	
P	P
➤	RED OPEN
➤	BLACK OPEN

NO	Description	QTY	UNIT
1	UL2464 18AWG 2C(RED/BLACK) 0D5.0 COLOR BLACK	1	PCS
2	DC PLUG 5.5*2.1	1	PCS
3	PVC:45/P BLACK		G

2.5 Pin Assignment


1-Port 2-Wire RS-485/ 4-Wire RS-422 Module



2.6 Wiring Note


2.6.1 RS-422 Wire Connections

4-Wire RS-422 Wiring



2.6.2 RS-485 Wire Connections

2-Wire RS-485 Wiring



Note!!

For non-isolated RS-422/485 ports, you should connect all signal grounds of RS-422/485 devices together. This reduces common-mode voltage between devices.

3. Setup and Test the module

3.1 Install the Utility

Step 1: Get the Utility

The software is located at:

[GW-7472-UL SERIES]



<https://www.icpdas.com/en/download/show.php?num=1313&model=GW-7472>

[GW-7473-UL SERIES]

<https://www.icpdas.com/en/download/show.php?num=1317&model=GW-7473>

Step 2: Install .NET Framework 4 component


The Utility tool requires the Windows Installer 3.1 and the .NET Framework 4 components. These components can be obtained from the web site.




Step 3: Install Utility tool

After installing the .Net Framework components, please run the GW-7472-UL SERIES Utility setup file.


1. Click the “Next” button to continue.




2. Select the installation path of the GW-7472-UL SERIES Utility and click the “Next” button.



3. Confirm the installation. Click the "Next" button to start the installation




4. Installation complete. Click the "Close" button to exit



3.2 Setting up the GW-7472-UL SERIES module

Step 1: Connect the power and host PC


1. Make sure your PC is under the workable network configuration and environment.
2. First, disable or correctly configure the firewall of the Windows system and any anti-virus software. Or, the “**Configure**” function of the GW-7472-UL SERIES Utility may not work. (Contact your system administrator for more details about how to do this.)
3. Check Init/Run switch is on **Init** position.



4. In Init mode, the GW-7472-UL SERIES is forced to the network configuration as following table. Connect the GW-7472-UL SERIES with your computer at the same sub network or by using the same Ethernet switch. Then power the GW-7472-UL SERIES on. Afterwards, you can use the command “ping 192.168.255.1” in the Command Prompt window to test if the connection between the GW-7472-UL SERIES and your computer is OK.


Item	Settings (Init Mode)
IP	192.168.255.1
Gateway	192.168.0.1
Mask	255.255.0.0

5. Make sure the System LED indicator is flashing.



Step 2: Search and configure the GW-7472-UL SERIES

1. Double click the GW-7472-UL SERIES Utility shortcut on the desktop.
2. Click the “**Network Scan**” button to search your GW-7472-UL SERIES.
3. Select the item of the GW-7472-UL SERIES and click the “**Configure**” button to open the configuration dialog.
4. After setting all the parameter of the GW-7472-UL SERIES, click the “**Update Settings**” button to save the configuration. After click the “**Update Settings**” button, the GW-7472-UL SERIES will reboot to complete the configuration.




Please refer to the section “4.2 Module Configuration” for details

3.3 Setting up the GW-7473-UL SERIES module


Step 1: Connect the power and host PC

1. Make sure your PC has workable network settings.
2. Disable or well configure your Windows firewall and anti-virus firewall first.
3. Check Init/Run DIP switch if it is on Run position.




4. You can make Modbus RTU connections between PC and GW-7473-UL SERIES with RS-485/RS-422 converter ◦
5. Connect both the GW-7473-UL SERIES and your computer to the same sub network or the same
6. Ethernet switch, and power the GW-7473-UL SERIES on. GW-7473-UL SERIES also supports to PoE connections. Users can make a PoE





Step 2: GW-7473-UL SERIES Utility


1. Double click the GW-7473-UL SERIES Utility shortcut on the desktop.
2. Select the connection interface Modbus RTU or Modbus TCP.
3. Click “connect” to open Configuration Window.



4. GW-7472-UL SERIES Utility Functionalities


4.1 Network Scan

1. Double click the GW-7472-UL SERIES Utility shortcut on the desktop.
2. Click the “**Network Scan**” button to search your GW-7472-UL SERIES. Afterwards, you can see all of the GW-7472-UL SERIES on the same network of your PC.



4.2 Module Configuration

1. Double click the GW-7472-UL SERIES Utility shortcut on the desktop.
2. Click the “**Network Scan**” button to search your GW-7472-UL SERIES.
3. Select the item of the GW-7472-UL SERIES and click the “**Configure**” button to open the Configuration dialog.




■ Item Descriptions:

Item	Description
Network Settings	For configuration of the <u>Address Type</u> , <u>Static IP Address</u> , <u>Subnet Mask</u> and <u>Default Gateway</u> of the GW-7472-UL SERIES Please refer to section “ 4.2.1 Network Settings ”
Modbus RTU Port Settings	For configuration of the <u>Baud Rate</u> , <u>Data Sizes</u> , <u>Parity</u> , <u>Stop Bits</u> , of the RS-485/RS-422 port of the GW-7472-UL SERIES Please refer to section “ 4.2.2 Modbus RTU Serial Port Settings ”
Modbus TCP Server IP Setting	For configuration of the IP of each Modbus TCP server. Please refer to section “ 4.2.3 Modbus TCP Server IP Settings ”
Setting File Management	For the setting files management of GW-7472-UL SERIES. Please refer to section “ 4.2.4 Setting File Management ”
Byte Order Setting	For configuration of the order of two bytes in a word of AI and AO. Please refer to section “ 4.2.5 Byte Order Setting ”
Modbus Request Command Setting	Modbus commands to communicate with the Modbus slaves Please refer to section “ 4.2.6 Modbus Request Settings ”

Note!!

All settings will take effected after rebooting the system of the GW-7472-UL SERIES module

4.2.1 Network Settings



The **Address Type**, **Static IP Address**, **Subnet Mask** and **Default Gateway** items are the most important network configuration and should always match the LAN definition of your PC. Or, the connection between the GW-7472-UL SERIES and your PC may have problem. Contact your network administrator to obtain a proper network configuration for the GW-7472-UL SERIES.

■ Item Descriptions:

Item	Description
Address Type	Static IP: If you don't have a DHCP server in your network, configure the network settings manually. Please refer to the section " 4.2.1.1 Manually Configuration "
	DHCP: Dynamic Host Configuration Protocol (DHCP) is a network application protocol that automatically assigns IP address to devices by the DHCP server. If there is no DHCP server in the network, the static IP must be used. Please refer to the section " 4.2.1.2 Dynamic Configuration "
Static IP Address	Each GW-7472-UL SERIES on the network must have a unique IP address. This field is used to assign an IP address for the GW-7472-UL SERIES.
Subnet Mask	The subnet mask defines which IP addresses of the network device are in the same sub-network.
Default Gateway	A gateway (or router) is a device that is used to build a connection between two sub-networks.
MAC Address	The MAC address of the GW-7472-UL SERIES.
Update Settings	Click this button to save the new settings to the GW-7472-UL SERIES.


4.2.1.1 Manually Configuration

In manually configuration, you have to assign all the network settings by yourself. The steps are shown below:

Step1: Select the “**Static IP**”.

Step2: Enter the **network settings**.

Step3: Click the “**Update Settings**” button to finish the configuration.



The image shows a 'Network Settings' window. The 'Address Type' dropdown is set to 'Static IP', marked with a purple circle '1'. Below it, the 'Static IP Address' field is highlighted with an orange box and marked with a purple circle '2'. The 'Subnet Mask' and 'Default Gateway' fields are also visible. To the right, an 'Update Settings' button is marked with a purple circle '3' and a yellow starburst icon.


MAC Address	00-0D-E0-80-00-32			
Address Type	Static IP			
Static IP Address	192	168	1	100
Subnet Mask	255	255	0	0
Default Gateway	192	168	0	1

4.2.1.2 Dynamic Configuration

The procedure of the dynamic configuration is very easy. If you have a DHCP server, network address can be configured dynamically by the following steps:

Step1: Select the “**DHCP**”.

Step2: Click the “**Update Settings**” button to finish the configuration.



The image shows a 'Network Settings' window. The 'Address Type' dropdown is set to 'DHCP', marked with a purple circle '1'. The 'Static IP Address' field is highlighted with an orange box. To the right, an 'Update Settings' button is marked with a purple circle '2' and a yellow starburst icon.

MAC Address	00-0D-E0-80-00-32			
Address Type	DHCP			
Static IP Address	192	168	1	100
Subnet Mask	255	255	0	0
Default Gateway	192	168	0	1

4.2.2 Modbus RTU Serial Port Settings


There four parameters in the Modbus RTU serial port configuration dialog.

■ Item Descriptions:

Item	Description	Default
Baud Rate (bps)	Set bard rate of the RS-485/422 ports.	115200
Data Size (bits)	Set data size of the RS-485/422 ports.	8
Parity	Set parity of the RS-485/422 ports.	None
Stop Bits (bits)	Set stop bits of the RS-485/422 ports.	1

Step1: Enter the **port settings**.

Step2: Click the “**Update Settings**” button to finish the configuration



4.2.3 Modbus TCP Server IP Setting

There two parameters in the Modbus TCP Server IP configuration dialog.

■ Item Descriptions:

Item	Description
Server No.	Select the number of the modbus TCP server.
Server IP	Set the IP of modbus TCP server.


Step1: Select the **Server No.** to modify its IP address.

Step2: Enter the **Server IP**.

Note: The connection to Modbus TCP server will be disabled when the last two bytes of IP address are both “0”.

Step3: Click the “**Confirm**” button to input the IP setting.

Step4: Click the “**Update Settings**” button to finish the configuration.



4.2.4 Setting File Management

Item Descriptions:

Item	Description
Load File	Load the setting file to configure the parameters of GW-7472-UL SERIES.
Save File	Save the setting file of the current configuration of GW-7472-UL SERIES.

- Note: Only setting files output from GW-7472-UL SERIES Utility can be loaded to configure the GW-7472-UL SERIES.


4.2.5 Byte Order Setting

There two options of the Byte Order Setting.

Item Descriptions:

Item	Description
High Low	The high byte is shown in front of low byte.
Low High	The low byte is shown in front of high byte.

Example:



4.2.6 Modbus Request Settings

The settings for the Modbus commands are provided as the following list:

■ Item Descriptions:

Item	Description
Device Options	The device options specific the Modbus network type and the number of Modbus TCP slaves. The option can be RTU, TCP No.0, TCP No.1, TCP No.2...to TCP No.9.
Function Code	Supported Modbus Function codes are 01 _{hex} , 02 _{hex} , 03 _{hex} , 04 _{hex} , 0F _{hex} and 10 _{hex}
ID	The Modbus slave device ID specifies the address of the device on the RS-485/422 network. This ID can be 1 ~ 247.
Start Address	The start address of the input/output registers stored in the Modbus slaves. This address can be 0 ~ 65535.
Count Bits/Words	Number of register data to be accessed from the Modbus slave
Total Input	Show how many bytes have been mapped in of the EtherNet/IP input registers
Total Output	Show how many bytes have been mapped in of the EtherNet/IP output registers
EIP Input Address (Bytes)	The mapping address in the EtherNet/IP input register.
EIP Output Address (Bytes)	The mapping address in the EtherNet/IP output register.
Command Interval (milliseconds)	Interval value of the Modbus commands. If the command is replied by the Modbus slave immediately, the GW-7472-UL SERIES still waits until the time interval passes. Set range value: 10 ~ 30000 (milliseconds); Default: 200 ms

Step1: Select the **Device Options**.

Step2: Enter the **Modbus Request commands**.

Step3: Click the “**Add**”, “**Delete**” buttons to add and remove the Modbus commands.

Step4: Click the “**Update Settings**” button to finish the configuration

Modbus Request Command

Device Options: **RTU**

Function Code: **FC2 Read multi-input discrete (1xxxx) for DI**

ID (dec): **1** (1~247) Command Interval: **200** (ms)

Count (dec): **16** (1~1920 bits)

Start Address (dec): **0** (0~65535)

Add **Delete**

ENIP Info

Total Input: **4** (bytes)


Total Output: **2** (bytes)

Update Settings and Reboot


	Device	ID	Function Code	Start Address	Count	Type	EIP Input Address (byte)	EIP Out (byte)
1	RTU	1	2	0	16	DI Bits	0~1	NA
2	RTU	2	15	0	16	DO Bits	NA	0~1
3	TCP NO.0	1	2	0	16	DI Bits	2~3	NA

4.2.7 Electronic Data Sheet

The Electronic Data Sheet (EDS) is a kind of file recorded all of the necessary information which is useful while an EtherNet/IP scanner want to access an EtherNet/IP adapter. It is an important bridge between the variety EtherNet/IP adapters and the configuration tool of the EtherNet/IP scanner. Through the EDS file, the configuration tool from 3rd parity is able to easily know that which parameters can be accessed or altered. After setting the parameters of the GW-7472-UL SERIES, an EDS file ("EDS_GW-7472-UL SERIES.eds") will be created in the same folder of the Utility tool.



4.3 Module Diagnostic



Item Descriptions:

Item	Description
UCMM/Forward Open Class 3 Behavior	Send UCMM packets or use the Forward_Open service to build the CIP class 3 connection to communicate with the GW-7472-UL SERIES. Please refer to section “ 4.3.1 UCMM/Forward Open Class 3 Behavior ”
Forward Open Class1 Behavior	Use the Forward_Open service to build the CIP class 1 connection to communicate with the GW-7472-UL SERIES. Please refer to section “ 4.3.2 Forward Open Class 1 Behavior ”
Response Message	EtherNet/IP packets responded from the GW-7472-UL SERIES.
Modbus TCP Servers Status	The connection status of Modbus TCP servers. Please refer to section “ 4.3.3 Modbus TCP Servers Status ”

4.3.1 UCMM/Forward Open Class 3 Behavior

This field is applied to send UCMM (Unconnected Message Manager) packages or the Forward Open service to build the CIP class 3 connection. Both of these two methods can be used to communicate with the GW-7472-UL SERIES.

Step1: Enter the **Service Code**, **Class Code**, **Instance ID**, **Attribute ID**, **Requested Data size**, **Request Data**, and **Request packet interval** parameters.

Step2: Click the “**UCMM**” or “**Class3**” buttons to communicate with the GW-7472-UL SERIES.

Step3: Click the “**DisConnect**” button to stop to communicate with the GW-7472-UL SERIES.

1 UCMM / Forward Open Class 3 Behavior

Service Code(hex) Class Code(hex)

Instance ID(hex) Attribute ID(hex)

Request Data(hex) Data Size(dec) RPI(dec) ms

2

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14
	11	22													

4.3.2 Forward Open Class 1 Behavior

Use this field to apply the Forward Open service to build the CIP class 1 connection to communicate with the GW-7472-UL SERIES.

Step1: Enter the **Class Code**, **Instance ID**, **O->T Point**, **O->T Point**, **O->T Size**, **T->O Size**, and **RPI** parameters.

Step2: Click the “**Class1**” button to communicate with the GW-7472-UL SERIES.

Step3: Click the “**DisConnect**” button to stop to communicate with the GW-7472-UL SERIES.

[illegible]

4.3.3 Modbus TCP Server Status

Modbus TCP server status indicates the connection status of every Modbus TCP servers.



: The IP address setting of this Modbus TCP server is illegal or user doesn't use it.



: The GW-7472-UL SERIES is trying to connect this Modbus TCP server.




: The GW-7472-UL SERIES is already connected to this Modbus TCP server.

4.4 Firmware Update

The GW-7472-UL SERIES supports firmware update through the Ethernet network with the BOOTP/TFTP protocol. Generally, the firmware is not necessary to update when it works well. If there are some bugs in the firmware of your GW-7472-UL SERIES or you need new functions which don't support in your GW-7472-UL SERIES, the firmware update is necessary. If the firmware update procedure is broken unfortunately, please try it again.

Before updating the firmware, you have to set the "Init Switch" to "Init" position and then re-power on the GW-7472-UL SERIES. Since the flash becomes writable, we can update the firmware through the Ethernet network.




Mode	Firmware Running	Flash Protection	Firmware Update	Configuration
Init	No	No	Yes	Factory
Run	Yes	Yes	No	User-Defined

Note:



1. Well configure the network settings of your PC. Or the update procedures through the Ethernet network may not work correctly.
2. The program (TFTP server) may not run correctly if there is another TFTP server running on the same PC.
3. The BOOTP and TFTP protocols use the Ethernet UDP port 67, 68 and 69. Please confirm that the firewall of the Windows system or anti-virus software can pass these UDP ports.

- Step1: Click the “**Download**” item to open the “Firmware Download” dialog.
- Step2: Enter the MAC address of the GW-7472-UL SERIES and an available IP address which will be temporally assigned to the GW-7472-UL SERIES via the BOOTP protocol. After finishing the firmware update, this IP address is useless.
- Step3: Select the firmware which will be updated.
- Step4: Click the “**Download**” button to start the update procedure.



Note:




The folder path of the new firmware can't include the character “ ” (the space character). Or the update procedure may be broken.

5. GW-7473 Utility Functionalities

5.1 Communication interface


1. Double click the GW-7473-UL SERIES Utility shortcut on the desktop.
2. Select the connection interface Modbus RTU or Modbus TCP
3. Click “connect” to open “Module Configuration” window



5.2 Communication interface

5.2.1 Modbus TCP Server Status

1. On the Diagnostic window, users can modify the Ethernet and Modbus RTU parameters with “Network Settings”.



2. Ethernet Configurations: “Static IP Address”, “Subnet Mask” and “Default Gateway”.

The default Ethernet settings are shown below.

Item	Settings (Init Mode)
IP	192.168.255.1
Gateway	192.168.0.1
Mask	255.255.0.0

3. Modbus RTU Configurations: “Net ID”, “Baud Rate”, “Data Bits”, “Stop Bits” and “Parity” , The default Modbus settings are shown below.

Item	Settings (Init Mode)
Net ID	1
Baud Rate	115200
Data Bits	8
Stop Bits	1
Parity	None

4. Click “Submit” to finish the configurations.

5.2.2 EtherNet/IP Adapter

1. Users can set the EtherNet/IP adapter information to the GW-7473-UL SERIES-UL SERIES with “Add Adapters” window. There are “Static IP Address”, “Input Instance” and “Output Instance”.

The screenshot shows a configuration window titled "Add Adapters". At the top, there is a "Static IP Address" field with four input boxes containing the values 192, 168, 255, and 1. To the right of these boxes are three buttons: "Add", "Edit", and "Del". Further right is a "Submit" button. Below the IP address section, there are two main sections: "Input Instance" and "Output Instance". Each section contains a table of configuration parameters. In the "Input Instance" section, there are fields for "Instance ID" (0), "Size" (0 bytes), "DI" (0 bytes, Start Address 0), and "DO" (0 bytes, Start Address 0). In the "Output Instance" section, there are fields for "Instance ID" (0), "Size" (0 bytes), "DO" (0 bytes, Start Address 0), and "AO" (0 bytes, Start Address 0).

In the “input instance” and “output instance” window, Users must to fill out “Instance ID” and “instance size”. The Instance size is equal to the sum of I/O status size. Users can also modify the I/O status size and their start address at the EtherNet/IP packet. For example, we want to add an EtherNet/IP adapter (EIP-2055) to the adapter menu. The EIP-2055 packet format is shown below.

Module	Data Assembly	ID	Byte count	Descriptions
EIP-2055 (IP:192.168.255.1)	Input Assembly	101	34	1 st Byte: DI status
				2 nd Byte: DO status
				3 rd ~34 th Byte: DI counters
	Output Assembly	102	2	1 st Byte: DO status
				2 nd Byte: to set DI counter zero

Fill out the EIP-2055 information to the “Adapter Settings” window:

Adapter Settings

Static IP Address: 192 168 255 1 **Add** **Edit** **Del** **Submit**

Input Instance

Instance ID: 101 Size: 34 bytes

Input

	Size	Start Address		Size	Start Address
DI	34 bytes	0	AI	0 bytes	0
DO	0 bytes	0	AO	0 bytes	0

Output Instance

Instance ID: 102 Size: 2 bytes

Output

	Size	Start Address
DO	2 bytes	0
AO	0 bytes	0

- Click “Add” to add the new EtherNet/IP adapter information to the menu. Click “Edit” to modify the menu. Click “Del” to remove the adapter information on the menu. Click “Submit” to save the configurations.

	No.	IP Address	In. ID	In. Size	Out. ID	Out. Size	DI(R)	DI(R) Ad
▶	0	192.168.22.55	101	34	102	2	34	0

- GW-7473-UL SERIES-UL SERIES will connect to the EtherNet/IP adapter automatically after rebooting.

5.2.3 Modbus Command

1. On the Modbus Command window, users can modify the Modbus command format. Click “Add” to add a Modbus Command to the menu. Click “Remove” to remove the command on the menu.

Request

NetID (dec) (1~247) Interval ms

Function Code

Address (dec) (0~65535)

Count (dec) bits

2. Click “START” to send Modbus command. Click “STOP” to finish the process.

5.3 GW-7473-UL SERIES Address Mapping

There are 200 bytes buffer for every I/O status, please refer to the mapping table below

Address	Description	Attribute
00001~00200	Digital output value of EtherNet/IP adapter	R/W
10001~10200	Digital input value of EtherNet/IP adapter	R
40001~40200	Analog output value of EtherNet/IP adapter	R/W
30001~30200	Analog input value of EtherNet/IP	R

5.4 Vendor Defined Function Code

There are four vendor defined function code for GW-7473-UL SERIES-UL SERIES configurations. Please refer to the following descriptions.

5.4.1 Function Code 100(0x64): Write IP Address

Users can set the IP address and Modbus settings of GW-7473-UL SERIES-UL SERIES with function code 0x64. If you send this function code to GW-7473-UL SERIES-UL SERIES, it will reboot after setting.

Request

Byte	Descriptions	
0		Address
1		Function Code (0x64)
2~5	Ethernet	IP Address
6~9		Subnet Mask
10~13		Default Gateway
14	Modbus	Net ID
15		Baud Rate
16		Data Bits
17		Stop Bits
18		Parity

Command format:

Users can select baud rate and Parity with index :

Index	Baud rate
0	2400
1	4800
2	9600
3	19200
4	38400
5	57600
6	115200

Index	Parity
0	None
1	Odd
2	Even

For example, If you want to set the following configuration into GW-7473-UL SERIES-UL SERIES (Address = 1):

IP address: 192.168.255.1

Subnet mask: 255.255.0.0

Default gateway: 192.168.0.254

Net ID: 1

Baud rate: 115200

Data bits: 8

Stop bits: 1 Parity: None

Please send the command below:

Bytes	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Item	Address	FC	IP Address				Subnet Mask				Default gateway				Net ID	Baud rate	Data bits	Stop bits	Parity
Data	01	64	01	ff	a8	c0	00	00	ff	ff	fe	00	a8	c0	01	06	08	01	00

If the configuration is set successfully, the GW-7473-UL SERIES-UL SERIES will reply you the same message.

5.4.2 Function Code 102(0x65): Read IP Address

Users can read the IP address and Modbus settings of GW-7473-UL SERIES-UL SERIES with function code 0x65. For example, If you want to read the IP address and Modbus settings from GW- 7473 (Address = 1), please send the command below:

Bytes	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Data	01	65	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00

The reply message is shown below:

Byte	Descriptions	
0		Address
1		Function Code (0x65)
2~5	Ethernet	IP Address
6~9		Subnet Mask
10~13		Default Gateway
14	Modbus	Net ID
15		Baud Rate
16		Data Bits
17		Stop Bits
18		Parity

5.4.3 Function Code 103(0x66): Write Adapter

Information

Users can set EtherNet/IP adapter information to GW-7473-UL SERIES-UL SERIES with function code 0x66. If you send this function code to GW-7473-UL SERIES-UL SERIES, it will reboot after setting.

Request Command format:

Byte	Descriptions
0	Address
1	Function Code (0x66)
2	adapter number
3~6	Adapter IP address
7	Input instance ID
8	Input Instance data size
9	Output instance ID
10	Output instance Size
11	(Read) DI Size
12	(Read) DI Address
13	(Read) DO Size
14	(Read) DO Address

15	(Read) AI Size
16	(Read) AI Address

For example, If you want to set EtherNet/IP adapter (EIP-2055) information into GW- 7473 (Address = 1):

Module	Data Assembly	ID	Byte count	Descriptions
EIP-2055 (IP:192.168.255.1)	Input Assembly	101	34	1 st Byte: DI status
				2 nd Byte: DO status
				3 rd ~34 th Byte: DI counters
	Output Assembly	102	2	1 st Byte: DO status 2 nd Byte: to set DI counter zero

Please send the command below:

Bytes	0	1	2	3	4	5	6	7	8	9	10
Item	Address	FC	adapter number	adapter IP address				Input instance ID	Input instance Size	Output instance ID	Output instance Size
Data	01	66	00	c0	a8	ff	01	65	22	66	02

Bytes	11	12	13	14	15	16	17	18	19	20	21	22	23
Item	Read												total
	DI size	DI address	DO size	DO address	AI size	AI address	AO size	AO address	DO size	DO address	AO size	AO address	adp. no.
Data	34	00	00	00	00	00	00	00	02	00	00	00	01

If the configuration is set successfully, the GW-7473-UL SERIES-UL SERIES will reply you the same message.

5.4.4 Function Code 104(0x67): Read Adapter

information

Users can read the adapter information from GW-7473-UL SERIES-UL SERIES with function code 0x67.

For example, If you want to the second adapter (adapter number = 1) information from GW-7473-UL SERIES-UL SERIES (Address = 1), please send the command below:

Bytes	0	1	2	3	4	5	6	7	8	9	10	11	...	18	19	20	21	22
Data	01	67	01	00	00	00	00	00	00	00	00	00	...	00	00	00	00	00


The reply message is shown below:

Byte	Descriptions
0	Address
1	Function Code (0x66)
2	adapter number
3~6	Adapter IP address
7	Input instance ID
8	Input Instance data size
9	Output instance ID
10	Output instance Size
11	(Read) DI Size
12	(Read) DI Address
13	(Read) DO Size
14	(Read) DO Address
15	(Read) AI Size
16	(Read) AI Address
17	(Read) AO Size
18	(Read) AO Address
19	(Write) DO Size
20	(Write) DO Address
21	(Write) AO Size
22	(Write) AO Address
23	total adapter number

5.5 Firmware Update

The GW-7473-UL SERIES-UL SERIES supports firmware update through the Ethernet network with the BOOTP/TFTP protocol. Generally, the firmware is not necessary to update when it works well. If there are some bugs in the firmware of your GW-7473-UL SERIES-UL SERIES or you need new functions which don't support in your GW-7473-UL SERIES-UL SERIES, the firmware update is necessary. If the firmware update procedure is broken unfortunately, please try it again.

Before updating the firmware, you have to set the "Init Switch" to "Init" position and then re-power on the GW-7473-UL SERIES-UL SERIES. Since the flash becomes writable, we can update the firmware through the Ethernet network.



Mode	Firmware Running	Flash Protection	Firmware Update	Configuration
Init	No	No	Yes	Factory
Run	Yes	Yes	No	User-Defined

Note:




- Well configure the network settings of your PC. Or the update procedures through the Ethernet network may not work correctly.
- The program (TFTP server) may not run correctly if there is another TFTP server running on the same PC.
- The BOOTP and TFTP protocols use the Ethernet UDP port 67, 68 and 69. Please confirm that the firewall of the Windows system or anti-virus software can pass these UDP ports.

Step1: Click the “Firmware Update” button.

Step2: Select the network interface which is connected with GW-7473-UL SERIES-UL SERIES.

Step2: Select the firmware which will be updated.

Step3: Click the “Download” button to start the update procedure.



Note:



The folder path of the new firmware can't include the character " " (the space character). Or the update procedure may be broken.


6. R/W Modbus devices from EtherNet/IP

Since the GW-7472-UL SERIES provides the functions of an EtherNet/IP adapter and the Modbus masters, there are some mechanisms for data-exchanging between EtherNet/IP objects and the Modbus registers. This section describes the EtherNet/IP Object Model of the GW-7472-UL SERIES and how to read/write the GW-7472-UL SERIES EtherNet/IP object data mapping to the registers of Modbus slaves by using the EtherNet/IP Explicit and Implicit Message.

6.1 Object Model

The Object Model for the GW-7472-UL SERIES is shown in the following figure. Inside the GW-7472-UL SERIES, there are one Modbus RTU master, one Modbus TCP client and an EtherNet/IP adapter. When booting up, the GW-7472-UL SERIES scans all of the input registers of Modbus slaves (and Modbus servers) and updates all of the output registers of Modbus slaves. At the same time, the Modbus masters exchanges the input data and Modbus connection conditions with the objects of the EtherNet/IP adapter.

The EtherNet/IP adapter of the GW-7472-UL SERIES provides six kinds of objects. Each object has its characteristic, service and instances. The Connection Manager Object is applied for building a connection before using the Explicit Messages and the Implicit Messages. The Message Router Object is used to route the message to other objects of the EtherNet/IP adapter. The Assembly Object, Identity Object, TCP/IP Object, and Ethernet Link Object are used to record the I/O information, device information, TCP/IP configuration, Ethernet link-specific status information respectively. After receiving an EtherNet/IP message, the GW-7472-UL SERIES will distinguish what the message type it is. The Explicit Message can direct access the Assembly Object or access other objects via the Message Router Object. The Implicit Message can only access I/O data of the Assembly Object. The UCMM Message is used to access all of the objects without building a connection. When the UCMM Message is got by the GW-7472-UL SERIES, the message is passed to the Message Router Object for routing. When the EtherNet/IP scanner communicates with the EtherNet/IP adapter of the GW-7472-UL SERIES, the GW-7472-UL SERIES replies the corresponding information. At the same time, the EtherNet/IP adapter exchanges the output data with the Modbus master.



6.2 Explicit Message

Explicit Messages are applied for accessing all of the objects in the object model. The specific instances and attributes for each Object Class are presented in “Appendix A: EtherNet/IP Object Model”. Before using Explicit Messages, you must use the Forward Open service of the Connection Manager Object to build a connection between the EtherNet/IP scanner and the GW-7472-UL SERIES. Afterwards, the Explicit Message can be used.

6.3 Implicit Message

Implicit Messages are applied only for accessing the Input Instance 65_{hex} and Output Instance 66_{hex} of the Assembly Object in the object model. Before using Implicit Messages, you must use the Forward Open service of the Connection Manager Object to build a connection between the EtherNet/IP scanner and the GW-7472-UL SERIES. Afterwards, the Implicit Message can be used.


6.4 UCMM

The UCMM are also applied for accessing all of the objects in the object model. The main feature of the UCMM is that you can send the UCMM without building a connection. It is a simple method for EtherNet/IP to get the information of all objects. However, because of using UCMM without building a connection, the reliability of the message transmission is worse than the Explicit Message.

6.5 Assembly Object

The GW-7472-UL SERIES supports one input instance, one output instance and one command status instance in Assembly Object. Each of these instances is mapping to the register data of the Modbus slaves. After you use the Utility to configure the GW-7472-UL SERIES, the mapping information between the registers of the Modbus slaves and the instances of the Assembly Object is created by following the configuration order of the Modbus

commands defined by the Utility. A GW-7472-UL SERIES allows setting maximum 30 Modbus RTU commands and 80 Modbus TCP commands to get the register data of the Modbus slaves. The unit of the input instance and output instance is BYTE. Therefore, no matter the data format is Coil (1 bit) or WORD, all of the register data of the Modbus slaves will be assigned to the instances of the Assembly Object by using BYTE format. While creating a mapping table, the data in the same Modbus command will be put together and be mapping to some section of the instance by using integral number of bytes. The input register data of the first Modbus command defined by the Utility are mapping to the most front end of the input instance. The input register data of the following Modbus command are mapping to the following section of the input instance. The situation is the same at the mapping of the output instance. The maximum data size of the input instance and output instance are 500 bytes respectively. The following figure shows the general concept of the mapping information of the input instance and output instance. For details about the input, output and status instances, please refer to the “Appendix A (4. Assembly Object (04_{hex}))”.



7. Supported Modbus Communication

Function Code (in hex)	Explanation
01	Read output status
02	Read input status
03	Read multiple data registers
04	Read input registers
0F	Write multiple bits
10	Write multiple data register

Appendix A: EtherNet/IP Object Model

1. Device Object Model

The Device Object Model is the logical organization of attributes, classes and services supported by a device. Objects are composed of attributes and services. There are three types of objects in any CIP device: Required Objects, Application Objects and Vendor Specific Objects.

Required Objects are object classes that must be supported by all devices on EtherNet/IP.

Applications Objects are classes that must be supported by all devices using the same profile. An example of a profile is a Discrete I/O device or an AC Drive. This ensures that devices from different vendors but with the same profile have a common interface to EtherNet/IP Client devices. For example, every AC Drive device must have a motor object among its required application objects. The attribute numbers for the maximum motor frequency and other motor data are predefined by the AC Drive profile to simply access to any device supporting the AC Drive profile.

Vendor Specific Objects are classes that add attributes and services that don't fit into the Required or Application Objects.

The required objects of the GW-7472-UL SERIES are list as below:

- Identity Object (0x01)
- Message Router Object (0x02)
- Assembly Object (0x04)
- Connection Manager Object (0x06)
- TCP Object (0xF5)
- Ethernet Link Object (0xF6)

2. Identity Object (01_{hex})

The Identify Object provides read only data that describes the general information about the device. The information may be the EtherNet/IP Vendor number, the major and minor revision and the serial number of the device. Your EtherNet/IP scanner has no direct control of any attributes in this object.

Class Attributes (Instance ID = 0_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	01 _{dec}	Get
2	Max Instance	UINT	01 _{dec}	Get
3	Number of Instances	UINT	01 _{dec}	Get
6	Max Class Attributes ID Number	UINT	07 _{dec}	Get
7	Max Instance Attributes ID Number	UINT	07 _{dec}	Get

Instance Attributes (Instance ID = 1_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Vendor ID	UINT	803 _{dec}	Get
2	Device Type	UINT	0C _{hex}	Get
3	Product Code	UINT	256 _{dec}	Get
4	Product Major Revision	USINT	01 _{dec}	Get
	Product Minor Revision	USINT	00 _{dec}	
5	Status	WORD	00 _{dec}	Get
6	Serial Number	UDINT	Unique 32 bit value	Get
7	Product Name Structure of: Product Name Size Product Name String	SHORT STRING	08 _{dec} "GW-7472-UL SERIES"	Get

Common Services

Service Code	Implemented for		Service Name
	Class	Instance	
0E _{hex}	Yes	Yes	Get_Attribute_Single
01 _{hex}	Yes (1,2,6,7)	Yes (1,2,3,4,5,6,7)	Get_Attributes_All

05 _{hex}	No	Yes	Reset
-------------------	----	-----	-------

3. Message Router Object (02_{hex})

The Message Router Object is used for routing the Explicit Message or UCMM to access the instance of the object with specific Class ID, Instance ID and Attribute ID. It provides two kinds of services for accessing any objects in the GW-7472-UL SERIES.

Class Attributes (Instance ID = 0_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	01 _{dec}	Get
2	Max Instance	UINT	01 _{dec}	Get
3	Number of Instances	UINT	01 _{dec}	Get
6	Max Class Attributes ID Number	UINT	07 _{dec}	Get
7	Max Instance Attributes ID Number	UINT	00 _{dec}	Get

Common Services

Service Code	Implemented for		Service Name
	Class	Instance	
0E _{hex}	Yes	No	Get_Attribute_Single
01 _{hex}	Yes	No	Get_Attributes_All

4. Assembly Object (04_{hex})

An EtherNet/IP Assembly Object assembles data from other objects into input and output packages that are exchanged with the EtherNet/IP scanner. Input objects refer to the collection of data items that are transferred from the server (the GW-7472-UL SERIES) to the Client (maybe the EtherNet/IP scanner). Output refers to the collection of data items that are transferred from the client (maybe the EtherNet/IP scanner) to the server (the GW-7472-UL SERIES).

The GW-7472-UL SERIES provides Input/Output/Status Assembly for transferring data and status from the Modbus RTU network to the EtherNet/IP scanner. Generally, before using an EtherNet/IP scanner, you need to configure what object and instance you are interesting. Therefore, the following table must be applied to confirm the Class ID, Instance ID and Attribute ID when using the configuration tool of the EtherNet/IP scanner. If the configuration tool of the EtherNet/IP scanner supports the EDS loader, you can get the EDS file of the GW-7472-UL SERIES by using Utility. Please refer to the section 4.2.4 for more details.

INPUT/OUTPUT ASSEMBLY

Input Instance: 65_{hex}

Output Instance: 66_{hex}

The input/output instance stores the Modbus Register data for the access of the EtherNet/IP scanner. The register data for all the Modbus nodes are packed into a maximum 500-byte data of the EtherNet/IP package. The size of the input/output instance is dependent on all the Modbus Read register data assigned by the Utility.

Class Attributes (Instance ID = 0_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	02 _{dec}	Get
2	Max Instance	UINT	03 _{dec}	Get
3	Number of Instances	UINT	03 _{dec}	Get
6	Max Class Attributes ID	UINT	07 _{dec}	Get

	Number			
7	Max Instance Attributes ID Number	UINT	03 _{dec}	Get

Instance 64_{hex} Attributes (Configuration Instance)

Most EtherNet/IP scanner contains a configuration path when opening an Implicit Message connection to the GW-7472-UL SERIES. Through the configuration path, the EtherNet/IP scanner can exchange the input and output data of the GW-7472-UL SERIES. Therefore, there is no data needed in the Configuration Instance.

Instance 65_{hex} Attributes (Input Instance)

Attribute ID	Name	Data Type	Default Data Value	Access Rule
3	Serial Read Data Structure of Node Read Data 1 ... Node Read Data n	BYTE [maximum 500]	All 0's	Get

The input data size is based on the arrangement of the input registers of the Modbus slaves configured by the GW-7472-UL SERIES Utility. The Input Instance data are packaged by following the command order defined in Utility.

Instance 66_{hex} Attributes (Output Instance)

Attribute ID	Name	Data Type	Default Data Value	Access Rule
3	Serial Data Structure of Node Read Data 1 ... Node Read Data n	BYTE [maximum 500]	All 0's	Get/Set

The output data size is based on the arrangement of the output registers of the Modbus slaves configured by the GW-7472-UL SERIES Utility. The Output Instance data are packaged by following the command order defined in Utility.

Instance 67_{hex} Attributes (Command Status Instance)

Attribute ID	Name	Data Type	Default Data Value	Access Rule
3	Serial Data Structure of 1 st Command status 2 nd Command status ... 30 th Command status	BYTE [fixed to 30]	All 0's	Get/Set

Command Status (in hex)	Explanation
00	No Error
01	Illegal device ID
02	Illegal function code
03	Illegal data address
04	Receiving an Invalid command
05	CRC checking error
06	Timeout error occurred

Common Services

Service Code	Implemented for		Service Name
	Class	Instance	
0E _{hex}	Yes	Yes	Get_Attribute_Single
10 _{hex}	No	Yes	Set_Attribute_Single

5. Connection Manager Object (06_{hex})

The Connection Manager Object allocates and manages the internal resources associated with both Implicit and Explicit Messaging Connections. The specific instance generated by the Connection Manager Object is referred to as a Connection instance or a Connection Object.

Class Attributes (Instance ID = 0_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	01 _{dec}	Get
2	Max Instance	UINT	01 _{dec}	Get
3	Number of Instances	UINT	01 _{dec}	Get
6	Max Class Attributes ID Number	UINT	07 _{dec}	Get
7	Max Instance Attributes ID Number	UINT	00 _{dec}	Get

Common Services

Service Code	Implemented for		Service Name
	Class	Instance	
0E _{hex}	Yes	No	Get_Attribute_Single
01 _{hex}	Yes	No	Get_Attributes_All
4E _{hex}	No	Yes	Forward_Close
54 _{hex}	No	Yes	Forward_Open

6. TCP/IP Interface Object (F5_{hex})

The TCP/IP Interface Object contains read-only data that describes the TCP/IP connection parameters between the Gateway and the EtherNet/IP scanner. The configurable items include the GW-7472-UL SERIES's IP address, network mask and gateway address. You can't directly control any attributes of this object.

Class Attributes (Instance ID = 0_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	01 _{dec}	Get
2	Max Instance	UINT	01 _{dec}	Get
3	Number of Instances	UINT	01 _{dec}	Get
6	Max Class Attributes ID Number	UINT	07 _{dec}	Get
7	Max Instance Attributes ID Number	UINT	06 _{dec}	Get

Instance Attributes (Instance ID = 1_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Status ¹	UINT	01 _{dec}	Get
2	Configuration Capability ²	UINT	04 _{dec}	Get
3	Configuration Control ³	UINT	00 _{dec}	Get
4	Physical Link Object ⁴ Structure of: Path Size Path	UINT Padded EPATH	02 _{dec} 20F6 _{hex} , 2401 _{hex}	Get
5	Interface Configuration ⁵ Structure of: IP Address Network Mask Gateway Address Name Server Name Server 2 Domain Name Size Domain Name	UINT UINT UINT UINT UINT UINT UINT	192 168 255 1 _{dec} 255 255 0 0 _{dec} 192 168 0 1 _{dec} 0 0 0 0	Get
6	Host Name ⁶ Structure of: Host Name Size Host Name	UINT String	0 0	Get

Common Services

Service Code	Implemented for		Service Name
	Class	Instance	
0E _{hex}	Yes	No	Get_Attribute_Single



- ¹ Section 5-3.2.2.1 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.
- ² Section 5-3.2.2.2 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.
- ³ Section 5-3.2.2.3 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.
- ⁴ Section 5-3.2.2.4 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.
- ⁵ Section 5-3.2.2.5 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.
- ⁶ Section 5-3.2.2.6 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.

7. Ethernet Link Object (F6_{hex})

The Ethernet Link Object contains read-only data that describes the status of the physical Ethernet link. You can't directly control any attributes of this object.

Class Attributes (Instance ID = 0_{hex})

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	01 _{dec}	Get
2	Max Instance	UINT	01 _{dec}	Get
3	Number of Instances	UINT	01 _{dec}	Get
6	Max Class Attributes ID Number	UINT	07 _{dec}	Get
7	Max Instance Attributes ID Number	UINT	03 _{dec}	Get

Instance Attributes (Instance ID = 1_{hex})

Attribute ID	Name	Data Type	Default Data Value	Access Rule
1	Interface Speed ⁷	UDINT	100 _{dec}	Get
2	Interface Flags ⁸	DWORD	03 _{dec}	Get
3	Physical Address ⁹	ARRAY of 6 USINTs	00 0D E0 xx xx xx _{hex}	Get

Common Services

Service Code	Implemented for		Service Name
	Class	Instance	
0E _{hex}	Yes	Yes	Get_Attribute_Single
01 _{hex}	Yes	Yes	Get_Attributes_All



⁷ Section 5-4.2.2.1 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.

⁸ Section 5-4.2.2.2 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.

⁹ Section 5-4.2.2.3 of "Volume 2: EtherNet/IP Adaptation of CIP" from ODVA for more details on this attribute.

8. CIP General Status Code

Reference Volume 1: CIP Common Specification Appendix B

General Status Code (in hex)	Status Name	Description of Status
00	Success	Service was successfully performed by the object specified.
01	Connection failure	A connection related service failed along the connection path.
02	Resource unavailable	Resources needed for the object to perform the requested service were unavailable
04	Path segment error	The path segment identifier or the segment syntax was not understood by the processing node. Path processing shall stop when a path segment error is encountered.
05	Path destination unknown	The path is referencing an object class, instance or structure element that is not known or is not contained in the processing node. Path processing shall stop when a path destination unknown error is encountered.
08	Service not supported	The requested service was not implemented or was not defined for this Object Class/Instance.
09	Invalid attribute value	Invalid attribute data detected
0E	Attribute not settable	A request to modify a non-modifiable attribute was received.
13	Not enough data	The service did not supply enough data to perform the specified operation.
14	Attribute not supported	The attribute specified in the request is not supported
15	Too much data	The service supplied more data than was expected
16	Object does not exist	The object specified does not exist in the device.
20	Invalid parameter	A parameter associated with the request was invalid. This code is used when a parameter does not meet the requirements of this specification and/or the requirements defined in an Application Object Specification.
26	Path Size Invalid	The size of the path which was sent with the Service Request is either not large enough to allow the Request to be routed to an object or too much routing data was included.

9. Connection Manager Service Request Error Codes

Reference Volume 1: CIP Common Specification Table 3-5.29

General Status (in hex)	Extended Status (in hex)	Explanation and Description
00		Service completed successfully
01	100	CONNECTION IN USE OR DUPLICATE FORWARD OPEN This extended status code shall be returned when an originator is trying to make a connection to a target with which the originator may have already established a connection
01	103	TRANSPORT CLASS AND TRIGGER COMBINATION NOT SUPPORTED A transport class and trigger combination has been specified which is not supported by the target. Routers shall not fail the connection based on the transport class and trigger combination. Only targets shall return this extended status code.
01	106	OWNERSHIP CONFLICT The connection cannot be established since another connection already "owns" some of the resources required for this connection.
01	107	CONNECTION NOT FOUND AT TARGET APPLICATION This extended status code shall be returned by the close connection request, where the connection which is to be closed is not active at the target node.
01	108	INVALID NETWORK CONNECTION PARAMETER This extended status code shall be returned as the result of specifying a connection type, connection priority, redundant owner or fixed / variable that is not supported by the target application. Only a target node shall return this extended status code.
01	109	INVALID CONNECTION SIZE This extended status code is returned when the target or router does not support the specified connection size.
01	113	CONNECTION MANAGER CANNOT SUPPORT ANY MORE CONNECTIONS
01	114	VENDOR ID OR PRODUCT CODE MISMATCH The Product Code or Vendor Id specified in the electronic key logical segment does not match the Product Code or Vendor Id of in the target device.
01	115	PRODUCT TYPE MISMATCH The Product Type specified in the electronic key logical segment does not match the Product Type of in the target device.
01	116	REVISION MISMATCH The major and minor revision specified in the electronic key logical segment does not correspond to a valid revision of the target device.
01	117	INVALID CONNECTIO POINT The connection point specified in the connection path does not correspond to a valid connection point for the target application.
01	118	INVALID CONFIGURATION FORMAT An instance number specified for the configuration data does not correspond to a configuration instance.
01	119	CONNECTION REQUEST FAILS SONCE THERE IS NO CONTROLLING CONNECTION CURRENTLY OPEN The extended status code shall be returned when an attempt is made to establish an echo (i.e. listen only) connection to a connection which has no controlling connection (i.e. owner).
01	11A	TARGET APPLICATION CANNOT SUPPORT ANY MORE CONNECTIONS The maximum number of connections supported by this instance of the Target

		Application has been exceeded.
01	205	PARAMETER ERROR IN UNCONNECTED SEND SERVICE One of the parameters in the unconnected send service was in error.
01	315	INVALID SEGMENT IN CONNECTION PATH Invalid Segment Type or Segment Value in Connection Path This extended status code is the result of a device being unable to decode the connection path. This could be caused by an unrecognized path type, a segment type occurring unexpectedly, or a myriad of other problems in the connection path.

Appendix B: Glossary

1. ARP (Address Resolution Protocol)

Consider two machines A and B that share a physical network. Each has an assigned IP address IP_A and IP_B , and a MAC address the MAC_A and MAC_B . The goal is to devise low-level software that hides MAC addresses and allows higher-level programs to work only with the IP addresses. Ultimately, however, communication must be carried out by the physical networks using whatever MAC address scheme the hardware supplies.

Suppose machine A wants to send a packet to machine B across a physical network to which they are both attached, but A only has the Internet address for B, IP_B . The question arises: how does A map that address to the MAC address for B, MAC_B ?

ARP provides a method of dynamically mapping 32-bit IP address to the corresponding 48-bit MAC address. The term dynamic is used since it happens automatically and is normally not a concern for either the application user or the system administrator.

2. Clients and Servers

The client-server paradigm uses the direction of initiation to categorize whether a program is a client or server. In general, an application program that initiates peer to peer communication is called a client. End users usually invoke client programs when they use network services.

Most client programs consist of conventional application program develop tools. Each time a client program is executed; it contacts a server, sends a request and waits for a response. When the response arrives, the client program continues processing. Client programs are often easier to develop than servers, and usually require no special system privileges to operate.

By comparison, a server is any program that waits for incoming requests from a client program. The server receives a request from a client, performs the necessary computation and returns the result to the client.

3. Ethernet

The term Ethernet generally refers to a standard published in 1982 by Digital Equipment Corp., Intel Corp. and Xerox Corp. Ethernet is the most popular physical layer local area network (LAN) technology today. Ethernet is a best-effort delivery system that uses CSMA/CD technology. It recognizes hosts using 48-bit MAC address.

4. Firmware

Firmware is an alterable program located or stored in the semi-permanent storage area, e.g., ROM, EEPROM, or Flash memory.

5. Gateway

Computers that interconnect two networks and pass packets from one to the other are called Internet Gateways or Internet Routers. Gateways route packets that are based on the destination network, not on the destination host.

6. ICMP (Internet Control Messages Protocol)

No system works correctly all the time. ICMP provides a method of communicating between the Internet Protocol software on one machine and the Internet Protocol software on another. It allows gateways to send error or control messages to other gateways or allows a host to know what is wrong with the network communication.

7. Internet

Physically, the Internet is a collection of packet switching networks interconnected by gateways along with TCP/IP protocol that allows them to perform logically as a single, large and virtual network. The Internet recognizes hosts using 32-bit IP address.

8. IP (Internet Protocol) address

Every interface on an Internet must have a unique IP address (also called an Internet address). These addresses are 32-bit numbers. They are normally written as four decimal numbers, one for each byte of the address such as "192.168.41.1". This is called dotted-decimal notation.

9. MAC (Media Access Control) address

To allow a computer to determine which packets are meant for it, each computer attached to an Ethernet is assigned a 48-bit integer known as its MAC address (also called an Ethernet address, hardware address or physical address). They are normally written as eight hexadecimal numbers such as “00:71:88:af:12:3e:0f:01”. Ethernet hardware manufacturers purchase blocks of MAC addresses and assign them in sequence as they manufacture the Ethernet interface hardware. Thus, no two hardware interfaces have the same MAC address.

10. Packet


A packet is the unit of data sent across a physical network. It consists of a series of bits containing data and control information, including the source and the destination node (host) address, and is formatted for transmission from one node to another.

11. Ping

Ping sends an ICMP echo request message to a host, expecting an ICMP echo reply to be returned. Normally, if a host cannot be pinged, you won't be able to use Telnet or FTP to connect to the host. Conversely, if Telnet or FTP cannot be used to connect to a host, Ping is often the starting point to determine what the problem is.

12. RARP (Reverse Address Resolution Protocol)

RARP provides a method of dynamically mapping 48-bit MAC address to the corresponding 32-bit IP address.



13. Socket

Each TCP segment contains the source and destination port number that can be used to identify the sending and receiving application. These two values, along with the source and destination IP address in the IP header, uniquely identify each connection.

The combination of an IP address and a port number is called a socket.

14. Subnet Mask

Subnet mask is often simply called the mask. Given its own IP address and its subnet mask, a host can determine if a TCP/IP packet is destined for a host that is (1) on its own subnet, or (2) on a different network. If (1), the packet will be delivered directly; otherwise if, will be delivered via gateways or routers.

15. TCP (Transmission Control Protocol)

TCP provides a reliable flow of data between two hosts. It is associated with tasks such as dividing the data passed to it from applications into appropriately sized chunks for the network layer below, acknowledging received packets, setting timeouts to make certain that the other end acknowledges packets that are sent, and so on.

16. TCP/IP

The transmission Control Protocol (TCP) and the Internet Protocol (IP) are the standard network protocols. They are almost always implemented and used together and called TCP/IP. TCP/IP can be used to communicate across any set of interconnected networks.

17. UDP (User Datagram Protocol)

UDP provides a much simpler service to the application layer. It just sends packets of data from one host to the other. But there is no guarantee that the packets will reach the destination host.

Appendix C: FAQ

1. Why does the GW-7472-UL SERIES series module fail on a (public) Internet connection?

The default IP address of the GW-7472-UL SERIES is 192.168.255.1, which can be only used on a private Internet connection. A private network packet will not be routed via a (public) Internet connection, which is the reason why the GW-7472-UL SERIES failed on the Internet.


The IANA has reserved three address spaces for private internets (RFC1918).

10.0.0.0 - 10.255.255.255 (10/8 prefix)


172.16.0.0 - 172.31.255.255 (172.16/12 prefix)

192.168.0.0 - 192.168.255.255 (192.168/16 prefix)

The GW-7472-UL SERIES can be operated on the Internet by using a legal public IP address. This address can be obtained from your ISP or network administrator.



A private internet client may communicate with a public Internet server (GW-7472-UL SERIESs) only if the NAT service for the client is available.



Note!!

IANA	Internet Assigned Numbers Authority
RFC	Request for Comments
ISP	Internet Service Providers
NAT	Network Address Translator



ICP DAS Web Site: <http://www.icpdas.com>

Contact Us (E-Mail): Service@icpdas.com