

I-8024UW / I-8028UW I-9024U / I-9028U Linux API Reference Manual

V 2.0.1 July 2020



Written by Edward Ku

Edited by Cindy Huang

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2018 by ICP DAS Co., Ltd. All rights are reserved.

Trademarks

Names are used for identification purposes only and may be registered trademarks of their respective companies.

Contact Us

If you have any problems, please feel free to contact us.
You can count on us for a quick response.
Email: service@icpdas.com

Table of Contents

Table of Contents	3
1. Introduction	5
1.1. Specifications	7
1.2. Pin Assignments	8
1.3. Jumper Setting	10
1.4. Wire Connections	11
1.5. Block Diagram	12
1.6. Dimensions	13
2. Quick Start	14
3. Power-on Mode	16
3.1. Power-on Value Mode	18
3.2. Retentive Mode	19
4. Watchdog.....	20
5. API References	25
5.1. i8028U_Init	27
5.2. i8028U_GetFirmwareVersion	28
5.3. i8028U_GetLibVersion	29
5.4. i8028U_ReadAO_GainOffset	30
5.5. i8028U_WriteAOHex.....	32
5.6. i8028U_WriteAO.....	34
5.7. i8028U_ReadAOHex.....	36
5.8. i8028U_ReadAO.....	38
5.9. i8028U_SetPowerOnEnStatus	40
5.10. i8028U_GetPowerOnEnStatus.....	41
5.11. i8028U_WritePowerOnHex_AO.....	42
5.12. i8028U_WritePowerOn_AO.....	44
5.13. i8028U_ReadPowerOnHex_AO.....	46
5.14. i8028U_ReadPowerOn_AO.....	48
5.15. i8028U_WriteSafeHex_AO.....	50
5.16. i8028U_WriteSafe_AO.....	52
5.17. i8028U_ReadSafeHex_AO.....	54
5.18. i8028U_ReadSafe_AO.....	56
5.19. i8028U_SetModuleWDTConfig.....	58
5.20. i8028U_GetModuleWDTConfig	60

5.21. i8028U_GetModuleWDTStatus	62
5.22. i8028U_ResetModuleWDT	63
5.23. i8028U_RefreshModuleWDT	64
Appendix A. Error Code	65
Appendix B. Revision History	66

1. Introduction

The I-9024U/I-9028U is a 4-channel/8-channel Isolated analog output module that can be used on a 9000 series PAC, and allows a programmable output range on all analog output channels (0 to 5 V, ± 5 V, 0 to 10 V, ± 10 V, +4 to +20 mA or 0 to +20 mA). Each Analog Output channel can be configured for an individual range, providing an RF immunity level matching that defined by the IEC 61000-4-3 standard. The I-9024U/I-9028U module features channel to-channel isolation as well as 4 kV ESD protection and 1000 VDC intra-module isolation.

And the I-8024UW/ I-8028UW is also a 4-channel/8-channel Isolated analog output module that can be used on a 8000 series PAC.

Features

Model	I-8024UW	I-8028UW	I-9024U	I-9028U
Channel	4	8	4	8
Voltage or Current Output	Jumper	Jumper	Software	Software
Range	0 ~ +5 VDC, ± 5 VDC, 0 ~ +10 VDC, ± 10 VDC, 0 ~ +20 mA, +4 ~ +20 mA			
Resolution	16-bit			
Power-on Value	Yes			
Safe Value	Yes			
System LED Indicator	1 LED as Power Indicator			
Dimension (L x W x H)	129 mm x 31 mm x 114 mm		144 mm x 30.3 mm x 134 mm	

Applicable Platform table

The following table shows which platform the module applies to.


Platform	OS	Module
XPAC	XP-8000(WES)	I-8024UW/ I-8028UW
	XP-8000-Atom (WES)	I-8024UW/ I-8028UW
	XP-8000-WES7 (WES7)	I-8024UW/ I-8028UW
	XP-8000-CE6 (WinCE 6.0)	I-8024UW/ I-8028UW
	XP-8000-Atom-CE6 (WinCE 6.0)	I-8024UW/ I-8028UW
	XP-9000-WES7(WES7)	I-9024U/ I-9028U
WinPAC	WP-8000 (CE 5.0/7.0)	I-8024UW/ I-8028UW
	WP-9000-CE7 (CE 7.0)	I-9024U/ I-9028U
LinPAC	LinPAC-8000(Linux kernel 3.2/4.4)	I-8024UW/ I-8028UW
	LinPAC-9000(Linux kernel 3.2/4.4)	I-9024U/ I-9028U
IPAC	iPAC-8000 (MiniOS7)	I-8024UW/ I-8028UW
	I-8000 (MiniOS7)	I-8024UW/ I-8028UW

1.1. Specifications

Model	I-8024UW	I-8028UW	I-9024U	I-9028U
Analog Output				
Channels	4	8	4	8
Current Output Wiring	Source			
Range	0 ~ +5 VDC, ±5 VDC, 0 ~ +10 VDC, ±10 VDC, 0 ~ +20 mA, +4 ~ +20 mA			
Resolution	16-bit			
Accuracy	±0.02% of FSR			
Zero Drift	±0.2 μV/°C			
Span Drift	±25 ppm/°C			
Short Circuit Protection	Yes			
Power-on Value	Yes			
Safe Value	Yes			
External Power Requirements				
Reserve Polarity Protection	Yes			
Powered from Terminal Block	Yes, 15 ~ 30 VDC			
Isolation	3000 VDC			
LED Indicators				
System LED Indicator	1 LED as Power Indicator			
Isolation				
Intra-module Isolation, Field-to-Logic	3000 VDC			
EMS Protection				
ESD (IEC 61000-4-2)	±4 kV Contact for each Terminal			
	±8 kV Air for Random Point			
Power				
Power Consumption	2 W Max.			
Mechanical				
Dimension (L x W x H)	129 mm × 31 mm × 114 mm		144 mm x 30.3 mm x 134 mm	
Environment				
Operating Temperature	-25 ~ +75°C			
Storage Temperature	-40 ~ +85°C			
Humidity	10 ~ 90% RH, non-condensing			


1.2. Pin Assignments

I-8024UW




Terminal No.	Pin Assignment
01	Aout0
02	AGND
03	Aout1
04	AGND
05	Aout2
06	AGND
07	Aout3
08	AGND
09	N/A
10	N/A
11	N/A
12	N/A
13	N/A
14	N/A
15	N/A
16	N/A
17	N.C.
18	Ext.PWR
19	Ext.GND
20	F.G.

I-8028UW




Terminal No.	Pin Assignment
01	Aout0
02	AGND
03	Aout1
04	AGND
05	Aout2
06	AGND
07	Aout3
08	AGND
09	Aout4
10	AGND
11	Aout5
12	AGND
13	Aout6
14	AGND
15	Aout7
16	AGND
17	N.C.
18	Ext.PWR
19	Ext.GND
20	F.G.

I-9024U



Pin Assignment	Terminal No.	Pin Assignment
Vout0	01	Vout1
Iout0	02	Iout1
AGND	03	AGND
Vout2	04	Vout3
Iout2	05	Iout3
AGND	06	AGND
-	07	-
-	08	-
-	09	-
-	10	-
-	11	-
-	12	-
EXT.PWR	13	EXT.PWR
EXT.PWR	14	EXT.PWR
EXT.GND	15	EXT.GND
EXT.GND	16	EXT.GND


I-9028U



Pin Assignment	Terminal No.	Pin Assignment
Vout0	01	Vout1
Iout0	02	Iout1
AGND	03	AGND
Vout2	04	Vout3
Iout2	05	Iout3
AGND	06	AGND
Vout4	07	Vout5
Iout4	08	Iout5
AGND	09	AGND
Vout6	10	Vout7
Iout6	11	Iout7
AGND	12	AGND
EXT.PWR	13	EXT.PWR
EXT.PWR	14	EXT.PWR
EXT.GND	15	EXT.GND
EXT.GND	16	EXT.GND

1.3. Jumper Setting

I-8024U




Voltage output

I-8028U




Current output

1.4. Wire Connections




1.5. Block Diagram




1.6. Dimensions

All dimensions are in millimeters.

I-9024U /I-9028U with Spring clamp terminal connector




I-8024UW /I-8028UW with Spring clamp terminal connector




2. Quick Start

The following is an illustration of the operating procedure for the I-8024UW/I-8028UW/I-9024U/I-9028U module:



ICP DAS provides a range of demo programs for different platforms that can be used to verify the functions of the I-8024UW/I-8028UW/I-9024U/I-9028U. The source code contained in these programs can also be reused in your own custom programs if needed.



We need to check the following steps before running the program.

1. First, user need to download LinPAC SDK, which is includes GNU toolchain, Libraries, header, examples files, etc.
2. Check the power cable, Ethernet cable, VGA monitor, the communication cable between controller and PC has been connected well, and then check the I-8024UW/I-8028UW/I-9024U/I-9028U has been plugged in the controller.
3. Next, check the communication between controller and PC is fine, and download the demo program files to the controller.
4. The following is a list of the locations where both the demo programs and associated libraries can be found on either the ICP DAS web site or the enclosed CD, and I-8024U/I-8028U/I-9024U/I-9028U use the same library and demo.

User can find the related files in the product CD or below website:

PRRODUCT	CPU	DOWNLOAD LINK
LP-8x4x	PXA270	http://www.icpdas.com/en/download/show.php?num=982&model=LP-8441-EN
LP-8x2x/9x2x	AM335x	http://www.icpdas.com/en/download/show.php?num=915&model=LP-8421
LX-8000/9000	x86/E38xx	http://www.icpdas.com/en/download/show.php?num=904&model=LX-9381

3. Power-on Mode

If the module is reset for any reason, the Analog Output will be activated in Power-on Mode so as to avoid any unknown errors that might cause the Analog Output from the module to inflict damage on other devices. This ensures that the output from the I-8024UW/I-8028UW/I-9024U/I-9028U module can be anticipated and guarantees that the output will not damage other devices when the system fail or be reset for any reason.

Two types of Power-on Mode are provided on the I-8024UW/I-8028UW/I-9024U/I-9028U module.

1. Power-on Value Mode
2. Retentive Mode

Power On mode does not support hot plug functionality. When hot plug on PAC Power On mode will not be affected, it only apply on the others cases caused by PAC power reset.

Configuring Power-on Mode

Power-on Mode included Power-on Value Mode and Retentive Mode. Below is a description of the conditions in each mode will apply when an abnormality be encountered and causes the Power-on Mode to be activated.

Mode	Output
Power-on Value Mode	Ser Power On as Power on Value and reset, then the module will output as configured power on value.
Retentive Mode	Ser Power On as Retentive and reset, then the module will output as late output.


If either the PAC or the module encounters an event that causes the hardware reset or the software reset, the Output will be set to those configured for the specific mode.

The following is an overview of the Analog Output value that will be set for the I-9028U module in each of the Power-on Mode conditions:

Mode	Hardware Reset	Software Reset
Power-on Value Mode	AO = Configured Power-on value	AO = Configured Power-on value
Retentive Mode	AO = Previous AO value	AO = Previous AO value


Note: Previous AO value means that after the module reset, the AO value will be retained. For example, if the Power-on Mode is set as Retentive Mode and a hardware reset happened, then the AO value will be the same as the value that existed prior to the hardware reset.

The following is a flowchart that illustrates the outcome of each Power-on Mode:




3.1. Power-on Value Mode

Power-on Value Mode is used to set the output value to the preconfigured Value after an unknown condition has caused the module reset.




3.2. Retentive Mode

Retentive Mode, also known as Virtual Battery Backup Mode, is used to ensure that the previous AO value is retained if an unknown condition has caused the I-9028U module to be reset.




4. Watchdog


The Watchdog Timer (WDT) on the I-9028U module is a software function that monitors the operating status of the module. Its purpose is to prevent problems due to network or communication errors, or host malfunctions, such as situations where the device is affected by noise, or the program is not stable, etc. When the “refresh WDT” function fails and a Watchdog timeout happened, all output values on the module will be set to the Safe Value state in order to prevent the controlled target from performing any erroneous operations.



A common application is provided as an example below. If the system encounters an event that causes it to become unresponsive for any reason, the I-9028U WDT and the WDT provided by the operating system for the 9000-series PAC can be used in combination, thereby preventing the system from hang becoming unresponsive, which may cause the Analog Output to be uncontrolled and result in damage to the device. The WDT on the 9000-series PAC will reset the PAC to solve the unresponsiveness problem, and then the Safe Value will be set for the I-9028U module to prevent the AO from becoming uncontrolled.




The Analog Output value for the module will be as below. When the WDT timeout is triggered, user can consider necessary to set suit WDT timeout interval and safe value to prevent the AO from becoming uncontrolled.




Watchdog operations include basic management operations, such as turning on and refreshing the module. The following sections provide a description of how to programmatically operate the watchdog using the watchdog functions.

Watchdog procedure

The following is an overview of the Watchdog process. More details instructions relating to the notes indicated in the diagrams can be found below. Note that a number of API functions will be used as part of these descriptions. For a more details explanation of these functions, refer to the relevant API reference in Chapter 6.





If a Watchdog timeout occurs and the WDT_Overwrite parameter = 0, all the Analog Output values on the I-9028U will be switched to Safe Values, and any operations where an output value needs to be written will not be accepted until the Watchdog is reset. In contrast, if a timeout occurs and the WDT_Overwrite parameter = 1, any output value that is written will be accepted and will reset the Watchdog.

For more details of how to use the Watchdog function, follow the processes described below.

Note 1: Configuring a Safe Value.

Note 2: Configuring the Watchdog timeout value and enabling the Watchdog

Note 3: Refreshing the Watchdog timer.

Note 4: Checking whether a Watchdog timeout has occurred

Note 5: Checking the communication status if a Watchdog timeout has occurred

Note 6: Writing the AO value when a WDT timeout has occurred and the AO is continually set to the Safe Value

5. API References

ICPDAS supplies a range of C API functions for the I-8024UW/I-8028UW/I-9024U/I-9028U module. When developing a custom program, refer to either the i8028.h header file, or the API functions described in the following sections for more detailed information.

The following is an overview of the functions provided in the LinPAC library - libi8k.a. Detailed information related to individual functions can be found in the following sections.

API naming

Platform	Product included	API prefix characters
Linux	I-8028UW	"i8028U_" + function name
	I-9028U	"i9028U_" + function name

Function	Description
i8028U_Init	Used to initialize the driver and confirm the hardware ID.
i8028U_GetFirmwareVersion	Used to retrieve the version number for the FPGA firmware of the I-9028 module and is used for troubleshooting purposes.
i8028U_GetLibVersion	Used to retrieve the version number for the I-9028 currently installed on the I-9028 module and is used for troubleshooting purposes.
i8028U_ReadAO_GainOffset	Used to retrieve the current gain and offset values for a specified input type and channel.
i8028U_WriteAOHex	Used to write the Analog Output value for a specified channel in hexadecimal format.
i8028U_WriteAO	Used to write the Analog Output value for a specified channel in decimal format.
i8028U_ReadAOHex	Used to read the Analog Output value for a specified channel in hexadecimal format.
i8028U_ReadAO	Used to read the Analog Output value for a specified channel
i8028U_SetPowerOnEnStatus	Used to set the Mode for the Power-on Value.

i8028U_GetPowerOnEnStatus	Used to read the current Mode being used for the Power-on Value.
i8028U_WritePowerOnHex_AO	Used to write the Power -on Value for a specified channel in hexadecimal format.
i8028U_WritePowerOn_AO	Used to write the Power -on Value for a specified channel in decimal format.
i8028U_ReadPowerOnHex_AO	Used to read the current Power -on Value for a specified channel in hexadecimal format.
i8028U_ReadPowerOn_AO	Used to read the current Power -on Value for a specified channel in decimal format.
i8028U_WriteSafeHex_AO	Used to write the Safe Value for a specified channel in hexadecimal format.
i8028U_WriteSafe_AO	Used to write the Safe Value for a specified channel in decimal format.
i8028U_ReadSafeHex_AO	Used to read the current Safe Value for a specified channel in hexadecimal format.
i8028U_ReadSafe_AO	Used to read the current Safe Value for a specified channel in decimal format.
i8028U_SetModuleWDTConfig	Used to configure the attributes for the Watchdog parameter on the I-9028 module.
i8028U_GetModuleWDTConfig	Used to read the current attributes of the Watchdog parameter on the I-9028 module.
i8028U_GetModuleWDTStatus	Used to retrieve the current status of the Watchdog on the I-9028 module.
i8028U_ResetModuleWDT	Used to reset the status of the Watchdog on the I-9028 module.
i8028U_RefreshModuleWDT	Used to refresh the status of the Watchdog on the I-9028 module.

5.1. i8028U_Init

This function is used to initialize the driver and confirm the hardware ID.

Syntax

```
short i8028U_Init(  
    int slot  
);
```

Parameters

slot:

specifies the number of slot (1 ~ 8).

Return Value

0 = the module in the slot is an I-8024U/I-8028U/I-9024U/I-9028U.

-1 = there is no module in this slot.

For other return values, see the Error Codes listed in Appendix A.

Note

Before executing any functions on the I-8024UW/I-8028UW/I-9024U/I-9028U, the `i8028U_Init` function needs to be called once for I-8024U/I-8028U/I-9024U/I-9028U. If there are two or more I-8024UW/I-8028UW/I-9024U/I-9028U modules, you need call the `i8028U_Init` function for each I-8024UW/I-8028UW/I-9024U/I-9028U module individually by passing the slot number that the I-8024UW/I-8028UW/I-9024U/I-9028U module is plugged into.

Example

[C]

```
int slot, err;  
Open_Slot(slot);  
err = i8028U_Init(slot);
```

5.2. i8028U_GetFirmwareVersion

This function is used to retrieve the version number of the FPGA firmware for a specified module. Note that this function is only used for troubleshooting or recording purposes.

Syntax

```
short i8028U_GetFirmwareVersion(  
    int slot,  
    short* ver  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

**ver*:

[output] The version number of the primary FPGA firmware for the module..

Return Value

please refer the Error Code.

Example

[C]

```
short ver = 0, slot = 2;  
Open_Slot(slot);  
i8028U_GetFirmwareVersion (slot, &ver);
```

5.3. i8028U_GetLibVersion

This function is used to retrieve the version number of the 9028 library file currently installed on the I-9028 module. Note that this function is only used for troubleshooting or recording purposes.

Syntax

```
short i8028U_GetLibVersion(void);
```

Parameters

None

Return Value

The version number of the library file currently being used on the module.

Example

[C]

```
short slot=2, ver;  
Open_Slot(slot);  
ver= pac_i8028U_GetLibVersion();
```

5.4. i8028U_ReadAO_GainOffset

This function is used to retrieve the gain and offset values for a specified input type and channel on the I-9028U module.

Syntax

```
void i8028U_ReadAO_GainOffset(  
    int slot,  
    int ch,  
    short gain,  
    unsigned short *gVal,  
    short *oVal  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

gain:

specifies the type code for the gain (0 ~ 5).

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20mA

**gVal:*

[output] the gain value for the input range.

**oVal:*

[output] the offset value for the input range.

Return Value

None

Example

[C]

```
unsigned slot=2, short gVal = 0;
short oVal = 0;
int ch, gain;
Open_Slot(slot);
i8028U_ReadAO_GainOffset(slot, ch, gain, &gVal, &oVal);
```

5.5. i8028U_WriteAOHex

This function is used to write the Analog Output value for a specified channel in hexadecimal format.

Syntax

```
short i8028U_WriteAOHex(  
    int slot,  
    int ch,  
    short gain,  
    short aoHex  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

gain:

specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

aoHex:

specifies the data in hexadecimal format.

Return Value

Please refer the Error Code.

Example

[C]

```
int slot, ch;  
short gain, hVal;  
Open_Slot(slot);  
i8028U_WriteAOHex(slot, ch, gain, hVal);
```

5.6. i8028U_WriteAO

This function is used to write the Analog Output value for a specified channel in decimal format.

Syntax

```
short i8028U_WriteAO(  
    int slot,  
    int ch,  
    short gain,  
    float aoData  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

gain:

specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20mA

aoData:

the data in decimal format.

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2, ch, val;  
short gain;  
Open_Slot(slot);  
i8028U_WriteAO(slot, ch, gain, val);
```

5.7. i8028U_ReadAOHex

This function is used to read the current Analog Output value from a specified channel in hexadecimal format.

Syntax

```
void i8028U_ReadAOHex(  
    int slot,  
    int ch,  
    short *gain,  
    short *aoHex  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

**gain:*

[Output] specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

**aoHex:*

[Output] the data in hexadecimal format.

Return Value

None

Example

[C]

```
int slot=2, ch ,gain;  
short hVal;  
Open_Slot(slot);  
i8028U_ReadAOHex(slot, ch, &gain, &hVal);
```

5.8. i8028U_ReadAO

This function is used to read the Analog Output value from a specified channel in decimal format.

Syntax

```
void i8028U_ReadAO(  
    int slot,  
    int ch,  
    short *gain,  
    float *ao  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

**gain:*

[Output] specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

**ao:*

[Output] the data in decimal format.

Return Value

None

Example

[C]

```
int slot=2, ch, gain;  
float fVal = 0.0;  
Open_Slot(slot);  
i8028U_ReadAO(slot, ch, &gain, &fVal);
```

5.9. i8028U_SetPowerOnEnStatus

This function is used to set the Mode for the Power-on Value.

Syntax

```
short i8028U_SetPowerOnEnStatus(  
    int slot,  
    short status  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

status:

specifies the type for the Power-on Mode (1 - 2), where:

- 1: Power-on Value Mode
- 2: Retentive Mode

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2, type;  
Open_Slot(slot);  
i8028U_SetPowerOnEnStatus(slot, type);
```


5.10. i8028U_GetPowerOnEnStatus

This function is used to read the current Mode being used for the Power-on Value.

Syntax

```
short i8028U_GetPowerOnEnStatus(  
    int slot,  
    short * status  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

**status*:

[output] specifies the type for the Power-on Mode (1 ~ 2), where:

- 1: Power-on Value Mode
- 2: Retentive Mode

Return Value

returns the type for Power-on Mode (1 ~ 2) where:

- 1: Power-on Value Mode
- 2: Retentive Mode

Example

[C]

```
int slot=2, status;  
Open_Slot(slot);  
i8028U_GetPowerOnEnStatus(slot, &status);
```

5.11. i8028U_WritePowerOnHex_AO

This function is used to write the Power-on Value for a specified channel in hexadecimal format.

Syntax

```
short i8028U_WritePowerOnHex_AO(  
    int slot,  
    int ch,  
    short gain,  
    short aoHex  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 – 7)

gain:

specifies the input type (0 - 4), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

aoHex:

the data in hexadecimal format.

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2, ch;  
short gain,hVal;  
Open_Slot(slot);  
i8028U_WritePowerOnHex_AO(slot, ch, gain, hVal);
```

5.12. i8028U_WritePowerOn_AO

This function is used to write the Power-on Value for a specified channel in decimal format.

Syntax

```
short i8028U_WritePowerOn_AO(  
    int slot,  
    int ch,  
    short gain,  
    float aoData  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 – 7).

gain:

specifies the input type (0 - 5), where:

0: 0~ 5 V

1: 0~ 10V

2: +/- 5V

3: +/-10V

4: +/-20 mA

5: 0 ~ 20mA

aoData:

the data in decimal format.

Return Value

0 = No Error,

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2, ch;  
short gain ;  
float fVal;  
Open_Slot(slot);  
i8028U_WritePowerOn_AO(slot, ch , gain, fVal);
```

5.13. i8028U_ReadPowerOnHex_AO

This function is used to read the Power-on Value from a specified channel in hexadecimal format.

Syntax

```
void i8028U_ReadPowerOnHex_AO(  
    int slot,  
    int ch,  
    short *gain,  
    short *aoHex  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 – 7).

**gain:*

[Output] specifies the input type (0 - 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

**aoHex:*

[Output] the data in hexadecimal format.

Return Value

None

Example

[C]

```
int slot=2, ch;  
short gain ,hVal;  
Open_Slot(slot);  
i8028U_ReadPowerOnHex_AO(slot, ch, &gain, &hVal);
```

5.14. i8028U_ReadPowerOn_AO

This function is used to read the Power-on Value from a specified channel in decimal format.

Syntax

```
void i8028U_ReadPowerOn_AO(  
    int slot,  
    int ch,  
    short *gain,  
    float *aoData  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 – 7).

**gain:*

[Output] specifies the input type (0 - 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

**aoData:*

[Output] the data in decimal format.

Return Value

None

Example

[C]

```
int slot=2, ch;  
short gain;  
float fVal;  
Open_Slot(slot);  
i8028U_ReadPowerOn_AO(slot, ch, &gain, &fVal);
```

5.15. i8028U_WriteSafeHex_AO

This function is used to write the Safe Value for a specified channel in hexadecimal format.

Syntax

```
short i8028U_WriteSafeHex_AO(  
    int slot,  
    int ch,  
    short gain,  
    short aoHex  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 – 7).

gain:

specifies the input type (0 - 4), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

aoHex:

the data in hexadecimal format.

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2, ch;  
short gain ,hVal;  
Open_Slot(slot);  
i8028U_WriteSafeHex_AO(slot, ch, gain, hVal);
```

5.16. i8028U_WriteSafe_AO

This function is used to write the Safe Value for a specified channel in decimal format.

Syntax

```
short i8028U_WriteSafe_AO(  
    int slot,  
    int ch,  
    short gain,  
    float aoData  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

gain:

specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5V

3: +/-10 V

4: +/-20 mA,

5: 0 ~ 20 mA

aoData:

the data in decimal format.

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2, ch;  
short gain;  
float fVal;  
Open_Slot(slot);  
i8028U_WriteSafe_AO(slot, ch, gain, fVal);
```

5.17. i8028U_ReadSafeHex_AO

This function is used to read the Safe Value from a specified channel in hexadecimal format.

Syntax

```
void i8028U_ReadSafeHex_AO(  
    int slot,  
    int ch,  
    short *gain,  
    short *aoHex  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

**gain:*

[Output] specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

**aoHex:*

[Output] the data in hexadecimal format.

Return Value

None

Example

[C]

```
int slot=2, ch;  
short gain ,hVal;  
Open_Slot(slot);  
i8028U_ReadSafeHex_AO(slot, ch, &gain, &hVal);
```

5.18. i8028U_ReadSafe_AO

This function is used to read the Safe Value from a specified channel in decimal format.

Syntax

```
void i8028U_ReadSafe_AO(  
    int slot,  
    int ch,  
    short *gain,  
    float *aoData  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

ch:

specifies the channel number (0 ~ 7).

**gain:*

[Output] specifies the input type (0 ~ 5), where:

0: 0 ~ 5 V

1: 0 ~ 10 V

2: +/-5 V

3: +/-10 V

4: +/-20 mA

5: 0 ~ 20 mA

**aoData:*

[Output] the data in decimal format.

Return Value

None

Example

[C]

```
int slot=2, ch;  
short gain;  
float fVal;  
Open_Slot(slot);  
i8028U_ReadSafe_AO(slot, ch, &gain, &fVal);
```

5.19. i8028U_SetModuleWDTConfig

This function is used to configure the attributes for the Watchdog parameter on the I-9028 module.

Syntax

```
short i8028U_SetModuleWDTConfig(  
    int slot,  
    short enStatus,  
    unsigned long wdtTimeout,  
    int ifWDT_Overwrite  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

enStatus:

sets the status of the Watchdog (0 or 1), where:

0: disables the Watchdog

1: enables the Watchdog

wdtTimeout:

sets duration of the Watchdog timeout in hexadecimal format (0~0xff), which is equal to 0 ~ 25.5 seconds

ifWDT_Overwrite:

determines whether or not an AO value can be written if a WDT timeout is currently active (0 or 1), where:

0: an AO value cannot be written if a WDT timeout is currently active

1: an AO can be written even if a WDT timeout is currently active

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2;
short enStatus;
unsigned long wdtTimeout;
int ifWDT_Overwrite;
Open_Slot(slot);
i8028U_SetModuleWDTConfig(slot, enStatus, wdtTimeout, ifWDT_Overwrite);
```

5.20. i8028U_GetModuleWDTConfig

This function is used to read the current attributes of the Watchdog parameter on the I-9028 module.

Syntax

```
short i8028U_GetModuleWDTConfig(  
    int slot,  
    short *enStatus,  
    unsigned long *wdtTimeout,  
    int *ifWDT_Overwrite  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

**enStatus:*

[Output] the current status of the Watchdog (0 or 1), where:

0: Watchdog disabled

1: Watchdog enabled

**wdtTimeout:*

[Output] the current duration that is set for the Watchdog timeout in hexadecimal format (0~0xff), which is equal to 0 ~ 25.5 seconds

**ifWDT_Overwrite:*

[Output] specifies whether or not an AO value can be written if a WDT timeout is currently active (0 or 1), where:

0: an AO value cannot be written if a WDT timeout is currently active

1: an AO can be written even if a WDT timeout is currently active

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2;
short enStatus;
unsigned long wdtTimeout;
int ifWDT_Overwrite;
Open_Slot(slot);
i8028U_GetModuleWDTConfig(slot, &enStatus, &wdtTimeout, &ifWDT_Overwrite);
```

5.21. i8028U_GetModuleWDTStatus

This function is used to retrieve the current status of the Watchdog on the I-9028 module.

Syntax

```
short i8028U_GetModuleWDTStatus(  
    int slot  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

Return Value

Indicates the status of the Watchdog timeout (0 - 1), where:

0: a Watchdog timeout is not currently active

1: a Watchdog timeout is currently active

Example

[C]

```
int slot=2 ,ret;  
Open_Slot(slot);  
ret = i8028U_GetModuleWDTStatus(slot);
```

5.22. i8028U_ResetModuleWDT

This function is used to reset the status of the Watchdog on the I-9028 module.

Syntax

```
void i8028U_ResetModuleWDT(  
    int slot  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2;  
Open_Slot(slot);  
i8028U_ResetModuleWDT(slot);
```

5.23. i8028U_RefreshModuleWDT

This function is used to refresh the status of the Watchdog on the I-9028 module.

Syntax

```
void i8028U_RefreshModuleWDT(  
    int slot  
);
```

Parameters

slot:

specifies the slot number (1 ~ 8).

Return Value

0 = No Error

For other return values, see the Error Codes listed in Appendix A.

Example

[C]

```
int slot=2;  
Open_Slot(slot);  
i8028U_RefreshModuleWDT(slot);
```


Appendix A. Error Code

Error Code	Definition	Description
0	No Error	This error code indicates that there are no errors.
-1	ID Error	This error code indicates that the ID of the module inserted into the specified slot is not for an I-9028U module.
-2	FRAM_ERROR	
-3	MODULE_STATUS_ERROR	
-7	WDTTIMEOUT	

Appendix B. Revision History

This chapter provides revision history information to this document.

The table below shows the revision history.

Revision	Date	Description
1.0.1	January 2018	Initial issue
2.0.0	July 2018	<ul style="list-style-type: none">• Modify library , demo path• Modify API
2.0.1	October 2020	<ul style="list-style-type: none">• Modify LinPAC SDK download path