Classification	ISaGRAF Englis	sh FAQ-06	55				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	1 / 20

ICP DAS Release Stable and Cost-effective Data Acquisition Auto-Report System?

Download FAQ-065 Demo.

1. Introduction

Please refer to Section 2 and 3 for VC++ 6.0 demo program. Please refer to Section 2 and 4 for VB 6.0 demo program. Please refer to Section 6 for more information about Ethernet security.

Many applications need to monitor/collect large amount of I/O and acquisition data distributed in widespread location for safety and management. The usual way to implement this is to apply one or couples of central PC/Server to poll (request one by one in turn) every PAC/PLC periodically in every spread location. This generates three disadvantages.

- (1) The CPU loading of the central PC/Server will become too heavy. That is because it must request every distributed local PAC one by one in turn periodically. So the result is the PC/Server becoming un-effective.
- (2) The second one is when the amount of local PACs is a little more or large, the PC/Server can not handle emergency events (because it request PAC in turn).
- (3) Every local PAC should setup a fixed Internet IP address for the PC/Server to request them. This waste money and Internet resource a lot.

ICP DAS ISaGRAF PACs I-7188EG, I-8437-80, and I-8837-80 support Auto-report data acquisition and I/O data to the remote Internet PC/Sever via UDP/IP protocol. They can be setup to report periodically and report at any time when emergency event happens. Moreover, at any time, the PC/Server can send command to the local PAC if necessary. For example, the time synchronization. This feature is very useful in the below three applications.

Useful Applications:

- 1. Distributed energy monitoring/management system, like electric power, gas, oil, water dam, etc.
- 2. Distributed facility safety monitoring/management system, like elevator, building, stock room, etc.
- 3. Other possible distributed data acquisition system.



- 1. If local PAC is I-7188EG, the price is much cost-effective compared with other PLC/PAC if they have similar solution. (ICP DAS I-7188EG, I-8437-80, and I-8837-80 all support this feature)
- The distributed local PAC doesn't need a fixed Internet IP. There is no limitation of the distance between the local PAC and the central PC/Server, 100 meters, 1 kilo-meter,..., 10000 kilo-meters are all possible.
- 3. Provides 4-Level Internet security protection.
 - Level 1: PAC do auto-report only if it wish do. PAC can be programmed to refuse any communication data coming from Internet normally. The PAC can be designed only accept one valid command when it auto-report data to the PC/Server, after that it can refuse any data again.
 - Level 2: "Security Password". Every delivered data between local PAC and PC/Server all add a "Security Password" protection.
 - Level 3: IP protection. PAC can be programmed to accept data only coming from one or couples of selected Internet IP address.
 - Level 4: Programmer can design his own security protection in both PAC and the PC/Server.

Classification	ISaGRAF Englis	sh FAQ-06	55				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	3 / 20

- 4. Local PAC will automatically report its acquisition and I/O data to remote PC/Server. It can report periodically and report when an emergency event triggered. Moreover, at any time, the PC/Server can send command to the local PAC if necessary. For example, the time synchronization command.
- 5. ICP DAS ISaGRAF PACs support various I/O modules, such as I-7000 series, I-87K series remote I/O. Also support Modbus RTU devices created by others, like Modbus power meters, Modbus inverters, Modbus temperature PACs ...
- 6. PACs support ISaGRAF with IEC61131-3 PLC standard, which provides Ladder Diagram, Structure Text, Function Block, IL, SFC and Flow Chart PLC languages. Easy to use and easy programming.
- ICP DAS provides VC++6.0 and VB6.0 and VB.net 2005 sample program which can run in PC/Server. And also provides ISaGRAF sample program for running in I-7188EG, I-8437-80, and I-8837-80 PACs. Please visit http://www.icpdas.com/en/faq/index.php?kind=280#751 FAQ-065.

Classification	ISaGRAF Englis	sh FAQ-06	55				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	4 / 20

2. Install software and hardware for demo testing

Please visit http://www.icpdas.com/en/faq/index.php?kind=280#751 FAQ-065 to download the related document and demo program. To know more about the UDP protocol for this demo, please refer to section 5.

ISaGRAF demo program

If the PAC is I-7188EG, please use "..\faq065_demo**demo_74.pia**" (7188EG since driver version of 2.18) If the PAC is I-8437-80 or I-8837-80, please use "..\faq065_demo**wdemo_61.pia**" (I-8x37 since driver version of 3.20)

Hardware configuration:

Note that the WinCon-8xx7 has been phased out, Visit the ISaGRAF website for more information about new PACs. https://www.icpdas.com/en/product/guide+Software+Development___Tools+ISaGRAF



Please set IP address of your testing PC to a Fixed IP = 10.0.0.91, Mask = 255.255.255.0.

The testing PAC can be one of I-7188EG or I-8437-80 or I-8837-80. Please set its IP address as a Fixed IP = 10.0.0.103 , Mask = 255.255.255.0

Note:

Sometimes PC/Server reside at the Internet with a fixed Internet IP address. Then all the local PACs in the same application must assign its proper Gateway IP. The value of this "Gateway IP" can be found in a PC which is in the same local area with the local PAC.

First please set IP of that PC as DHCP (Obtain an IP address automatically), then open a Command Prompt, key-in "ipconfig" as below, then we got the Gateway IP setting.

Classification	ISaGRAF Engl	sh FAQ-0	65				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	5 / 20
cw 命令提; C: \Docum Windows Ethernet C: \Docum	赤字元 ments and Settin IP Configuratio adapter 區域通 Connection-spec IP Address Subnet Mask Default Gateway ments and Settin	ogs \Admini on 線: ific DNS , ogs \Admini	strator> ipc Suffix b 	onfig anchiao. 0.0.0.91 55.255.2 0.0.0.25	icpdas.com 255.0 4		
Here we use one "DCON Utility". as disable and se	e I-7018Z I/O mo Please set its "Al et its Ch.1 throug	dule in thi DDR" as 1, gh Ch.10 as	s demo. Please "Baud rate" as s "T/C K-Type".	do initia 9600, "	al configuratic Format" as 2's	on for it by s complem	using the ent, Checksum'

Then if the PAC is **I-7188EG**, please connect this I-7018Z module at its **COM2: RS-485**. And then wire an external resistor about 110 to 330 ohms to be between the D2+ and D2- pin of the I-7188EG's COM2: RS485 port. Then recycle the power of I-7188EG. And then download the ISaGRAF demo program "demo_74" to I-7188EG.

If the PAC is **I-8437-80 or I-8837-80**, please connect this I-7018Z module at its **COM3: RS-485**. And then wire an external resistor about 110 to 330 ohms to be between the D+ and D- pin of the PAC's COM3: RS485 port. Then recycle the power of the PAC. And then download the ISaGRAF demo program "wdemo_61" to the PAC.

If successfully download ISaGRAF program, the below similar window will show up.

Sagraf - WDEMO_6	1 - Debugger			
File Control Tools Option	ns <u>H</u> elp			
))I ≈ 🕨 N 🕨	😚 🕮 🗭			
RUN allowed=0	current=3	maximum=15	overflow=0	

Classification	ISaGRAF Englis	sh FAQ-06	55				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	6 / 20

<u>File E</u> dit <u>O</u> ptio	ons <u>H</u> elp	
🗅 🖹 🕍 🔺	- 🗄 🛰 🔍 👘	
Name	Value	Comment
Year1	2007	
Month1	5 🚽	Date & Time of Local PAC
Day1	30	
Hour1	13	
Minute1	8	Auto-report Interval setting and progressing
Second1	17	
state1		receiving state information
l'I Poport interval	(1#598574ms)	timer to snow the time elapse
Timeout_interval	1#1111	interval to report data to PC / Server, initias 1 minu interval that PC (Server pust yearly lipit op 15 geog
need	1001 186315483	File variating recoder that reply , init as to second
D No	1863154825	modified before every sending init as -1
nsq2	1000101020	the coming message
p port	0	UDP IP port No. of the sender
nsq ip addr	-	ip addr of the sender (string format)
R_Command	0	Command in the coming data

"Msg1" is the message from Local PAC sent to the PC/Server.

"Msg2" is the reply message from the PC/Server to Local PAC.

"Msg_ip_addr" and "ip_port"

are the source IP address and UDP port No. which sent message to the local PAC. Normally, it is the IP and port No. of the central PC/Server. If it is not, that means some other un-friendly station or PC sending UDP data to the Local PAC.

"R_Command"

is the <command> field in the message from the PC/Server. (Here in this demo is 2 or 4)

Then please run VC++ 6.0 **demo_01** program in your testing PC (refer to Section 3) , or run VB 6.0 **demo_7** program in your testing PC (refer to Section 4).

Classification	ISaGRAF Englis	sh FAQ-06	55				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	7 / 20

3. VC++ 6.0 demo program

Please finish the steps listed in Section 2 first before doing the steps in this section.

Please set your PC's IP address to a fixed IP = 10.0.0.91, Mask = 255.255.255.0 for testing this demo. (Because the ISaGRAF demo program "demo_74" and "wdemo_61" running on the Local PAC will report message to the PC with IP = 10.0.0.91 and with UDP port No. = 12001)

The VC++ 6.0 demo program "**demo_01.exe**" resides at "...\vc++6_demo\demo_01\release\" (Please visit http://www.icpdas.com/en/faq/index.php?kind=280#751 FAQ-065 to download it.) Please run MS. VC++ 6.0 development studio to open the source code of this "demo_01", the file is "...\vc++6_demo\demo_01**demo_01.dsw**"

To run "**demo_01.exe**", open a Command Prompt on the PC first. Then get into folder of "...\vc++6_demo\demo_01\release\" to click it. Then key-in the command as below to run it.

Syntax: demo_01 UDP_port Security_passwd (file_name)

"UDP_port" is the UDP port No. which this PC is going to bind it to receive message coming from local PACs (value can be 1001 to 65535). This demo uses value of 12001.

"Security_passwd" is the protocol security password. Value can be 0, or 1 to 2147483647, or -2147483647 to -1. This demo uses value of 1234567.

"File_name" is an option. You may specify it or leave it empty. If specifying a name to it, then demo_01.exe will create a new empty file to record all valid message from the local PACs.

Example 1:	Demo_01	12001	1234567	
Example 2:	Demo_01	12001	1234567	data1.txt

🔤 I8xx7 - demo_01 12001 1234567 data1.txt
D:\Chun_D\WC++6_project\demo_01\Release> demo_01 12001 1234567 data1.txt
Demo of Receiving message via UDP/IP from ISaGRAF controller and then reply back a time synchronization frame to the controller.
More information at www.icpdas.com - FAQ - Software - ISaGRAF - 065
Please set IP of this PC as a fixed IP = 10.0.0.91 Mask = 255.255.255.0 , Contro 11er IP = 10.0.0.103 , Mask = 255.255.255.0
Please run ISaGRAF program "Demo_74" in the i-7188EG (driver since 2.18) . or run ISaGRAF program "WDemo_61" in the W-8xx7 (driver since 3.37) or i-8x37 (driver since 3.20) .
To exit this program, please press at Ctrl-C
The given parameter are : UDP_port_No = 12001 Security_passwd = 1234567
Starting at 2007/7/23, 11:13:6

Classification	ISaGRAF Englis	sh FAQ-06	5				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	8 / 20

How to test?

The local PAC will send message to the PC/Server when below events happen in this demo.

- 1. 15 seconds later after the Local PAC is power up. (This only deliver once)
- 2. Send once at every minute past. (Continuously and periodically)

In the following item 3 to item 8, local PAC will send once when each event happens.

- 3. If the RS-485 communication between the Local PAC and I-7018Z is broken.
- 4. If the RS-485 communication between the Local PAC and I-7018Z is back to OK again.
- 5. If any one of I-7018Z's Ch.1 through Ch.10's temperature sensor is damaged or broken.
- 6. If any one of I-7018Z's Ch.1 through Ch.10's temperature sensor is back to OK again.
- 7. If any one of I-7018Z's Ch.1 through Ch.10's temperature reading larger than 60 degree Celsius.
- 8. If any one of I-7018Z's Ch.1 through Ch.10's temperature reading is back to under 60 degree Celsius again.
- A. After **demo_01.exe** is running, please disconnect the RS-485 connection between the I-7018Z and the Local PAC. It should display a coming message from the local PAC similar as below.

```
🐨 命令提示字元
                                                                   - 🗆 ×
C:\Chun\udp_ip_demo\demo_01\Release>
                                 demo_01
                                         12001
                                               1234567
                                                       data1.txt
                                                                       .
Demo of Receiving message via UDP/IP from ISaGRAF controller and then
 reply back a time synchronization frame to the controller.
Please run ISaGRAF program "Demo_74" in the i-7188EG (driver since 2.18) control
ler
 or run ISaGRAF program "WDemo_61" in the W-8xx7 (driver since 3.37) or i-8x37
(driver since 3.20) controller.
To exit this program, please press at Ctrl-C
The given parameter are :
 UDP_port_No = 12001
 Security_passwd = 1234567
Starting at 2007/5/30, 15:38:46
try to create socket... Ok
Wait data coming ...
1: Receive 116 characters... "1001,42402515,1,2007,5,30,15,38,54,0,999990,99990
,999990,999990,999990,2390,999990,999990,999990,999990,57357,13234"
 Receive 22 integers well ~
 Command is from controller Station No. = 1001 , Command=1
  Controller local time is 2007/5/30 , 15:38:54
  Communication between this local controller and the i-7018z is broken !
  Temperature (Ch.1 to 10) ... " > 9900.0 means sensor is broken !!!"
   [[ 9999.90]] [[ 9999.90]] [[ 9999.90]] [[ 9999.90]] [[ 9999.90]]
         23.90 [[ 9999.90]] [[ 9999.90]] [[ 9999.90]] [[ 9999.90]]
```

Classification	ISaGRAF Englis	sh FAQ-06	55				
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	9 / 20

- B. Then please recover the RS-485 connection between the I-7018Z and the PAC. It should display a coming message.
- C. Please observe if receiving a message every minute.
- D. Please measure the temperature of a glass of hot water by one channel K-type sensor of the I-7188Z. If the temperature is over 60 degree Celsius, it should display a message. And then if the temperature is back to under 60 degree Celsius again, one another Message should be displayed.
- E. Remove one channel K-type sensor from the I-7018Z, it should receive one message. Then recover it, another message should be received.
- F. This demo provides a time synchronization feature. If the date and time sent by the local PAC differ more than 20 seconds than the time on the PC/Server, the PC will drop this message and reply back <command> = 4 to inform the local PAC to adjust its date and time and then send data to the PC/Server once again.

(Here use so big value of 20 seconds because the application may be applied in the Internet. Sometime the Internal communication is busy. If your application is in local intranet, you may reduce this value to, for example, 5 seconds).

User can modify the date or time on the PC/Server, then you will see the PAC 's date and time will be modified also when it sends next message to the PC/Server.

Classification	ISaGRAF English FAQ-065						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	10 / 20

4. VB 6.0 demo program

Please finish the steps listed in section 2 first before doing the steps in this section.

Please set your PC 's IP address to a fixed IP = 10.0.0.91 , Mask = 255.255.255.0 for testing this demo. (Because the ISaGRAF demo program "demo_74" and "wdemo_61" running in the Local PAC will report message to the PC with IP = 10.0.0.91 and with UDP port No. = 12001)

The VB 6.0 demo program "**demo_7.exe**" resides at "...\vb6_demo\demo_7\" (Please visit http://www.icpdas.com/en/faq/index.php?kind=280#751 FAQ-065 to download it.) Please run MS. VB 6.0 development studio to open the source code of this "demo_7", the file is "...\vb6_demo\demo_7\demo_7.vbp"

After running this "**demo_7.exe**", a "VB 6.0 Demo_7" window will show up as below. Please enter the proper value of the following items and then click on "**Start**" to test it.

"UDP_port_No"	is the UDP port No. which this PC is going to bind it to receive message coming
	from local PACs (value can be 1001 to 65535). This demo uses value of 12001.
"Security_passwd"	is the protocol security password . Value can be 0, or 1 to 2147483647, or
	-2147483647 to -1. This demo uses value of 1234567.
"Output_File_name"	is an option. You may specify it or leave it empty. If specifying a name to it, then
	demo_01.exe will create a new empty file to record all valid message from the

local PACs.

Please refer to www.icpdas.com · FAQ · Software · ISaGRAF · 065 for more. Please set PC IP=10.0.091 , Controller IP=10.0.0103 Mask=255.255.255.0 Local controller · 7188E G, i58.37 or W-58x7 will auto-report data to this PC / Server via UDP IP protocol. Hardware configuration: Dere i64780 or W-8347 link ts CDM2:R5485 to one i7018z (ADDR=1, 9600, 8),1, No-Checksum, 10-Ch. as Thermo-Couple K-type) or Dere i7188E G, ink its CDM2:R5485 to one i7018z (ADDR=1, 9600, 8),1, No-Checksum, 10-Ch. as Thermo-Couple K-type) or Dere i7188E G, link its CDM2:R5485 to one i7018z (ADDR=1, 9600, 8),1, No-Checksum, 10-Ch. as Thermo-Couple K-type) or Dere i7188E G, link its CDM2:R5485 to one i7018z (ADDR=1, 9600, 8),1, No-Checksum, 10-Ch. as Thermo-Couple K-type) or This program is to receive udp frame from a i77188E G or i68.37 or W-8xx7 If the local controller is i-8x37 (driver since 3.20) or Wincon-8xx7 (driver since 3.37), it should run ISaGRAF demo program "WDemo_61" Parameters UDP_port_No: 12001 Security_passwd: 1234567 Output_File_name: data1.txt Vinsock state: Socket closed I Please click 'Stat' button to stat it. 2007/6/7 11:58:56 Data in Controller station No. = 1001 Ch.03: Ch.07: Ch.08: Ch.08: Ch.09: Ch.09: Ch.09:	STREAM ST										
Parameters UDP_port_No : 12001 Security_passwd : 1234567 Output_File_name : data1.txt Start Stop Winsock state : Socket closed ! Please click 'Start' button to start it. 2007/6/7 11:58:56 Data in Controller station No. = 1001 Ch.03 : Ch.04 : Ch.05 Ch.06 : Ch.07 : Ch.08 : Ch.09 : Ch.10 : i-7018z Comm. state : ICP DAS Co. Ltd Technical Document	Please refer to www.icpdas.com - FAQ - Software - ISaGRAF - 065 for more. Please set PC IP=10.0.0.91, Controller IP=10.0.0.103 Mask=255.255.0 Local controller - 7188EG, i-8x37 or W-8xx7 will auto-report data to this PC / Server via UDP IP protocol. Hardware configuration: One i-8437-80 or W-8347 link its CDM3:RS485 to one i-70182 (ADDR=1, 9600, 8,N,1, No-Checksum, 10-Ch. as Thermo-Couple K-type) or One i-7188EG link its CDM2:RS485 to one i-70182 (ADDR=1, 9600, 8,N,1, No-Checksum, 10-Ch. as Thermo-Couple K-type) 1. This program is only for demo purpose. ICP DAS and Chun has no responsibility for it. 2. This program is to receive udp frame from a i-7188EG or i-8x37 or W-8xx7 If the local controller is i-7188EG (driver since 2.18), it should run ISaGRAF demo program "Demo_74" If the local controller is i-8x37 (driver since 3.20) or Wincon-8xx7 (driver since 3.37), it should run ISaGRAF demo program "WDemo_61"										
Winsock state: Socket closed I Please click 'Start' button to start it. 2007/6/7 11:58:56 Data in Controller station No. = 1001 Ch.01: Ch.02: Ch.03: Ch.05: Ch.06: Ch.07: Ch.08: Ch.08: Ch.07: Ch.08: Ch.09: Ch.09: Ch.10: i-7018z Comm. state : ICP. DAS Co. Ltd. Technical Document	Parameters UDP_port_No : 12001 Security_passwd : 1234567 Output_File_name : data1.txt Start Stop										
Data in Controller station No. = 1001 Ch.01 : ···· Ch.02 : ···· Ch.03 : ···· Ch.04 : ···· Ch.05 ···· Ch.06 : ···· Ch.07 : ···· Ch.08 : ···· Ch.09 : ···· Ch.10 : ···· i-7018z Comm. state : ····	Winsock state : Socket closed ! Please click 'Start' button to start it. 2007/6/7 11:58:56										
Ch.01: Ch.02: Ch.03: Ch.04: Ch.05: Ch.05: Ch.06: Ch.06:<	Data in Controller station No. = 1001										
Ch.07: Ch.08: Ch.09: Ch.10: i-7018z Comm. state :	Ch.01 : Ch.02 : Ch.03 : Ch.04 : Ch.05 Ch.06 :										
ICP DAS Co. Ltd. Technical Document	Ch.07 : Ch.08 : Ch.09 : Ch.10 : i-7018z Comm. state :										
ICP DAS Co. Ltd. Technical Document											
ICP DAS Co. Ltd. Technical Document											
ICP DAS Co. Ltd. Technical Document											
ICP DAS Co. Ltd. Technical Document											
ICP DAS Co. 1td Technical Document											
ICP DAS Co. 1td Technical Document											
	ICP DAS Co., Ltd. Technical Document										

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	11 / 20

How to test?

The local PAC will send message to the PC/Server when below events happen in this demo.

- 1. 15 seconds later after the Local PAC is power up. (This only deliver once)
- 2. Send once at every minute past. (Continuously and periodically)

In the following item 3 to item 8, local PAC will send once when each event happens.

- 3. If the RS-485 communication between the Local PAC and I-7018Z is broken.
- 4. If the RS-485 communication between the Local PAC and I-7018Z is back to OK again.
- 5. If any one of I-7018Z 's Ch.1 through Ch.10 's temperature sensor is damaged or broken.
- 6. If any one of I-7018Z 's Ch.1 through Ch.10 's temperature sensor is back to OK again.
- 7. If any one of I-7018Z 's Ch.1 through Ch.10 's temperature reading larger than 60 degree Celsius.
- 8. If any one of I-7018Z 's Ch.1 through Ch.10 's temperature reading is back to under 60 degree Celsius again.
- A. After **demo_7.exe** is running, please disconnect the RS-485 connection between the I-7018Z and the Local PAC. It should display a coming message from the local PAC similar as below.

VB60 Demo 7 III	DP Demo - PC / Serve	r				
ease refer to www.icpdas. cal controller - 7188EG, i- One i-8437-80 or W-8347 One i-7188EG link its CON This program is only for d This program is to receive f the local controller is i-71	.com - FAQ - Software - IS -8x37 or W-8xx7 will auto-r link its CDM3:RS485 to o 42:RS485 to one i-7018z j emo purpose, ICP DAS ar s udp frame from a i-7188E 88EG (driver since 2.18).	aGRAF - 065 for more. report data to this PC / 9 ne i-70182 (ADDR=1, 9 (ADDR=1, 9600, 8,N,1, d Chun has no respons EG or i-8x37 or W-8xx7 it should run ISaGRAF (Please set PC IP=10.0.0 Server via UDP IP protoco 600, 8,N,1, No-Checksum No-Checksum, 10-Ch. as ibility for it. demo program "Demo_74"	.91 , Controller IP=10.0 bl. Hardware conf , 10-Ch. as Thermo-Co Thermo-Couple K-type	0.0.103 Ma: iguration: buple K-type e)	k=255.255.255.0 a) or
f the local controller is F8x Parameters UDP_port_No : 12001	37 (driver since 3.20) or W	Vincon-8xx7 (driver sinc	e 3.37), it should run ISaG Output_File_name : dat	a1.txt	VDemo_61	Stop
finsock state : Socket op	pen !			20	07/6/7 12	14:41
Data in Controller station M Ch.01 : Broken	No. = 1001 Ch.02 : Broken	Ch.03 : Broken	Ch.04 : Broken	Ch.05 Broken	Ch.06	23.9 °C
Ch.07 : Broken	Ch.08 : Broken	Ch.09 : Broken	Ch.10 : Broken 🧹	i-7018z Comm. s	tate : B	roken
eply 46 bytes 9001,53	1976561,2,2007,6,7,12,14	4,36,30355,21679				

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	12 / 20

- B. Then please recover the RS-485 connection between the I-7018Z and the PAC. It should display a coming message.
- C. Please observe if receiving a message every minute.
- D. Please measure the temperature of a glass of hot water by one channel K-type sensor of the I-7188Z. If the temperature is over 60 degree Celsius, it should display a message. And then if the temperature is back to under 60 degree Celsius again, one another Message should be displayed.
- E. Remove one channel K-type sensor from the I-7018Z, it should receive one message. Then recover it, another message should be received.
- F. This demo provides a time synchronization feature. If the date and time sent by the local PAC differ more than 20 seconds than the time on the PC/Server, the PC will drop this message and reply back <command> = 4 to inform the local PAC to adjust its date and time and then send data to the PC/Server once again.

(Here use so big value of 20 seconds because the application may be applied in the Internet. Sometime the Internal communication is busy. If your application is in local intranet, you may reduce this value to, for example, 5 seconds).

User can modify the date or time on the PC/Server, then you will see the PAC date and time will be modified also when it sends next message to the PC/Server.

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	13 / 20

5. UDP protocol definition in the demo listed in this document

This protocol definition is valid for the ISaGRAF demo program "**demo_74**" and "**Wdemo_61**" and VC++ 6.0 demo program "**demo_01**" and VB 6.0 demo program "**demo_7**".

1. Local PAC is as UDP Client , while PC/Server is as UDP Server. Only Local PAC can auto-send data (message/string) to the PC/Server.

(The message variable - "IP_correct_PC" and integer variable - "Port_correct_PC" in the ISaGRAF demo program "demo_74" and "Wdemo_61" specify the IP address and UDP port No. of the target PC/Server. And also there is similar definition of the target PC/Server in the ISaGRAF IO connection window - "udp_ip").

 PC/Server must reply a message with <Command> = 2 or 4 to the local PAC in 15 seconds after it receives a valid message from the local PAC. The replied message must contain the exact same <ID No.> as the <ID No.> it received from the local PAC.

The local PAC will drop the replied message with incorrect <ID No.>. If the local PAC doesn't receive a valid replied message from the PC/Server in 15 seconds, it will send message once to the PC/Server with a different <ID No.>. Then if PC/Server still not replied it in 15 seconds, local PAC will continuously send message again until it receives a valid replied message.

(The timer variable - "Timeout_interval" in the ISaGRAF demo program "demo_74" and "Wdemo_61" defines this Timeout value)

- 3. The local PAC will send message to the PC/Server when below events happen in this demo.
 - (1) 15 seconds later after the Local PAC is power up. (This only deliver once)
 - (2) Send once at every minute past. (Continuously and periodically)

In the following item (3) to item (8), local PAC will send once when each event happens.

- (3) If the RS-485 communication between the Local PAC and I-7018Z is broken.
- (4) If the RS-485 communication between the Local PAC and I-7018Z is back to OK again.
- (5) If any one of I-7018Z 's Ch.1 through Ch.10 's temperature sensor is damaged or broken.
- (6) If any one of I-7018Z 's Ch.1 through Ch.10 's temperature sensor is back to OK again.
- (7) If any one of I-7018Z 's Ch.1 through 10 's temperature reading larger than 60 degree Celsius.
- (8) If any one of I-7018Z 's Ch.1 through 10 's temperature reading is back to under 60 degree Celsius again.

Classification	ISaGRAF Englis	ISaGRAF English FAQ-065					
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	14 / 20

4. UDP message format of Local PAC sending to the PC/Server.

Security_passwd: Must be specified as the same value in the ISaGRAF IO connection window – "udp_ip" and in the PC VC++ and VB demo program to communicate well.

Value can be 0: means "No encoding" (it is not safe), or 1 to 2147483647, or -2147483647 to -1 (none-zero value means "with encoding", it is much safe).

If setting as a none-zero value, please refer to the "convert_to_udp_deliver_buf()", "convert_back_udp_deliver_buf()" and "udp_ip_crc()" function in the VC++ 6.0 "demo_01" or VB 6.0 "demo_7" for its encoding algorithm.

When setting "Security_passwd" as 0, every delivered message can not exceed 255 bytes.

When setting "Security_passwd" as none-zero value, every delivered message can not exceed 259 bytes. The last added 4-bytes is the <4-byte-Checksum > calculated by the "udp_ip_crc()" function.

Local PAC will send the below format to the PC/Server

Security_passwd is 0: (No 4-byte-Checksum at the end)

<Station_No of local PAC>,<ID No.>,<Command>,

<Year>,<Month>,<Day>,<Hour>,<Minute>,<second>,<I-7018Z Comm. state>,

<C1>,<C2>,<C3>,<C4>,<C5>,<C6>,<C7>,<C8>,<C9>,<C10>,

<User-defined CRC>

For example:

1001,850334470,1,2007,5,30,17,31,51,1,999990,999990,999990,999990,999990,2360, 999990,999990,999990,999990,46677,18632

It means,

<Station_No of local PAC> is 1001

<ID No.> is 850334470

<Command> is 1

PAC's date and time is 2007/5/30 , 17:31:51

< I-7018Z Comm. state > is 1 : RS-485 communication OK

The temperature reading value of Ch.1 through Ch.10 are,

broken, broken, broken, broken, broken, 23.60 degree, broken, broken, broken, broken

(value of 999990 means T/C Sernsor is broken)

< User-defined CRC > is 46677,18632

r lacenneannn	ISaGPAF Eng	lish FAO. O	65							
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	15 / 20			
						3				
Security_	passwd is not 0	: (Wit	n 4-byte-Cl	hecksum a	t the end)					
<statio< td=""><td>n_No of local P/</td><td>AC>,<id no<="" td=""><td>.>,<comma< td=""><td>and>,</td><td></td><td></td><td></td></comma<></td></id></td></statio<>	n_No of local P/	AC>, <id no<="" td=""><td>.>,<comma< td=""><td>and>,</td><td></td><td></td><td></td></comma<></td></id>	.>, <comma< td=""><td>and>,</td><td></td><td></td><td></td></comma<>	and>,						
<year>,</year>	<month>,<day< td=""><td>>,<hour>,<</hour></td><td>Minute>,<</td><td>second>,<</td><td>-7018Z Comm.</td><td>state>,</td><td></td></day<></month>	>, <hour>,<</hour>	Minute>,<	second>,<	-7018Z Comm.	state>,				
<c1>,<c2>,<c3>,<c4>,<c5>,<c6>,<c7>,<c8>,<c10>,</c10></c8></c7></c6></c5></c4></c3></c2></c1>										
<user-defined crc=""><4-byte-Checksum></user-defined>										
<commar< td=""><td>d> definition:</td><td></td><td></td><td></td><td></td><td></td><td></td></commar<>	d> definition:									
1 : Loc	al PAC report d	ata to the F	PC/Server							
			-,							
<i-7018z (<="" td=""><td>Comm. state> d</td><td>lefinition:</td><td></td><td></td><td></td><td></td><td></td></i-7018z>	Comm. state> d	lefinition:								
1 : RS-485 communication is OK between local PAC and I-7018Z										
0 : RS-	485 communica	ation is bro	ken betwe	en local PA	C and I-7018Z					
<user-def< td=""><td>ined CRC> defi</td><td>nition:</td><td></td><td></td><td></td><td></td><td></td></user-def<>	ined CRC> defi	nition:								
< User-dei Can be	ined CRC> defi defined as a dif	nition : ferent algo	rithm by tl	ne User. Th	iis demo apply t	he followin	g algorithm			
< User-def Can be (Please	ined CRC> defind defined as a dif apply a differer	nition : ferent algo nt algorithn	rithm by th n in real ap	ne User. Th oplication f	iis demo apply t or safety)	he followin	g algorithm			
< User-def Can be (Please Value is fix	ined CRC> defined as a dif apply a different apply a different	nition: ferent algo nt algorithn (Charactor)	rithm by th n in real ap	ne User. Th oplication f	iis demo apply t or safety)	he followin	g algorithm			
< User-del Can be (Please Value is fix	ined CRC> defined as a dif apply a different ad as 11 bytes	nition: ferent algo nt algorithn (Character)	rithm by th n in real ap . It contain	ne User. Th oplication f ns two valu	iis demo apply t or safety) ue of 0 to 65535	he followin separated	g algorithm by a ","			
< User-def Can be (Please Value is fix For examp	ined CRC> defined as a dif apply a differen ed as 11 bytes le,	nition: ferent algo nt algorithn (Character)	rithm by th n in real ap . It contain	ne User. Th oplication f ns two valu	iis demo apply t or safety) ue of 0 to 65535	he followin separated	g algorithm by a ","			
<user-def< b=""> Can be (Please Value is fix For examp</user-def<>	ined CRC> defi defined as a dif apply a differen ed as 11 bytes le,	nition: ferent algo nt algorithn (Character)	rithm by th n in real ap . It contain	ne User. Th oplication f ns two valu	iis demo apply t or safety) ue of 0 to 65535	he followin separated	g algorithm by a " <i>,"</i>			
<user-def< b=""> Can be (Please Value is fix For examp valu</user-def<>	ined CRC> defined as a dif apply a different ad as 11 bytes le, e_1 value	nition: ferent algo nt algorithn (Character)	rithm by th n in real ap . It contain Fixe	ne User. Th oplication f ns two valu e d Length c	iis demo apply t or safety) ue of 0 to 65535 of 11 Bytes (Cha	he followin separated racter)	g algorithm by a ","			
<user-def< b=""> Can be (Please Value is fix For examp valu</user-def<>	ined CRC> defi defined as a dif apply a different red as 11 bytes le, e_1 value 0 0	nition: ferent algo nt algorithm (Character)	rithm by th n in real ap . It contain Fixe 0	ne User. Th oplication f ns two valu e d Length c , 0'	iis demo apply t or safety) ue of 0 to 65535 of 11 Bytes (Cha (with 4 Space C	he followin separated racter) har. before	g algorithm by a "," : 'O')			
 <user-def< li=""> Can be (Please Value is fix For examp valu valu </user-def<>	Fined CRC> defined as a dif defined as a dif apply a different and as 11 bytes le, e_1 value 0 0 1 1	nition: ferent algo nt algorithm (Character)	rithm by th n in real ap . It contain Fixe ' 0, ' 1,	ne User. Th oplication f ns two valu e d Length c , 0' , 1'	iis demo apply t or safety) ue of 0 to 65535 of 11 Bytes (Cha (with 4 Space C (with 4 Space C	he followin separated racter) har. before	g algorithm by a "," • 'O') • '1')			
 <user-def< li=""> Can be (Please Value is fix For examp value (0) 21 </user-def<>	ined CRC> defined as a dif defined as a dif apply a different aed as 11 bytes le, e_1 value 0 0 L 21	nition: ferent algo nt algorithm (Character)	rithm by th n in real ap . It contain Fixe ' 0, ' 1, ' 21,	ne User. The polication for two values two values of the second s	iis demo apply t or safety) ue of 0 to 65535 of 11 Bytes (Cha (with 4 Space C (with 4 Space C (with 3 Space C	he followin separated racter) har. before har. before	g algorithm by a "," • '0') • '1') • '2')			
 <user-def< li=""> Can be (Please Value is fix For examp value (2: 32: </user-def<>	ined CRC> defined as a dif defined as a different apply a different ted as 11 bytes le, 0 0 L 21 L 321	nition: ferent algo nt algorithm (Character)	rithm by th n in real ap . It contain Fixe ' 0, ' 1, ' 21 ' 321	ne User. The polication for two values two values of the second s	iis demo apply t or safety) ue of 0 to 65535 of 11 Bytes (Cha (with 4 Space C (with 4 Space C (with 3 Space C (with 2 Space C	he followin separated racter) har. before har. before har. before	g algorithm by a "," • '0') • '1') • '2') • '3')			
 <user-def< li=""> Can be (Please Value is fix For examp value (1) 22 322 4322 </user-def<>	ined CRC> defined as a dif defined as a different apply a different acd as 11 bytes le, e_1 value 0 0 L 21 L 321 L 4321	nition: ferent algo nt algorithm (Character)	rithm by th n in real ap . It contain Fixe ' 0, ' 1, ' 21 ' 321 ' 4321,	ne User. The polication for two values two values of the second s	iis demo apply t or safety) ue of 0 to 65535 of 11 Bytes (Cha (with 4 Space C (with 4 Space C (with 3 Space C (with 2 Space C (with 1 Space C	he followin separated racter) har. before har. before har. before	g algorithm by a "," • '0') • '1') • '2') • '3') • '4')			

Below steps - (a) to (d) is to get value 1, while - (e) is to get value 2 (Please apply a different algorithm in real application for safety)

 (a) extract the string not including the <User-defined CRC> and <4-byte-Checksum> into byte array - user_buf[] (for convient, we call this byte array as "user_buf[]")

Classific	ation	ISaGRAF Engli	sh FAQ-00	65							
Author		Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	16 / 20			
(b)	 (b) replace user_buf[3] as user_buf[3] xor 100 That is user_buf[3] = user_buf[3] ^ (unsigned char)100 ; (user may use [2], [4], , and may be not using 100, whatever, this depends on your own decision. Please use your own algorithm for safety.) 										
(c)	 (c) replace user_buf[7] as user_buf[7] xor 200 That is user_buf[7] = user_buf[7] ^ (unsigned char)200; (user may use [5], [6],, and may not use 200, whatever, this depends on your own decision. Please use your own algorithm for safety.) 										
(d)	(d) Calculate <user-defined crc=""> as two byte => <crc_hi><crc_lo) Then <user-defined crc=""> = 256*<crc_hi> + <crc_lo). 0="" 65535.<="" a="" and="" between="" is="" it="" p="" value=""></crc_lo).></crc_hi></user-defined></crc_lo) </crc_hi></user-defined>										
(e)	 (e) using a different algorithm to get value 2 proceed (a), then proceed (b) by using user_buf[4] = user_buf[4]^(unsigned char)48 then proceed (c) by using user_buf[6] = user_buf[6]^(unsigned char)197 then proceed (d). Then we get value 2. It is a value between 0 and 65535. (Please use your own algorithm for safety.) 										
5. UDP	message rity_pas	e format of the F swd: Using the s	PC/Server	replying to loca nition as item 4	al PAC						
<u>PC/Se</u>	erver wi	ll reply below fo	<u>rmat to th</u>	<u>e local PAC</u> .							
Secu	rity_pas	swd is 0: (No	4-byte-Ch	ecksum at the	end)						
<br <' </td <td>Station_ Year>,<n User-def</n </td> <td>No of PC/Server Month>,<day>,< fined CRC></day></td> <td>r>,<same i<br="">Hour>,<n< td=""><td>D No. from the linute>,<secon< td=""><td>e local PA d>,</td><td>۲C>,<comma< td=""><td>nd>,</td><td></td></comma<></td></secon<></td></n<></same></td>	Station_ Year>, <n User-def</n 	No of PC/Server Month>, <day>,< fined CRC></day>	r>, <same i<br="">Hour>,<n< td=""><td>D No. from the linute>,<secon< td=""><td>e local PA d>,</td><td>۲C>,<comma< td=""><td>nd>,</td><td></td></comma<></td></secon<></td></n<></same>	D No. from the linute>, <secon< td=""><td>e local PA d>,</td><td>۲C>,<comma< td=""><td>nd>,</td><td></td></comma<></td></secon<>	e local PA d>,	۲C>, <comma< td=""><td>nd>,</td><td></td></comma<>	nd>,				
Fc 9(or exam 001,519	ple, 805546,2,2007,5	5,30,18,59	,53,6830,4267	9						
lt	means,										
<	Station	_No of PC/Serve	er > is 900	1							
<	ID No.>	is 519805546									
<	Commai	nd> is 2									
D	ate and	Time on PC/Ser	r ver is 200	7/5/30, 18:59:	53						
<	User-de	efined CRC > is 6	830,42679	9 (there is on	e Space (Char. Before	the first "6")				

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	17 / 20

Security_passwd is not 0: (With 4-byte-Checksum at the end)

<Station_No of PC/Server>,<Same ID No. from the local PAC>,<Command>, <Year>,<Month>,<Day>,<Hour>,<Minute>,<second>, <User-defined CRC><4-byte-Checksum>

<Command> definition:

- 2: to inform the local PAC that PC/Server receive its correct data.
- 4: to inform the local PAC that its date and time differ more than 20 seconds than the PC/Server, please adjust PAC's date and time and then send data to PC/Server once again.

<User-defined CRC> definition:

Using the same definition as item 4.

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	18 / 20

6. PAC Ethernet security

Note: WinCon-8xx7 has been phased out, the user can use ISaGRAF XPAC. Visit the ISaGRAF website for new information.

https://www.icpdas.com/en/product/guide+Software+Development__Tools+ISaGRAF

6.1 : Modbus TCP/IP security

There are some ways user can get access to the Wincon-8xx7 via its ethernet port.

- 1. Using Modbus TCP protocol at port No.= 502. (ISaGRAF and other HMI can do this)
- 2. Using FTP (for example, keyin "ftp://10.0.0.103" on the Internet Explorer)
- 3. Using Telent (for example, keyin "telnet 10.0.0.103" in the "command" window)
- 4. Using the Web server (The Web HMI does)

Note:

1. While for I-8437-80/8837-80, I-8437/8837 and I-7188EG, only item 1 is possible.

2. If the PAC is W-8x47/8x46, when using "ftp", "telnet", "Web HMI" & "Modbus TCP/IP", please connect your PC/HMI to W-8x47/8x46's "LAN1" port, and please use "NS-205" or "NS-208" Ethernet switch.

For safety, recommend to disable item 2 and 3 at run time for ISaGRAF PAC. For using the Web HMI (item 4 above), checking "Enable Web HMI", clicking the Settings button and set the proper username & password.



Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	19 / 20

About item 1, user may set up to 8 IP address for ISaGRAF or other HMI to get access to the I-8x37 or I-7188EG via the Modbus TCP/IP protocol as below.

On the **IO connection** window of ISaGRAF, please connect "**vip**" and entering the IP which can get access to the PAC via Modbus TCP/IP protocol. If "vip" is not connected, any remote IP can get access to your PAC via Modbus TCP/IP protocol. If "vip" is connected and No IP is entered (all assigned as "N/A"), No HMI and ISaGRAF can get access to it by Modbus TCP/IP anymore.





Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Jun. 2007	Page	20 / 20

6.2 : Using "dis_stop" to disable/enable the ISaGRAF Download function

For some reason, to prevent someone to use ISaGRAF software to stop or to download a different PAC project already running on the I-7188EG or I-8437/8837, the "Dis_stop" can be applied . Please connect "**dis_stop**" at a slot No. larger than 8 and init the channel value to become **TRUE**. Then stop/download command is not allowed in this PAC.

ISaGRAF - 15 - 1/O connection	
<u>File Edit T</u> ools <u>Options H</u> elp	
🖆 🔤 🗟 🇭 🍈 🗘 🦊 🕞 👗 🚝	
0	
1 Enable_Stop	
2	
3	
4	
5	

To disable "Dis_stop" to accept stop/download command, please run the original ISaGRAF project to link to this PAC and set the channel value to become **False**.

Click the link for more ISaGRAF FAQ: http://www.icpdas.com/en/faq/index.php?kind=280#751