

2.6: Using Variable Array


If your ISaGRAF Workbench is version of 3.4 or 3.5, you can declare variable array in the ISaGRAF dictionary, And then program them in each language (ST, LD, FBD, SFC, IL & FC).

Please close all ISaGRAF windows first, and then add two extra lines in your ISaGRAF workbench root “EXE” directory, normally in the c:\isawin\exe.

In the “C:\ISAWIN\EXE\ISA.INI”, adds two extra lines on the top of this file.

**[DEBUG]
arrays=1**

And then re-open the ISaGRAF workbench, you will find there is one more “Dim” column in the ISaGRAF dictionary. The number entered can be **1** to **255**. However **it is very important, please always declare the proper number you want. The larger “Dim” number, the larger memory is consumed.**



If using “Variable Array” in the program, please DO NOT check the 2nd , 7th , 8th and 9th Optimizer options, or the value of the Variable array will be incorrect. Recommend to check only the 1st – “Run two optimizer passes” option.

The index of the variable array is always starting from 0. For example, if you declare an integer “CNT” with “Dim” = 10 , the variable array will be CNT[0..9] , that is the item can be used is CNT[0], CNT[1], ..., CNT[9].

How to program variable array ?

For example, the below ST code can assign an initial value of 100 to 109 to CNT[0] to CNT[9]

```
(* INIT is declared as an internal Boolean with initial value of TRUE *)  
(* CNT is declared as an integer array with "Dim" = 10 *)  
(* ii is declared as an internal integer *)
```

```
IF INIT THEN
```

```
    INIT := FALSE ; (* only do it once at 1st PLC scan cycle *)
```

```
For ii := 0 to 9 do
```

```
    CNT[ii] := 100 + ii ;
```


```
End_For ;
```

```
END_IF ;
```


Note: Please do not exceed the "Dim" number of variable array. For example please do not program at CNT[10] or CNT[11] in the above example since the CNT 's dimension is only 10 , CNT[0], CNT[1], ..., CNT[9]. There is no CNT[10], CNT[11], ...

How to debug variable array ?

After you compile your ISaGRAF project, you may download the project to the controller or simulate it. Please open the "Tools" - "Spy lists" on the "Debugger" windows. (please refer to section 9.12 for more information about "Spy lists"). Insert the name you want to debug.



Please remember to save the “spy list” to a name, for example – “list1” and then put it into the workspace. You will find the “list1” will automatically pop-up when you open the debugger.



2.6.1 Assign Network address No. To Variable Array

To assign Modbus Network address number to the variable array. Please assign the network address number to the first element, For example, No. = 1 assigned to CNT[0]. And the using “S_MB_ADR()” function as below.

Integer/Real Variable

Name: CNT Network Address: 1

Comment:

Unit:

Attributes:

- ☒ Internal
- ☐ Input
- ☐ Output
- ☐ Constant

Format:

- ☒ Integer (standard)
- ☐ Real

Initial value: 0

☐ Retain

Dim: 10

Cancel

Next

Previous

Extended

Please assign the first number for the first element.
(please refer to section 4.1 for more information)
The number enter here is always in Hex. format.

And then using “S_MB_ADR” to assign the other network address number for each element. For example,

1. **Assign continuous Network No = 1 ,2 ,3, ...,10 to CNT[0], CNT[1], CNT[2], ..., CNT[9]**

(* INIT is declared as internal Boolean with initial value at TRUE *)

(* TMP is declared as internal Boolean *)

IF INIT THEN

INIT := FALSE ; (* only do it at 1st PLC scan *)

TMP := S_MB_ADR(1, 10, 0) ; (* assign 10 elements starting at No.=1, continuous No. *)

END_IF;

2. **Assign Jumping Network No = 1 , 3 , 5, ...,19 to CNT[0], CNT[1], CNT[2], ..., CNT[9]**

(* INIT is declared as internal Boolean with initial value at TRUE *)

(* TMP is declared as internal Boolean *)

IF INIT THEN

INIT := FALSE ; (* only do it at 1st PLC scan *)

TMP := S_MB_ADR(1, 10, 1) ; (* assign 10 elements starting at No.=1, jumping No. *)

END_IF;

2.6.2 Setting Variable Array As Retained Variable

To set “variable array” as retained data, please assign the network address number to the first element, For example, No. = 1 assigned to CNT[0]. And then using “Retain_A()” function as below. Please refer to chapter 10.1 for more information about the “New retained function”.

Integer/Real Variable

Name: Network Address:

Comment:

Unit:

Attributes:

- ☒ Internal
- ☐ Input
- ☐ Output
- ☐ Constant

Format:

- ☒ Integer
- ☐ Real

Initial value:

☐ Retain

Sim:

Buttons: Cancel, Next, Previous

Callout 1: Please assign the first number for the first element. (please refer to section 4.1 for more information) The number enter here is always in Hex. format.

Callout 2: Do Not check the “Retain” option for variable array.

For example, setting integer variable array CNT[0..9] as retained data in the integer retained memory starting from 20 , 21 , ... to 29.

(* INIT is declared as internal Boolean with initial value at TRUE *)

(* TMP is declared as internal Boolean *)

IF INIT THEN

INIT := FALSE ; (* only do it at 1st PLC scan *)

TMP := Retain_A('N', 1, 10, 20) ;

(*

1st parameter : 'B' : boolean , 'N' : Integer , 'F' : Real , 'T' : Timer

2nd parameter : Network address No. for the 1st element of the "Variable Array".

3rd parameter : 1 - 255 , number of element in the “variable array” to be assigned as retained data.

4th parameter : starting retained address for this “variable array”.

7188EG/XG+X607/608, I-8xx7+S256/512 : 'B' & 'T' is 1 to 256 , 'N' & 'F' is 1 to 1024 .

Wincon-8xx7/8xx6+S256/512 : 'B' & 'T' is 1 to 1024 , 'N' & 'F' is 1 to 4096

*)

END_IF;