
PISO-P32C32/P32A32

Digital I/O Card

Linux Software Manual

Warranty

All products manufactured by ICP DAS are warranted against defective materials for a period of one year from the date of delivery to the original purchaser.

Warning

ICP DAS assume no liability for damages consequent to the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright 2010 by ICP DAS. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Tables of Contents

1. Linux Software Installation	3
1.1 Linux Driver Installing Procedure	3
1.2 Linux Driver Uninstalling Procedure.....	3
2. Static Library Function Description	4
2.1 Table of ErrorCode and ErrorString	5
2.2 Function Descriptions	5
2.3 Digital I/O FUNCTIONS	5
2.3.1 <i>PIODA_GetDriverVersion</i>	5
2.3.2 <i>PIODA_GetLibraryVersion</i>	6
2.3.3 <i>PIODA_Open</i>	6
2.3.4 <i>PIODA_Close</i>	6
2.3.5 <i>PIODA_DriverInit</i>	6
2.3.6 <i>PIODA_Digital_Output</i>	7
2.3.7 <i>PIODA_Digital_Input</i>	8
3. PISO-P32C32/P32A32 Linux Demo.....	9
3.1 Demo code “port.c”	9
3.2 Demo code “port_a.c”	9

1. Linux Software Installation

The PISO-P32C32/P32A32 can be used in linux kernel 2.4.X and 2.6.X. For Linux O.S, the recommended installation and uninstall steps are given in Sec 1.1 ~ 1.2

1.1 Linux Driver Installing Procedure

Step 1: Copy the linux driver "ixpio-0.20.15.tar.gz" (or the later driver version) in the directory "NAPDOS\Linux" of the companion CD or download the latest driver from our website to the linux host.

Step 2: You must use the '**root**' identity to compile and install PIO/PISO linux driver.

Step 3: Decompress the tarball "ixpio.tar.gz".

Step 4: Type '**cd**' to the directory containing the package's source code and type '**./configure**' to configure the package for your linux system.

Step 5: Type '**make**' to compile the package.

Step 6: You can type '**./ixpio.inst**' to install the PIO/PISO driver module and build the device file "ixpioX" in the device directory "/dev" automatically.

1.2 Linux Driver Uninstalling Procedure

Step 1: Type '**cd**' to the directory containing the package's source code.

Step 2: Type '**./ixpio.remove**' to remove the PIO/PISO driver module.

2. Static Library Function Description

The static library is the collection of function calls of the PIO-DIO cards for linux kernel 2.4.x and 2.6.x system. The application structure is presented as following figure. The user application program developed by C(C++) language can call library “libpio.a” in user mode. And then static library will call the module ixpio to access the hardware system.




Figure 2.1

2.1 Table of ErrorCode and ErrorString

Table 2.1

Error Code	Error ID	Error String
0	PIODA_NOERROR	OK (No error !)
1	PIODA_MODULE_NAME_GET_ERROR	Module name can't get from file /proc/ixpio/ixpio
5	PIODA_DIGITAL_OUTPUT_ERROR	Digital output error
6	PIODA_DIGITAL_INPUT_ERROR	Digital input error

2.2 Function Descriptions

Table 2.2

Function Definition
char * PIODA_GetDriverVersion(void);
char * PIODA_GetLibraryVersion(void);
int PIODA_Open(char *dev_file);
WORD PIODA_Close(WORD fd);
WORD PIODA_DriverInit(WORD);
WORD PIODA_Digital_Output(WORD, WORD, byte);
WORD PIODA_Digital_Input(WORD, WORD, WORD *);

2.3 Digital I/O FUNCTIONS

2.3.1 PIODA_GetDriverVersion

- **Description:**
To show the version number of PIO/PISO linux driver.
- **Syntax:**
char * PIODIO_GetDriverVersion(Void)
- **Parameter:**
None
- **Return:**
The version of PIO/PISO linux driver.

2.3.2 PIODA_GetLibraryVersion

- **Description:**
To show the version number of PIO/PISO linux static library..
- **Syntax:**
`char * PIODIO_GetLibraryVersion(void)`
- **Parameter:**
None
- **Return:**
The version of PIO/PISO linux static library.

2.3.3 PIODA_Open

- **Description:**
To open device file.
- **Syntax:**
`int PIODIO_Open(char *dev_file)`
- **Parameter:**
`dev_file` : The path of device file
- **Return:**
The file descriptor of device file. If the file descriptor < 0, it means that open device file failure.

2.3.4 PIODA_Close

- **Description :**
To close device file.
- **Syntax :**
`Word PIODIO_Close(WORD fd)`
- **Parameter :**
`fd` : The file descriptor of device file that get from function PIODIO_Open
- **Return:**
"PIODA_NOERROR"
(Please refer to "Section 2.1 Error Code")

2.3.5 PIODA_DriverInit

- **Description :**
To allocates the computer resource for the device. This function must be

called once before applying other PIODA functions.

- **Syntax :**
WORD PIODA_DriverInit(WORD fd)
- **Parameter :**
fd : The file descriptor of device file that get from function PIODIO_Open
- **Return:**
"PIODA_MODULE_NAME_GET_ERROR"
"PIODA_NOERROR"
(Please refer to "Section 2.1 Error Code")

2.3.6 PIODA_Digital_Output

- **Description :**
This subroutine sends the 8 bits data to the specified I/O port.
- **Syntax :**
WORD PIODA_Digital_Output(WORD fd, WORD port, byte data);
- **Parameter :**
fd : The file descriptor of device file that get from function PIODIO_Open.
port : The value of DO port . Please refer to "Table 2.3" DI/O port ID.

Table 2.3

PISO-P32C32 Port ID	PISO-P32A32 Port ID	DI/O Port
PISOP32C32_DIOA	PISOP32A32_DIOA	DI/O 0 ~ DI/O 7
PISOP32C32_DIOB	PISOP32A32_DIOB	DI/O 8 ~ DI/O 15
PISOP32C32_DIOC	PISOP32A32_DIOC	DI/O 16 ~ DI/O 23
PISOP32C32_DIOD	PISOP32A32_DIOD	DI/O 24 ~ DI/O 31
PISOP32C32_DIO_ALL	PISOP32A32_DIO_ALL	DI/O 0 ~ DI/O 31

data : 8 bits data.

- **Return:**
"PIODA_DIGITAL_OUTPUT_ERROR"
"PIODA_NOERROR"
(Please refer to "Section 2.1 Error Code")

2.3.7 PIODA_Digital_Input

- **Description :**

This subroutine reads the 8 bits data from the specified I/O port.

- **Syntax :**

WORD PIODA_Digital_Input(WORD fd, WORD port, WORD *di_data);

- **Parameter :**

fd : The file descriptor of device file that get from function
PIODIO_Open.

port : The value of DI port. Please refer to "Table 2.3" DI/O port ID.

di_data : A variable address used to storage the 8 bits input data.

- **Return:**

"PIODA_DIGITAL_INPUT_ERROR"

"PIODA_NOERROR"

(Please refer to "Section 2.1 Error Code")

3. PISO-P32C32/P32A32 Linux Demo

All of demo programs will not work normally if PIO/PISO linux driver would not be installed correctly. During the installation process of PIO/PISO linux driver, the install-scripts “ixpio.inst” will setup the correct kernel driver. After driver(version 0.20.15 or the later driver version) compiled and installation, the related demo programs, development library and declaration header files for different development environments are presented as follows.

Table 3.1

Driver Name	Directory Path	File Name	Description
ixpio-0.20.15	include	piodio.h	PIO/PISO library header
	lib	libpio.a	PIO/PISO static library
	examples/pisop32c32	port.c	Digital input and output demo
	examples/pisop32a32	port_a.c	DI and DO demo with library

3.1 Demo code “port.c”

This demo program is used to output digital from DO 0 ~ 31, input digital data from DI 0 ~ 31.

3.2 Demo code “port_a.c”

This demo program coded by using the static library “libpio.a”. It is used to output digital from DO 0 ~ 31 , input digital data from DI 0 ~ 31.