SMS-531 FAQ

Tables of Content

ICP DAS CO., LTD.

Q01：How to get the status of transmitting SMS?

A01：Please query Input Register(Function Code: 4) address 0x0~0xF.

Step 1：Get the last transmitting SMS buffer number. (SMS-531 Modbus address is 1.)

Query => 01 04 00 10 00 01 30 0F (Input Register, address 0x10)

Response => 01 04 02 00 00 B9 30 (The last transmitting SMS buffer number is 0.)

Step 2：Get the status of transmitting SMS buffer 0~15. (SMS-531 Modbus address is 1.)

Query => 01 04 00 00 00 10 F1 C6 (Input Register, address 0x0~0xF)

Response => 01 04 20 02 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 92 61 (Transmitting)

Query => 01 04 00 10 00 01 30 0F

Response => 01 04 20 03 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 93 CD (Transmitted successfully)

Q02：I can't make a good wav file. What kind of program do you offer for it?

A02："Format Factory" can make a good wav file, please refer the below steps to make wav file.

The "Format Factory" download website: http://www.pcfreetime.com/index.html

Step 1：Select "Audio"

ICP DAS CO., LTD.

Step 2：Select "WAV"

Step 3：Add an audio file, and set the output format.

ICP DAS CO., LTD.

Step 4：Audio setting

Step 5：Select the output folder

Step 6：Start converting.

Q03：When I send Modbus RTU command to change the contents of dynamic SMS

**and dynamic phone number, SMS-531 reply exception 2. How to solve this problem?**

A3：When SMS-531 sending dynamic SMS, the contents of dynamic SMS and dynamic phone number can not be edit.

The suggest way is:

Step 1：Check the status of transmitting dynamic SMS is not 1 or 2

Step 2：Set dynamic phone number

Step 3：Set the content of dynamic SMS

Step 4：Transmitting the dynamic SMS