

Classification				
Author		Date	NO.	FAQ-004

Q.How to use two or more cards in the same time without calling ActiveBoard() function again and again?

Ans:

You can record the Base-Address of all cards first, and then calling I/O functions directly without ActiveBoard()function calls anymore. For example, to use ISO-P64 under Windows 2000:

```
// Get address first
1. ISO_ActiveBoard(0)
2. ISO_GetConfigAddress(&wBase0, &BoardNo)
3. ISO_ActiveBoard(1)
4. ISO_GetConfigAddress(&wBase1,&BoardNo)
// I/O directly
5. ISO_InputByte(wBase0+n)
6. ISO_InputByte(wBase1+n)
```

Written by Claire Lai
Date:2004/9/8