

## Packing List

In addition to this guide, the package includes the following items:



IP-8411/IP-8811/  
IP-8441/IP-8841



D-SUB Cable  
(CA-0915)



Screw Driver

## Technical Support

[service@icpdas.com](mailto:service@icpdas.com)

[www.icpdas.com](http://www.icpdas.com)

## The default IP settings for Ethernet PAC are as follows:

IP Address : 192.168.255.1

Mask : 255.255.0.0


Gateway : 192.168.0.1

### Resources

How to search for drivers, manuals and spec information on ICP DAS website.

- For Desktop Web

- For Mobile Web



## Connect to the power supply

