


In **XPAC(CE6)** platform, please follow the below steps to compile HART I/O program smoothly.


[Step1]

In “Project Settings” -> “C/C++” -> “Preprocessor definitions” option, add “**_ALLPAC_SERIES**” definition.



[Step2]

In “Project Settings” -> “Link” -> “Object/library modules” option, add “**xpacsdk_ce.lib**” and “**xpachart_ce.lib**” library file.



[Step3]


Include “**xpacsdk_ce.h**” and “**dcon2hart.h**” these two files.

```
// I87H17W_AI_CE5Dlg.cpp : implementation file
//

#include "stdafx.h"
#include "I87H17W_AI_CE5.h"
#include "I87H17W_AI_CE5Dlg.h"
#include "xpacsdk_ce.h"
#include "dcon2hart.h"
```

[Step4]

Owing to MFC library doesn't support in WinCE 6.0. So in EVC program, users need to set “Not Using MFC” option.



[Step5]

Please copy "[xpacsdk_ce.dll](#)" and "[xpachart_ce.dll](#)" these two files to be the same folder of HART I/O program first before running the HART I/O program.