




HART_I/O_API_Library_WinPAC(CE5) (v1.01)

In **WinPAC/ViewPAC** platform, please follow the below steps to compile HART I/O program smoothly.


[Step1]

In “**Project Settings**” -> “**C/C++**” -> “**Preprocessor definitions**” option, add “**_ALLPAC_SERIES**” definition.



[Step2]

In “**Project Settings**” -> “**Link**” -> “**Object/library modules**” option, add “**winpacsdk.lib**” and “**winpachart.lib**” library file.



[Step3]

Include "[winpacsdk.h](#)" and "[dcon2hart.h](#)" these two files.

```
I87H17W_AI_CE5D1g.cpp : implementation file

#include "stdafx.h"
#include "I87H17W_AI_CE5.h"
#include "I87H17W_AI_CE5D1g.h"
#include "winpacsdk.h"
#include "dcon2hart.h"
```

[Step4]

Please copy "[winpacsdk.dll](#)" and "[winpachart.dll](#)" these two files to be the same folder of HART I/O program first before running the HART I/O program.