
## Q: Why the time setting of WISE controller goes wrong suddenly?

## A:

Please update the firmware to v1.3.0 or later, and check the battery status on the top of the webpage:



If the battery status is not OK, please change the battery and perform Time Synchronization again.