

Q: How does the Email sending function works on WISE?

A:

WISE will send the edited email to the SMTP server you previously set up; and then the server will send the email to the receiver(s). To ensure appropriate operation, a self-hosted SMTP server and account is recommended. Currently the email sending function work with the SMTP Email server that uses **port 25** and must be **without SSL** cryptographic protocols.

Following is the suggestion for you to let the WISE Email sending function work fine.

1. A self-hosted SMTP server is recommended for Email sending function. [You can directly enable the non-SSL protocol supported by yourself and always keep the setting without any interference. It is the best solution.](#)
2. In general, the ISP vendor also provides the SMTP Email service, and it supports the [SSL](#) protocol and [non-SSL](#) protocol together. We suggest you can contact with your ISP vendor for the [non-SSL](#) SMTP Email service, and use the SMTP server for the Email sending function of WISE.