

**Q: What to do if I forget my WISE password?**

**A:**

The default login password for WISE is "**wise**", if you make a change to the password and forget the password, please send an email with your question and the **MAC address** of the WISE controller to [service@icpdas.com](mailto:service@icpdas.com) We will send you a program to reset the password to "**wise**".