

**Classification:**

Product Functionality for I-7000/M-7000 series

**Question**

When to use repeater in the RS-485 network?

**Answer**

The user should use repeater when the network has more than 256 modules, or it has been over 1.2 Km distance.