M2M RTU Center

User Manual

Warranty

All products manufactured by ICP DAS are warranted against defective materials for one year from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for damages consequent to the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use or any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright 2010 by ICP DAS Co., LTD. All rights reserved worldwide.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

1

Tables of Content

Chapter 1 Introduction	3
Chapter 2 Hardware Requirement	4
2.1 Software architecture	4
2.2 Application architecture 2.3 System requirement	5 5
Chapter 3 Installing .NET Compact Framework	7
Chapter 4 RTU Center operation	9
4.1 Main menu	9
4.2 NEW Device	11
4.3 Delete Device	12
4.4 Modify IP	12
4.5 Modify Port	13
4.6 Control module I/O	14
4.7 Modify the module parameters	16
4.8 Close the connection	17
4.9 Upload SD File	18
Chapter 5 Restful API And Modbus Server	19
5.1 Set Restful API and Modbus Server	19
5.2 Modbus Server Memory Planning	20
5.2 How Restful API Get & Post	34

Chapter 1 Introduction

The M2M RTU Center provided by ICP DAS is an M2M (Machine to Machine) management software that has strong core technology for handling data and lets the user save the trouble of dealing with large IO data. The RTU Center supports the G-4514 RTU, GTP-541M, and other RTU products in ICP DAS that allow users to manage these RTU devices remotely. It can monitor the local IO data, local GPS data, and IO data of Modbus RTU modules. With M2M RTU Center software, users can establish the remote system by the OPC Client of the user's SCADA software with our NAPOPC DA Server or EZ Data logger software of ICP DAS. That provides an easy way to complete a user's project.

NAPOPC.M2M OPC Server is a free OPC DA Server (The "OPC" stands for "OLE for Process Control" and the "DA" stands for " Data Access") provided by ICP DAS. EZ Data Logger is small data logger software. It can be applied to a small remote I/O system. With its user-friendly interface, users can quickly and easily build a data logger software without any programming skills.

The M2M RTU Center with G-4514 RTU or GTP-541M applications can be divided into 2 parts: One part is the fixed intelligent remote management equipment such as water monitor system, vending machine system, remote machine monitor, home security, POS system, power measurement system, etc. Another kind of application is movement management equipment such as vehicle management system, maritime system, taxi dispatch system, etc. Anyway, the M2M RTU Center can save the cost and development time for users.

Features:

- RTU series Management tool
- Up to 10 M2M RTU devices can be managed in one RTU Center software in the free version.
- Up to 1024 M2M RTU devices can be managed in one RTU Center software in the official version.
- Help users to connect to any Modbus device to GPRS/Ethernet by M2M RTU devices
- Easy and quick to build a Remote monitor system
- Windows-based software
- Support NAPOPC.M2M server, EzDatalog, and M2M API tool of ICP DAS

RUN-TIME LICENSE				
Free Version	Up to 10 M2M RTU devices can be managed in one RTU Center software.			
Official version	Up to 1024 M2M RTU devices can be managed in one RTU Center software.			
T	DTU Canter l'access also access d'access d'activitates			

To order an M2M RTU Center license, please contact your distributor.

Chapter 2 Hardware Requirement

2.1 Software architecture

When users want to use the following software or others to their system with RTU products of ICP DAS, M2M RTU Center must be executed at the same time.

Device	Description
NAPOPC.M2M	OPC server
EZ Data Logger software	Version 4.24 or higher
.NET Framework software	Version 2.0 or higher



2.2 Application architecture -----Restful API M2M OPC Server EZ Data ogge Modbus TCP Server ð RTU-140 3G/4G Ethernet **RTU** Cente Control And Request RTU Devices IO **RTU Center Control IO** RTU Devices Report IO Status Through Restful API Or Modbus TCP Server 0 0 Ethernet RS485 G-4514-4GAU Remote PC Local PC With Fixed IP GTP-541M **RTU Devices Modbus Devices** (Max. 32 DI/DO For Each Device) (Max. 16 DI/DO For Each Device)

2.3 System requirement

• Software requirement:

Operating system Version	Support
Windows 2000	\checkmark
Windows XP	\checkmark
Windows 7	\checkmark
Windows 10	\checkmark

• Hardware requirement:

Hardware Items	Requirement
CPU	1.0 GHz or higher
Memory	512 MB or higher
Hardware space	100 MB or higher
Other	CD-ROM or DVD-ROM

Support Hardware	
Product Type	Description
G-4514 Series RTU	Intelligent GPRS Remote Terminal Unit
GT-540	Smart GPRS Remote Terminal Unit
GRP-540	Ethernet/Serial/CAN to 4G Gateway
GTP-541M	4G Multi Function Controller with GPS
RTU-140	4G Remote Terminal Unit with GPS

Flowchart for using RTU devices



Chapter 3 Installing .NET Compact Framework

It needs the runtime environment with .NET Framework 2.0 or above to execute the M2M RTU Center in the PC. If there has .NET Framework 2.0 or above on the PC, section 3.1 can be omitted.

Microsoft .Net Framework Version 2.0:

http://www.microsoft.com/downloads/details.aspx?FamilyID=0856eacb-4362-

4b0d-8edd-aab15c5e04f5&DisplayLang=en

Microsoft .Net Framework Version 3.5:

http://www.microsoft.com/downloads/details.aspx?familyid=333325FD-AE52-

4E35-B531-508D977D32A6&displaylang=en

The install figure is as follows:

• Press "Next" to the next step.



 Select the "I accept the terms of the License Agreement" and "Install" to the next step.

CENSE TERMS			
ou live, one of i			
ou live, one of i			
and the second second	rs arrillares.	licenses this	
se Microsoft Wi	ndows oper	ating system	
supplement. \	ou may not	use it if you	do
iy use a copy o	r this supple	ement with ea	cn
8 8			~
		Prin	*
Agreement" ar	nd proceedin	ng to use the	
ood, and agree	ed to the ter	ms of the End	d-User
oou, anu ayree		Ins or the End	1-Osei
	ay use a copy o	ay use a copy of this supple Agreement" and proceedin	ay use a copy of this supplement with ea

• The installation process would be going

Hicrosoft .NET Framework 2.0 Setup	
Installing components	
The items you selected are being installed.	
Text-Ilition Drogram	
Installation mograss.	
Generating script operations for action:	
Updating component registration	
	Cancel

• After finishing the installation, press "Finish" to exit the program.

Microsoft .NET Framework 2.0 Setup	
Setup Complete	
Microsoft .NET Framework 2.0 has been successfully installed.	
It is highly recommended that you download and install the latest service packs and security updates for this product.	
For more information, visit the following Web site:	
Product Support Center	
	Finish

Chapter 4 RTU Center operation

OPC Server: Launch M2M RTU Center from the Start menu "Start \rightarrow All Programs \rightarrow ICPDAS \rightarrow ICP DAS OPC Suite \rightarrow NAPOPC.M2M \rightarrow M2M_RTU_Center".

4.1 Main menu

		M2M RTU Center				
lool Menu	•	File Settings Help				
Function Items		🗁 🚮 🔮 🔹	😭 🎑			
		GTP-541M		Rest C	Status	
		- G-4514		Parameter Device Name	RTU-140	
				Station ID	3	
				Describe		
Station Information	•					
Detail Information						
		Date / Time Messi	age			
		2021/04/13 17:11:43.821 Add a 2021/04/13 17:11:35.302 Add a	a new device "G-4514" (S	station ID=3) tation ID=2)		
		2021/04/13 17:11:26.556 Add a	new device "GTP-541M	(Station ID=1)		
		2021/04/13 17:04:46.253 Server	r Started (Local IP: 169.3	254.139.183, Local PORI: 10000)		
• ·· · • · ·						
Connection Information	•					
.					_	
Status Line		Server Started Local IP: 169.254.139.183	Local PORT: 10000 Ve	rsion 1.31_1207 USB Hard Key: N	0	

>The main menu of RTU Center includes the following sections:

- Tool menu:
 - File: Save or open station information of the user.
 - Settings: Modify the local IP or local port.
 - Help: Describe the version of RTU Center and other information.
- ♦ 8 function items:
 - Open file: Open the station information of the user.
 - Save file: Save the station information of the user.
 - New Device: Add a new device.
 - Delete Device: Delete the assigned device.
 - Modify IP: Modify the local IP
 - Modify port: Modify the local port
 - About: The version of RTU Center and other information.
 - Exit: Exit the RTU Center.

Station Information:

Manage total stations interface. It will turn green light from a red light when the station connects to RTU Center successfully.

attings Help			File Settings Help				
/ 🗟 🔮 🌒 🍓				2 3			
	Parameter Device Name Station D Describe	Status GTF-641M 99	 - (* [11251])		Pa De Sta De Co Co Dala Re Re Re Se Se	rameter tice Name tion D binot mecter Method te&Time mode Calent (PF mode Calent PORT mode Calent (PF mode Calent PORT ante-attime (unit sec) attheat time (unit sec)	Status GTD-441M 99 Only, OPR3 GPR5 30210413 1750 09 2223 138 39 345 10 10 3 3

Before Connection

After Connection, It Shows Information Of The Station

- ➤Detailed Information:
 - ◆ It shows detailed information when you select one module

M2M RTU Center			
File Settings Help			
📂 🗟 💣 🔮		1	
🖃 🍎 GTP-541M	Parameter	Status	
Local IO	Modbus Module Name	Local IO	
Custom	Modbus Slave ID	255	
Custom	Date&Time	2021/04/13 17:59:16	
Cubion	DI Count	5	
Select One Module	DO Count	2	
	Al Count	4	
	AO Count	0	
	Counts	5	
	Data Valid	1	
	DIO	0	
	DI1	0	
	DI2	0	
	DI3	0	
	DI4	0	
	DO0	0	
	DO1	0	
	AIO	FFFFh	
	Al1	FFFEh	
	AI2	FFFEh	
	AI3	FFFEh	
	Count0	n	

Detailed Information

➤Connection Information:

- ◆ Total stations connect to RTU Center information.
- Status Line:
 - Show the related information during the operation procedure including:
 - The status of the Server of the PC
 - ■The local IP of the PC
 - The local port of the PC

4.2 NEW Device

>It adds a new device. The description is below:

Choose Function Item > New Device.

M2N	A RTU Center	
File	Settings Help	
E	MB SERVICES REST	
•	Device Properties	
	Device Properties x	
	Device Name (Type:Unicode, Max. size: 20) Module Setting Station ID 1 (1 ~ 65535) Describe	

- Device Name: Input your Device name
- ■Module: Select your connection module like G-4514 or GTP-541M...etc.
- Station ID: Input the station ID. It can't repeat the same station ID in the RTU Center. The station ID must match your connection module. (Range: 1 ~ 65535)
- Describe: It shows in the field of "Detailed Information"
- ■Operation:
 - •OK: Exit the window and add a new device
 - Cancel: Exit the window and don't add
 - It will add to "Station Information" after press the "OK" button

4.3 Delete Device

> It deletes a device. The description is below:

Select the device that you want to delete.

M2M RTU Cente	er.				
File Settings	Help				
	3	1		MB SERVICES REST	ம்
GTP-541M			Paramete	er	

◆Choose Function Item > Delete Device.



Device Name Station ID

Describe

Status GTP-541M

99

4.4 Modify IP

Local IP		×
Local IP:	169.254.139.183	
Modify IP:		
🛩 Modify	🔀 Cancel	

- Local IP: Show your old IP address
- > Modify IP: Show your new IP address
- Operation:
 - ♦ Modify: Exit the Modify IP window and modify the IP address
 - Cancel: Exit the Modify IP window and don't save

4.5 Modify Port

Local Port	×
Local Port: 10000	
Modify Port: 10000	
✓ Modify Kancel	

>Local port: Show your old port address.

>Modify port: Show your new port address.

- ≻Operation:
 - Modify: Exit the Modify port window and modify the port address.
 - ■Cancel: Exit the Modify port window and don't save.

4.6 Control module I/O

• It controls an IO of the module. The description is below:

• Double-click the module that you want to control, like Local IO or M-7000 module.

	M2M RTU Center				
	<u>File</u> Settings <u>H</u> elp				
		2 💙 🄇	🕒 🈂		
			Parameter	Status	
	GTP-541M-RTU		Modbus Module Name	Local IO	
Double Click The Module	Local IO		Modbus Slave ID	255	
	Custom		Date&Time	2021/04/21 20:59:52	
	Custom		DI Count	5	
	🔴 RTU-140		DO Count	2	
			Al Count	4	
			AO Count	0	
			Counts	5	
			Data Valid	1	
			DI	0	
			DI2	0	
			DI3	0	
			DI4	0	
			DO0	0	
			DO1	0	
			AI0	FFFFh	
			Al1	FFFFh	
			AIZ	FFFEN	
			Alb Count0	0	
Operation	Vrite Output - Local IO				×
	- Write Digital Output (Red Led. ON, C	sray Led. OFF)			
	DO 0 DO 1	DO 2 DO 3	DO 4 DO 5	DO 6 DO 7	
Control DO					Exit
	DO 8 DO 9	DO 10 DO 11	DO 12 DO 13	DO 14 DO 15	
	Write Analog Output				
	Read back Output value	Read back Output value	Read back Output value	Read back Output value	
	AO 0 (Hex)	AO 1 (Hex)	AO 2 (Hex)	AO 3 (Hex)	
	Read back Output value	Read back Output value	Read back Output value	Read back Output value	
Control AO	AO 4 (Hex)	AO 5 (Hex)	AO 6 (Hex)	AO 7 (Hex)	
		Read back Output value	Read back Output value	Read back Output value	
	Read back Output value				
	AO 8 (Hex)	AO 9 (Hex)	AO 10 (Hex)	AO 11 (Hex)	
	Read back Output value	Read back Output value	Read back Output value	Read back Output value	
	AO 12 (Haw)	40 12 (How)	AC 11 (Jaw)	AO 15 (Upp)	
	AU 12 (TIEX)	AU IS (HEX)	NO 14 (LIEX)	AC IS (Hex)	
	Set Counter				
	Counter 0: 00000	0 0 0 0 0 Set Zero	Counter 1: 0 0 0 0	0 0 0 0 0 0 Set Zero	
	Counter 2: 0 0 0 0 0	0 0 0 0 0 Set Zero	Counter 3: 0 0 0 0	0 0 0 0 0 0 Set Zero	
Control Counter					
		Set 7		Colorologo Set Zerra	
	Counter 4: 000000	JUUUUU Set Zelo	Counter 5: 0 0 0 0	00000	
	Counter 6: 0 0 0 0 0	0 0 0 0 Set Zero	Counter 7: 0 0 0 0	0 0 0 0 0 0 Set Zero	
					<i>i</i>

- Control DO: If your module had to DO counts, you can control them.
 - DO0 ~ DO15 :
 - **D** Red: the voltage logic is high
 - Gray: the voltage logic is low
 - Disable: your module does not have this DO count.
 - Operation
 - DO0 ~ DO15 Gray: Set the DO output on
 - DO0 ~ DO15 Red: Set the DO output off
- Control AO: If your module had AO counts, you can control them.

•AO0 ~ AO15

- □ Read back: Get the AO value.
- □ Output Value: Want to set the AO value.
- $\bullet \, \text{Operation}$
 - □ AO0 ~ AO15 : Set the AO value
- Control Counter: If your module had Counter counts, you can control them.
 - Counter0 ~ Counter7
 - Get the Counter value.
 - Operation
 - Set Zero Coutner0 ~ Set Zero Counter 7 : Set the counter value to zero

4.7 Modify the module parameters

• It modifies the module parameter. The description is below:

• Right-click the module that you want to modify and select the "Parameters" item.

	125.227.224.157:908 M2M RTU Center	9 - 這端桌面連線			
	<u>File</u> <u>S</u> ettings <u>H</u> elp	2 🔊 🙆			
Right Click The Module ←	GCIPSATIARU Custom Custom Custom Custom Custom Custom RTU-140	ameters se the connection load SD File	Parameter Dexice Name Station ID Describe Connacted Priority Connacted Method Date&Time Remote Client IP Remote Client IP Remote Client PORT Send once time (unit: sec) Heartbeat time (unit: sec) Modbus module number	Status GTP-541M-RTU 3 Only GPRS GPRS 2021/04/21 21:01:43 2021/04/21 21:01:43 20150 10 10 3	
Main Parameter					_
	Par	ameter- GTP-541M-RTU ain Parameter Device T	īme		Exit
Modify Station ID	•	Station ID:	3 3 (1 ~ 6553	Save to 5 DEC.)	Device
Modify Update Interval And Heartbeat Time	•	Update Interval: Heartbeat Time:	10 [10 (0 ~ 99999999 DEC, U 10 [10]	nit: Sec.) Save to	Device
			(0 ~ 99999999 DEC, U	nit: Sec.)	

■ Modify Station ID: Modify the station ID of the module.

- •Old Station ID: the old station ID of the module.
- •New Station ID: the new station ID of the module.

Operation

- Save to Device: Set the new Station ID to the assigned module.
- Modify Update Interval: Modify the Update Interval of the module. Set module report time interval. The module calculates time intervals according to report base time. (Unit: sec)
 - □ Old Update Interval: the old Update Interval of the module.
 - □ New Update Interval: the New Update Interval of the module.
 - **Old** Heartbeat Time: the old Heartbeat Time of module.
 - □ New Heartbeat Time: the new Heartbeat Time of the module.
- Save to Device: Set the new Update Interval to the assigned module.

16

Main Parameter Device Time		Exit
Device Time	Command	
2021/04/21 21:05:44	Set	Set as Now

- Device time: show the time of the module. Users also can change the time in this field to key in the specific time.
- Operation
 - "Set as Now": Set the PC time to module. After setting the time successfully, the information of module time.
 - Set: Set the module time according to the "Device Time" field. After setting the time successfully, the information of module time would be updated.

4.8 Close the connection

- It closes the connection. The description is below:
 - Right-click the module that you want to modify and select the "Close the connection" item.
 - Close the assigned connection.

4.9Upload SD File

- It Uploads SD Files. The description is below:
 - Right-click the module that you want to modify and select the "Upload SD File" item.
 - ♦ Upload SD File



- File name list: List all the file names.
- File parameter: List this file parameter. Like: Filename and File size.
- Operation
 - Refresh File Name: Refresh the File name list from the remote module.
 - Save File: Upload and Save the assigned File from the remote module.
 - Del File: Delete the assigned SD File on the remote module.
 - Exit: Exit upload SD file program.

Chapter 5 Restful API And Modbus Server

Restful API and Modbus Server architecture



5.1Set Restful API and Modbus Server

- It set Restful API and Modbus server. The description is below:
 - Choose function item > MB Restful Service Setting



■Host IP

- ■Web Service Port: from 0 ~ 65535
- ■Web Service Key: Secure key of Restful Service

Attention: for security reasons, it is recommended to operate only on the local side,

like "Host IP = 127.0.0.1".

- Modify Modbus Parameter: information of Modbus server
 - ■Modbus server Slave ID
 - ■Modbus server port: from 0 ~ 65535
- ♦ Path of log files:
 - Automatically output in the current directory:

"/MB_Restful_Service/yyyy-mm-dd.txt"

5.2 Modbus Server Memory Planning



- 1. Device Description
 - RTU Center has 16 groups (Group 0 ~ 15)
 - Each group has 64 RTU devices (RTU device 1 ~ 64)
 - Each RTU device has 11 modules (1 *Local device + 10 *Modbus device)
- 2. IO Number
 - Max.32 DI for each device.
 - Max.32 DO for each device.
 - Max.16 AI for each device.
 - Max.16 AO for each device.
 - Max.16 Counters for each device.

3. IO Description

Item	Description		
Discrete Input	0 means OFF and 1 means ON.		
Coil			
Input Register	AI (first half)	Counter (second half)	
	From 0 to 65535 (Uint16) for unipolar	From 0 to 65535 (Uint16)	
	input ranges. Like 0 ~ 5V, 0 ~ 10V.		
	From -32768 to 32767 (Int16) for bipolar		
	input ranges. Like ±5V, ±10V		
Holding Register	From 0 to 65535 (UINT16).		
	From -32768 to 32767 (INT16).		

4. Read RTU device status

Step1. Calculate RTU device in which group: (Station ID -1) / 64

Step2. Write group which is calculated in the previous step to Modbus address"**0**" Note. The default [current control group] is 0. If the Station ID is during 1~64, then the step1 and step2 can be ignored.

Step3. Check online status of local RTU device through Modbus address "000~ 00063" Step4. Check online status of slave RTU device through Modbus address "100~ 00739"

System Module			
Description	Function	Address	
Select current control group	Input Register	00000	
Check current control group	Holding Register		
Local device online / offline	Discrete Input	00000 ~ 00063	
Reserve	-	00064 ~ 00099	
Modbus Device Of RTU device 1 online / offline	Discrete Input	00100 ~ 00109	
Modbus Device Of RTU device 2 online / offline		00110 ~ 00119	
Modbus Device Of RTU device 3 online / offline		00120 ~ 00129	
Modbus Device Of RTU device 4 online / offline		00130 ~ 00139	
Modbus Device Of RTU device 5 online / offline		00140 ~ 00149	
Modbus Device Of RTU device 6 online / offline		00150 ~ 00159	
Modbus Device Of RTU device 7 online / offline		00160 ~ 00169	
Modbus Device Of RTU device 8 online / offline		00170 ~ 00179	
Modbus Device Of RTU device 9 online / offline		00180 ~ 00189	
Modbus Device Of RTU device 10 online / offline		00190 ~ 00199	
Modbus Device Of RTU device 11 online / offline		00200 ~ 00209	
Modbus Device Of RTU device 12 online / offline		00210 ~ 00219	
Modbus Device Of RTU device 13 online / offline		00220 ~ 00229	

Modbus Device Of RTU device 14 online / offline	00230 ~ 00239
Modbus Device Of RTU device 15 online / offline	00240 ~ 00249
Modbus Device Of RTU device 16 online / offline	00250 ~ 00259
Modbus Device Of RTU device 17 online / offline	00260 ~ 00269
Modbus Device Of RTU device 18 online / offline	00270 ~ 00279
Modbus Device Of RTU device 19 online / offline	00280 ~ 00289
Modbus Device Of RTU device 20 online / offline	00290 ~ 00299
Modbus Device Of RTU device 21 online / offline	00300 ~ 00309
Modbus Device Of RTU device 22 online / offline	00310 ~ 00319
Modbus Device Of RTU device 23 online / offline	00320 ~ 00329
Modbus Device Of RTU device 24 online / offline	00330 ~ 00339
Modbus Device Of RTU device 25 online / offline	00340 ~ 00349
Modbus Device Of RTU device 26 online / offline	00350 ~ 00359
Modbus Device Of RTU device 27 online / offline	00360 ~ 00369
Modbus Device Of RTU device 28 online / offline	00370 ~ 00379
Modbus Device Of RTU device 29 online / offline	00380 ~ 00389
Modbus Device Of RTU device 30 online / offline	00390 ~ 00399
Modbus Device Of RTU device 31 online / offline	00400 ~ 00409
Modbus Device Of RTU device 32 online / offline	00410 ~ 00419
Modbus Device Of RTU device 33 online / offline	00420 ~ 00429
Modbus Device Of RTU device 34 online / offline	00430 ~ 00439
Modbus Device Of RTU device 35 online / offline	00440 ~ 00449
Modbus Device Of RTU device 36 online / offline	00450 ~ 00459
Modbus Device Of RTU device 37 online / offline	00460 ~ 00469
Modbus Device Of RTU device 38 online / offline	00470 ~ 00479
Modbus Device Of RTU device 39 online / offline	00480 ~ 00489
Modbus Device Of RTU device 40 online / offline	00490 ~ 00499
Modbus Device Of RTU device 41 online / offline	00500 ~ 00509
Modbus Device Of RTU device 42 online / offline	00510 ~ 00519
Modbus Device Of RTU device 43 online / offline	00520 ~ 00529
Modbus Device Of RTU device 44 online / offline	00530 ~ 00539
Modbus Device Of RTU device 45 online / offline	00540 ~ 00549
Modbus Device Of RTU device 46 online / offline	00550 ~ 00559
Modbus Device Of RTU device 47 online / offline	00560 ~ 00569
Modbus Device Of RTU device 48 online / offline	00570 ~ 00579
Modbus Device Of RTU device 49 online / offline	00580 ~ 00589
Modbus Device Of RTU device 50 online / offline	00590 ~ 00599
Modbus Device Of RTU device 51 online / offline	00600 ~ 00609

	M2M RTU Center User Manual			
Modbus Device Of RTU device 52 online / offlin	ne 00610 ~ 00619			
Modbus Device Of RTU device 53 online / offlin	ne 00620 ~ 00629			
Modbus Device Of RTU device 54 online / offlin	ne 00630 ~ 00639			
Modbus Device Of RTU device 55 online / offlin	ne 00640 ~ 00649			
Modbus Device Of RTU device 56 online / offlin	ne 00650 ~ 00659			
Modbus Device Of RTU device 57 online / offlin	ne 00660 ~ 00669			
Modbus Device Of RTU device 58 online / offlin	ne 00670 ~ 00679			
Modbus Device Of RTU device 59 online / offlin	ne 00680 ~ 00689			
Modbus Device Of RTU device 60 online / offlin	ne 00690 ~ 00699			
Modbus Device Of RTU device 61 online / offlin	ne 00700 ~ 00709			
Modbus Device Of RTU device 62 online / offlin	ne 00710 ~ 00719			
Modbus Device Of RTU device 63 online / offlin	ne 00720 ~ 00729			
Modbus Device Of RTU device 64 online / offlin	ne 00730 ~ 00739			
Note. RTU device 1 means Station ID 1, 65, 12	9, and 960,			
RTU device 2 means Station ID 2, 66, 13	0, and 961,			
RTU device 3 means Station ID 3, 67, 131, and 962,				
RTU device 4 means Station ID 4, 68, 132, and 963,				
and so on.				
5. Read / Write RTU devices:				
Step1. Calculate RTU device in which group: (Station ID – 1) / 64			
Step2. Write group which is calculated in the p	previous step to Modbus address"0"			
Note. The default [current control group] is 0. If the Station ID is during 1~64, then the stop1 and stop2 can be ignored				
Step3. Calculate Modbus address				
(1) Calculate RTU device in which group	→ DID = (Station ID - 1) / 64			
(2) Calculate index of RTU device in group	$\Rightarrow MID = 0 [l ocal device]$			
	$\Rightarrow MID = 1 [Slave device]$			
	→ MID = 10 [Slave device10]			
	L J			

(3) Calculate Modbus address \rightarrow ADDR = 1000 + MID x 64 + DID x 704

Step4. Read / Write Modbus address which is calculated in previous step Attention: Station ID must between 1 and 1024.

DI Address				
Group 0 ~ 15				
Description Address				
RTU Device 1 (Station ID 1, 65, 129, …, 960)				
Local Device	01000 ~ 01031			
Slave Device 1 01064 ~ 01095				

Slave Device 2	01128 ~ 01159	
Slave Device 3	01192 ~ 01223	
Slave Device 4	01256 ~ 01287	
Slave Device 5	01320 ~ 01351	
Slave Device 6	01384 ~ 01415	
Slave Device 7	01448 ~ 01479	
Slave Device 8	01512 ~ 01543	
Slave Device 9	01576 ~ 01607	
Slave Device 10	01640 ~ 01671	
RTU Device 2 (Station	ID 2, 66, 130,, 961)	
Local Device	01704 ~ 01735	
Slave Device 1	01768 ~ 01799	
Slave Device 2	01832 ~ 01863	
Slave Device 3	01896 ~ 01927	
Slave Device 4	01960 ~ 01991	
Slave Device 5	02024 ~ 02055	
Slave Device 6	02088 ~ 02119	
Slave Device 7	02152 ~ 02183	
Slave Device 8	02216 ~ 02247	
Slave Device 9	02280 ~ 02311	
Slave Device 10	02344 ~ 02375	
RTU Device 3 (Station	ID 3, 67, 131,, 962)	
Local Device	02408 ~ 02439	
Slave Device 1	02472 ~ 02503	
Slave Device 2	02536 ~ 02567	
Slave Device 3	02600 ~ 02631	
Slave Device 4	02664 ~ 02695	
Slave Device 5	02728 ~ 02759	
Slave Device 6	02792 ~ 02823	
Slave Device 7	02856 ~ 02887	
Slave Device 8	02920 ~ 02951	
Slave Device 9	02984 ~ 03015	
Slave Device 10	03048 ~ 03079	
RTU Device 4 (Station ID 4, 68, 132,, 963)		
Local Device	03112 ~ 03143	
Slave Device 1	03176 ~ 03207	
Slave Device 2	03240 ~ 03271	
Slave Device 3	03304 ~ 03335	

	WIZH KIE Center Oser Manuar
Slave Device 4	03368 ~ 03399
Slave Device 5	03432 ~ 03463
Slave Device 6	03496 ~ 03527
Slave Device 7	03560 ~ 03591
Slave Device 8	03624 ~ 03655
Slave Device 9	03688 ~ 03719
Slave Device 10	03752 ~ 03783
RTU Device 64 (Station	ID 64, 128, 192,, 1024)
Local Device	45352 ~ 45383
Slave Device 1	45416 ~ 45447
Slave Device 2	45480 ~ 45511
Slave Device 3	45544 ~ 45575
Slave Device 4	45608 ~ 45639
Slave Device 5	45672 ~ 45703
Slave Device 6	45736 ~ 45767
Slave Device 7	45800 ~ 45831
Slave Device 8	45864 ~ 45895
Slave Device 9	45928 ~ 45959
Slave Device 10	45992 ~ 46023

DO Address		
Group 0 ~ 15		
Description	Address	
RTU Device 1 (Station ID 1, 65, 129,, 960)		
Local Device	01000 ~ 01031	
Slave Device 1	01064 ~ 01095	
Slave Device 2	01128 ~ 01159	
Slave Device 3	01192 ~ 01223	
Slave Device 4	01256 ~ 01287	
Slave Device 5	01320 ~ 01351	
Slave Device 6	01384 ~ 01415	
Slave Device 7	01448 ~ 01479	
Slave Device 8	01512 ~ 01543	
Slave Device 9	01576 ~ 01607	
Slave Device 10	01640 ~ 01671	
RTU Device 2 (Station ID 2, 66, 130,, 961)		
Local Device	01704 ~ 01735	

Slave Device 1	01768 ~ 01799
Slave Device 2	01832 ~ 01863
Slave Device 3	01896 ~ 01927
Slave Device 4	01960 ~ 01991
Slave Device 5	02024 ~ 02055
Slave Device 6	02088 ~ 02119
Slave Device 7	02152 ~ 02183
Slave Device 8	02216 ~ 02247
Slave Device 9	02280 ~ 02311
Slave Device 10	02344 ~ 02375
RTU Device 3 (Station	ID 3, 67, 131,, 962)
Local Device	02408 ~ 02439
Slave Device 1	02472 ~ 02503
Slave Device 2	02536 ~ 02567
Slave Device 3	02600 ~ 02631
Slave Device 4	02664 ~ 02695
Slave Device 5	02728 ~ 02759
Slave Device 6	02792 ~ 02823
Slave Device 7	02856 ~ 02887
Slave Device 8	02920 ~ 02951
Slave Device 9	02984 ~ 03015
Slave Device 10	03048 ~ 03079
RTU Device 4 (Station	ID 4, 68, 132,, 963)
Local Device	03112 ~ 03143
Slave Device 1	03176 ~ 03207
Slave Device 2	03240 ~ 03271
Slave Device 3	03304 ~ 03335
Slave Device 4	03368 ~ 03399
Slave Device 5	03432 ~ 03463
Slave Device 6	03496 ~ 03527
Slave Device 7	03560 ~ 03591
Slave Device 8	03624 ~ 03655
Slave Device 9	03688 ~ 03719
Slave Device 10	03752 ~ 03783
RTU Device 64 (Station I	D 64, 128, 192,, 1024)
Local Device	45352 ~ 45383
Slave Device 1	45416 ~ 45447

Slave Device 2	45480 ~ 45511
Slave Device 3	45544 ~ 45575
Slave Device 4	45608 ~ 45639
Slave Device 5	45672 ~ 45703
Slave Device 6	45736 ~ 45767
Slave Device 7	45800 ~ 45831
Slave Device 8	45864 ~ 45895
Slave Device 9	45928 ~ 45959
Slave Device 10	45992 ~ 46023

AI Address		
Group 0 ~ 15		
Description	Туре	Address
RTU D	evice 1 (Station ID 1, 65, 129, .	, 960)
Local Device	AI	01000 ~ 01015
	Reserve	01016 ~ 01031
	Counter	01032 ~ 01063
Slave Device 1	AI	01064 ~ 01079
	Reserve	01080 ~ 01095
	Counter	01096 ~ 01127
Slave Device 2	AI	01128 ~ 01143
	Reserve	01144 ~ 01159
	Counter	01160 ~ 01191
Slave Device 3	AI	01192 ~ 01207
	Reserve	01208 ~ 01223
	Counter	01224 ~ 01255
Slave Device 4	AI	01256 ~ 01271
	Reserve	01272 ~ 01287
	Counter	01288 ~ 01319
Slave Device 5	AI	01320 ~ 01335
	Reserve	01336 ~ 01351
	Counter	01352 ~ 01383
Slave Device 6	AI	01384 ~ 01399
	Reserve	01400 ~ 01415
	Counter	01416 ~ 01447
Slave Device 7	AI	01448 ~ 01463
	Reserve	01464 ~ 01479
	Counter	01480 ~ 01511

	1112	MI KIU CCIICI USCI Manual
Slave Device 8	AI	01512 ~ 01527
	Reserve	01528 ~ 01543
	Counter	01544 ~ 01575
Slave Device 9	AI	01576 ~ 01591
	Reserve	01592 ~ 01607
	Counter	01608 ~ 01639
Slave Device 10	AI	01640 ~ 01655
	Reserve	01656 ~ 01671
	Counter	01672 ~ 01703
RTU D	evice 2 (Station ID 2, 66, 130, .	, 961)
Local Device	AI	01704 ~ 01719
	Reserve	01720 ~ 01735
	Counter	01736 ~ 01767
Slave Device 1	AI	01768 ~ 01783
	Reserve	01784 ~ 01799
	Counter	01800 ~ 01831
Slave Device 2	AI	01832 ~ 01847
	Reserve	01848 ~ 01863
	Counter	01864 ~ 01895
Slave Device 3	AI	01896 ~ 01911
	Reserve	01912 ~ 01927
	Counter	01928 ~ 01959
Slave Device 4	AI	01960 ~ 01975
	Reserve	01976 ~ 01991
	Counter	01992 ~ 02023
Slave Device 5	AI	02024 ~ 02039
	Reserve	02040 ~ 02055
	Counter	02056 ~ 02087
Slave Device 6	AI	02088 ~ 02103
	Reserve	02104 ~ 02119
	Counter	02120 ~ 02151
Slave Device 7	AI	02152 ~ 02167
	Reserve	02168 ~ 02183
	Counter	02184 ~ 02215
Slave Device 8	AI	02216 ~ 02231
	Reserve	02232 ~ 02247
	Counter	02248 ~ 02279
Slave Device 9	AI	02280 ~ 02295

<u>M2M RTU Center User Manual</u>		
	Reserve	02296 ~ 02311
	Counter	02312 ~ 02343
Slave Device 10	AI	02344 ~ 02359
	Reserve	02360 ~ 02375
	Counter	02376 ~ 02407
RTU D	evice 3 (Station ID 3, 67, 131, .	, 962)
Local Device	AI	02408 ~ 02423
	Reserve	02424 ~ 02439
	Counter	02440 ~ 02471
Slave Device 1	AI	02472 ~ 02487
	Reserve	02488 ~ 02503
	Counter	02504 ~ 02535
Slave Device 2	AI	02536 ~ 02551
	Reserve	02552 ~ 02567
	Counter	02568 ~ 02599
Slave Device 3	AI	02600 ~ 02615
	Reserve	02616 ~ 02631
	Counter	02632 ~ 02663
Slave Device 4	AI	02664 ~ 02679
	Reserve	02680 ~ 02695
	Counter	02696 ~ 02727
Slave Device 5	AI	02728 ~ 02743
	Reserve	02744 ~ 02759
	Counter	02760 ~ 02791
Slave Device 6	AI	02792 ~ 02807
	Reserve	02808 ~ 02823
	Counter	02824 ~ 02855
Slave Device 7	AI	02856 ~ 02871
	Reserve	02872 ~ 02887
	Counter	02888 ~ 02919
Slave Device 8	AI	02920 ~ 02935
	Reserve	02936 ~ 02951
	Counter	02952 ~ 02983
Slave Device 9	AI	02984 ~ 02999
	Reserve	03000 ~ 03015
	Counter	03016 ~ 03047
Slave Device 10	AI	03048 ~ 03063
	Reserve	03064 ~ 03079

M2M RTU Center User Manual		
	Counter	03080 ~ 03111
RTU D	evice 4 (Station ID 4, 68, 132, .	, 963)
Local Device	AI	03112 ~ 03127
	Reserve	03128 ~ 03143
	Counter	03144 ~ 03175
Slave Device 1	AI	03176 ~ 03191
	Reserve	03192 ~ 03207
	Counter	03208 ~ 03239
Slave Device 2	AI	03240 ~ 03255
	Reserve	03256 ~ 03271
	Counter	03272 ~ 03303
Slave Device 3	AI	03304 ~ 03319
	Reserve	03320 ~ 03335
	Counter	03336 ~ 03367
Slave Device 4	AI	03368 ~ 03383
	Reserve	03384 ~ 03399
	Counter	03400 ~ 03431
Slave Device 5	AI	03432 ~ 03447
	Reserve	03448 ~ 03463
	Counter	03464 ~ 03495
Slave Device 6	AI	03496 ~ 03511
	Reserve	03512 ~ 03527
	Counter	03528 ~ 03559
Slave Device 7	AI	03560 ~ 03575
	Reserve	03576 ~ 03591
	Counter	03592 ~ 03623
Slave Device 8	AI	03624 ~ 03639
	Reserve	03640 ~ 03655
	Counter	03656 ~ 03687
Slave Device 9	AI	03688 ~ 03703
	Reserve	03704 ~ 03719
	Counter	03720 ~ 03751
Slave Device 10	AI	03752 ~ 03767
	Reserve	03768 ~ 03783
	Counter	03784 ~ 03815
RTU Device 64 (Station ID 64, 128, 192,, 1024)		
Local Device	AI	45352 ~ 45367

Publication October, 2022 Ver. 1.12

	M2	<u>M RTU Center User Manual</u>
	Reserve	45368 ~ 45383
	Counter	45384 ~ 45415
Slave Device 1	AI	45416 ~ 45431
	Reserve	45432 ~ 45447
	Counter	45448 ~ 45479
Slave Device 2	AI	45480 ~ 45495
	Reserve	45496 ~ 45511
	Counter	45512 ~ 45543
Slave Device 3	AI	45544 ~ 45559
	Reserve	45560 ~ 45575
	Counter	45576 ~ 45607
Slave Device 4	AI	45608 ~ 45623
	Reserve	45624 ~ 45639
	Counter	45640 ~ 45671
Slave Device 5	AI	45672 ~ 45687
	Reserve	45688 ~ 45703
	Counter	45704 ~ 45735
Slave Device 6	AI	45736 ~ 45751
	Reserve	45752 ~ 45767
	Counter	45768 ~ 45799
Slave Device 7	AI	45800 ~ 45815
	Reserve	45816 ~ 45831
	Counter	45832 ~ 45863
Slave Device 8	AI	45864 ~ 45879
	Reserve	45880 ~ 45895
	Counter	45896 ~ 45927
Slave Device 9	AI	45928 ~ 45943
	Reserve	45944 ~ 45959
	Counter	45960 ~ 45991
Slave Device 10	AI	45992 ~ 46007
	Reserve	46008 ~ 46023
	Counter	46024 ~ 46055

AO Address		
Group 0 ~ 15		
Description	Address	
RTU Device 1 (Station ID 1, 65, 129,, 960)		
Local Device	01000 ~ 01031	

M2M RTU Center User Manual Slave Device 1 01064 ~ 01095 Slave Device 2 01128 ~ 01159 Slave Device 3 01192 ~ 01223 Slave Device 4 01256 ~ 01287 Slave Device 5 01320 ~ 01351 Slave Device 6 01384 ~ 01415 Slave Device 7 01448 ~ 01479 Slave Device 8 01512 ~ 01543 Slave Device 9 01576 ~ 01607 Slave Device 10 01640 ~ 01671 Reserve 01672 ~ 01703 RTU Device 2 (Station ID 2, 66, 130, ..., 961) Local Device 01704 ~ 01735 01768 ~ 01799 Slave Device 1 Slave Device 2 01832 ~ 01863 Slave Device 3 01896 ~ 01927 Slave Device 4 01960 ~ 01991 Slave Device 5 02024 ~ 02055 Slave Device 6 02088 ~ 02119 Slave Device 7 02152 ~ 02183 Slave Device 8 02216 ~ 02247 Slave Device 9 02280 ~ 02311 Slave Device 10 02344 ~ 02375 Reserve 02376 ~ 02407 RTU Device 3 (Station ID 3, 67, 131, ..., 962) Local Device 02408 ~ 02439 Slave Device 1 02472 ~ 02503 Slave Device 2 02536 ~ 02567 Slave Device 3 02600 ~ 02631 Slave Device 4 $02664 \sim 02695$ Slave Device 5 02728 ~ 02759 Slave Device 6 02792 ~ 02823 Slave Device 7 02856 ~ 02887 Slave Device 8 02920 ~ 02951 Slave Device 9 $02984 \sim 03015$ Slave Device 10 03048 ~ 03079 Reserve 03080 ~ 03111 RTU Device 4 (Station ID 4, 68, 132, ..., 963)

	MZWI KIU Center User Manual
Local Device	03112 ~ 03143
Slave Device 1	03176 ~ 03207
Slave Device 2	03240 ~ 03271
Slave Device 3	03304 ~ 03335
Slave Device 4	03368 ~ 03399
Slave Device 5	03432 ~ 03463
Slave Device 6	03496 ~ 03527
Slave Device 7	03560 ~ 03591
Slave Device 8	03624 ~ 03655
Slave Device 9	03688 ~ 03719
Slave Device 10	03752 ~ 03783
Reserve	03784 ~ 03815
RTU Device 64 (Station ID 64, 128, 192,, 1024)	
Local Device	45352 ~ 45383
Slave Device 1	45416 ~ 45447
Slave Device 2	45480 ~ 45511
Slave Device 3	45544 ~ 45575
Slave Device 4	45608 ~ 45639
Slave Device 5	45672 ~ 45703
Slave Device 6	45736 ~ 45767
Slave Device 7	45800 ~ 45831
Slave Device 8	45864 ~ 45895
Slave Device 9	45928 ~ 45959
Slave Device 10	45992 ~ 46023

5.2 How Restful API Get & Post

GET	/DeviceInfoQuerry/DeviceNum				
Response	Responses:				
Media ty	Media type: application/json				
Example	Example Value:				
{"Device	{"DeviceNum":"5","ModbusName":["Local IO,MB_33","Local IO,MB_33","Local				
ÍO,MB_3	IO,MB_33","Local IO,MB_33","Local				
IO,MB_3	IO.MB_33"]."ModbusNum":[2.2.2.2.2]."ModuleName":["aa_0001"."aa_0002"."aa_0003"				
."aa 0004"."aa 0005"]."ModuleNameLength":[7.7.7.7.7]."SlaveID":["255.33"."255.33"."					
255,33","255,33","255,33"],"StationID":[1,2,3,4,5],"Status":["online","online					
ine","offline"]}					
Value Pa	Value Parsed:				
▼ {	and a structure of the th				
v "Mo	bdbusName": [
	"Local IO,MB_33",				
	"Local IO,MB_33",				
	"Local IO,MB_33", "Local IO MB_33"				
	"Local IO,MB_33"				
],					
▼ "Mo	dbusNum": [
	2, 2.				
	2,				
	2,				
1	2				

<pre>"ModuleName": [</pre>	
"aa_0001",	
"aa_0002",	
"aa_0003",	
"aa_0004",	
"aa_0005"	
],	
▼ "ModuleNameLength": [
7,	
7,	
7,	
7,	
7	
],	
▼ "SlaveID": [
"255.33".	
"255.33".	
"255.33".	
"255.33".	
"255.33"	
1.	
<pre>v "StationID": [</pre>	
1.	
2.	
3.	
4.	
5	
1,	
v "Status": [
"online",	
"online",	
"online",	
"online",	
"offline"	
1	
}	
*	

GET /DeviceInfoQuerry/{Station ID, Slave ID}

Responses:

Media type: application/json

Example Value:

Value Parsed:

```
/DeviceInfoQuerry/SetInfo
 POST
  SID
             // Integer
  • MID
             // Integer
  • Type // String
  • Offset // Integer
  • Value // String
PHP Example:
 $dataArr = array("SID"=>(int)$_POST['pSid'],"MID"=>(int)$_POST['pMid'],
 "Type"=>$_POST['pType'],"Offset"=>(int)$_POST['pOffset'],"Value"=>$_POST['pVal']);
$returnVal = CallAPI("POST", POST['postUrl'], json_encode($dataArr));
 function CallAPI($method, $url, $data = false)
 ł
     $curl = curl_init();
     switch ($method)
     ł
         case "POST":
             curl_setopt($curl, CURLOPT_POST, 1);
             if ($data)
                 curl_setopt($curl, CURLOPT_POSTFIELDS, $data);
             break;
         case "PUT":
             curl_setopt($curl, CURLOPT_PUT, 1);
             break;
         default:
             if ($data)
                 $url = sprintf("%s?%s", $url, http_build_query($data));
     }
     // Optional Authentication:
     curl setopt($curl, CURLOPT HTTPAUTH, CURLAUTH BASIC);
     curl_setopt($curl, CURLOPT_USERPWD, "username:password");
     curl_setopt($curl, CURLOPT_URL, $url);
     curl_setopt($curl, CURLOPT_HTTPHEADER, array(
         'Content-Type: application/json',
      ));
     curl_setopt($curl, CURLOPT_RETURNTRANSFER, 1);
     $result = curl_exec($curl);
     curl_close($curl);
     return $result;
```

Responses:

{"Status":"ok/failed"}

HTTP Methods : Post (By curl)

Query=> curl -X POST -H "Content-Type: application/json" -d '{"SID": {Station ID}, "MID": {Slave ID}, "Type": "{DO/DOCH/AOCH}", "Offset": {Value}, "Value": "{Value}"}' http://{IP}:{Port}/DeviceInfoQuery/SetInfo EX: curl -X POST -H "Content-Type: application/json" -d "{\"SID\": 1, \"MID\": 255, \"Type\": \"DO\", \"Offset\": 0, \"Value\": \"0,0,0,0\"}" http://127.0.0.1:7788/DeviceInfoQuery/SetInfo curl -X POST -H "Content-Type: application/json" -d "{\"SID\": 1, \"MID\": 255, \"Type\": \"AOCH\", \"Offset\": 0, \"Value\": \"1234\"}" http://127.0.0.1:7788/DeviceInfoQuery/SetInfo Response<= {"Status": "ok/failed"} C:\Windows\system32\cmd.exe D:\curl-7.65.3-win64-mingw\bin>curl -X POST -H "Content-Type: application/json" -d "{\"SID\": 1, \"MID\": 255, \"Type\": \"DO\", \"Offset\": 0, \"Ualue\": \"0,0 ,0,0\"}" http://127.0.0.1:7788/DeviceInfoQuery/SetInfo {"Status":"ok"} D:\curl-7.65.3-win64-mingw\bin>

Note: curl is used in command lines or scripts to transfer data. Users can down from the following URL: <u>https://curl.se/</u>

Parameters

Parameter	Description	
Station ID	RTU Device ID (1~65535)	
Slave ID	Modbus Device ID (Local: 255, Slave:0~254)	
Value	DI: 0 Or 1	
	DO: 0 Or 1	
	AI: 0 ~ 65535	
	AO: 0 ~ 65535	

Version Record

Version	Ву	Date	Description
1.00	Yide	2010/02/12	
1.01	Yide	2010/03/28	
1.02	Yide	2010/06/02	
1.03	Bird	2011/11/02	
1.11	Selby	2021/04/23	New features:
			1.Modbus Server
			2.Restful API support
1.12	Ferris	2022/10/31	

s