## Q: How many PCs can be connected to one 7188E/8000E device?

Ans : It depends on how many serial ports on the 7188E/8000E and how many serial ports of 7188E/800E that each PC connected on it.

7188E/8000E has 32 sockets totally and it reserves some sockets for listening.

7188E/8000E provides one command port for configuring all data (serial) ports. Thus, no matter how many data (serial) ports of 7188E/8000E you used, you need one more socket connection for the command port to configure them.

	CMD	Data	Listening Sockets	Left Sockets	PCs with all ports	PCs with 1 port
	Ports	Ports	=1 CMD + all Data	=Max Listening	=Left / (1 CMD + all Data)	=Left / (1 CMD+1 Data)
7188E1	1	1	2	32 - 2 = 30	30 / 2 = 15	30 / 2 = 15
7188E2	1	2	3	32 - 3 = 29	29 / 3 = 9	29 / 2 = 14
7188EA/X						
7188E3	1	3	4	32 - 4 = 28	28 / 4 = 7	28 / 2 = 14
7188E4	1	4	5	32 - 5 = 27	27 / 5 = 5	27 / 2 = 13
7188E5	1	5	6	32 - 6 = 26	26 / 6 = 4	26 / 2 = 13
7188E8	1	8	9	32 - 9 = 23	23 / 9 = 2	23 / 2 = 11
8430/8830	1	2	3	32 - 3 = 29	29 / 3 = 9	29 / 2 = 14
8431/8831						

## Note:

1. CMD port = Command port (TCP port 10000)

It's used to configure all data ports (TCP port 10001 ~ 10008) of a 7188E/8000E, such as baudrate, data format ... etc.

- Data port (TCP port 10001 ~ 10008 whichs are mapped to serial port 1 ~ 8 of 7188E/8000E), it's used to send/receive data only.
- Listening Sockets (of 7188E/8000E) = Number of Data ports + 1 CMD port (VCOM3010.exe reserves 2 more sockets for TELNET and UDP CMD port listening.)
- 4. Left Sockets (of 7188E/8000E) = Max. (32) sockets Listening sockets
- 5. Number of PCs could be connected to one 7188E/8000E with all data ports used
  = Left sockets / [Number of Data ports + 1 CMD port ]
- Number of PCs could be connected to one 7188E/8000E with 1 data port used
  = Left sockets / (1 Data port + 1 Command port) = Left sockets / 2

Written by Gary Lin

Date:2002/12/16