Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	1 / 19

Chapter 6: Linking RS-485 I-7000 & I-87K I/O Modules

Note:

1. The I-87017**R** and I-87017**RC** is better than I-87017 and I-87017C in industrial application.

 The I-87018Z is better than I-87018R and I-87018 in industrial application. (I-87018Z has 10-channels. The precision is better than I-87018R and I-87018. And each channel can configure to be different Input type and range. For example, using Ch.1 to 4 to measure 4 to 20 mA, using Ch.5 to 8 as Thermo-Couple K-Type, using Ch.9 to measure +/- 2.5 V, and using Ch.10 as Thermo-Couple R-Type.)

3. The I-7018Z is better than I-7018R and I-7018. (The reason is the same as I-87018Z)

I-7018Z: http://www.icpdas.com/en/product/I-7018Z-G_S I-87018Z: http://www.icpdas.com/en/product/I-87018ZW-G_S

For more description about using I-87018Z and I-7018Z, please refer to section 11.3.9 of the ISaGRAF user manual or http://www.icpdas.com/en/faq/index.php?kind=280#751 – FAQ-055.

Please refer to Section 1.5 of the I-8xx7 Getting Started for connection instructions between the I-8xx7 PAC system to the I-7000 and I-87K I/O modules.

Very Important:

Please wire an terminal resistor around 110 to 330 ohms at I-7188EG/XG, I-8xx7 or W-8xx7 PAC's RS-485 port , between the D+ and the D- pin (or beween the RS-485+ and RS-485- pin).

This will ensure the host watchdog of I-7000 and I-87K output modules to work correctly when the communication between the PAC and the I-7000/I-87K output modules is broken. (You can try 110 ohms first, then try 220 ohms, then others)

For example, if you don't wire any terminal resistor and enable the host watchdog function at "bus7000b" (Section 6.2 of the ISaGRAF user manual, the "host_watchdog" parameter set as 1), when you just un-plug the I-7000's "DATA+" pin (keep "Data-" pin connected with the PAC), you will see the watchdog doesn't work in this I-7000. If you wire a resistor about 110 ohms between the PAC's RS-485 D+ and D- pin, if you un-plug anyone of I-7000's "Data+" or "Data-" pin, the watchdog will work correctly.

Classification	ISaGRAF English FAQ-061						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	2 / 19

6.1: Configuring The I-7000 & I-87K Modules

Note:

- A. If RS-485 remote I-7000 and I-87K I/O module's type is Analog Input, please configure the format as "2's complement" by DCON Utility. Like : I-7005, I-7013,I-7015, I-7016, I-7017, I-7017R, I-7017RC, I-7018, I-7018R, I-7018Z, I-7019, I-7019R, I-7033, I-87013, I-87015, I-87016, I-87017, I-87017R, I-87017RC, I-87018, I-87018R, I-87018Z and I-87019R.
- B. If RS-485 remote I-7000 and I-87K I/O module's type is Analog Output, please configure the format as "Engineer Unit" by DCON Utility. Like : I-7021, I-7022, I-7024, I-87022, I-87024 and I-87026.

To begin configuration of the I-7000 and I-87K series modules to the PAC system, use the "DCON Utility" program to set up the I-7000 and I-87K modules. Please use DCON Utility of version 4.4.3 or later version at http://www.icpdas.com/en/product/guide+Software+Utility_Driver+DCON_Utility_Pro

- **Notes:** 1. Make sure the hardware connection is correct.
 - 2. Search and configure the modules one by one.
 - 3. Connect the module's INIT* to GND and Power on the module.

Step1: Hardware connection

- A. The power supply must be DC power between +10V to +30V.
- B. Wiring diagram for connecting to I-7000: (one module for each time)



Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	3 / 19

Note: For configuring I-7000 and I-87K I/O module, you have to prepare an I-7520R converter. Refer to "DCON Utility User's Manual" for other wiring diagram. Visit the website for more converters. http://www.icpdas.com/en/product/guide+Industrial_Communication+Serial_Communication+ Converter

Step2: Set I/O module to initial state

If the module is a new one, factory have set a default settings for user's convenient. If you don't know the configuration of the module, please set the I/O module to initial state.

- *** To set I-7000 module to initial state is to wire connect the INIT* to GND and Power on the module. Then the module will become initial state. (Some new designed I-7000 modules have a Dip-switch at its back. Please switch it to the "INIT" position, then power up the module)
- *** I-87K module's initial state is set by I-87K4/5/8/9's dip switch. For example, setting dip-2 to "ON", and then re-cycle the power, it means the second slot is in initial state. If using I-87K5 and I-87K9, please DO NOT plug I-87K board in its left-most slot for initial configuration. Please plug at 2nd to 9th slot for initial configuration. The dip-1 is for 2nd slot of I-87K5 and I-87K9, ..., dip-4 is for 5th slot, Dip-8 is for 9th slot of I-87K9).

Some new designed I-87K I/O modules have dip-switch built-in. Their "INIT/Normal" state is controlled by its own dip-switch not by the dip-switch of I-87K4/5/8/9.

I/O Module	I-7000	M-7000	87K series
Address	1	1	1
Baud rate	9600	9600	115200
Checksum	Disabled	Not defined	Disabled
Protocol	DCON Protocol	Modbus Protocol	DCON Protocol

The default state from factory:

The initial state after initiation:

I/O Module	7000 series (I-7000 and M-7000)	87K series
Address	0	0
Baud rate	9600	115200
Checksum	Disabled	Disabled
Protocol	DCON Protocol	DCON Protocol

Classific	cation	ISaG	GRAF Englis	sh FAQ-06	51						
Author		Chur	n Tsai	Version	1.0.0	Date	Apr. 2007	7 Page	!	4 / 19	
				• •						I	
Step3:	Select C	OM	port and b	baud rate	to search						
Execute	Execute the DCON Utility from "Start/programs/DAQPro/DCON Utility/".										
			_								
Pro	arome (D)		🖬 DAQPro			🕨 💼 D	CON Utility 🔸	🖉 DCO1	l Utility		
IIO	grams(r)		🛅 Rainlendar			+ 🛅 N	APOPC	🖬 Unins	tall DCON	Utility	`
			🦲 Internet Ex 🗟 OpenOffic	plorer			CE_Pro ►	E DCOl	√_Support	t_Module_List	
🤳 sta	art 🛛 🗹	Ø	m PDFCreato	e.org 2.0 r			I	E versio			
						1					
1 Click	"CON/ Do	nt" m	enu to celo	oct the CO	M nort and ha	ud rate	to search V	011 (20 6)	alert m	ulti-haud	
rate.	protocol	or ch	ecksum co	nditions if	vou do not kr	ow the	module's se	tting, but	t it will	spend mc	ore
time	to scan th	he ne	twork. Afte	er selection	n, click "OK".			0, 11			
2. Click	上 "Sta	art Se	arch" icon	to begin s	earch module	Click	🔟 when it i	s found.			
	DCOX -	U t ility									
	<u>Fi</u> e <u>C</u> OM	Port	1. <u></u>	minel <u>H</u> e	Select the CO	M Port and	Baud Rate	×			
	The Found	d Out I	-7000/8000 m	odule	COM to search		Time Out Setti	ng :			
								300 ms			
	Module	X	Address B	audrate Che	Baud Rate to s	earch:					
		2.)		921600	460800	230400	115200			
		\bigcirc				38400 2400	j ⊘ 19200 j⊘ [⊂ 1200	9600			
					<u>S</u> ela	ct All	Cl <u>e</u> ar			=	
					-Select Protoco	l Option					
	<					ON Contraction	Modbu:	s RTU	>		
	Search	ning Sta	atus:		- Select Checks	um Uptior Disable	r I Enable				
	COM Po	ort: JCOI	M 2 Addr	^{ess:} 00[dec]					-		
								ĸ		~	
						el				11.	
				ICP DAS (Co., Ltd. Techn	ical Doc	ument				
					,						



Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	6 / 19

IMPORTANT NOTES Regarding remote I-7000 & I-87K Modules:

One I-8xx7, I-7188EG/XG PAC system can link up to a maximum of **64** pcs. of I-7000 and I-87K modules (**However 255 pcs for W-8xx7**). It is recommended though that you do not link more than **24** modules to a single I-8xx7 and 7188EG/XG, while 64 modules for a W-8xx7 PAC system.

Each I-7000 and I-87K module MUST have it's own unique address to properly link to an ISaGRAF PAC system. The default "Checksum" setting is disabled (If set as enabled, please connect "bus7000b" listed in section 6.2 and set "checksum" parameter to 1), and make sure that all of the I-7000 and I-87K modules are set to the same baud rate and same checksum setting as the PAC system (9600 baud by default).

When you receive any of the I-7000 series modules or I-87K modules you will receive documentation called "Getting Started With I-7000 Series Modules" that provides instructions on how to properly configure these modules. If you need assistance on changing the baud rate or checksum, please refer to the "Change Baud Rate & Checksum" section in the "Getting Started With I-7000 Series Modules". You can find all of the documentation on the wesite provided with your I-7000 series module from ICP DAS in a file titled "getstart.pdf".

If RS-485 remote I-7000 and I-87K I/O module's type is Analog Input, please configure the format as "2's complement" by DCON Utility. Like : I-7005, I-7013,I-7015, I-7016, I-7017, I-7017R, I-7017RC, I-7018, I-7018R,I-7018Z, I-7019, I-7019R, I-7033, I-87013, I-87015, I-87016, I-87017, I-87017R, I-87017RC, I-87018,I-87018R, I-87018Z and I-87019R.

If RS-485 remote I-7000 and I-87K I/O module's type is Analog Output, please configure the format as "Engineer Unit" by DCON Utility. Like : I-7021, I-7022, I-7024, I-87022, I-87024 and I-87026.

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	7 / 19

6.2: Opening the "Bus7000b" Function

To create a link between the I-8xx7, I-7188EG/XG & W-8xx7 PAC system and an I-7000 and I-87K module, you need to connect the "Bus7000b" function through the "ISaGRAF I/O Connection" window.

The "Bus7000b" function is considered a "virtual board", and must be selected from the "Equipments" section of the "Select Board/Equipment" window.

The "Bus7000b" MUST be connected to slot number **8 or higher** on the "ISaGRAF I/O Connection" window (since slot 0 through 7 are used to connect to real I-8000 boards). **Only one "Bus7000b"** can be linked to one PAC system! If you attempt to connect more than one "Bus7000b" to an ISaGRAF PAC, it will not work.



In the example provided, set the slot below number 9 to "Bus7000b: Remote".

ICP DAS Co., Ltd. Technical Document

Classification	ISaGRAF Englis	SaGRAF English FAQ-061								
Author	Chun Tsai	Version	1.0.0	Date Apr. 2007		Page	8 / 19			
ISaGRAF - C File Edit Iools 0 1 2 3 4 5 6 7 8 9 m bus7 10	CREATION - 1/O conn © Options Help D ① ① ↓ F (000b t ··· +	100 ref = / 100 ref = / 1000 com_ 1000 com_ 1000 com_ 1 1	L □ port = 3 baud = 9600 watchdog = 0 dog_timer = 1E sum = 0		Com_port set I-8xx7: 3 or 4 I-7188EG/XG W-8xx7: 3	tting: (COM3 or : 2 or 3	COM4)			

The "**com_port**" parameter can have a value of 3 (for COM3) or 4 (for COM4) for the I-8xx7 PAC, while 2 (COM2) or 3 (COM3) for the I-7188EG/XG, and 3 (COM3) for the W-8xx7. This parameter defines which COM port ID the PAC system will communicate with the I-7000/I-87K module. The default value for the "com_port" parameter is 3.

The "**com_baud**" parameter defines the baud rate that the ISaGRAF PAC will communicate with the I-7000/I-87K module. The possible values are 2400, 4800, 9600, 19200, 38400, 57600, and 115200. Make sure that the PAC and the I-7000/I-87K modules are all set to the same "com_baud" value.

The "**host_watchdog**" parameter enables or disables the watchdog function for the I-7000 and I-87K module. Setting the "host_watchdog" parameter to a non-zero value will enable the "host_watchdog" feature.

The "**watchdog_timer**" parameter defines the amount of time before a "host_watchdog" will occur. The value for the "watchdog_timer" is defined in a **hexadecimal** value with the units defined in 0.1second increments. For example, if the "watchdog_timer" is set to a value of 1E, the "watchdog_timer" is set for 3 seconds. If the "watchdog_timer" value is set to 2A, the "watchdog_timer" is set for 4.2 seconds.

The "**checksum**" parameter defines the remote IO is using "0: No checksum" or "1: with checksum". (The old "bus7000" not supporting "checksum" options. **Bus700b** does support it)

If the host watchdog feature is activated and the watchdog timeout occurs on PAC that means the connection between the PAC and I/O modules is break, and then the value of I-7000/I-87K modules will be set to a "safe" value that configured by using DCON Utility. Normally for Digital Output channel, the "safe" state is D/O=OFF or D/O=False.

There is an analog input channel available on the "Bus7000b: Remote" virtual board. This analog input channel will return a value equal to the currently set baud rate.

ICP DAS Co., Ltd. Technical Document

Classification	ISaGRAF Englis						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	9 / 19

6.3: Programming an I-7000 & I-87K Module

6.3.1: Program I_7xxx or I_87xxx remote IO function blocks

To link any I-7000 and I-87K module to the I-8xx7, I-7188EG/XG & W-8xx7 PAC system, the "Bus7000b" module MUST be opened first. Once the "Bus7000b" is opened, the "I_7xxx" / "I-87K" function block can now be programmed and you can access all of the I/O channels available from that function block, and that data can now be used in a LD program.

NOTE: Please declare all variables which connect to the I-7000/I-87K block as "Internal" attribution.





Classification	ISaGRAF English FAQ-061						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	10 / 19

Example 3: Programming a I-87017R or I-7017RC function block

(The hardware should be I-87017RC and I-7017RC, current input measurement)

I-87017RC and I-7017RC can measure current input of \pm 20 mA , 0 ~ 20mA and 4 ~ 20mA. Unlike I-87017, I-87017R and I-7017, no external 125 ohm resistor required . Please configure their format as "2's complement" by DCON Utility. (The "A4_20_to" function can be used to convert the analog input value to user's engineering value, please refer to ISaGRAF Appendix A.4)

Pango typo			I-7017RC /87017RC				
(by "DCON Utility")	Physical value	Analog Input value					
		- 32768	0	+32767			
7	4 ~ 20 mA		4 mA	20 mA			
D	± 20 mA	- 20 mA	0 mA	20 mA			
1A	0 ~ 20 mA		0 mA	20 mA			



Classification	ISaGRAF English FAQ-061						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	11 / 19

Note:

If the current input sensor is 4 to 20 mA, user may better set I-7017RC or I-87017RC ' range type to "[D] : +/- 20 mA", or "[1A] : 0 ~ 20 mA". (set as " [7] : 4 to 20 mA" is not good)

The reason is :

If setting RS-485 I-7017RC or I-87017RC 's range type as "**[7] : 4 to 20 mA**", analog input value of 0 or close to 0 could mean the Sensor input is 4 mA, and also possible the Sensor is broken-line. So it is not easy to distinguish these two situation by software.

Howevr, if setting I-7017RC or I-87017RC 's range type as "**[D] : +/- 20 mA**" or "**[1A] : 0 ~ 20 mA**", analog input value of 0 or close to 0 only means the Sensor is broken-line . If the Sensor input is 4 to 20mA , the analog value should be 6553 to 32767, not close to 0.

(Of course, the communication state of the RS-485 I-7017RC and I-87017RC should be Ok. The "Ok1" and "OK2" variable in the above example 3 can indicate the communication is Ok or not. If the communication is False, it means the PAC can not link to the RS-485 I/O well. You need to handle this situation in your ISaGRAF program).

Example 4: Program I-7018 block for I-7018R and I-7018 (Please use new "i_7018n" block)

(I-7018Z is a better hardware than I-7018 and I-7018R. Please refer to Section 11.3.9 of ISaGRAF user manual or http://www.icpdas.com/en/faq/index.php?kind=280#751 FAQ-055 for demo example)

Please configure I-7018 and I-7018R's format as "2's complement" by DCON Utility. Then please program a "I_7018n" block (The "I_7018n" block request all 8-channels by one single command, however the "I_7018" block need to send 8 commands for 8-channels)



Classification	ISaGRAF English FAQ-061						
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	12 / 19

The other RS-485 I-7000 and I-87K I/O all use the similar way.

Note:

If RS-485 remote I-7000 and I-87K I/O module's type is **Analog Input, please configure the format as "2's complement" by DCON Utility.** Like : I-7005, I-7013, I-7015, I-7016, I-7017, I-7017R, I-7018, I-7018R, I-7018Z, I-7019, I-7019R, I-7033, I-87013, I-87015, I-87016, I-87017, I-87017R, I-87018, I-87018R, I-87018Z and I-87019R.

If RS-485 remote I-7000 and I-87K I/O module's type is **Analog Output, please configure the format as "Engineer Unit" by DCON Utility.** Like : I-7021, I-7022, I-7024, I-87022, I-87024 and I-87026.

Below table is for the I-7017, 7017R, 87017, 87017R.

(These modules need external 125 ohm resistor if using "D: ± 20mA")

Danca tuan		I-7017 / 87017					
(by DCON Utility)	Physical value	Analog Input value					
(by DCON Othry)		-32768	0	+32767			
8	\pm 10V	- 10V	0V	+ 10V			
9	± 5V	- 5V	0V	+ 5V			
А	\pm 1V	- 1V	0V	+ 1V			
В	± 500mV	- 500mV	0mV	+ 500mV			
С	\pm 150mV	- 150mV	0mV	+ 150mV			
D	\pm 20mA	- 20mA	0mA	+ 20mA			

Below table is for the I-7017RC and I-87017RC (no external 125 ohm resistor required)

Dense tuen			I-7017 / 87017			
(by DCON Utility)	Physical value	Analog Input value				
		-32768	0	+32767		
7	4 ~ 20mA		4mA	20mA		
D	± 20mA	- 20mA	0mA	20mA		
1A	0 ~ 20mA		0mA	20mA		

Classificatio	n	ISaGRAF E	nglish FAQ-061					
Author		Chun Tsai	Version 1.	0.0	Date	Apr. 2007	Page	13 / 19
Please refer	to th	e on-line he	lp for each I/O m	nodule's tab	le or ref	fer to the ISaG	RAF Appendi	x D.
Double-click	on tł	ne function	block and click th	ne Info butto	on and t	then click the N	lote button.	
1	📷 ISa(FRAF - TEST1:LD	91 - Quick LD Program					
-	File E	dit <u>T</u> ools Options) 📈 🛄 ዱ 🔒	Help 1 😵 🔀 🗈 💰 🚯 I	?⊦ Q, Q, ⊞ ∰				
	F2: HEE	F3: HHE F4: THE F5:	O4 F6: OH F7: HO F8: T ₀ HT	F9: →> +F9:@>				
	(* *)		I 7019N	сс	MM OK15	<u> </u>		
		ŀ	lenQ					
			15-ADR_NI1_A	A1				
		Function block		•	×			
		GET_SN ge	at hardware unique serial No.					
		GET_VER GO GETCTS GO HYSTER by	et Hardware Driver Version et CTS status /steresis	<u>C</u> ancel				
		I_7005D 80	ch Thermistor, 2'comp, Integer ch Thermistor, Enginer,Integer	<u>l</u> nfo				
		I_7005D3 80 I_7011D 1 I_7012D 1	ch Thermistor, Enginer, Real Thermo. , 1 DI/EV, 2 DO/ALM Ana-Inn: 1 DI/EV, 2 DO Para t	meters - T 7018N	<u> </u>			X
	┛	L_7013D 1 L_7013D2 1c	CH. RTD,2's complement					
	pos=2,3	L_7014D 1. L_7015 6. L_7016D 1	Ana-Inp ,1 DI/EV,2 DO CH. Analog Input , RTD AI 1 AO 1 DI/EV 4 DO	I_7018N			<u>N</u> ote	
		L_7016D2 2.	AI, 1 AO, 1 DI/EV, 4 DO CH. Analog Input	<u>50</u> - 51-	→[]+ NI1_ →[]+ NI1_			
		L_7017RC 8 L_7018 8 7018N Es	CH. Analog Input suppo CH. Thermocouple Inpu Inster: S.CH. Thermocourt	53 - 53 -	→[Z]+ NI3_ →[Z]+ NI3_ NI4			
				S5	→[Z]+ NI5_		•	
		Technical	notes			×		
		C function	blocks	n:Faster, 8 CH. Therm	iocouple Input	_		
			'IE Q IS FALSE . IT M	IFANS COMMUN	NICATION	S BAD, TH		
		NIL	NI8 : integer Ana	alog input value	of channe	el 1 ~ 8		
			_ Min →	—> Ma	×)			
		mod	-32768 bus val: 8000 —> 0	0 327 1000> 7FFF	767			
		notes(Ve	ery Imp ortantj:			•		
			ICP DAS Co.	, Ltd. Techn	ical Doc	ument		

Classificatio	n ISaGRAF Er	iglish FAQ-0	61	I			
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	14 / 19
5.3.2: Settiı "Deg	ng a special "AD ree Celsius" or '	PR_" param 'Degree Fal	eter of rer hrenheit"	note tempe input value	erature input	t module to	o get clear
CPDAS provi	des many tempe	rature input	modules as	s below.			
With "broker Thermo RTD ty Thermi	n-line detection" ocouple type: I-8 pe: I-8 ister type: I-8	or called "wi 37018Z, I-870 37013, 87015 37005, 7005	re opening 018R, 87019 5, 7013, 702	detection" 9R, 7018Z, 7(15, 7033	018R, 7018BL,	, 7019, 7019	IR
Without "bro Thermo	oken-line detectio ocouple type: I-8	on" 37018, 7018,	7018P				
The "ADR_" For example setting", the normally –32 Utility). (Nor	oarameter of tem setting "ARD_" o value of 1 to 255 768 to + 32767 ir mally, value of –3	perature IO f the "I_7033 indicates the n the case. It 2768 & +327	function bl 3" function e address c depends o 767 means	ock can be " block to 1 to f the remote n the IO moo wire "broker	standard setti 255 (Dec. val 1-7033. The t dule's "Type c n-line")	ing" or "spec lue) means ' cemperature ode" setting	cial setting". "standard e input value g (Set by DCC
	· (10-ADR_) ³³ Q_) NI1_ —Ter NI2_ —Ter	nper1 nper2	0k1 >	1	
	/		NI3 Ter	nper3			
	ADR_ = 10 (TT= the temperatur	00, RR=00, A e input value	A= 0A , Hex e is normall) means "sta y –32768 to	andard setting + 32767	;", address=:	10,
	If ADR_= 16# 10 "Degree Celsius address=26, the example, value	201A (TT=10 s", "type code temperatur of 4556 mar), RR=20, A e=20 of this re input val is "45.56" o	A=1A, Hex) n s I-7033 mod ue is a clear degree. "-500	neans "specia lule set by DC "Degree Celsi)" means "-5.0	l setting", ON Utility", us" value, fo 00" degree.	or
lf user want t Celsius. Then	to get a clear tem please set "ADR	perature inp _" to a specia	out value, fo al value def	or example, v fined as belo	value of 2312 w.	means "23.	12" Degree
Important:	Special "ADR_" s	etting is sup	ported sinc	e driver vers	ion of		
					mont		

Classification	ISaGRAF Engl	sh FAQ-06	51				
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	15 / 19
1-8v	v7·311 I_719	8FG: 2 09	I-2188XC· 2	07 \\/	-8xx7·3 2/		
1-07	×7. 3.11, I-710	86LG. 2.0 <i>9</i> ,	, 1-7100AU.2	.07, 00	-0,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
		ICP DAS (Co., Ltd. Techn	ical Docu	ument		

							T	-			
Classification	ISaGRAF Engli	ISaGRAF English FAQ-061									
Author	Chun Tsai	nun Tsai Version 1.0.0 Date Apr. 2007 Page 16 / 19									
Format: TTRRAA (Hex.)											
TT=10 (Convert to "Degree Celsius")											
TT=20 (Convert to "Degree Fahrenheit")											
TT=00 (standard setting, -32768 to +32767. RR should be set as 00 if TT=00)											
RK: ty	/pe code setting (of the rela	ited temperatu	re input	moal	ne					
AA: du		ed temper	ature input inc	dule							
For example, setting "ADR_" as											
A. 16#102011:	(TT=10, RR=20, AA=11, Hex) the input value will be "Degree Celsius", unit is 0.01 degree, range= "20 : Platinum 100, a=0.00385, degree Celsius", address=17(Dec.). That results input value of "2356" = 23.56 Degree Celsius, "-489" = -4.89 Degree Celsius, "999990" = sensor broken-line.										
B. 16#202A03:	(TT=20, RR=2A, A unit is 0.01 degre address=3(Dec.). "500" = 5.00 Deg	(TT=20, RR=2A, AA=03, Hex)) the input value will be "Degree Fahrenheit", unit is 0.01 degree, range= "2A : Platinum 1000, a=0.00385, degree Celsius", address=3(Dec.). That results input value of "4512" = 45.12 Degree Fahrenheit, "500" = 5.00 Degree Fahrenheit, "999990" = sensor broken line.									
C. 16#01:	(TT=00, RR=00, A address=1	A=1) stan	dard setting, th	ne input v	value	will be ,	-32768 to +	32767,			



W-8x37 and W-8x47 have been phased out, visit the ISaGRAF wesite http://www.icpdas.com/en/product/guide+Software+Development__Tools+ISaGRAF for new products. Also, refer to Chapter 20 of ISaGRAF user manual for more information about redundancy solutions.

uPAC-7188EG (Rev.1.19 or above), I-7188XG (Rev.1.17 or above) & I-8417/8817/8437/8837 (Rev.2.27 or above) support Redundant Bus7000. These configurations are listed as the following.

The Fbus/Ebus are for exchanging data between the "Redundant Master" & "Redundant Slave", and the **Fbus/Ebus cable** must be always working (break is not allowed).

I-7188XG:





ICP DAS Co., Ltd. Technical Document

Classification	ISaGRAF Englis	ISaGRAF English FAQ-061					
Author	Chun Tsai	Version	1.0.0	Date	Apr. 2007	Page	19 / 19

Visit to ISaGRAF Download Center to download these demo programs.

http://www.icpdas.com/en/download/show.php?num=1005&nation=US&kind1=6&kind2=&model=&kw =ISAGRAF

Demo example for I-7188XG:

The demo project uses "Configuration 1" and located at demo_48a & demo_48b.

Demo example for I-7188EG:

The demo project uses "Configuration 2" with Ebus and located at demo_51a & demo_51b.

Demo example for I-8437/8837:

The demo project uses "Configuration 4" with Ebus and located at demo_49a & demo_49b.

Click the link for more ISaGRAF FAQ: http://www.icpdas.com/en/faq/index.php?kind=280#751