	opike		1.0.0			1 480	
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	1/8
Classification	ISaGRAF E	ISaGRAF English FAQ-148					

I-87017DW, I-87017ZW and I-87019ZW are released about Aug. 2011.

The following ICP DAS ISaGRAF controllers (PAC) support I-87017DW, I-87017ZW and I-87019ZW.

- I-8417/8817/8437/8837/8437-80/8837-80: for remote I/O unit only (ISaGRAF driver Ver.4.15 or later)
- I-7188EG/EGD: for remote I/O unit only (ISaGRAF driver Ver.3.15 or later)
- I-7188XG/XGD: for remote I/O unit only (ISaGRAF driver Ver.3.14 or later)
- uPAC-7186EG/EGD: for remote I/O unit only (ISaGRAF driver Ver.1.14 or later)
- iPAC-8447 / 8847 (ISaGRAF driver Ver.1.10 or later)
- WinPAC-8147 / 8447 / 8847 , WinPAC-8146 / 8446 / 8846 (ISaGRAF driver Ver.1.37 or later)
- XP-8xx7-CE6/8xx6-CE6 (ISaGRAF driver Ver.1.17 or later)
- VP-25W7/23W7 , VP-25W6/23W6 (ISaGRAF driver Ver.1.29 or later)

I-87017DW can be used as an "8-Ch. Differential" or "16-Ch. Single-Ended" Analog Input, I-87017DW detail information: http://www.icpdas.com/en/product/I-87017DW-G I-87017ZW can be used as a "10-Ch. Differential" or "20-Ch. Single-Ended" Analog Input, I-87017ZW detail information: http://www.icpdas.com/en/product/I-87017ZW-G

I-87019ZW can be used as a "10-Ch. universal" Analog Input, I-87019ZW detail information: http://www.icpdas.com/en/product/I-87019ZW-G S

If you cannot find "i87017d8", "i8717d16", "i8717z10" and "i8717z20" in the window "IO connection" > "equipments" of your PC/ISaGRAF, please get the "i87017d8.xia", "i8717d16.xia", "i8717z10.xia", "i8717z10.xia", "i87019z.bia", "i87017d8.fia", "i8717d16.fia", "i8717z10.fia", "i8717z10.fia" and "i\_87019z.fia" files from the following direction:

- https://www.icpdas.com/en/download/file.php?num=962 (io\_lib.zip)
- https://www.icpdas.com/en/faq/index.php?kind=280#751 > Englich > FAQ 148
- Please visit the webpage to download " io\_lib.zip " and install I/O libraries by clicking "setup.exe" after unzip the file.

http://www.icpdas.com/en/download/show.php?num=368&nation=US&kind1=&model=&kw=isagraf

Next, restore "i87017d8.xia", "i8717d16.xia", "i8717z10.xia", "i8717z10.xia", "i\_87019z.bia", "i87017d8.fia", "i8717d16.fia", "i8717z10.fia", "i8717z10.fia" and "i\_87019z.fia" into the PC / ISaGRAF as the steps shown in the next page.

Classification	ISaGRAF English						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	2/8

Restore the "IO complex equipments" - "i87017d8.xia", "i8717d16.xia", "i8717z10.xia" and "i8717z10.xia" to the PC / ISaGRAF.



Classification	ISaGRAF English						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	3/8

Restore the "C- function blocks" - "i87017d8.fia", "i8717d16.fia", "i8717z10.fia", "i8717z10.fia" and "i\_87019z.fia" to the PC / ISaGRAF.



## 1.1. I-87017DW User Guide

I-87017DW can be set as an 8 Ch. Differential or 16 Ch. Single-Ended Analog Input by jumper.



Each channel of I-87017DW can set the individual range type, listed as below:

Range Type	Physical Value	I-87017D	W Analog Ir (Decimal)	nput value	8 CH. Differential	16 CH. Single-Ended
		- 32768	0	+32767		•
8	$\pm$ 10 V	-10 V	0 V	+10 V	Support	Support
9	± 5 V	-5 V	0 V	+5 V	Support	Support
А	$\pm$ 1 V	-1 V	0 V	+1 V	Support	Support
В	$\pm$ 500 mV	-500 mV	0 V	+500 mV	Support	Support
C	$\pm$ 150 mV	-150 mV	0 V	+150 mV	Support	Support
7	4 ~ 20 mA		4 mA	20 mA	Support	Not support
D	$\pm$ 20mA	- 20mA	0 mA	20mA	Support	Not support
1A	0 ~ 20 mA		0 mA	20mA	Support	Not support

Classification	ISaGRAF English						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	4/8



Classification	ISaGRAF English FAQ-148						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	5/8

# 1.2. I-87017ZW User Guide

I-87017ZW can be set as a 10 Ch. Differential or 20 Ch. Single-Ended Analog Input by jumper.



Each channel of I-87017ZW can set the individual range type, listed as below:

Range Type	Range Type Physical Value		V Analog In (Decimal)	out value	10 CH.	20 CH.
	Value	- 32768	0	+32767	Differential	Single-Ended
8	$\pm$ 10 V	-10 V	0 V	+10 V	Support	Support
9	± 5 V	-5 V	0 V	+5 V	Support	Support
A	$\pm$ 1 V	-1 V	0 V	+1 V	Support	Support
В	$\pm$ 500 mV	-500 mV	0 V	+500 mV	Support	Support
С	$\pm$ 150 mV	-150 mV	0 V	+150 mV	Support	Support
7	4 ~ 20 mA		4 mA	20 mA	Support	Not Support
D	$\pm$ 20mA	- 20mA	0 mA	20mA	Support	Not Support
1A	0 ~ 20 mA		0 mA	20mA	Support	Not Support

NOTE: Single-Ended Analog Input cannot measure current input.

### Use the I-87017ZW in the Slot 0~7 of the PAC (ISaGRAF iP/WP/XP/VP PAC):

In the "IO connection" window, connect the related slot number to "i8717z10" or "i8717z20". "i8717z10" is for 10 Ch. Differential Analog Input; "i8717z20" is for 20 Ch. Single-Ended Analog Input.

iSaGRAF - TEST - I/O connection	- 🗆 🗙	ISAGRAF - TEST - 1/O connection	- 🗆 🗙
<u>File Edit T</u> ools <u>Options H</u> elp		<u>File Edit T</u> ools <u>Options H</u> elp	
🙆 🔤 🗟 🎾 🌐 🗘 🤑 탉 👗 🚟			
0 mm i8717z10   mm i8717z10 ▲   mm i8717z10 ▲   mm Al1_10 ~ ↓   mm Al1_10 ~ ↓ <t< th=""><th><u> </u></th><th>0 mi8717z20 ▲ ▶ :m ref = 87017FB   1 0 ↓ :m cf = 87017FB   1 0 ↓ :m cHo1_rang = 8   2 0 ↓ :m cHo2_rang = 8   3 :m cHo3_rang = 8 :m cHo4_rang = 8   5 :m cHo5_rang = 8 :m cHo6_rang = 8   6 :m cHo8_rang = 8 :m cHo8_rang = 8   7 :m cHo9_rang = 8 :m cHo9_rang = 8</th><th><b>•</b></th></t<>	<u> </u>	0 mi8717z20 ▲ ▶ :m ref = 87017FB   1 0 ↓ :m cf = 87017FB   1 0 ↓ :m cHo1_rang = 8   2 0 ↓ :m cHo2_rang = 8   3 :m cHo3_rang = 8 :m cHo4_rang = 8   5 :m cHo5_rang = 8 :m cHo6_rang = 8   6 :m cHo8_rang = 8 :m cHo8_rang = 8   7 :m cHo9_rang = 8 :m cHo9_rang = 8	<b>•</b>
e the I-870177W/ as a Remote I/O:	•	8 9 1 2000 CH10_rang = 8 9 1	-
ug on the I-87K4/5/8/9 or RU-87P4/8 to use	e it as a	RS-485 remote I/O. Please run the DCON	Utility o

Classification	ISaGRAF English						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	6/8

PC to configure the I-87017ZW's Address (NET-ID), Baud-rate, range mode of channels and other settings. In "IO connection" window, connect to "bus7000b" and set the com\_port, com\_baud and other settings.



Then, write an ISaGRAF Ladder program as below to use it.

"i7017z10" is for 10 Ch. Differential Analog Input; "i7017z20" is for 20 Ch. Single-Ended Analog Input.

	17017Z10 en Q	]	Q_1 <>	 ·	e, <sup>#017220</sup> 0_	0_1
1-	ADR_ NI1			1_	ADR_ NH_	
0-	TYP1_ NI2	<b>→</b> √2			N12_	-92
0-	TYP2_ NI3				ND_	 /4
0-	TYP3_ NI4				N 15_	-16
0-	TYP4_ NI5				NI6_	-1/6
0-	TYP5_ NI6				NF_	 
0-	TYP6_ NI7				N9_	
0-	TYP7 NI8	-ve			NIID_	
0-	TYP8 NI9				NB1_	-/11
0-	TYP9 NI10				N112_ N113	¥13
0-	TYP10				- NI14_	
-		-			NI15_	Y15
					N116_	N
					N195_	
					N119_	
				I	N (20)	

ADR\_: the Address (NET-ID) of the Remote I/O.

TYP1~TYP10 : set the Range Type. "i7017z20" cannot measure the current input, so no Range setting.

16#7 : 4mA ---> 20mA

16#1A: 0mA ---> 20mA

16#0 : other Range (+/- 10V,+/- 5V,+/- 1V,+/- 500mV,+/- 150mV,+/- 20mA)

## 1.3. I-87019ZW User Guide

Each channel of I-87019ZW can set the individual range type, listed as below:

Range Type	Physical	I-87019ZW A	nalog Input val	ue (Decimal)
	Value	- 32768	0	+32767
0	$\pm$ 15 mV	-15 mV	0 V	+15 mV
1	$\pm$ 50 mV	-50 mV	0 V	+50 mV
2	$\pm$ 100 mV	-100 mV	0 V	+100 mV
3	$\pm$ 500 mV	-500 mV	0 V	+500 mV
4	$\pm$ 1 V	-1 V	0 V	+1 V
5	± 2.5 V	-2.5 V	0 V	+2.5 V
8	$\pm$ 10 V	-10 V	0 V	+10 V
9	± 5 V	-5 V	0 V	+5 V
А	$\pm$ 1 V	-1 V	0 V	+1 V
В	± 500 mV	-500 mV	0 V	+500 mV
С	$\pm$ 150 mV	-150 mV	0 V	+150 mV
7	4 ~ 20 mA		4 mA	20 mA

Classification	ISaGRAF English						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	7/8

	6 \ D	± 20mA	- 20mA	0 mA	20mA				
	1A	0 ~ 20 mA		0 mA	20mA				
	Thermocouple								
	E	J-Type	<b>-210</b> ℃	0°C	<b>760</b> ℃				
			-9054	0	32767				
	F	К-Туре	<b>-270</b> ℃	0°C	<b>1372</b> ℃				
			-6448	0	32767				
	10	Т-Туре	<b>-270</b> ℃	0°C	<b>400</b> °C				
			-22118	0	32767				
	11	E-Type	<b>-270</b> ℃	0°C	<b>1000</b> °C				
			-8847	0	32767				
	12	R-Type		0°C	<b>1768</b> ℃				
				0	32767				
	13	S-Type		0°C	<b>1768</b> °C				
				0	32767				
	14	В-Туре		0°C	<b>1820</b> °C				
				0	32767				
	15	N-Type	<b>-270</b> ℃	<b>0</b> °C	<b>1300</b> °C				
			-6805	0	32767				
	16	С-Туре		0°C	<b>2320</b> ℃				
				0	32767				
	17	L-Type	<b>-200</b> ℃	0°C	<b>800</b> ℃				
			-8192	0	32767				
	18	M-Type	<b>-200</b> ℃	<b>0</b> °C	<b>100</b> °C				
			-32768	0	16384				
	19	L-Type	<b>-200</b> ℃	<b>0</b> °C	<b>900</b> ℃				
		(DIN43710)	-7281	0	32767				

Use the I-87019ZW in the Slot 0~7 of the PAC (ISaGRAF iP/WP/XP/VP PAC): In the "IO connection" window, connect the related slot number to "i\_87019z".

📷 ISaGRAF - TEST - 1/O connection	- 🗆 🗙
<u>File E</u> dit <u>T</u> ools <u>Options H</u> elp	
🖴 📼 🗟 🗭 🍈 🗘 🕂 🕒 🖌 🇯	
0 🖿 i_87019z 🔹 ↔ 🔺 🕨 ref = 87019FA	<b>_</b>
1	
2 CH2_rang = 8	
3 CH3_rang = 8	
4 :8000 CH4_rang = 8	
5 CH5_rang = 8	
6 CH6_rang = 8	
7 CH7_rang = 8	
8 CH8_rang = 8	
9 CH9_rang = 8	
10 CH10_rang = 8	
11 🔹 1 🗹	-

Classification	ISaGRAF English						
Author	Spike	Version	1.0.0	Date	Oct. 2011	Page	8/8

#### Use the I-87019ZW as a Remote I/O:

Plug on the I-87K4/5/8/9 or RU-87P4/8 to use it as a RS-485 remote I/O. Please run the DCON Utility on PC to configure the I-87019ZW's Address (NET-ID), Baud-rate, range mode of channels and other settings. In "IO connection" window, connect to "bus7000b" and set the com\_port, com\_baud and other settings.



Then, write an ISaGRAF Ladder program as below to use it. "i\_87019z" is for I-87019ZW 10 Ch. Universal Analog Input.



ADR\_: the Address (NET-ID) of the Remote I/O.

TYP1~TYP10 : set the Range Type. Please refer to the I-87019ZW Range List.

For detail application, please refer to ISaGRAF FAQ-061 : http://www.icpdas.com/faq/isagraf/061\_c.htm