

## Packing List

In addition to this guide, the package includes the following items:



CAN-2053C



Screw Driver



Quick Start

## Resources


How to search for drivers, manuals and spec information on ICP DAS website.

## Technical Support

[service@icpdas.com](mailto:service@icpdas.com)

[www.icpdas.com](http://www.icpdas.com)


- For Mobile Web



- For Desktop Web

# 1 Node ID, baud rate and terminal resistance

According to the user's requirements for CANopen network, set the node ID and CAN baud rate of this module on the CANopen network. If the module is located at the terminal of the network, according to the standard CANopen network specification, this module must enable the terminal resistance.




## 2 I/O channel connection


Input Type	ON State LED ON Readback as 1	OFF State LED OFF Readback as 0
Relay Contact	Relay On 	Relay Off 
TTL/CMOS Logic	Voltage > 3.5 V 	Voltage < 1 V 
NPN Output	Open Collector On 	Open Collector Off 
PNP Output	Open Collector On 	Open Collector Off 

## 3 CAN port connection

### 2-wire Connection



### 3-wire Connection



### 4-wire Connection

