
Intelligent RS-232/485/422 to CAN Converter



I-7530A

Dimensions

The I-7530A is designed to unleash the power of CAN bus via RS-232/485/422 communication method. It accurately converts messages between CAN and RS-232/485/422 networks. This module let you communicate with CAN devices easily from any PC or devices with RS-232/485/422 interface. The programmable RS-232/485/422 device (For example: PC, PLC or PAC) can use the serial port to connect to the CAN network via the I-7530A.

Features

- Compatible with CAN specification 2.0A and 2.0B
- Fully compatible with ISO 11898-2 standard
- Support various baud rate from 10 kbps to 1 Mbps
- Jumper for 120Ω terminator resistor
- Software configurable CAN and RS-232/RS-422/ RS-485 communication parameters
- 1000 frames in CAN received buffer, 900 frames in RS-232/RS-422/RS-485 received buffer
- Watchdog inside
- Provide the transparent communication between the RS-232/RS-485/RS-422 devices via CAN bus
- Enable different RS-232/RS-485/RS-422 devices into an individual group in CAN bus network (Full-duplex communication mode of RS-232/ RS-422 devices is not supported)

Utility Features

| Same it | 1 | - | | | |
|----------------|-----------|---------|-------------------|----------|--------|
| 1 1 | r 31 | ্ | | | |
| Connect Disco | meet Exit | About | | | |
| Settings Test | 1 | | | | |
| RS-232 Parame | sters | | CAN Parameters | | |
| RS-232 Baudral | e 115200 | bil/sec | CAN Specification | 2.08 | |
| Data Bit | 8 | - 1a | CAN bus Baudrate | 1000K · | bit/se |
| Stop Bit | 1 | - bit | Acceptance Code | 00000000 | (Hex) |
| Parity | None | - bit | Acceptance Mask | FFFFFFF | (Hex) |
| Add Checksum | No | - | | | |
| Error Response | No | ส | | | |

- CAN bus baud rate configuration
- CAN acceptance filter configuration


- CAN 2.0A or 2.0B specific selection
- Serial COM baud rate and data bit setting
- Serial COM command error response selection
- Utility tool for transmitting / receiving CAN messages

CAN Monitor & Data log Tools

- Show CAN messages by hex or decimal format
- CAN messages with timestamp
- Easy-to-use data logger for the diagnosis of the CAN networks and recording of the received data
- Send the predefined CAN messages manually or cyclically



Block Diagram






AN Series

Hardware Specifications

| CAN Interface | | | |
|---------------------|---|--|--|
| Controller | Microprocessor inside with 20MHz | | |
| Transceiver | NXP 82C250 | | |
| Connector | 9-pin male D-Sub (CAN_L, CAN_H, N/A for others) | | |
| Port Channels | 1 | | |
| Buad Rate | 10 k, 20 k, 50 k, 100 k, 125 k, 250 k, 500 k, 800 k and 1 Mbps | | |
| Protection | 3000 V_{DC} power protection on CAN side, 2500Vrms photo-couple isolation on CAN bus | | |
| Terminator Resistor | Selectable 120 Ω terminator resistor by jumper | | |
| Support Protocol | CAN 2.0A/2.0B | | |
| Receive Buffer | 1000 data frames | | |
| UART Interface | | | |
| СОМ | RS-232 × RS-485 × RS-422 | | |
| Connector | 14-pin terminal connector RS-232 : TxD, RxD, GND RS-422 : Tx+, Tx-, Rx+, Rx- RS-485 : D+, D- | | |
| Baud Rate | 110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 bps | | |
| Data Bits | 5, 6, 7, 8 | | |
| Stop Bits | 1,2 | | |
| Parity | None, Even, Odd | | |
| Receive Buffer | 900 data frames | | |
| Power | | | |
| Power Consumption | 1W | | |
| Power Requirement | Unregulated $+10V_{DC} \sim +30V_{DC}$. Power reverse protection, Over-Voltage brown-out protection | | |
| LED | | | |
| Round LED | ON LED: Power and Data Flow; ERR LED: Error | | |
| Mechanism | | | |
| Installation | DIN-Rail | | |
| Dimensions | 72mm x 118mm x 33mm (W x L x H) | | |
| Environment | | | |
| Operating Temp. | -25°C to 75°C | | |
| Storage Temp. | -30°C to 80°C | | |
| Humidity | 10~90% non-condensing | | |
| | | | |

Pin Assignments



| n Assig | nments | |
|--------------|-----------------------------|-------|
| Table 1: RS- | 232/485/422 Connector (CN1) | |
| Terminal | RS-232/485/422 | |
| 1 | (Y)DATA+ (RS-485) | |
| 2 | (G)DATA- (RS-485) | |
| 3 | Not Connect | 19 1 |
| 4 | Tx+ (RS-422) | 10 1 |
| 5 | Tx- (RS-422) | 19 |
| 6 | Rx+ (RS-422) | 10 |
| 7 | Rx- (RS-422) | 10 |
| 8 | Not Connect | 10 |
| 9 | RXD (RS-232) | 19 |
| 10 | TXD (RS-232) | 19 |
| 11 | (B)GND (RS-232) | 10 14 |
| 12 | Not Connect | 10 14 |
| 13 | +Vs (Power) | - |
| 14 | (B)GND (Power) | - |
| Table 2: C/ | AN DB9 Male Connector (CN2) | |
| Terminal | 2-wire CAN | |
| 1 | Not Connect | Ô |
| 2 | CAN Low | |
| 3 4 | - | |
| 5 | Not Connect | 1 - 6 |
| 6 | 1 | 0 |
| 7 | CAN High | 9 |
| 8 | Not Connect | |
| 9 | Not Connect | |

Ordering Information

I-7530A-G CR

Intelligent RS-232/RS-485/RS-422 to CAN converter (RoHS)